

INSTRUCTION MANUAL (Applied)

FR-D720-0.1K to 15K FR-D740-0.4K to 15K FR-D720S-0.1K to 2.2K FR-D710W-0.1K to 0.75K

OUTLINE

WIRING

1

PRECAUTIONS FOR USE OF THE INVERTER

3

PARAMETERS

4

TROUBLESHOOTING

5

PRECAUTIONS FOR MAINTENANCE AND INSPECTION

6

SPECIFICATIONS

7

Thank you for choosing this Mitsubishi Inverter.

This Instruction Manual (Applied) provides instructions for advanced use of the FR-D700 series inverters.

Incorrect handling might cause an unexpected fault. Before using the inverter, always read this Instruction Manual and the Instruction Manual (Basic) [IB-0600365ENG] packed with the product carefully to use the equipment to its optimum performance.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect the inverter until you have read through the Instruction Manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION".

MARNING

Incorrect handling may cause hazardous conditions, resulting in death or severe injury.

⚠CAUTION

Incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause only material damage.

The ▲CAUTION level may even lead to a serious consequence according to conditions. Both instruction levels must be followed because these are important to personal safety.

1. Electric Shock Prevention

♠WARNING

- While power is ON or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.
- Do not run the inverter with the front cover or wiring cover removed. Otherwise you may access the exposed highvoltage terminals or the charging part of the circuitry and get an electric shock.
- Even if power is OFF, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before wiring or inspection, power must be switched OFF. To confirm that, LED indication of the operation panel must be checked. (It must be OFF.) Any person who is involved in wiring or inspection shall wait for at least 10 minutes after the power supply has been switched OFF and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.
- This inverter must be earthed (grounded). Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical code (NEC section 250, IEC 536 class 1 and other applicable standards).

A neutral-point earthed (grounded) power supply for 400V class inverter in compliance with EN standard must be used

- Any person who is involved in wiring or inspection of this equipment shall be fully competent to do the work.
- The inverter must be installed before wiring. Otherwise you may get an electric shock or be injured.
- Setting dial and key operations must be performed with dry hands to prevent an electric shock. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.
- Do not change the cooling fan while power is ON. It is dangerous to change the cooling fan while power is ON.
- Do not touch the printed circuit board with wet hands.
 Otherwise you may get an electric shock.
- When measuring the main circuit capacitor capacity, the DC voltage is applied to the motor for 1s at powering OFF.
 Never touch the motor terminal, etc. right after powering OFF to prevent an electric shock.

2. Fire Prevention

⚠CAUTION

- Inverter must be installed on a nonflammable wall without holes (so that nobody touches the inverter heatsink on the rear side, etc.). Mounting it to or near flammable material can cause a fire.
- If the inverter has become faulty, the inverter power must be switched OFF. A continuous flow of large current could cause a fire.
- When using a brake resistor, a sequence that will turn OFF power when a fault signal is output must be configured. Otherwise the brake resistor may excessively overheat due to damage of the brake transistor and such, causing a fire.
- Do not connect a resistor directly to the DC terminals P/+ and N/-. Doing so could cause a fire.

ACAUTION

- The voltage applied to each terminal must be the ones specified in the Instruction Manual. Otherwise burst, damage, etc. may occur.
- The cables must be connected to the correct terminals.
 Otherwise burst, damage, etc. may occur.
- Polarity must be correct. Otherwise burst, damage, etc. may occur.
- While power is ON or for some time after power-OFF, do not touch the inverter since the inverter will be extremely hot. Doing so can cause burns.

4. Additional Instructions

Also the following points must be noted to prevent an accidental failure, injury, electric shock, etc.

(1) Transportation and Mounting

ACAUTION

- The product must be transported in correct method that corresponds to the weight. Failure to do so may lead to injuries.
- Do not stack the boxes containing inverters higher than the number recommended.
- The product must be installed to the position where withstands the weight of the product according to the information in the Instruction Manual.
- Do not install or operate the inverter if it is damaged or has parts missing.
- When carrying the inverter, do not hold it by the front cover or setting dial; it may fall off or fail.
- Do not stand or rest heavy objects on the product.
- The inverter mounting orientation must be correct.
- Foreign conductive bodies must be prevented to enter the inverter. That includes screws and metal fragments or other flammable substance such as oil.
- As the inverter is a precision instrument, do not drop or subject it to impact.
- The inverter must be used under the following environment: Otherwise the inverter may be damaged.

	Surrounding air temperature	-10°C to +50°C (non-freezing) (-10°C to +40°C for totally-enclosed structure feature)
ent	Ambient humidity	90%RH or less (non-condensing)
Environment	Storage temperature	-20°C to +65°C *1
Envi	Atmosphere	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)
	Altitude/ vibration	Maximum 1,000m above sea level. 5.9m/s ² or less at 10 to 55Hz (directions of X, Y, Z axes)

*1 Temperature applicable for a short time, e.g. in transit.

(2) Wiring

↑CAUTION

- Do not install a power factor correction capacitor or surge suppressor/capacitor type filter on the inverter output side. These devices on the inverter output side may be overheated or burn out.
- The connection orientation of the output cables U, V, W to the motor affects the rotation direction of the motor.

(3) Trial run

♠ CAUTION

 Before starting operation, each parameter must be confirmed and adjusted. A failure to do so may cause some machines to make unexpected motions.

(4) Usage

⚠WARNING

- Any person must stay away from the equipment when the retry function is set as it will restart suddenly after trip.
- Since pressing (STOP) RESET key may not stop output depending on the function setting status, separate circuit and switch that make an emergency stop (power OFF, mechanical brake operation for emergency stop, etc.) must be provided.
- OFF status of the start signal must be confirmed before resetting the inverter fault. Resetting inverter alarm with the start signal ON restarts the motor suddenly.
- The inverter must be used for three-phase induction motors.
 - Connection of any other electrical equipment to the inverter output may damage the equipment.
- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the product.

ACAUTION

- The electronic thermal relay function does not guarantee protection of the motor from overheating. It is recommended to install both an external thermal and PTC thermistor for overheat protection.
- Do not use a magnetic contactor on the inverter input for frequent starting/stopping of the inverter. Otherwise, the life of the inverter decreases.
- The effect of electromagnetic interference must be reduced by using an EMC filter or by other means.
 Otherwise nearby electronic equipment may be affected.
- Appropriate measures must be taken to suppress harmonics. Otherwise power supply harmonics from the inverter may heat/damage the power factor correction capacitor and generator.
- When driving a 400V class motor by the inverter, the motor must be an insulation-enhanced motor or measures must be taken to suppress surge voltage. Surge voltage attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.
- When parameter clear or all parameter clear is performed, the required parameters must be set again before starting operations because all parameters return to the initial value.
- The inverter can be easily set for high-speed operation.
 Before changing its setting, the performances of the motor and machine must be fully examined.
- Stop status cannot be hold by the inverter's brake function. In addition to the inverter's brake function, a holding device must be installed to ensure safety.
- Before running an inverter which had been stored for a long period, inspection and test operation must be performed.
- For prevention of damage due to static electricity, nearby metal must be touched before touching this product to eliminate static electricity from your body.

(5) Emergency stop

ACAUTION

- A safety backup such as an emergency brake must be provided to prevent hazardous condition to the machine and equipment in case of inverter failure.
- When the breaker on the inverter input side trips, the wiring must be checked for fault (short circuit), and internal parts of the inverter for a damage, etc. The cause of the trip must be identified and removed before turning ON the power of the breaker.
- When any protective function is activated, appropriate corrective action must be taken, and the inverter must be reset before resuming operation.

(6) Maintenance, inspection and parts replacement

ACAUTION

 Do not carry out a megger (insulation resistance) test on the control circuit of the inverter. It will cause a failure.

(7) Disposal

⚠CAUTION

• The inverter must be treated as industrial waste.

General instruction

Many of the diagrams and drawings in this Instruction Manual show the inverter without a cover or partially open for explanation. Never operate the inverter in this manner. The cover must be always reinstalled and the instruction in this Instruction Manual must be followed when operating the inverter.

OUTLINE	1
(OUTLINE

	1.1 F	roduct checking and parts identification	2
	1.2 I	nverter and peripheral devices	3
	1.2.1	Peripheral devices	4
	1.3 F	Removal and reinstallation of the cover	5
	1.3.1	Front cover	5
	1.3.2	Wiring cover	7
	1.4 I	nstallation of the inverter and enclosure design	8
	1.4.1	Inverter installation environment	8
	1.4.2	Cooling system types for inverter enclosure	10
	1.4.3	Inverter placement	11
2	WIF	RING	13
	2.1 V	Viring	
	2.1.1	Terminal connection diagram	14
	2.2 N	lain circuit terminal specifications	15
	2.2.1	Specification of main circuit terminal	15
	2.2.2	Terminal arrangement of the main circuit terminal, power supply and the motor wiring	15
	2.2.3	Cables and wiring length	17
	2.3	control circuit specifications	20
	2.3.1	Control circuit terminal	20
	2.3.2	Changing the control logic	22
	2.3.3	Wiring of control circuit	24
	2.3.4	Safety stop function	27
	2.3.5	Connection to the PU connector	29
	2.4	Connection of stand-alone option unit	31
	2.4.1	Connection of a dedicated external brake resistor (MRS type, MYS type, FR-ABR) (0.4K or more)	31
	2.4.2	Connection of the brake unit (FR-BU2)	
	2.4.3	Connection of the high power factor converter (FR-HC)	
	2.4.4	Connection of the power regeneration common converter (FR-CV)	35
	2.4.5	Connection of a DC reactor (FR-HEL)	35
3	DDE	CAUTIONS FOR USE OF THE INVERTER	37
•		AND I I AIR AND AL TITE HAR FILLEN	JI

J.I E	imo and leakaye currents	30
3.1.1	Leakage currents and countermeasures	38
3.1.2	EMC measures	
3.1.3	Power supply harmonics	
3.1.4	Harmonic suppression guideline in Japan	43
3.2 lı	nstallation of power factor improving reactor	45
3.3 P	Power-OFF and magnetic contactor (MC)	46
3.4 lı	nverter-driven 400V class motor	47
3.5 P	Precautions for use of the inverter	48
3.6 F	ailsafe of the system which uses the inverter	50
4 PAR	RAMETERS	53
4.1 0	Operation panel	54
4.1.1		
4.1.1	Names and functions of the operation panel	
4.1.2	Easy operation mode setting (easy setting mode)	
4.1.4	Changing the parameter setting value	
4.1.5	Setting dial push	
4.2 P	Parameter list	
4.2.1	Parameter list	
4.3 A	Adjustment of the output torque (current) of the motor	75
431	Manual torque boost (Pr. 0, Pr. 46)	75
4.3.2	Acquiring large starting torque and low speed torque (General-purpose magnetic flux vector control (Pr. 71, Pr. 80))	
4.3.3	Slip compensation (Pr. 245 to Pr. 247)	
4.3.4	Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157)	80
4.4 L	imiting the output frequency	84
4.4.1	Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	84
4.4.2	Avoiding mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)	85
4.5 V	//F pattern	86
4.5.1	Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)	86
4.5.2	Load pattern selection (Pr. 14)	88
4.6 F	requency setting by external terminals	90
4.6.1	Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)	90
4.6.2	Jog operation (Pr. 15, Pr. 16)	92
4.6.3	Remote setting function (Pr. 59)	94

	Setting of acceleration/deceleration time and acceleration/ leceleration pattern	. 97
4.7.1	Setting of the acceleration and deceleration time	07
470	(Pr. 7, Pr. 8, Pr. 20, Pr. 44, Pr. 45)	
4.7.2 4.7.3	Starting frequency and start-time hold function (Pr. 13, Pr. 571)	
4.8	Selection and protection of a motor	101
4.8.1	Motor overheat protection (Electronic thermal O/L relay, PTC thermistor protection) (Pr. 9, P Pr. 561)	
4.8.2	Applied motor (Pr. 71, Pr. 450)	. 104
4.8.3	Exhibiting the best performance for the motor (offline auto tuning) (Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90, Pr. 96)	. 106
4.9 N	Notor brake and stop operation	110
4.9.1	DC injection brake (Pr. 10 to Pr. 12)	. 110
4.9.2	Selection of a regenerative brake (Pr. 30, Pr. 70)	. 111
4.9.3	Stop selection (Pr. 250)	. 113
4.10 F	unction assignment of external terminal and control	114
4.10.1	Input terminal function selection (Pr. 178 to Pr. 182)	. 114
4.10.2		
4.10.3		
4.10.4	Start signal operation selection (STF, STR, STOP signal, Pr. 250)	. 118
4.10.5	Output terminal function selection (Pr. 190, Pr. 192, Pr. 197)	. 120
4.10.6	Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)	. 124
4.10.7	Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153, Pr. 166, Pr. 167)	. 125
4.10.8	Remote output selection (REM signal, Pr. 495, Pr. 496)	. 127
4.11 N	Nonitor display and monitor output signal	128
4.11.1	Speed display and speed setting (Pr. 37)	. 128
4.11.2	Monitor display selection of DU/PU and terminal FM (Pr. 52, Pr. 54, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891)	. 129
4.11.3	Reference of the terminal FM (pulse train output) (Pr. 55, Pr. 56)	. 134
4.11.4	Terminal FM calibration (calibration parameter C0 (Pr. 900))	. 135
	peration selection at power failure and instantaneous power ailure	137
		.01
4.12.1	Automatic restart after instantaneous power failure/flying start (Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	. 137
4.12.2	Power-failure deceleration stop function (Pr. 261)	. 143
4.13 C	peration setting at fault occurrence	145
4.13.1	Retry function (Pr. 65, Pr. 67 to Pr. 69)	. 145
	! Input/output phase loss protection selection (Pr. 251, Pr. 872)	

4.13.3	Earth (ground) fault detection at start (Pr. 249)	147
4.14 E	nergy saving operation	148
4.14.1	Optimum excitation control (Pr. 60)	148
4.15 M	otor noise, EMI measures, mechanical resonance	149
4.15.1	PWM carrier frequency and Soft-PWM control (Pr. 72, Pr. 240, Pr. 260)	149
4.15.2	Speed smoothing control (Pr. 653)	150
4.16 F	requency setting by analog input (terminal 2, 4)	151
4.16.1	Analog input selection (Pr. 73, Pr. 267)	151
	Response level of analog input and noise elimination (Pr. 74)	
	Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	
4.17 M	isoperation prevention and parameter setting restriction	159
4.17.1	Reset selection/disconnected PU detection/PU stop selection (Pr. 75)	159
4.17.2	Parameter write disable selection (Pr. 77)	162
4.17.3	Reverse rotation prevention selection (Pr. 78)	163
4.17.4	Extended parameter display (Pr. 160)	163
4.17.5	Password function (Pr. 296, Pr. 297)	164
4.18 S	election of operation mode and operation location	166
4.18.1	Operation mode selection (Pr. 79)	166
4.18.2	Operation mode at power-ON (Pr. 79, Pr. 340)	176
4.18.3	Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 551)	177
4.19 C	ommunication operation and setting	181
4.19.1	Wiring and configuration of PU connector	181
4.19.2	Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)	184
4.19.3	Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)	185
4.19.4	Communication EEPROM write selection (Pr. 342)	188
4.19.5	Mitsubishi inverter protocol (computer link communication)	189
4.19.6	Modbus-RTU communication specifications (Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	201
4.20 S	pecial operation and frequency control	213
4.20.1	PID control (Pr. 127 to Pr. 134, Pr. 575 to Pr. 577)	213
4.20.2	Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)	221
4.20.3	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)	227
4.21 U	seful functions	229
4.21.1	Cooling fan operation selection (Pr. 244)	229
4.21.2	Display of the lives of the inverter parts (Pr. 255 to Pr. 259)	

4.21.	.3 Maintenance timer alarm (Pr. 503, Pr. 504)	20 .
4.21	4 Current average value monitor signal (Pr. 555 to Pr. 557)	235
4.21	5 Free parameter (Pr. 888, Pr. 889)	237
4.22	Setting the parameter unit and operation panel	238
4.22	1 RUN key rotation direction selection (Pr. 40)	238
4.22	2 PU display language selection(Pr.145)	238
4.22	3 Operation panel frequency setting/key lock selection (Pr. 161)	239
4.22	4 Magnitude of frequency change setting (Pr. 295)	241
4.22	5 Buzzer control (Pr. 990)	242
4.22	6 PU contrast adjustment (Pr. 991)	242
4.23	FR-E500 series operation panel (PA02) setting	243
4.23	1 Built-in potentiometer switching (Pr. 146)	243
4.23	2 Bias and gain of the built-in frequency setting potentiometer (C22 (Pr. 922) to C25 (P	r. 923)) 244
4.24	Parameter clear/ All parameter clear	250
4.25	Initial value change list	251
	Check and clear of the faults history	
	_	
	DUBLESHOOTING	255
TRO	DUBLESHOOTING	
TRO	_	
TR(DUBLESHOOTING	256
TRC 5.1 5.2	OUBLESHOOTING Reset method of protective function	256 257
5.1 5.2 5.3	DUBLESHOOTING Reset method of protective function List of fault or alarm indications	256 257
5.1 5.2 5.3 5.4	DUBLESHOOTING Reset method of protective function List of fault or alarm indications Causes and corrective actions	256 257 258
5.1 5.2 5.3 5.4	Reset method of protective function List of fault or alarm indications Causes and corrective actions Correspondences between digital and actual characters Check first when you have a trouble	256 257 258 267
5.1 5.2 5.3 5.4 5.5	Reset method of protective function List of fault or alarm indications Causes and corrective actions Correspondences between digital and actual characters Check first when you have a trouble	256257258267268
5.1 5.2 5.3 5.4 5.5	Correspondences between digital and actual characters Check first when you have a trouble	256257258267268
5.1 5.2 5.3 5.4 5.5 5.5.1	Reset method of protective function	256257258267268268270
5.1 5.2 5.3 5.4 5.5 5.5.1 5.5.2 5.5.3	Reset method of protective function	256257258267268268270271
TRC 5.1 5.2 5.3 5.4 5.5 5.5.1 5.5.2 5.5.3 5.5.4	Reset method of protective function	256257258267268268270271271
TRC 5.1 5.2 5.3 5.4 5.5. 5.5.1 5.5.2 5.5.3 5.5.4 5.5.5	Reset method of protective function	256257258267268270271271271
TRC 5.1 5.2 5.3 5.4 5.5 5.5.1 5.5.2 5.5.3 5.5.4 5.5.5 5.5.6	Reset method of protective function	256257258267268270271271271271271
TRC 5.1 5.2 5.3 5.4 5.5 5.5.3 5.5.4 5.5.5 5.5.6 5.5.7	Reset method of protective function	256257258267268268270271271271271271271
TRC 5.1 5.2 5.3 5.4 5.5 5.5.1 5.5.2 5.5.3 5.5.4 5.5.5 5.5.6 5.5.7 5.5.8	Reset method of protective function List of fault or alarm indications Causes and corrective actions Correspondences between digital and actual characters Check first when you have a trouble Motor does not start Motor or machine is making abnormal acoustic noise Inverter generates abnormal noise Motor generates heat abnormally Motor rotates in the opposite direction Speed greatly differs from the setting Acceleration/deceleration is not smooth Speed varies during operation Operation mode is not changed properly O Operation panel display is not operating	256257258267268270271271271271271272272
TRC 5.1 5.2 5.3 5.4 5.5. 5.5.3 5.5.4 5.5.5 5.5.6 5.5.7 5.5.8 5.5.9	Reset method of protective function List of fault or alarm indications Causes and corrective actions Correspondences between digital and actual characters Check first when you have a trouble Motor does not start Motor or machine is making abnormal acoustic noise Inverter generates abnormal noise Motor generates heat abnormally Motor rotates in the opposite direction Speed greatly differs from the setting Acceleration/deceleration is not smooth Speed varies during operation Operation mode is not changed properly O Operation panel display is not operating	256257258267268270271271271271271272272
TRC 5.1 5.2 5.3 5.4 5.5 5.5.1 5.5.2 5.5.3 5.5.4 5.5.5 5.5.6 5.5.7 5.5.8 5.5.9 5.5.1	Reset method of protective function	256257258267268268271271271271271271272273273273

6 PRECAUTIONS FOR MAINTENANCE AND INSPECTION 27

6.1	Inspection items	276
6.	I.1 Daily inspection	276
6.	I.2 Periodic inspection	276
6.1	I.3 Daily and periodic inspection	277
6.1	I.4 Display of the life of the inverter parts	278
6.	1.5 Checking the inverter and converter modules	279
6.1	I.6 Cleaning	280
6.	I.7 Replacement of parts	280
6.2	Measurement of main circuit voltages, currents and po	wers 284
6.2	2.1 Measurement of powers	286
6.2	2.2 Measurement of voltages and use of PT	286
6.2	2.3 Measurement of currents	287
6.2	2.4 Use of CT and transducer	287
6.2	2.5 Measurement of inverter input power factor	287
6.2	2.6 Measurement of converter output voltage (across terminals P and N)	287
6.2	2.7 Measurement of inverter output frequency	287
6.2	2.8 Insulation resistance test using megger	
6.2	2.9 Pressure test	288
7 S	PECIFICATIONS	289
7.1	Rating	290
7.2	Common specifications	292
7.3	Outline dimension drawings	
APPI	ENDIX	297
Δnn	endix1 For customers replacing the conventional model with th	is inverter 298
	·	
Ap	pendix 1-1 Replacement of the FR-S500 series	298
App	endix2 Specification change	300
Ap	pendix 2-1 SERIAL number check	300
Ap	pendix 2-2 Changed function	300
App	endix3 Index	301

MEMO

OUTLINE

This chapter explains the "OUTLINE" for use of this product. Always read the instructions before using the equipment.

1.1	Product checking and parts identification2
1.2	Inverter and peripheral devices3
1.3	Removal and reinstallation of the cover5
1.4	Installation of the inverter and enclosure design 8


<abbreviation></abbreviation>	
PU	Operation panel and parameter unit (FR-PU04/FR-PU07)
Inverter	Mitsubishi inverter FR-D700 series
FR-D700	Mitsubishi inverter FR-D700 series
Pr	Parameter number
PU operation	Operation using the PU (operation panel/FR-PU04/FR-PU07)
External operation	Operation using the control circuit signals
Combined operation	Operation using both the PU (operation panel/FR-PU04/FR-
	PU07) and External operation
Operation panel for E500, PA02	FR-E500 series operation panel
Mitsubishi standard motor	SF-JR
Mitsubishi constant-torque motor .	SF-HRCA
<trademark></trademark>	

- Microsoft and Visual C++ are registered trademarks of Microsoft Corporation in the United States
- Company and product names herein are the trademarks and registered trademarks of their respective owners.

<Mark>

and/or other countries.

Q REMARKS : Additional helpful contents and relations with other functions are stated.



POINT :Useful contents and points are stated.

Parameters referred to: Related parameters are stated.





4

5


6

7

1.1 Product checking and parts identification

Unpack the inverter and check the capacity plate on the front cover and the rating plate on the inverter side face to ensure that the product agrees with your order and the inverter is intact.

•Inverter model



Accessory

Fan cover fixing screws (M3 × 35mm)

These screws are necessary for compliance with the EU Directive. (Refer to the Instruction Manual (Basic))


Capacity	Number
1.5K to 3.7K	1
5.5K to 15K	2

Harmonic suppression guideline (when inverters are used in Japan)

All models of general-purpose inverters used by specific consumers are covered by "Harmonic suppression guideline for consumers who receive high voltage or special high voltage". (For further details, *refer to page 43*.)



1.2 Inverter and peripheral devices






- The life of the inverter is influenced by surrounding air temperature. The surrounding air temperature should be as low as possible within the permissible range. This must be noted especially when the inverter is installed in an enclosure. (Refer to page δ)
 Wrong wiring might lead to damage of the inverter. The control signal lines must be kept fully away from the main
- circuit to protect them from noise. (Refer to page 14)
- Do not install a power factor correction capacitor, surge suppressor or EMC filter (capacitor) on the inverter output side. This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them.
- Electromagnetic wave interference
 The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, install the FR-BIF optional EMC filter (capacitor) (for use in the input side only) or FR-BSF01 or FR-BLF EMC filter (ferrite core) to minimize interference. (Refer to page 40).
- Réfer to the Instruction Manual of each option and peripheral devices for details of peripheral devices.

1.2.1 Peripheral devices

Check the inverter model of the inverter you purchased. Appropriate peripheral devices must be selected according to the capacity. Refer to the following list and prepare appropriate peripheral devices:

Inverter Model				Moulded Case Circuit Breaker (MCCB) *1 or Earth Leakage Circuit Breaker (ELB) *2		Magnetic Contactor (MC) *3		Reactor	
		(kW)	Reactor c	onnection	Reactor connection		FR-HAL	FR-HEL	
			without	with	without	with	1 IX-IIAL		
	FR-D720-0.1K	0.1	30AF 5A	30AF 5A	S-N10	S-N10	0.4K *5	0.4K *5	
	FR-D720-0.2K	0.2	30AF 5A	30AF 5A	S-N10	S-N10	0.4K *5	0.4K *5	
>	FR-D720-0.4K	0.4	30AF 5A	30AF 5A	S-N10	S-N10	0.4K	0.4K	
200V	FR-D720-0.75K	0.75	30AF 10A	30AF 5A	S-N10	S-N10	0.75K	0.75K	
se 2	FR-D720-1.5K	1.5	30AF 15A	30AF 10A	S-N10	S-N10	1.5K	1.5K	
has	FR-D720-2.2K	2.2	30AF 20A	30AF 15A	S-N10	S-N10	2.2K	2.2K	
Three-Phase	FR-D720-3.7K	3.7	30AF 30A	30AF 30A	S-N20, S-N21	S-N10	3.7K	3.7K	
hre	FR-D720-5.5K	5.5	50AF 50A	50AF 40A	S-N20, S-N21	S-N20, S-N21	5.5K	5.5K	
-	FR-D720-7.5K	7.5	100AF 60A	50AF 50A	S-N25	S-N20, S-N21	7.5K	7.5K	
	FR-D720-11K	11	100AF 75A	100AF 75A	S-N35	S-N35	11K	11K	
	FR-D720-15K	15	225AF 125A	100AF 100A	S-N50	S-N50	15K	15K	
	FR-D740-0.4K	0.4	30AF 5A	30AF 5A	S-N10	S-N10	H0.4K	H0.4K	
_	FR-D740-0.75K	0.75	30AF 5A	30AF 5A	S-N10	S-N10	H0.75K	H0.75K	
400V	FR-D740-1.5K	1.5	30AF 10A	30AF 10A	S-N10	S-N10	H1.5K	H1.5K	
se 4	FR-D740-2.2K	2.2	30AF 15A	30AF 10A	S-N10	S-N10	H2.2K	H2.2K	
has	FR-D740-3.7K	3.7	30AF 20A	30AF 15A	S-N10	S-N10	H3.7K	H3.7K	
Three-Phase	FR-D740-5.5K	5.5	30AF 30A	30AF 20A	S-N20, S-N21	S-N11, S-N12	H5.5K	H5.5K	
hre	FR-D740-7.5K	7.5	30AF 30A	30AF 30A	S-N20, S-N21	S-N20, S-N21	H7.5K	H7.5K	
-	FR-D740-11K	11	50AF 50A	50AF 40A	S-N20, S-N21	S-N20, S-N21	H11K	H11K	
	FR-D740-15K	15	100AF 60A	50AF 50A	S-N25	S-N20, S-N21	H15K	H15K	
> C	FR-D720S-0.1K	0.1	30AF 5A	30AF 5A	S-N10	S-N10	0.4K *5	0.4K *5	
200V	FR-D720S-0.2K	0.2	30AF 5A	30AF 5A	S-N10	S-N10	0.4K *5	0.4K *5	
Single-Phase	FR-D720S-0.4K	0.4	30AF 10A	30AF 10A	S-N10	S-N10	0.75K *5	0.75K *5	
Ä	FR-D720S-0.75K	0.75	30AF 15A	30AF 10A	S-N10	S-N10	1.5K *5	1.5K *5	
gle-	FR-D720S-1.5K	1.5	30AF 20A	30AF 20A	S-N10	S-N10	2.2K *5	2.2K *5	
Sin	FR-D720S-2.2K	2.2	50AF 40A	30AF 30A	S-N20, S-N21	S-N10	3.7K *5	3.7K *5	
1007	FR-D710W-0.1K	0.1	30AF 10A	30AF 5A	S-N10	S-N10	0.75K *4, *5	— *6	
	FR-D710W-0.2K	0.2	30AF 10A	30AF 10A	S-N10	S-N10	1.5K *4, *5	— *6	
Single-Phase	FR-D710W-0.4K	0.4	30AF 15A	30AF 15A	S-N10	S-N10	2.2K *4, *5	— *6	
Sing	FR-D710W-0.75K	0.75	30AF 30A	30AF 20A	S-N10	S-N10	3.7K *4, *5	— *6	

^{*1} •Select an MCCB according to the power supply capacity.



^{*2} For the use in the United States or Canada, select a UL and cUL certified fuse with Class T fuse equivalent cut-off speed or faster with the appropriate rating for branch circuit protection. Alternatively, select a UL489 molded case circuit breaker (MCCB).

- *4 When connecting a single-phase 100V power input model to a power transformer (50kVA or more), install an AC reactor (FR-HAL) so that the performance is more reliable. (Refer to page 45 for details.)
- *5 The power factor may be slightly lower.
- *6 Single-phase 100V power input model is not compatible with DC reactor.

(1)

- When the inverter capacity is larger than the motor capacity, select an MCCB and a magnetic contactor according to the inverter model and cable and reactor according to the motor output.
- When the breaker on the inverter input side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc.
 Identify the cause of the trip, then remove the cause and power ON the breaker.

[•]Install one MCCB per inverter.

^{*3} Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stop during motor driving, the electrical durability is 25 times.

When using the MC for emergency stop during motor driving or using on the motor side during commercial-power supply operation, select the MC with class AC-3 rated current for the motor rated current.




1.3 Removal and reinstallation of the cover

1.3.1 Front cover

3.7K or less


●Removal (Example of FR-D740-1.5K)

- 1) Loosen the installation screws of the front cover. (The screws cannot be removed.)
- 2) Remove the front cover by pulling it like the direction of arrow.



●Reinstallation (Example of FR-D740-1.5K)


- 1) Place the front cover in front of the inverter, and install it straight.
- 2) Tighten the installation screws on the front cover.



5.5K or more


●Removal (Example of FR-D740-7.5K)

- 1) Loosen the installation screws of the front cover. (The screws cannot be removed.)
- 2) Remove the front cover by pulling it like the direction of arrow with holding the installation hook on the front cover.



●Reinstallation (Example of FR-D740-7.5K)

- 1) Insert the two fixed hooks on the lower side of the front cover into the sockets of the inverter.
- 2) Tighten the installation screws on the front cover.



()

- Fully make sure that the front cover has been reinstalled securely.
- The same serial number is printed on the capacity plate of the front cover and the rating plate of the inverter. Since these plates have the same serial numbers, always reinstall the removed cover onto the original inverter.


1.3.2 Wiring cover

Removal and reinstallation


3.7K or less

• Hold the side of the wiring cover, and pull it downward for • Also pull the wiring cover downward by holding a frontal part of the wiring cover.

To reinstall, fit the cover to the inverter along the guides.




Example of FR-D740-1.5K




Example of FR-D740-1.5K

• See below diagram for wiring cover of FR-D720-3.7K. Hold the dent of the wiring cover (marked with an arrow) with thumb and the side with other fingers and pull downward for removal



5.5K or more

• The cover can be removed easily by pulling it toward you. To reinstall, fit the cover to the inverter along the guides.



1.4 Installation of the inverter and enclosure design

When an inverter enclosure is to be designed and manufactured, heat generated by contained equipment, etc., the environment of an operating place, and others must be fully considered to determine the enclosure structure, size and equipment layout. The inverter unit uses many semiconductor devices. To ensure higher reliability and long period of operation, operate the inverter in the ambient environment that completely satisfies the equipment specifications.

1.4.1 Inverter installation environment

As the inverter installation environment should satisfy the standard specifications indicated in the following table, operation in any place that does not meet these conditions not only deteriorates the performance and life of the inverter, but also causes a failure. Refer to the following points and take adequate measures.

Environmental standard specifications of inverter

Item	Description
Surrounding air	-10°C to +50°C (non-freezing) (-10°C to +40°C for totally-enclosed structure feature)
temperature	-10 C to +30 C (non-neezing) (-10 C to +40 C for totally-enclosed structure leature)
Ambient humidity	90%RH or less (non-condensing)
Atmosphere	Free from corrosive and explosive gases, free from dust and dirt
Maximum altitude	1,000m or less
Vibration	5.9m/s ² or less at 10 to 55Hz (directions of X, Y, Z axes)

(1) Temperature

The permissible surrounding air temperature of the inverter is between -10°C and +50°C (-10°C to +40°C for totally-enclosed structure feature). Always operate the inverter within this temperature range. Operation outside this range will considerably shorten the service lives of the semiconductors, parts, capacitors and others. Take the following measures so that the surrounding air temperature of the inverter falls within the specified range.

- 1) Measures against high temperature
 - Use a forced ventilation system or similar cooling system. (Refer to page 10)
 - · Install the panel in an air-conditioned electrical chamber.
 - · Block direct sunlight.
 - · Provide a shield or similar plate to avoid direct exposure to the radiated heat and wind of a heat source.
 - · Ventilate the area around the panel well.
- 2) Measures against low temperature
 - · Provide a space heater in the enclosure.
 - Do not power OFF the inverter. (Keep the start signal of the inverter OFF.)
- 3) Sudden temperature changes
 - Select an installation place where temperature does not change suddenly.
 - · Avoid installing the inverter near the air outlet of an air conditioner.
 - If temperature changes are caused by opening/closing of a door, install the inverter away from the door.

(2) Humidity

Normally operate the inverter within the 45 to 90% range of the ambient humidity. Too high humidity will pose problems of reduced insulation and metal corrosion. On the other hand, too low humidity may produce a spatial electrical breakdown. The insulation distance specified in JEM1103 "Control Equipment Insulator" is defined as humidity 45 to 85%.

- 1) Measures against high humidity
 - Make the panel enclosed, and provide it with a hygroscopic agent.
 - Take dry air into the enclosure from outside.
 - Provide a space heater in the enclosure.
- 2) Measures against low humidity

What is important in fitting or inspection of the unit in this status is to discharge your body (static electricity) beforehand and keep your body from contact with the parts and patterns, besides blowing air of proper humidity into the enclosure from outside.

3) Measures against condensation

Condensation may occur if frequent operation stops change the in-enclosure temperature suddenly or if the outsideair temperature changes suddenly.

Condensation causes such faults as reduced insulation and corrosion.

- Take the measures against high humidity in 1).
- Do not power OFF the inverter. (Keep the start signal of the inverter OFF.)



(3) Dust, dirt, oil mist

Dust and dirt will cause such faults as poor contact of contact points, reduced insulation or reduced cooling effect due to moisture absorption of accumulated dust and dirt, and in-enclosure temperature rise due to clogged filter. In the atmosphere where conductive powder floats, dust and dirt will cause such faults as malfunction, deteriorated insulation and short circuit in a short time.

Since oil mist will cause similar conditions, it is necessary to take adequate measures.

Countermeasures

- Place in a totally enclosed enclosure.
 Take measures if the in-enclosure temperature rises. (Refer to page 10)
- Purge air.

Pump clean air from outside to make the in-enclosure pressure higher than the outside-air pressure.

(4) Corrosive gas, salt damage

If the inverter is exposed to corrosive gas or to salt near a beach, the printed board patterns and parts will corrode or the relays and switches will result in poor contact.

In such places, take the measures given in Section 3.

(5) Explosive, flammable gases

As the inverter is non-explosion proof, it must be contained in an explosion proof enclosure. In places where explosion may be caused by explosive gas, dust or dirt, an enclosure cannot be used unless it structurally complies with the guidelines and has passed the specified tests. This makes the enclosure itself expensive (including the test charges). The best way is to avoid installation in such places and install the inverter in a non-hazardous place.

(6) Highland

Use the inverter at the altitude of within 1000m. If it is used at a higher place, it is likely that thin air will reduce the cooling effect and low air pressure will deteriorate dielectric strength.

(7) Vibration, impact

The vibration resistance of the inverter is up to 5.9m/s^2 at 10 to 55 Hz frequency and 1mm amplitude for the directions of X, Y, Z axes. Vibration or impact, if less than the specified value, applied for a long time may make the mechanism loose or cause poor contact to the connectors.

Especially when impact is imposed repeatedly, caution must be taken as the part pins are likely to break.

Countermeasures

- Provide the panel with rubber vibration isolators.
- Strengthen the structure to prevent the enclosure from resonance.
- Install the enclosure away from sources of vibration.

1.4.2 Cooling system types for inverter enclosure

From the enclosure that contains the inverter, the heat of the inverter and other equipment (transformers, lamps, resistors, etc.) and the incoming heat such as direct sunlight must be dissipated to keep the in-enclosure temperature lower than the permissible temperatures of the in-enclosure equipment including the inverter.

The cooling systems are classified as follows in terms of the cooling calculation method.

- 1) Cooling by natural heat dissipation from the enclosure surface (totally enclosed type)
- 2) Cooling by heat sink (aluminum fin, etc.)
- 3) Cooling by ventilation (forced ventilation type, pipe ventilation type)
- 4) Cooling by heat exchanger or cooler (heat pipe, cooler, etc.)


	Cooling System	Enclosure Structure	Comment			
Natural	Natural ventilation (enclosed, open type)	INV	Low in cost and generally used, but the enclosure size increases as the inverter capacity increases. For relatively small capacities.			
cooling	Natural ventilation (totally enclosed type)	INV	Being a totally enclosed type, the most appropriate for hostile environment having dust, dirt, oil mist, etc. The enclosure size increases depending on the inverter capacity.			
	Heatsink cooling	Heatsink NV	Having restrictions on the heatsink mounting position and area, and designed for relative small capacities.			
Forced cooling	Forced ventilation		For general indoor installation. Appropriate for enclosure downsizing and cost reduction, and often used.			
	Heat pipe	Heat pipe	Totally enclosed type for enclosure downsizing.			



1.4.3 Inverter placement

(1) Installation of the inverter Enclosure surface mounting


Remove the front cover and wiring cover to mount the inverter to the surface.





NOTE


- When encasing multiple inverters, install them in parallel as a cooling measure.
- · Install the inverter vertically.




(2) Clearances around inverter

To ensure ease of heat dissipation and maintenance, leave at least the shown clearances around the inverter. At least the following clearances are required under the inverter as a wiring space, and above the inverter as a heat dissipation space.

Surrounding air temperature and humidity




Leave enough clearances and take cooling measures.



When using the inverters at the surrounding air temperature of 40℃ or less, the inverters can be installed without any clearance between them (0cm clearance).

When surrounding air temperature exceeds 40°C, clearances between the inverters should be 1cm or more (5cm or more for the 5.5K or more).



* 5cm or more for the 5.5K or more

(3) Inverter mounting orientation

Mount the inverter on a wall as specified. Do not mount it horizontally or any other way.


(4) Above inverter

Heat is blown up from inside the inverter by the small fan built in the unit. Any equipment placed above the inverter should be heat resistant.

(5) Arrangement of multiple inverters

When multiple inverters are placed in the same enclosure, generally arrange them horizontally as shown in the right figure (a). When it is inevitable to arrange them vertically to minimize space, take such measures as to provide guides since heat from the bottom inverters can increase the temperatures in the top inverters, causing inverter failures.


When mounting multiple inverters, fully take caution not to make the surrounding air temperature of the inverter higher than the permissible value by providing ventilation and increasing the enclosure size.



Arrangement of multiple inverters

(6) Arrangement of ventilation fan and inverter

Heat generated in the inverter is blown up from the bottom of the unit as warm air by the cooling fan. When installing a ventilation fan for that heat, determine the place of ventilation fan installation after fully considering an air flow. (Air passes through areas of low resistance. Make an airway and airflow plates to expose the inverter to cool air.)



2 WIRING

This chapter describes the basic "WIRING" for use of this product.

Always read the instructions before using the equipment.

2.1	Wiring	. 14
	Main circuit terminal specifications	
	Control circuit specifications	
	Connection of stand-alone option unit	

2

3

ļ


5

6

7

2.1 Wiring

2.1.1 Terminal connection diagram



- To prevent a malfunction caused by noise, separate the signal cables more than 10cm from the power cables. Also separate the main circuit wire of the input side and the output side.
- After wiring, wire offcuts must not be left in the inverter.
 Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean. When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- The output of the single-phase power input model is three-phase 200V.



2.2 Main circuit terminal specifications


2.2.1 Specification of main circuit terminal

Terminal	Terminal Name	Description					
Symbol	Terminal Name	Description					
R/L1,		Connect to the commercial power supply.					
S/L2,	AC power input	Keep these terminals open when using the high power factor converter (FR-HC) or					
T/L3 *1		power regeneration common converter (FR-CV).					
U, V, W	Inverter output	Connect a three-phase squirrel-cage motor.					
P/+, PR	Brake resistor connection	Connect a brake resistor (FR-ABR, MRS type, MYS type) across terminals P/+ and PR.					
F/T, FK	Brake resistor confiection	(The brake resistor can not be connected to the 0.1K and 0.2K.)					
P/+. N/-	Brake unit connection	Connect the brake unit (FR-BU2), power regeneration common converter (FR-CV)					
F/+, IN/-	Brake unit connection	or high power factor converter (FR-HC).					
P/+. P1 *2	DC reactor connection	Remove the jumper across terminals P/+ and P1 and connect a DC reactor.					
F/T, F I *2	De reactor connection	Single-phase 100V power input model is not compatible with DC reactor.					
	Earth (Ground)	For earthing (grounding) the inverter chassis. Must be earthed (grounded).					


- *1 When using single-phase power input, terminals are R/L1 and S/L2.
- *2 Terminal P1 is not available for single-phase 100V power input model.

2.2.2 Terminal arrangement of the main circuit terminal, power supply and the motor wiring


●Three-phase 200V class




* For wiring to earth (ground) terminals of FR-D720-5.5K and 7.5K, use the earthing cable wiring space (marked with an arrow) to route the wires.




●Three-phase 400V class



●Single-phase 200V class



●Single-phase 100V class



- Make sure the power cables are connected to the R/L1, S/L2, T/L3. (Phase need not be matched.) Never connect the power cable to the U, V, W of the inverter. Doing so will damage the inverter.
- Connect the motor to U, V, W. Turning ON the forward rotation switch (signal) at this time rotates the motor counterclockwise when viewed from the load shaft.



2.2.3 Cables and wiring length

(1) Applied wire size

Select the recommended cable size to ensure that a voltage drop will be 2% max.

If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.

The following table indicates a selection example for the wiring length of 20m.

Three-phase 200V class (when input power supply is 220V)

			Cri	mping				Cab	le Size			
Applicable Inverter	Terminal	Tightening Torque	Terminal		HIV Cables, etc. (mm ²) *1			AWG *2		PVC Cables, etc. (mm ²) *3		
Model	Screw		R/L1		R/L1		Earth	R/L1		R/L1		Earth
	Size *4	N·m	S/L2	U, V, W	S/L2	U, V, W	(ground)	S/L2	U, V, W	S/L2	U, V, W	(ground)
			T/L3		T/L3		cable	T/L3		T/L3		cable
FR-D720-0.1K to 0.75K	M3.5	1.2	2-3.5	2-3.5	2	2	2	14	14	2.5	2.5	2.5
FR-D720-1.5K, 2.2K	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5
FR-D720-3.7K	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	12	12	4	4	4
FR-D720-5.5K	M5	2.5	5.5-5	5.5-5	5.5	5.5	5.5	10	10	6	6	6
FR-D720-7.5K	M5	2.5	14-5	8-5	14	8	5.5	6	8	16	10	6
FR-D720-11K	M5	2.5	14-5	14-5	14	14	14	6	6	16	16	16
FR-D720-15K	M6 (M5)	4.4	22-6	22-6	22	22	14	4	4	25	25	16

Three-phase 400V class (when input power supply is 440V)

			Cri	mping				Cab	le Size			
Applicable Inverter Model	Terminal	Tightening	Terminal		HIV Cables, etc. (mm ²) *1			AWG *2		PVC Cables, etc. (mm ²) *3		
	Screw	Torque	R/L1		R/L1		Earth	R/L1		R/L1		Earth
	Size *4	N·m	S/L2	U, V, W	S/L2	U, V, W	(ground)	S/L2	U, V, W	S/L2	U, V, W	(ground)
			T/L3		T/L3		cable	T/L3		T/L3		cable
FR-D740-0.4K to 3.7K	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5
FR-D740-5.5K	M4	1.5	5.5-4	2-4	3.5	2	3.5	12	14	4	2.5	4
FR-D740-7.5K	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	12	12	4	4	4
FR-D740-11K	M4	1.5	5.5-4	5.5-4	5.5	5.5	8	10	10	6	6	10
FR-D740-15K	M5	2.5	8-5	8-5	8	8	8	8	8	10	10	10

Single-phase 200V class (when input power supply is 220V)

Applicable Inverter Model			Cri	mping	Cable Size							
	Terminal Screw Size *4	Tightening Torque N·m	Terminal		HIV Cables, etc. (mm ²) *1			AWG *2		PVC Cables, etc. (mm ²) *3		
			R/L1 S/L2	U, V, W	R/L1 S/L2	U, V, W	Earth (ground) cable	R/L1 S/L2	U, V, W	R/L1 S/L2	U, V, W	Earth (ground) cable
FR-D720S-0.1K to 0.75K	M3.5	1.2	2-3.5	2-3.5	2	2	2	14	14	2.5	2.5	2.5
FR-D720S-1.5K	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5
FR-D720S-2.2K	M4	1.5	5.5-4	2-4	3.5	2	3.5	12	14	4	2.5	4

Single-phase 100V class (when input power supply is 100V)

			Cri	mping	Cable Size							
Applicable Inverter Model	Screw Torque Size *4 N·m	Tightening	Terminal		HIV Cables, etc. (mm ²) *1			AWG *2		PVC Cables, etc. (mm ²) *3		
		R/L1 S/L2	III V W	R/L1 S/L2	U, V, W	Earth (ground) cable	R/L1 S/L2	U, V, W	R/L1 S/L2	U, V, W	Earth (ground) cable	
FR-D710W-0.1K to 0.4K	M3.5	1.2	2-3.5	2-3.5	2	2	2	14	14	2.5	2.5	2.5
FR-D710W-0.75K	M4	1.5	5.5-4	2-4	3.5	2	2	12	14	4	2.5	2.5

- *1 The cable size is that of the cable (HIV cable (600V class 2 vinyl-insulated cable) etc.) with continuous maximum permissible temperature of 75°C. Assumes that the surrounding air temperature is 50°C or less and the wiring distance is 20m or less.
- *2 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 75°C. Assumes that the surrounding air temperature is 40°C or less and the wiring distance is 20m or less.

 (Selection example for use mainly in the United States.)
- *3 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 70°C. Assumes that the surrounding air temperature is 40°C or less and the wiring distance is 20m or less.

 (Selection example for use mainly in Europe.)
- *4 The terminal screw size indicates the terminal size for R/L1, S/L2, T/L3, U, V, W, PR, P/+, N/-, P1 and a screw for earthing (grounding). Screw size for earthing (grounding) the FR-D720-15K is indicated in parenthesis.

 For single-phase power input, the terminal screw size indicates the size of terminal screw for R/L1, S/L2, U, V, W, PR, P/+, N/-, P1 and a screw for earthing (grounding).



NOTE

Tighten the terminal screw to the specified torque. A screw that has been tightened too loosely can cause a short circuit or malfunction. A screw that has been tightened too tightly can cause a short circuit or malfunction due to the unit breakage. Use crimping terminals with insulation sleeve to wire the power supply and motor.

The line voltage drop can be calculated by the following formula:

Line voltage drop [V]=
$$\frac{\sqrt{3} \times \text{wire resistance}[m\Omega/m] \times \text{wiring distance}[m] \times \text{current}[A]}{1000}$$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.

(2) Earthing (Grounding) precautions

- Always earth (ground) the motor and inverter.
 - 1) Purpose of earthing (grounding)

Generally, an electrical apparatus has an earth (ground) terminal, which must be connected to the ground before use. An electrical circuit is usually insulated by an insulating material and encased. However, it is impossible to manufacture an insulating material that can shut off a leakage current completely, and actually, a slight current flow into the case. The purpose of earthing (grounding) the case of an electrical apparatus is to prevent operator from getting an electric shock from this leakage current when touching it.

To avoid the influence of external noises, this earthing (grounding) is important to audio equipment, sensors, computers and other apparatuses that handle low-level signals or operate very fast.

2) Earthing (grounding) methods and earthing (grounding) work

As described previously, earthing (grounding) is roughly classified into an electrical shock prevention type and a noise-affected malfunction prevention type. Therefore, these two types should be discriminated clearly, and the following work must be done to prevent the leakage current having the inverter's high frequency components from entering the malfunction prevention type earthing (grounding):


(a)If possible, use (I) independent earthing (grounding) in figure below for the inverter. If independent earthing (grounding) is not available, use (II) joint earthing (grounding) in the figure below which the inverter is connected with the other equipment at an earthing (grounding) point.


The (III) common earthing (grounding) as in the figure below, which inverter shares a common earth (ground) cable with the other equipment, must be avoided.


A leakage current including many high frequency components flows in the earth (ground) cables of the inverter and inverter-driven motor. Therefore, use the independent earthing (grounding) and separated the earthing (grounding) cable of the inverter from equipments sensitive to EMI.

In a high building, it may be effective to use the EMI prevention type earthing (grounding) connecting to an iron structure frame, and electric shock prevention type earthing (grounding) with the independent earthing (grounding) together.

- (b)This inverter must be earthed (grounded). Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards). Use an neutral-point earthed (grounded) power supply for 400V class inverter in compliance with EN standard.
- (c)Use the thickest possible earth (ground) cable. The earth (ground) cable should be of not less than the size indicated in the table on the previous *page 17*.
- (d)The earthing (grounding) point should be as near as possible to the inverter, and the earth (ground) cable length should be as short as possible.
- (e)Run the earth (ground) cable as far away as possible from the I/O wiring of equipment sensitive to noises and run them in parallel in the minimum distance.







POINT

To be compliant with the EU Directive (Low Voltage Directive), refer to the Instruction Manual (Basic).



(3) Total wiring length


The overall wiring length for connection of a single motor or multiple motors should be within the value in the table below.

100V, 200V class

Pr. 72 PWM frequency selection Setting (carrier frequency)	0.1K	0.2K	0.4K	0.75K	1.5K or More
1 (1kHz) or less	200m	200m	300m	500m	500m
2 to15 (2kHz to 14.5kHz)	30m	100m	200m	300m	500m

400V class

Pr. 72 PWM frequency selection Setting (carrier frequency)	0.4K	0.75K	1.5K	2.2K	3.7K or More
1 (1kHz) or less	200m	200m	300m	500m	500m
2 to15 (2kHz to 14.5kHz)	30m	100m	200m	300m	500m



When driving a 400V class motor by the inverter, surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor. (Refer to page 84)



- Especially for long-distance wiring, the inverter may be affected by a charging current caused by the stray capacitances of the wiring, leading to a malfunction of the overcurrent protective function, fast response current limit function, or stall prevention function or a malfunction or fault of the equipment connected on the inverter output side. If malfunction of fast-response current limit function occurs, disable this function. If malfunction of stall prevention function occurs, increase the stall level. (Refer to page 80 for Pr. 22 Stall prevention operation level and Pr. 156 Stall prevention operation selection)
- Refer to page 149 for details of Pr. 72 PWM frequency selection. Refer to the manual of the option for details of surge voltage suppression filter (FR-ASF-H/FR-BMF-H).
- When using the automatic restart after instantaneous power failure function with wiring length exceeding below, select without frequency search (Pr. 162 = "1, 11"). (Refer to page 137)

Motor capacity	0.1K	0.2K	0.4K or more
Wiring length	20m	50m	100m

2.3 Control circuit specifications

2.3.1 Control circuit terminal

indicates that terminal functions can be selected using *Pr. 178 to Pr. 182, Pr. 190, Pr. 192, Pr. 197 (I/O terminal function selection). (Refer to page 114).*

(1) Input signal

Туре	Terminal Symbol	Terminal Name	Description	Rated Specifications	Refer to Page
	STF	Forward rotation start Reverse rotation start	Turn ON the STF signal to start forward rotation and turn it OFF to stop. Turn ON the STR signal to start reverse rotation and turn it OFF to stop. When the STF and STR signals are turned ON simultaneously, the stop command is given.	Input resistance 4.7kΩ Voltage when contacts are open 21 to 26VDC	118
	RH, RM, RL	Multi-speed selection	Multi-speed can be selected according to the combination of RH, RM and RL signals.	When contacts are short- circuited 4 to 6mADC	90
		Contact input common (sink) (initial setting)	Common terminal for contact input terminal (sink logic) and terminal FM.		
Contact input	SD	External transistor common (source)	When connecting the transistor output (open collector output), such as a programmable controller, when source logic is selected, connect the external power supply common for transistor output to this terminal to prevent a malfunction caused by undesirable currents.	_	_
		24VDC power supply common	Common output terminal for 24VDC 0.1A power supply (PC terminal). Isolated from terminals 5 and SE.		
	PC	External transistor common (sink) (initial setting)	When connecting the transistor output (open collector output), such as a programmable controller, when sink logic is selected, connect the external power supply common for transistor output to this terminal to prevent a malfunction caused by undesirable currents.	Power supply voltage range 22 to 26.5VDC permissible load current	23
		Contact input common (source) 24VDC power supply	Common terminal for contact input terminal (source logic). Can be used as 24VDC 0.1A power supply.	100mA	
	10	Frequency setting power supply	Used as power supply when connecting potentiometer for frequency setting (speed setting) from outside of the inverter. (Refer to Pr. 73 Analog input selection.)	5.0V ± 0.2VDC permissible load current 10mA	151
	2	Frequency setting (voltage)	Inputting 0 to 5VDC (or 0 to 10V) provides the maximum output frequency at 5V (10V) and makes input and output proportional. Use <i>Pr. 73</i> to switch between input 0 to 5VDC input (initial setting) and 0 to 10VDC.	Input resistance 10k Ω ± 1k Ω Permissible maximum voltage 20VDC	151
Frequency setting	4	Frequency setting (current)	Inputting 4 to 20mADC (or 0 to 5V, 0 to 10V) provides the maximum output frequency at 20mA and makes input and output proportional. This input signal is valid only when the AU signal is ON (terminal 2 input is invalid). To use terminal 4 (initial setting is current input), set "4" in any of <i>Pr.178 to Pr.182 (input terminal function selection)</i> to assign the function, and turn ON AU signal. Use <i>Pr. 267</i> to switch from among input 4 to 20mA (initial setting), 0 to 5VDC and 0 to 10VDC. Set the voltage/current input switch in the "V" position to select voltage input (0 to 5V/0 to 10V).	Current input: Input resistance $233\Omega \pm 5\Omega$ Maximum permissible current 30mA Voltage input: Input resistance $10\text{k}\Omega \pm 1\text{k}\Omega$ Permissible maximum voltage 20VDC Current input (initial status) Voltage input	151
	5	Frequency setting	Frequency setting signal (terminal 2, 4) common terminal. Do not earth (ground).		_
PTC thermistor	10 2	PTC thermistor input	For connecting PTC thermistor output. When PTC thermistor protection is valid (<i>Pr. 561</i> ≠ "9999"), terminal 2 is not available for frequency setting.	Adaptive PTC thermistor specification Heat detection resistance : 500Ω to $30k\Omega$ (Set by $Pr. 561$)	101





NOTE

Set *Pr. 267* and a voltage/current input switch correctly, then input analog signals in accordance with the settings. Applying a voltage with voltage/current input switch in "I" position (current input is selected) or a current with switch in "V" position (voltage input is selected) could cause component damage of the inverter or analog circuit of output devices. (*Refer to page 151 for details.*)

(2) Output signal

Туре	Terminal Symbol	Terminal Name	Descrip	tion	Rated Specifications	Reference Page
Relay	A, B, C	Relay output (fault output)	1 changeover contact output ind protective function has activated Fault: discontinuity across B-C (Normal: continuity across B-C (o	Contact capacity:230VAC 0.3A (power factor =0.4) 30VDC 0.3A	120	
Open collector	RUN	Inverter running	Switched Low when the inverter output frequency is equal to or higher than the starting frequency (initial value 0.5Hz). Switched High during stop or DC injection brake operation. (Low is when the open collector output transistor is ON (conducts). High is when the transistor is OFF (does not conduct).)		Permissible load 24VDC (maximum 27VDC) 0.1A (a voltage drop is 3.4V maximum when the signal is ON)	120
	SE	Open collector output common	Common terminal of terminal RUN.		_	_
Pulse	FM	For meter	Select one e.g. output frequency from monitor items. Not output during inverter reset. Not output during inverter reset. The output signal is proportional to the magnitude of the corresponding monitoring item.	Output item: Output frequency (initial setting)	Permissible load current 1mA 1440 pulses/s at 60Hz	129


(3) Communication

Туре	Terminal Symbol	Terminal Name	Description	Reference Page
RS-485	-	PU connector	With the PU connector, communication can be made through RS-485.	
			Conforming standard: EIA-485 (RS-485)	
			Transmission format: Multidrop link	181
			Communication speed: 4800 to 38400bps	
			Overall length: 500m	

(4) Safety stop signal

Terminal Symbol	Terminal Name	Description	Rated Specifications	Reference Page
S1	Safety stop input (Channel 1)	Terminals S1 and S2 are for safety stop input signals used with the safety relay module. Terminals S1 and S2 are used	Input resistance: 4.7kΩ Current: 4 to 6 mA	
S2	Safety stop input (Channel 2)	shortening/opening across terminals S1 and SC and across S2 and SC. In the initial status, terminals S1 and S2 are shorted with terminal SC by shortening wire.	(In case of shorted to SC) Voltage: 21 to 26 V (In case of open from SC)	
SO	Safety monitor output (open collector output)	The signal indicates the status of safety stop input. Low indicates safe state, and High indicates drive enabled or fault detected. (Low is when the open collector output transistor is ON (conducts). High is when the transistor is OFF (does not conduct).) If High is output when both of terminals S1 and S2 are open, refer to the Safety stop function instruction manual (BCN-A211508-000) for the cause and countermeasure.	Load: 24VDC/0.1A max. Voltage drop: 3.4V max. (In case of 'ON' state)	27
SC	Safety stop input terminal common	Common terminal for terminals S1, S2 and SO. Connected to terminal SD inside of the inverter.	_	

2.3.2 Changing the control logic



The input signals are set to sink logic (SINK) when shipped from the factory.

To change the control logic, the jumper connector above the control terminal must be moved to the other position.

 Change the jumper connector in the sink logic (SINK) position to source logic (SOURCE) position using tweezers, a pair of long-nose pliers etc. Change the jumper connector position before switching power ON.

(1)


- · Fully make sure that the front cover has been reinstalled securely.
- The capacity plate is placed on the front cover and the rating plate is on the inverter. Since these plates have the same serial numbers, always reinstall the removed cover onto the original inverter.
- The sink-source logic change-over jumper connector must be fitted in only one of those positions. If it is fitted in both positions at the same time, the inverter may be damaged.



- (1) Sink logic type and source logic type
 - In sink logic, a signal switches ON when a current flows from the corresponding signal input terminal.


 Terminal SD is common to the contact input signals. Terminal SE is common to the open collector output signals.
 - In source logic, a signal switches ON when a current flows into the corresponding signal input terminal.

 Terminal PC is common to the contact input signals. Terminal SE is common to the open collector output signals.
- Current flow concerning the input/output signal when sink logic is selected
- Current flow concerning the input/output signal when source logic is selected




- When using an external power supply for transistor output
- Sink logic type

Use terminal PC as a common terminal, and perform wiring as shown below. (Do not connect terminal SD of the inverter with terminal 0V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



· Source logic type


Use terminal SD as a common terminal, and perform wiring as shown below. (Do not connect terminal PC of the inverter with terminal +24V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



2.3.3 Wiring of control circuit

(1) Standard control circuit terminal layout

Recommend wire size: 0.3mm² to 0.75mm²



(2) Wiring method

Wiring

Use a blade terminal and a wire with a sheath stripped off for the control circuit wiring. For a single wire, strip off the sheath of the wire and apply directly.


Insert the blade terminal or the single wire into a socket of the terminal.

 Strip off the sheath about the length below. If the length of the sheath peeled is too long, a short circuit may occur among neighboring wires. If the length is too short, wires might come off.
 Wire the stripped wire after twisting it to prevent it from becoming loose. In addition, do not solder it.



2) Crimp the blade terminal.

Insert wires to a blade terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve. Check the condition of the blade terminal after crimping. Do not use a blade terminal of which the crimping is inappropriate, or the face is damaged.



Blade terminals available on the market: (as of Oct. 2008)

●Phoenix Contact Co.,Ltd.

\Mino Cina (mano2)	Blade Terminal Model			Blade terminal	
Wire Size (mm ²)	with insulation sleeve	without insulation sleeve	for UL wire*	crimping tool	
0.3	AI 0,5-10WH	_	_		
0.5	AI 0,5-10WH	_	AI 0,5-10WH-GB		
0.75	AI 0,75-10GY	A 0,75-10	AI 0,75-10GY-GB	CRIMPFOX ZA3	
1	AI 1-10RD	A1-10	AI 1-10RD/1000GB	CRIMPFOX ZAS	
1.25, 1.5	AI 1,5-10BK	A1,5-10	AI 1,5-10BK/1000GB		
0.75 (for two wires)	AI-TWIN 2 x 0,75-10GY	_	_		


 $^{^{\}star}$ A blade terminal with an insulation sleeve compatible with MTW wire which has a thick wire insulation

●NICHIFU Co.,Ltd.


Wire Size (mm ²)	Blade terminal product number	Insulation product number	Blade terminal crimping tool
0.3 to 0.75	BT 0.75-11	VC 0.75	NH 67



3) Insert the wire into a socket.



When using a single wire or a stranded wire without a blade terminal, push an open/close button all the way down with a flathead screw driver, and insert the wire.






NOTE

- When using a stranded wire without a blade terminal, twist enough to avoid short circuit with a nearby terminals or wires.
- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause to damage of inverter or injury.

Wire removal

Pull the wire with pushing the open/close button all the way down firmly with a flathead screwdriver.





NOTE

Use a small flathead screwdriver (Tip thickness: 0.4mm/tip width: 2.5mm).
 If a flathead screwdriver with a narrow tip is used, terminal block may be damaged.
 Introduced products: (as of Oct. 2008)

Product	Type	Maker
Flathead screwdriver	SZF 0- 0,4 x 2,5	Phoenix Contact Co.,Ltd.

 Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause to damage of inverter or injury.

(3) Control circuit common terminals (SD, 5, SE)

Terminals SD, SE and 5 are common terminals for I/O signals.(All common terminals are isolated from each other.) Do not earth them. Avoid connecting the terminal SD and 5 and the terminal SE and 5.


Terminal SD is a common terminal for the contact input terminals (STF, STR, RH, RM, RL) and frequency output signal (FM). The open collector circuit is isolated from the internal control circuit by photocoupler

Terminal 5 is a common terminal for the frequency setting signals (terminals 2 or 4). It should be protected from external noise using a shielded or twisted cable.

Terminal SE is a common terminal for the open collector output terminal (RUN). The contact input circuit is isolated from the internal control circuit by photocoupler.

(4) Signal inputs by contactless switches

The contacted input terminals of the inverter (STF, STR, RH, RM, RL) can be controlled using a transistor instead of a contacted switch as shown on the right.



External signal input using transistor

(5) Wiring instructions

- 1) It is recommended to use the cables of 0.3mm² to 0.75mm² gauge for connection to the control circuit terminals.
- 2) The maximum wiring length should be 30m (200m for terminal FM).
- 3) Do not short across terminals PC and SD. Inverter may be damaged.
- 4) Use two or more parallel micro-signal contacts or twin contacts to prevent contact faults when using contact inputs since the control circuit input signals are micro-currents.





Micro signal contacts

Twin contacts

- 5) Use shielded or twisted cables for connection to the control circuit terminals and run them away from the main and power circuits (including the 200V relay sequence circuit).
- 6) Do not apply a voltage to the contact input terminals (e.g. STF) of the control circuit.
- 7) Always apply a voltage to the fault output terminals (A, B, C) via a relay coil, lamp, etc.



2.3.4 Safety stop function

(1) Description of the function

The terminals related to the safety stop function are shown below.

Refer to page 20 for the rated specification of each terminal.

Terminal Symbol		Description	
S	31 *1	For input of safety stop channel 1.	Between S1 and SC / S2 and SC
S2*1		For input of safety stop channel 2.	Open: In safety stop mode. Short: Other than safety stop mode.
SO*2	SAFE signal	For output of safety stop condition. The signal is output when inverter output is shut off due to the safety stop function.	OFF: Drive enabled ON: Output shutoff, no fault
	SC	Common terminal for S1,S2,SO signals. (SC is connected terminal SD internally.)	_
RUN *3	SAFE2 signal	As output for failure detection and alarm. The signal is output while safety circuit fault (E.SAF) is not activated.	OFF: Safety circuit fault (E.SAF) ON: Status other than Safety circuit fault (E.SAF)
	SE	Common terminal for open collector outputs (terminal RUN)	_

- *I In the initial status, terminal S1 and S2 are shorted with terminal SC by shortening wire. Remove the shortening wire and connect the safety relay module when using the safety stop function.
- *2 In the initial setting, safety monitor output signal (SAFE signal) is assigned to terminal SO. The function can be assigned to other terminals by setting "80 (positive logic) or 180 (negative logic)" to any of Pr. 190, Pr. 192 or Pr. 197 (Output terminal function selection). (Refer to page 120)
- *3 In the initial setting, inverter running (RUN signal) is assigned to terminal RUN. Set "81" to Pr. 190 RUN terminal function selection to assign SAFE2 signal. The function can be assigned to other terminals by setting "81 (positive logic) or 181 (negative logic)" to any of Pr. 190, Pr. 192 or Pr. 197 (Output terminal function selection). (Refer to page 120)




NOTE

- Use SAFE signal for the purpose to monitor safety stop status. SAFE signal cannot be used as safety stop input signal to other devices (other than the safety relay module.)
- SAFE2 signal can only be used to output an alarm or to prevent restart of an inverter. The signal cannot be used as safety stop input signal to other devices.

(2) Wiring connection diagram

To prevent restart at fault occurrence, connect terminals RUN (SAFE2 signal) and SE to terminals XS0 and XS1, which are the feedback input terminals of the safety relay module.

By setting Pr.190 RUN terminal function selection = "81 (SAFE2 signal)", terminal RUN is turned OFF at fault occurrence.





NOTE

• Changing the terminal assignment using *Pr. 190, Pr. 192, Pr. 197 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

(3) Safety stop function operation

Input power	Input	signal	Failure	Output	signal	Operation state
iliput power	S1-SC	S2-SC	i allule	SAFE*1	SAFE2*1	Operation state
OFF	_	_	_	OFF	OFF	Output shutoff (Safe state)
	Short	Short	No failure	OFF	ON	Drive enabled
	SHOIL	Short	Detected	OFF	OFF	Output shutoff (Safe state)
			No failure	ON	ON	Output shutoff (Safe state)
	Open	Open Open	(SA)			
ON			Detected	OFF	OFF	Output shutoff (Safe state)
	Short	Short Open	Detected	OFF	OFF	Output shutoff (Safe state)
	SHOIL	Ореп	(E.SAF)	Oli	Oll	
	Open	Short	Detected	OFF	FF OFF Output shutoff (Sa	Output shutoff (Safe state)
	Open	SHOIL	(E.SAF)	OF P	OFF	Output shuton (Sale state)

^{*1} ON: Transistor used for an open collector output is conducted.

OFF: Transistor used for an open collector output is not conducted.

For more details, refer to the Safety stop function instruction manual (BCN-A211508-000).




2.3.5 Connection to the PU connector

Using the PU connector, you can perform communication operation from the parameter unit (FR-PA07), enclosure surface operation panel (FR-PA07), or a personal computer, etc.

Parameter setting and monitoring can be performed by FR Configurator (FR-SW3-SETUP-W□).

Remove the inverter front cover when connecting.




•When connecting the parameter unit or enclosure surface operation panel using a connection cable

Use the optional FR-CB2□□ or connector and cable available on the market.

Insert the cable plugs securely into the PU connector of the inverter and the connection connector of the FR-PU07, FR-PA07 along the guide until the tabs snap into place.

Install the inverter front cover after connecting.



(I) REMARKS

- Overall wiring length when the parameter unit is connected: max. 20m
- Refer to the following when fabricating the cable on the user side. Examples of product available on the market (as of October 2008)


	Product	Туре	Maker
1)	Communication cable	SGLPEV-T (Cat5e/300m) 24AWG × 4P	Mitsubishi Cable Industries, Ltd.
2)	RJ-45 connector	5-554720-3	Tyco Electronics Corporation

●RS-485 communication

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

The protocol can be selected from Mitsubishi inverter and Modbus-RTU.

· PU connector pin-outs



Pin Number	Name	Description
1)	SG	Earth (ground)
1)	30	(connected to terminal 5)
2)	_	Parameter unit power supply
3)	RDA	Inverter receive+
4)	SDB	Inverter send-
5)	SDA	Inverter send+
6)	RDB	Inverter receive-
7)	SG	Earth (ground)
')	36	(connected to terminal 5)
8)	_	Parameter unit power supply



NOTE

- Pins No. 2 and 8 provide power to the parameter unit. Do not use these pins for RS-485 communication.
- When making RS-485 communication with a combination of the FR-D700 series, FR-E500 series and FR-S500 series, incorrect connection of pins No.2 and 8 (parameter unit power supply) of the above PU connector may result in the inverter malfunction or failure.
- Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector. The product could be damaged due to differences in electrical specifications.

For further details, Refer to page 181.

•Conforming standard: EIA-485 (RS-485)

•Transmission form: Multidrop link

•Communication speed: Maximum 38400 bps

•Overall extension: 500m



2.4 Connection of stand-alone option unit

The inverter accepts a variety of stand-alone option units as required.

Incorrect connection will cause inverter damage or accident. Connect and operate the option unit carefully in accordance with the corresponding option unit manual.

2.4.1 Connection of a dedicated external brake resistor (MRS type, MYS type, FR-ABR) (0.4K or more)

Install a dedicated brake resistor (MRS type, MYS type, FR-ABR) outside when the motor driven by the inverter is made to run by the load, quick deceleration is required, etc. Connect a dedicated brake resistor (MRS type, MYS type, FR-ABR) to terminal P/+ and PR. (For the locations of terminal P/+ and PR, refer to the terminal block layout (page 15).) Set parameters below.

Connected Brake Resistor	Pr. 30 Regenerative function selection Setting	Pr. 70 Special regenerative brake duty Setting		
MRS type, MYS type	0 (initial value)		_	
MYS type (used at 100% torque/6%ED)	1	6%		Refer to page
FR-ABR	1	7.5K or less 10%		111
INADIX	1	11K or more	6%	



NOTE


The brake resistor connected should only be the dedicated brake resistor.

FR-D720-1.5K to 3.7K FR-D740-0.4K to 3.7K FR-D720S-1.5K, 2.2K FR-D710W-0.75K	FR-D720-0.4K, 0.75K FR-D720S-0.4K, 0.75K FR-D710W-0.4K
Connect the brake resistor across terminals P/+ and PR. Jumper *1 Terminal PR	Connect the brake resistor across terminals P/+ and PR. Jumper *1 Terminal P/+ Terminal PR
Brake resistor	Brake resistor
FR-D720-5.5K, 7.5K FR-D740-5.5K to 15K	FR-D720-11K, 15K
Connect the brake resistor across terminals P/+ and PR.	Connect the brake resistor across terminals P/+ and PR.
Jumper *1, *22 Terminal P/+ Terminal PR Brake resistor	Jumper 11 Brake resistor

- *1 Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor. (Single-phase 100V power input model is not compatible with DC reactor.)
- *2 The shape of jumper differs according to capacities.

(1) When using the brake resistor (MRS type, MYS type) and high-duty brake resistor (FR-ABR)


• It is recommended to configure a sequence, which shuts off power in the input side of the inverter by the external thermal relay as shown below, to prevent overheat and burnout of the brake resistor (MRS type, MYS type) and high duty brake resistor (FR-ABR) in case the regenerative brake transistor is damaged. (The brake resistor can not be connected to the 0.1K and 0.2K.)



- *1 Refer to the table below for the type number of each capacity of thermal relay and the diagram below for the connection. (Always install a thermal relay when using a brake resistor whose capacity is 11K or more.)
- *2 When the power supply is 400V class, install a step-down transformer.

Power Supply Voltage	Brake Resistor	Thermal Relay Type (Mitsubishi product)	Contact Rating
	MRS120W200	TH-N20CXHZ-0.7A	440)/40 54
100V,	MRS120W100	TH-N20CXHZ-1.3A	110VAC 5A, 220VAC 2A(AC11 class) 110VDC 0.5A.
200V	MRS120W60	TH-N20CXHZ-2.1A	
	MRS120W40	TH-N20CXHZ-3.6A	220VDC 0.25A(DC11class)
	MYS220W50 (two units in parallel)	TH-N20CXHZ-5A	

	l .	1	
Power Supply Voltage	High-duty Brake Resistor	Thermal Relay Type (Mitsubishi product)	Contact Rating
	FR-ABR-0.4K	TH-N20CXHZ-0.7A	
	FR-ABR-0.75K	TH-N20CXHZ-1.3A	
	FR-ABR-2.2K	TH-N20CXHZ-2.1A	
100V,	FR-ABR-3.7K	TH-N20CXHZ-3.6A	
200V	FR-ABR-5.5K	TH-N20CXHZ-5A	
	FR-ABR-7.5K	TH-N20CXHZ-6.6A	110VAC 5A, 220VAC 2A(AC11 class)
	FR-ABR-11K	TH-N20CXHZ-11A	
	FR-ABR-15K	TH-N20CXHZ-11A	
	FR-ABR-H0.4K	TH-N20CXHZ-0.24A	110VDC 0.5A,
	FR-ABR-H0.75K	TH-N20CXHZ-0.35A	220VDC 0.25A(DC11 class)
	FR-ABR-H1.5K	TH-N20CXHZ-0.9A	,
	FR-ABR-H2.2K	TH-N20CXHZ-1.3A	
400V	FR-ABR-H3.7K	TH-N20CXHZ-2.1A	
	FR-ABR-H5.5K	TH-N20CXHZ-2.5A	
	FR-ABR-H7.5K	TH-N20CXHZ-3.6A	
	FR-ABR-H11K	TH-N20CXHZ-6.6A	
	FR-ABR-H15K	TH-N20CXHZ-6.6A	





NOTE


- Brake resistor can not be used with the brake unit, high power factor converter, power supply regeneration converter, etc.
- · Do not use the brake resistor with a lead wire extended.
- Do not connect a resistor directly to terminals P/+ and N/-. This could cause a fire.



2.4.2 Connection of the brake unit (FR-BU2)

Connect the brake unit (FR-BU2(-H)) as shown below to improve the braking capability at deceleration. If the transistors in the brake unit should become faulty, the resistor can be unusually hot. To prevent unusual overheat and fire, install a magnetic contactor on the inverter's input side to configure a circuit so that a current is shut off in case of fault.


(1) Connection example with the GRZG type discharging resistor



- *1 Connect the inverter terminals (P/+ and N/-) and brake unit (FR-BU2) terminals so that their terminal names match with each other. (Incorrect connection will damage the inverter and brake unit.)
- *2 When the power supply is 400V class, install a step-down transformer.
- *3 The wiring distance between the inverter, brake unit (FR-BU2) and discharging resistor should be within 5m. Even when the wiring is twisted, the cable length must not exceed 10m.
- *4 It is recommended to install an external thermal relay to prevent overheat of discharging resistor.
- *5 Refer to FR-BU2 manual for connection method of discharging resistor.

<Recommended external thermal relay>

Brake Unit	Discharging Posister	Recommended External
Drake Unit	Discharging Resistor	Thermal Relay
FR-BU2-1.5K	GZG 300W-50Ω (one)	TH-N20CXHZ 1.3A
FR-BU2-3.7K	GRZG 200-10 Ω (three in series)	TH-N20CXHZ 3.6A
FR-BU2-7.5K	GRZG 300-5 Ω (four in series)	TH-N20CXHZ 6.6A
FR-BU2-15K	GRZG 400-2 Ω (six in series)	TH-N20CXHZ 11A
FR-BU2-H7.5K	GRZG 200-10 Ω (six in series)	TH-N20CXHZ 3.6A
FR-BU2-H15K	GRZG 300-5 Ω (eight in series)	TH-N20CXHZ 6.6A
FR-BU2-H30K	GRZG 400-2 Ω (twelve in series)	TH-N20CXHZ 11A






NOTE

• Set "1" in Pr. 0 Brake mode selection of the FR-BU2 to use GRZG type discharging resistor.

• Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

(2) Connection example with the FR-BR(-H) type resistor



- *1 Connect the inverter terminals (P/+ and N/-) and brake unit (FR-BU2) terminals so that their terminal names match with each other.
 - (Incorrect connection will damage the inverter and brake unit.)
- *2 When the power supply is 400V class, install a step-down transformer.
- *3 The wiring distance between the inverter, brake unit (FR-BU2) and resistor unit (FR-BR) should be within 5m each. Even when the wiring is twisted, the cable length must not exceed 10m.
- *4 Normal: across TH1-TH2...close, Alarm: across TH1-TH2...open
- *5 A jumper is connected across BUE and SD in the initial status.




NOTE

• Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

2.4.3 Connection of the high power factor converter (FR-HC)

When connecting the high power factor converter (FR-HC) to suppress power harmonics, perform wiring securely as shown below. Incorrect connection will damage the high power factor converter and inverter.



- *1 Keep input terminals (R/L1, S/L2, T/L3) open. Incorrect connection will damage the inverter.
- *2 Do not insert an MCCB between the terminals P/+ and N/- (between P and P/+, between N and N/-). Opposite polarity of terminals N/- and P/+ will damage the inverter.
- *3 Use Pr. 178 to Pr. 182 (input terminal function selection) to assign the terminals used for the X10, RES signal. (Refer to page 114)
- *4 Be sure to connect terminal RDY of the FR-HC to the X10 signal or MRS signal assigned terminal of the inverter, and connect terminal SE of the FR-HC to terminal SD of the inverter. Without proper connecting, FR-HC will be damaged.


NOTE

- The voltage phases of terminals R/L1, S/L2, T/L3 and terminals R4, S4, T4 must be matched.
- Use sink logic (factory setting) when the FR-HC is connected. The FR-HC cannot be connected when source logic is selected.
- Do not remove a jumper across terminal P/+ and P1.



2.4.4 Connection of the power regeneration common converter (FR-CV)

When connecting the power regeneration common converter (FR-CV), connect the inverter terminals (P/+ and N/-) and power regeneration common converter (FR-CV) terminals as shown below so that their symbols match with each other.



- *1 Keep input terminals (R/L1, S/L2, T/L3) open. Incorrect connection will damage the inverter.
- *2 Do not insert an MCCB between the terminals P/+ and N/- (between P/L+ and P/+, between N/L- and N/-). Opposite polarity of terminals N/- and P/+ will damage the inverter.
- *3 Always connect the power supply and terminals R/L11, S/L21, T/MC1.
 - Operating the inverter without connecting them will damage the power regeneration common converter.
- *4 Use *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the terminals used for the X10, RES signal. (*Refer to page 114*)
 *5 Be sure to connect terminal RDYB of the FR-CV to the X10 signal or MRS signal assigned terminal of the inverter, and connect terminal
- SE of the FR-CV to terminal SD of the inverter. Without proper connecting, FR-CV will be damaged.




NOTE

- The voltage phases of terminals R/L11, S/L21, T/MC1 and terminals R2/L1, S2/L2, T2/L3 must be matched.
- Use sink logic (factory setting) when the FR-CV is connected. The FR-CV cannot be connected when source logic is selected.
- Do not remove a jumper across terminal P/+ and P1.

2.4.5 Connection of a DC reactor (FR-HEL)

When using the DC reactor (FR-HEL), connect it across terminals P/+ and P1.

In this case, the jumper connected across terminals P/+ and P1 must be removed. Otherwise, the reactor will not exhibit its performance.





NOTE

- · The wiring distance should be within 5m.
- The size of the cables used should be equal to or larger than that of the power supply cables (R/L1, S/L2, T/L3). (Refer to page 17)
- Single-phase 100V power input model is not compatible with DC reactor.

MEMO

3 PRECAUTIONS FOR USE OF THE INVERTER

This chapter explains the "PRECAUTIONS FOR USE OF THE INVERTER" for use of this product.

Always read the instructions before using the equipment.

3.1	EMC and leakage currents	38
3.2	Installation of power factor improving reactor	45
3.3	Power-OFF and magnetic contactor (MC)	46
3.4	Inverter-driven 400V class motor	47
3.5	Precautions for use of the inverter	48
3.6	Failsafe of the system which uses the inverter	50

3.1 EMC and leakage currents

3.1.1 Leakage currents and countermeasures

Capacitances exist between the inverter I/O cables, other cables and earth and in the motor, through which a leakage current flows. Since its value depends on the static capacitances, carrier frequency, etc., low acoustic noise operation at the increased carrier frequency of the inverter will increase the leakage current. Therefore, take the following measures. Select the earth leakage current breaker according to its rated sensitivity current, independently of the carrier frequency setting.

(1) To-earth (ground) leakage currents

Leakage currents may flow not only into the inverter's own line but also into the other lines through the earth (ground) cable, etc. These leakage currents may operate earth (ground) leakage circuit breakers and earth leakage relays unnecessarily.

Suppression technique

- If the carrier frequency setting is high, decrease the *Pr. 72 PWM frequency selection* setting.

 Note that motor noise increases. Selecting *Pr. 240 Soft-PWM operation selection* makes the sound inoffensive.
- By using earth leakage circuit breakers designed for harmonic and surge suppression in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).
- •To-earth (ground) leakage currents
 - Take caution as long wiring will increase the leakage current. Decreasing the carrier frequency of the inverter reduces the leakage current.
 - Increasing the motor capacity increases the leakage current. The leakage current of the 400V class is larger than that of the 200V class.

(2) Line-to-line leakage currents

Harmonics of leakage currents flowing in static capacitances between the inverter output cables may operate the external thermal relay unnecessarily. When the wiring length is long (50m or more) for the 400V class small-capacity model (7.5kW or less), the external thermal relay is likely to operate unnecessarily because the ratio of the leakage current to the rated motor current increases.

Line-to-line leakage current data example (400V class)

Motor Capacity	Rated Motor	Leakage Cu	rrent (mA) *
(kW)	Current (A)	Wiring length 50m	Wiring length 100m
0.4	1.1	620	1000
0.75	1.9	680	1060
1.5	3.5	740	1120
2.2	4.1	800	1180
3.7	6.4	880	1260
5.5	9.7	980	1360
7.5	12.8	1070	1450


•Motor: SF-JR 4P

•Carrier frequency: 14.5kHz

Used wire: 2mm², 4 cores

Cabtyre cable

*The leakage current of the 200V class is about a half.



Line-to-line leakage currents path

Measures

- Use Pr. 9 Electronic thermal O/L relay.
- If the carrier frequency setting is high, decrease the Pr. 72 PWM frequency selection setting.
 Note that motor noise increases. Selecting Pr. 240 Soft-PWM operation selection makes the sound inoffensive.
 To ensure that the motor is protected against line-to-line leakage currents, it is recommended to use a temperature sensor to directly detect motor temperature.

•Installation and selection of moulded case circuit breaker

Install a moulded case circuit breaker (MCCB) on the power receiving side to protect the wiring of the inverter input side. Select the MCCB according to the inverter input side power factor (which depends on the power supply voltage, output frequency and load). Especially for a completely electromagnetic MCCB, one of a slightly large capacity must be selected since its operation characteristic varies with harmonic currents. (Check it in the data of the corresponding breaker.) As an earth leakage current breaker, use the Mitsubishi earth leakage current breaker designed for harmonics and surge suppression.



(3) Selection of rated sensitivity current of earth (ground) leakage current breaker

When using the earth leakage current breaker with the inverter circuit, select its rated sensitivity current as follows, independently of the PWM carrier frequency.

 Breaker designed for harmonic and surge suppression


Rated sensitivity current: I∆n≥10×(Ig1+Ign+Igi+Ig2+Igm)

· Standard breaker


Rated sensitivity current:

 $I\Delta n \ge 10 \times \{Ig1 + Ign + Igi + 3 \times (Ig2 + Igm)\}$

Example of leakage current of cable path per 1km during the commercial power supply operation when the CV cable is routed in metal conduit



Example of leakage current of three-phase induction motor during the commercial power supply operation (200V 60Hz)



lg1, lg2: Leakage currents in wire path during commercial

power supply operation


Ign: Leakage current of inverter input side EMC filter

Igm: Leakage current of motor during commercial power


supply operation

Igi: Leakage current of inverter unit

Example of leakage current per 1km during the commercial power supply operation when the CV cable is routed in metal conduit (Three-phase three-wire delta connection 400V60Hz)




Example of leakage current of three phase induction motor during the commercial power supply operation (Totally-enclosed fan-cooled type motor 400V60Hz)



<Example>

●Selection example (in the case of the left figure (400V class 人 connection))



	Breaker Designed for Harmonic and Surge Suppression	Standard Breaker
Leakage current lg1 (mA)	<u> </u>	m 00m = 0.11
Leakage current Ign (mA) 0 (without EMC filter)		MC filter)
Leakage current Igi (mA)	1	
Leakage current lg2 (mA)	$\frac{1}{3} \times 66 \times \frac{60}{100}$	Om = 1.32
Leakage current ig2 (IIIA)	3 100	00m
Motor leakage current Igm (mA)	0.36	
Total leakage current (mA)	2.79	6.15
Rated sensitivity current (mA) (≥ lg × 10)	30	100



NOTE

- Install the earth leakage breaker (ELB) on the input side of the inverter.
- In the A connection earthed-neutral system, the sensitivity current is blunt against an earth (ground) fault in the
 inverter output side. Earthing (Grounding) must conform to the requirements of national and local safety regulations
 and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)
- When the breaker is installed on the output side of the inverter, it may be unnecessarily operated by harmonics even if the effective value is less than the rating.
 - In this case, do not install the breaker since the eddy current and hysteresis loss will increase, leading to temperature rise.
- General products indicate the following models. BV-C1, BC-V, NVB, NV-L, NV-G2N, NV-G3NA, NV-2F earth leakage relay (except NV-ZHA), NV with AA neutral wire open-phase protection
 - The other models are designed for harmonic and surge suppressionNV-C/NV-S/MN series, NV30-FA, NV50-FA, BV-C2, earth leakage alarm breaker (NF-Z), NV-ZHA, NV-H

3.1.2 EMC measures


Some electromagnetic noises enter the inverter to malfunction it and others are radiated by the inverter to malfunction peripheral devices. Though the inverter is designed to have high immunity performance, it handles low-level signals, so it requires the following basic techniques. Also, since the inverter chops outputs at high carrier frequency, that could generate electromagnetic noises. If these electromagnetic noises cause peripheral devices to malfunction, EMI measures should be taken to suppress noises. These techniques differ slightly depending on EMI paths.

- (1) Basic techniques
 - · Do not run the power cables (I/O cables) and signal cables of the inverter in parallel with each other and do not bundle
 - · Use twisted shield cables for the detector connecting and control signal cables and connect the sheathes of the shield cables to terminal SD.
 - Earth (Ground) the inverter, motor, etc. at one point.
- (2) Techniques to reduce electromagnetic noises that enter and malfunction the inverter (Immunity measures) When devices that generate many electromagnetic noises (which use magnetic contactors, magnetic brakes, many relays, for example) are installed near the inverter and the inverter may be malfunctioned by electromagnetic noises, the following measures must be taken:
 - Provide surge suppressors for devices that generate many electromagnetic noises to suppress electromagnetic noises.
 - Fit data line filters (page 41) to signal cables.
 - · Earth (Ground) the shields of the detector connection and control signal cables with cable clamp metal.
- (3) Techniques to reduce electromagnetic noises that are radiated by the inverter to malfunction peripheral devices (EMI measures)

Inverter-generated electromagnetic noises are largely classified into those radiated by the cables connected to the inverter and inverter main circuits (I/O), those electromagnetically and electrostatically induced to the signal cables of the peripheral devices close to the main circuit power supply, and those transmitted through the power supply cables.

Telephone

(8)






Propagation Path	Measures
	When devices that handle low-level signals and are liable to malfunction due to electromagnetic noises, e.g.
	instruments, receivers and sensors, are contained in the enclosure that contains the inverter or when their signal
	cables are run near the inverter, the devices may be malfunctioned by air-propagated electromagnetic noises. The
	following measures must be taken:
(1)(2)(3)	Install easily affected devices as far away as possible from the inverter.
	Run easily affected signal cables as far away as possible from the inverter and its I/O cables.
	Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
	Insert common mode filters into I/O and capacitors between the input lines to suppress cable-radiated noises.
	Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
	When the signal cables are run in parallel with or bundled with the power cables, magnetic and static induction noises
	may be propagated to the signal cables to malfunction the devices and the following measures must be taken:
(4)(5)(6)	Install easily affected devices as far away as possible from the inverter.
(4)(3)(0)	Run easily affected signal cables as far away as possible from the I/O cables of the inverter.
	• Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
	Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
	When the power supplies of the peripheral devices are connected to the power supply of the inverter in the same line,
(7)	inverter-generated noises may flow back through the power supply cables to malfunction the devices and the
(1)	following measures must be taken:
	Install the common mode filter (FR-BLF, FR-BSF01) to the power cables (output cable) of the inverter.
	When a closed loop circuit is formed by connecting the peripheral device wiring to the inverter, leakage currents may
(8)	flow through the earth (ground) cable of the inverter to malfunction the device. In such a case, disconnection of the
	earth (ground) cable of the device may cause the device to operate properly.

Data line filter

Data line filter is effective as an EMC measure. Provide a data line filter for the detector cable, etc.

EMC measures





For compliance with the EU EMC directive, refer to the Instruction Manual (Basic).

3.1.3 Power supply harmonics

The inverter may generate power supply harmonics from its converter circuit to affect the power generator, power capacitor etc. Power supply harmonics are different from noise and leakage currents in source, frequency band and transmission path. Take the following countermeasure suppression techniques.


•The differences between harmonics and RF noises are indicated below:

Item	Harmonics	Noise	
Frequency	Normally 40th to 50th degrees or less	High frequency (several 10kHz to 1GHz order)	
rrequency	(up to 3kHz or less)	Tright frequency (several Tokriz to TGTIZ order)	
Environment To-electric channel, power impedance		To-space, distance, wiring path	
Quantitative understanding	Theoretical calculation possible	Random occurrence, quantitative grasping difficult	
Generated amount	Nearly proportional to load capacity	Change with current variation ratio (larger as switching	
Generated amount	Nearly proportional to load capacity	speed increases)	
Affected equipment immunity Specified in standard per equipment		Different depending on maker's equipment specifications	
Suppression example	Provide reactor.	Increase distance.	

Suppression technique

The harmonic current generated from the inverter to the input side differs according to various conditions such as the wiring impedance, whether a reactor is used or not, and output frequency and output current on the load side.

For the output frequency and output current, we understand that this should be calculated in the conditions under the rated load at the maximum operating frequency.





NOTE

The power factor improving capacitor and surge suppressor on the inverter output side may be overheated or damaged by the harmonic components of the inverter output. Also, since an excessive current flows in the inverter to activate overcurrent protection, do not provide a capacitor and surge suppressor on the inverter output side when the motor is driven by the inverter. For power factor improvement, install a reactor on the inverter input side or in the DC circuit.



3.1.4 Harmonic suppression guideline in Japan

Harmonic currents flow from the inverter to a power receiving point via a power transformer. The harmonic suppression guideline was established to protect other consumers from these outgoing harmonic currents.

The three-phase 200V input specifications 3.7kW or less (single-phase 200V power input model 2.2kW or less, single-phase 100V power input model 0.75kW) are previously covered by "Harmonic suppression guideline for household appliances and general-purpose products" and other models are covered by "Harmonic suppression guideline for consumers who receive high voltage or special high voltage". However, the transistorized inverter has been excluded from the target products covered by "Harmonic suppression guideline for household appliances and general-purpose products" in January 2004 and "Harmonic suppression guideline for household appliances and general-purpose products" was repealed on September 6, 2004.

All capacity and all models of general-purpose inverter used by specific consumers are covered by "Harmonic suppression guideline for consumers who receive high voltage or special high voltage" (hereinafter referred to as "Guideline for specific consumers").

"Guideline for specific consumers"

This guideline sets forth the maximum values of harmonic currents outgoing from a high-voltage or especially high-voltage consumer who will install, add or renew harmonic generating equipment. If any of the maximum values is exceeded, this guideline requires that consumer to take certain suppression measures.

Table 1 Maximum Values of Outgoing Harmonic Currents per 1kW Contract Power

Received Power Voltage	5th	7th	11th	13th	17th	19th	23rd	Over 23rd
6.6kV	3.5	2.5	1.6	1.3	1.0	0.9	0.76	0.70
22kV	1.8	1.3	0.82	0.69	0.53	0.47	0.39	0.36
33kV	1.2	0.86	0.55	0.46	0.35	0.32	0.26	0.24

(1) Application for specific consumers




Table 2 Conversion Factors for FR-D700 Series

Class	Ci	Circuit Type		
		Without reactor	K31= 3.4	
3	Three-phase bridge	With reactor (AC side)	K32 = 1.8	
J	(Capacitor smoothing)	With reactor (DC side)	K33 = 1.8	
		With reactors (AC, DC sides)	K34 = 1.4	
1	Single-phase bridge	Without reactor	K41= 2.3	
4	(Capacitor smoothing)	With reactor (AC side)	K42 = 0.35 *	
5	Self-excitation three-phase bridge	When high power factor converter is used	K5 = 0	

^{*} K42=0.35 is a value when the reactor value is 20%. Since a 20% reactor is large and considered to be not practical, K42=1.67 is written as conversion factor for a 5% reactor in the technical data JEM-TR201 of the Japan Electric Machine Industry Association and this value is recommended for calculation for the actual practice.

Table 3 Equivalent Capacity Limits

Received Power Voltage	Reference Capacity
6.6kV	50kVA
22/33 kV	300kVA
66kV or more	2000kVA

Table 4 Harmonic Contents (Values at the fundamental current of 100%)

	Reactor	5th	7th	11th	13th	17th	19th	23rd	25th
	Not used	65	41	8.5	7.7	4.3	3.1	2.6	1.8
Three-phase bridge	Used (AC side)	38	14.5	7.4	3.4	3.2	1.9	1.7	1.3
(Capacitor smoothing)	Used (DC side)	30	13	8.4	5.0	4.7	3.2	3.0	2.2
	Used (AC, DC sides)	28	9.1	7.2	4.1	3.2	2.4	1.6	1.4
Single-phase bridge	Not used	50	24	5.1	4.0	1.5	1.4	_	_
(Capacitor smoothing)	Used (AC side) *	6.0	3.9	1.6	1.2	0.6	0.1	_	_

^{*} The harmonic contents for "single-phase bridge/with reactor" in the table 4 are values when the reactor value is 20%. Since a 20% reactor is large and considered to be not practical, harmonic contents when a 5% reactor is used is written in the technical data JEM-TR201 of The Japan Electrical Manufacturers' Association and this value is recommended for calculation for the actual practice.

1) Calculation of equivalent capacity (P0) of harmonic generating equipment

The "equivalent capacity" is the capacity of a 6-pulse converter converted from the capacity of consumer's harmonic generating equipment and is calculated with the following equation. If the sum of equivalent capacities is higher than the limit in Table 3, harmonics must be calculated with the following procedure:

P0 = $\Sigma(Ki \times Pi)$ [kVA]

Ki: Conversion factor (refer to Table 2)

Pi: Rated capacity of harmonic generating equipment*[kVA]

i: Number indicating the conversion circuit type

* Rated capacity: Determined by the capacity of the applied motor and found in Table 5. It should be noted that the rated capacity used here is used to calculate generated harmonic amount and is different from the power supply capacity required for actual inverter drive.

2) Calculation of outgoing harmonic current

Outgoing harmonic current = fundamental wave current (value converted from received power voltage) \times operation ratio \times harmonic content

- Operation ratio: Operation ratio = actual load factor × operation time ratio during 30 minutes
- · Harmonic content: Found in Table 4.

Table 5 Rated Capacities and Outgoing Harmonic Currents for Inverter Drive

Accelerate	Ra	Rated Fundamental Rated Outgoing Harmonic Current Converted from 6.6kV(mA)					(mA)					
• •	Applicable Current [A] Wave Current Capacity					(1	No react	or, 100%	6 operat	ion ratio	o)	
Motor (kW)	200V	400V	Converted from 6.6kV (mA)	(kVA)	5th	7th	11th	13th	17th	19th	23rd	25th
0.4	1.61	0.81	49	0.57	31.85	20.09	4.165	3.773	2.107	1.519	1.274	0.882
0.75	2.74	1.37	83	0.97	53.95	34.03	7.055	6.391	3.569	2.573	2.158	1.494
1.5	5.50	2.75	167	1.95	108.6	68.47	14.20	12.86	7.181	5.177	4.342	3.006
2.2	7.93	3.96	240	2.81	156.0	98.40	20.40	18.48	10.32	7.440	6.240	4.320
3.7	13.0	6.50	394	4.61	257.1	161.5	33.49	30.34	16.94	12.21	10.24	7.092
5.5	19.1	9.55	579	6.77	376.1	237.4	49.22	44.58	24.90	17.95	15.05	10.42
7.5	25.6	12.8	776	9.07	504.4	318.2	65.96	59.75	33.37	24.06	20.18	13.97
11	36.9	18.5	1121	13.1	728.7	459.6	95.29	86.32	48.20	34.75	29.15	20.18
15	49.8	24.9	1509	17.6	980.9	618.7	128.3	116.2	64.89	46.78	39.24	27.16

3) Application of the guideline for specific consumers

If the outgoing harmonic current is higher than the maximum value per 1kW contract power \times contract power, a harmonic suppression technique is required.

4) Harmonic suppression techniques

No.	Item	Description
1	Reactor installation	Install an AC reactor (FR-HAL) on the AC side of the inverter or a DC reactor (FR-HEL) on its DC side
'	(FR-HAL, FR-HEL)	or both to suppress outgoing harmonic currents.
	High power factor converter	The converter circuit is switched ON/OFF to convert an input current waveform into a sine wave,
2	(FR-HC)	suppressing harmonic currents substantially. The high power factor converter (FR-HC) is used with the
	(114-116)	standard accessory.
3	Installation of power factor	When used with a series reactor, the power factor improving capacitor has an effect of absorbing
3	improving capacitor	harmonic currents.
4	Transformer multi-phase	Use two transformers with a phase angle difference of 30° as in \bot -Δ, Δ-Δ combination to provide an
7	operation	effect corresponding to 12 pulses, reducing low-degree harmonic currents.
5	Passive filter	A capacitor and a reactor are used together to reduce impedances at specific frequencies, producing a
3	(AC filter)	great effect of absorbing harmonic currents.
	Active filter	This filter detects the current of a circuit generating a harmonic current and generates a harmonic
6	(Active filter)	current equivalent to a difference between that current and a fundamental wave current to suppress a
	(Active litter)	harmonic current at a detection point, providing a great effect of absorbing harmonic currents.





Installation of power factor improving reactor 3.2

When the inverter is connected near a large-capacity power transformer (500kVA or more) or when a power capacitor is to be switched over, an excessive peak current may flow in the power input circuit, damaging the converter circuit. To prevent this, always install an optional reactor (FR-HAL, FR-HEL).


When connecting a single-phase 100V power input inverter to a power transformer (50kVA or more), install an AC reactor (FR-HAL) so that the performance is more reliable.

Three-phase power input





Single-phase power input



When connecting the FR-HEL, remove the jumper across terminals P/+ and P1. The wiring length between the FR-HEL and inverter should be 5m maximum and minimized.

(I) REMARKS

- Use the same wire size as that of the power supply wire (R/L1, S/L2, T/L3). (Refer to page 17)
- Single-phase 100V power input model is not compatible with DC reactor.

3.3 Power-OFF and magnetic contactor (MC)

(1) Inverter input side magnetic contactor (MC)


On the inverter input side, it is recommended to provide an MC for the following purposes. (Refer to *page 4* for selection.)

- 1) To release the inverter from the power supply when the fault occurs or when the drive is not functioning (e.g. emergency stop operation). For example, MC avoids overheat or burnout of the brake resistor when heat capacity of the resistor is insufficient or brake regenerative transistor is damaged with short while connecting an optional brake resistor.
- 2) To prevent any accident due to an automatic restart at restoration of power after an inverter stop made by a power failure
- 3) While the power is ON, inverter is consuming a little power even during inverter stop. When stopping the inverter for an extended period of time, powering OFF the inverter will save power slightly.
- 4) To separate the inverter from the power supply to ensure safe maintenance and inspection work.

The inverter's input side MC is used for the above purpose, select class JEM1038-AC3 MC for the inverter input side current when making an emergency stop during normal operation.

> REMARKS

Since repeated inrush currents at power ON will shorten the life of the converter circuit (switching life is about 1,000,000 times.), frequent starts and stops of the MC must be avoided. Turn ON/OFF the inverter start controlling terminals (STF, STR) to run/stop the inverter.



Inverter start/stop circuit example

As shown on the left, always use the start signal (ON or OFF of STF(STR) signal) to make a start or stop.

*1 When the power supply is 400V class, install a step-down transformer.

(2) Handling of inverter output side magnetic contactor

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned ON while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided for switching to the commercial power supply, for example, switch it ON/OFF after the inverter and motor have stopped.



3.4 Inverter-driven 400V class motor

In the PWM type inverter, a surge voltage attributable to wiring constants is generated at the motor terminals. Especially for a 400V class motor, the surge voltage may deteriorate the insulation. When the 400V class motor is driven by the inverter, consider the following measures:

Measures

It is recommended to take either of the following measures:

(1) Rectifying the motor insulation and limiting the PWM carrier frequency according to the wiring length

For the 400V class motor, use an insulation-enhanced motor.

Specifically,

- 1) Specify the "400V class inverter-driven insulation-enhanced motor".
- 2) For the dedicated motor such as the constant-torque motor and low-vibration motor, use the "inverter-driven, dedicated
- 3) Set Pr. 72 PWM frequency selection as indicated below according to the wiring length.

		Wiring Length				
	50m or less	50m to 100m	exceeding 100m			
Pr. 72 PWM frequency selection	15 (14.5kHz) or less	8 (8kHz) or less	2 (2kHz) or less			

(2) Suppressing the surge voltage on the inverter side

Connect the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) on the inverter output side.



NOTE

- For details of *Pr. 72 PWM frequency selection*, *refer to page 149*.

 For explanation of surge voltage suppression filter (FR-ASF-H/FR-BMF-H), refer to the manual of each option.

3.5 Precautions for use of the inverter

The FR-D700 series is a highly reliable product, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the product.

Before starting operation, always recheck the following items.

- (1) Use crimping terminals with insulation sleeve to wire the power supply and motor.
- (2) Application of power to the output terminals (U, V, W) of the inverter will damage the inverter. Never perform such wiring.
- (3) After wiring, wire offcuts must not be left in the inverter.
 - Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean.
 - When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- (4) Use cables of the size to make a voltage drop 2% maximum.
 - If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.
 - Refer to page 17 for the recommended wire sizes.
- (5) The overall wiring length should be 500m maximum.
 - Especially for long distance wiring, the fast-response current limit function may decrease or the equipment connected to the secondary side may malfunction or become faulty under the influence of a charging current due to the stray capacity of the wiring. Therefore, note the overall wiring length. (*Refer to page 19*)
- (6) Electromagnetic wave interference
 - The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, install the FR-BIF optional capacitor type filter (for use in the input side only) or FR-BSF01 or FR-BLF common mode filter to minimize interference.
- (7) Do not install a power factor correction capacitor, surge suppressor or capacitor type filter on the inverter output side. This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them. (When using capacitor type filter (FR-BIF) for a single-phase power input model, make sure of secure insulation of T/L3-phase, and connect to the input side of the inverter.)
- (8) For some short time after the power is switched OFF, a high voltage remains in the smoothing capacitor. When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched OFF, and then make sure that the voltage across the main circuit terminals P/+ and N/- of the inverter is not more than 30VDC using a tester, etc.
- (9) A short circuit or earth (ground) fault on the inverter output side may damage the inverter modules.
 - Fully check the insulation resistance of the circuit prior to inverter operation since repeated short circuits caused by
 peripheral circuit inadequacy or an earth (ground) fault caused by wiring inadequacy or reduced motor insulation
 resistance may damage the inverter modules.
 - Fully check the to-earth (ground) insulation and phase to phase insulation of the inverter output side before power-on. Especially for an old motor or use in hostile atmosphere, securely check the motor insulation resistance etc.
- (10) Do not use the inverter input side magnetic contactor to start/stop the inverter.

Always use the start signal (turn ON/OFF STF and STR signals) to start/stop the inverter. (Refer to page 46)

(11) Across terminals P/+ and PR, connect only an external regenerative brake discharging resistor.


Do not connect a mechanical brake.

The brake resistor can not be connected to the 0.1K and 0.2K. Never short between terminals P/+ and PR.



- (12) Do not apply a voltage higher than the permissible voltage to the inverter I/O signal circuits.

 Application of a voltage higher than the permissible voltage to the inverter I/O signal circuits or opposite polarity may damage the I/O devices. Especially check the wiring to prevent the speed setting potentiometer from being connected incorrectly to short terminals 10-5.
- (13) Provide electrical and mechanical interlocks for MC1 and MC2 which are used for bypass operation. When the wiring is incorrect and if there is a bypass operation circuit as shown right, the inverter will be damaged due to arcs generated at the time of switch-over or chattering caused by a sequence error.



- (14) If the machine must not be restarted when power is restored after a power failure, provide a magnetic contactor in the inverter's input side and also make up a sequence which will not switch ON the start signal.
 If the start signal (start switch) remains ON after a power failure, the inverter will automatically restart as soon as the power is restored.
- (15) Instructions for overload operation

When performing operation of frequent start/stop of the inverter, rise/fall in the temperature of the transistor element of the inverter will repeat due to a repeated flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing current at locked condition, starting current, etc. Decreasing current may increase the life. However, decreasing current will result in insufficient torque and the inverter may not start. Therefore, choose the inverter which has enough allowance for current (up to 2 rank larger in capacity).

- (16) Make sure that the specifications and rating match the system requirements.
- (17) If electromagnetic noise generated from the inverter causes frequency setting signal to fluctuate and motor rotation speed to be unstable when changing motor speed with analog signal, the following countermeasures are effective.
 - Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
 - Run signal cables as far away as possible from power cables (inverter I/O cables).
 - Use shield cables as signal cables.
 - Install a ferrite core on the signal cable (Example: ZCAT3035-1330 TDK).

3.6 Failsafe of the system which uses the inverter

When a fault occurs, the inverter trips to output a fault signal. However, a fault output signal may not be output at an inverter fault occurrence when the detection circuit or output circuit fails, etc. Although Mitsubishi assures best quality products, provide an interlock which uses inverter status output signals to prevent accidents such as damage to machine when the inverter fails for some reason and at the same time consider the system configuration where failsafe from outside the inverter, without using the inverter, is enabled even if the inverter fails.

Interlock method which uses the inverter status output signals
 By combining the inverter status output signals to provide an interlock as shown below, an inverter alarm can be detected.

No	Interlock Method	Check Method	Used Signals	Refer to Page
1)	Inverter protective function operation	Operation check of an alarm contact Circuit error detection by negative logic	Fault output signal (ALM signal)	123
2)	Inverter operating status	Operation ready signal check	Operation ready signal (RY signal)	122
3)	Inverter running status	Logic check of the start signal and running signal	Start signal (STF signal, STR signal) Running signal (RUN signal)	118, 122
4)	Inverter running status	Logic check of the start signal and output current	Start signal (STF signal, STR signal) Output current detection signal (Y12 signal)	118, 125

1)Check by the inverter fault output signal

When the fault occurs and the inverter trips, the fault output signal (ALM signal) is output (ALM signal is assigned to terminal ABC in the initial setting).

Check that the inverter functions properly.

In addition, negative logic can be set (ON when the inverter is normal, OFF when the fault occurs).

2)Checking the inverter operating status by the inverter operation ready completion signal Operation ready signal (RY signal) is output when the


inverter power is ON and the inverter becomes operative.


Check if the RY signal is output after powering ON the inverter.

Checking the inverter operating status by the start signal input to the inverter and inverter running signal.

The inverter running signal (RUN signal) is output when the inverter is running (RUN signal is assigned to terminal RUN in the initial setting).

Check if RUN signal is output when inputting the start signal to the inverter (forward signal is STF signal and reverse signal is STR signal). For logic check, note that RUN signal is output for the period from the inverter decelerates until output to the motor is stopped, configure a sequence considering the inverter deceleration time.







4)Checking the motor operating status by the start signal input to the inverter and inverter output current detection signal.

The output current detection signal (Y12 signal) is output when the inverter operates and currents flows in the motor. Check if Y12 signal is output when inputting the start signal to the inverter (forward signal is STF signal and reverse signal is STR signal). Note that the current level at which Y12 signal is output is set to 150% of the inverter rated current in the initial setting, it is necessary to adjust the level to around 20% using no load current of the motor as reference with *Pr.150 Output current detection level*.

For logic check, as same as the inverter running signal (RUN signal), the inverter outputs for the period from the inverter decelerates until output to the motor is stopped, configure a sequence considering the inverter deceleration time.

Output	Pr. 190, Pr. 192, Pr. 197 Setting				
Signal	Positive logic	Negative logic			
ALM	99	199			
RY	11	111			
RUN	0	100			
Y12	12	112			

 When using various signals, assign functions to Pr.190, Pr.192, Pr.197 (output terminal function selection) referring to the table on the left.



NOTE

Changing the terminal assignment using *Pr. 190, Pr. 192, Pr. 197 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

(2) Backup method outside the inverter

Even if the interlock is provided by the inverter status signal, enough failsafe is not ensured depending on the failure status of the inverter itself. For example, when the inverter CPU fails, even if the interlock is provided using the inverter fault signal, start signal and RUN signal, there is a case where a fault signal is not output and RUN signal is kept output even if an inverter fault occurs.


Provide a speed detector to detect the motor speed and current detector to detect the motor current and consider the backup system such as checking up as below according to the level of importance of the system.

1)Start signal and actual operation check

Check the motor running and motor current while the start signal is input to the inverter by comparing the start signal to the inverter and detected speed of the speed detector or detected current of the current detector. Note that the motor current runs as the motor is running for the period until the motor stops since the inverter starts decelerating even if the start signal turns OFF. For the logic check, configure a sequence considering the inverter deceleration time. In addition, it is recommended to check the three-phase current when using the current detector.

2)Command speed and actual operation check

Check if there is no gap between the actual speed and commanded speed by comparing the inverter speed command and detected speed of the speed detector.



MEMO

4 PARAMETERS

This chapter explains the "PARAMETERS" for use of this product.

Always read the instructions before using the equipment.

The following marks are used to indicate the controls as below.

WFV/F control

GPMIVOGeneral-purpose magnetic flux vector control (Parameters without any mark are valid for both controls.)

1

2

3

1

5

6

7

Operation panel

4.1.1 Names and functions of the operation panel

The operation panel cannot be removed from the inverter.

Operation mode indication

PU: Lit to indicate PU operation mode.

EXT: Lit to indicate External operation mode. (Lit at power-ON at initial setting.)

NET: Lit to indicate Network operation mode.

PU, EXT: Lit to indicate External/PU combined operation mode 1, 2.

These turn OFF when command source is not on operation panel (Refer to page 177).

Unit indication

Hz: Lit to indicate frequency. (Flickers when the set frequency monitor is displayed.)

A: Lit to indicate current.

(Both "Hz" and "A" turn OFF when other than the above is displayed.)

Monitor (4-digit LED)

Shows the frequency, parameter number,

Setting dial

(Setting dial: Mitsubishi inverter dial) Used to change the frequency setting and parameter values.

Press to display the following.

- Displays the set frequency in the monitor mode
- Present set value is displayed during calibration
- Displays the order in the faults history mode

Mode switchover

Used to change each setting mode.





Pressing $\frac{PU}{EXT}$ simultaneously changes

the operation mode. (Refer to page 56) Pressing for a while (2s) can lock operation. (Refer to page 239)

Determination of each setting

If pressed during operation, monitor changes as below;





Operating status indication

Lit or flicker during inverter operation.

ON: Indicates that forward rotation operation is being performed. Slow flickering (1.4s cycle):

Reverse rotation operation Fast flickering (0.2s cycle):

When (RUN) was pressed or the

start command was given, but the operation can not be made.

- •When the frequency command is less than the starting frequency.
- •When the MRS signal is input.

Parameter setting mode indication Lit to indicate parameter setting mode.

Monitor indication

Lit to indicate monitoring mode

Stop operation

Used to stop Run command. Fault can be reset when protective function is activated (fault).

Operation mode switchover

Used to switch between the PU and External operation mode.

When using the External operation mode (operation using a separately connected frequency setting potentiometer and start signal), press this key to light up the EXT indication.

(Press (MODE) simultaneously (0.5s) (Refer to

page 56), or change Pr. 79 setting to change to combined mode .)


PU: PU operation mode

EXT: External operation mode Cancels PU stop also.

Start command

The rotation direction can be selected by setting Pr. 40.

4.1.2 Basic operation (factory setting)



4.1.3 Easy operation mode setting (easy setting mode)

Setting of Pr. 79 Operation mode selection according to combination of the start command and speed command can be easily made.

Changing example

Start command: external (STF/STR), frequency command: operate with



Display -

1. Screen at powering ON

The monitor display appears.

 $2.\ \text{Press}\ \frac{\boxed{\text{PU}}}{\boxed{\text{EXT}}} \text{and}\ \sqrt{\text{MODE}} \text{for } 0.5\text{s}$

3. Turn until 79 - 3 appears. (refer to the table below for other settings)

Operation -



Flickering

Operation Panel Indication	Operation Method				
Operation Faner indication	Start command	Frequency command			
Flickering Flickering	RUN				
Flickering Flickering	External (STF, STR)	Analog voltage input			
Flickering	External (STF, STR)				
Flickering	RUN	Analog voltage input			

4. Press (SET) to set.



Flicker ··· Parameter setting complete!!

___ The monitor display appears after 3s.



REMARKS


? Er! is displayed ... Why?

Parameter write is disabled with "1" set in Pr. 77.

? Er 2 is displayed ... Why?

Setting can not be made during operation. Turn the start switch ((RUN), STF or STR) OFF.

- Press (MODE) before pressing (SET) to return to the monitor display without setting. In this case, the mode changes to External
 operation mode when performed in the PU operation mode (PU JOG operation mode) and to PU operation mode when
 performed in the External operation mode.
- Reset can be made with (STOP).
- The priorities of the frequency commands when *Pr.* 79 = "3" are "Multi-speed operation (RL/RM/RH/REX) > PID control (X14) > terminal 4 analog input (AU) > digital input from the operation panel".



Changing example

Change the Pr. 1 Maximum frequency setting.



- Screen at powering ON
 The monitor display appears.
- 2. Press $\frac{PU}{EXT}$ to choose the PU operation mode.
- 3. Press (MODE) to choose the parameter setting mode.
- 4. Turn until P_{\cdot} (Pr. 1) appears.
- **5.** Press (SET) to read the present set value.
 - " / 2 [] [] "(120.0Hz (initial value)) appears.
- 6. Turn to change the set value to "FITT" (60.00Hz).
- 7. Press (SET) to set.





PU indication is lit.



PRM indication is lit.



(The parameter number read previously appears.)



MODE










Flicker...Parameter setting complete!!

- Turn to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.
- Press (MODE) twice to return to frequency monitor.

• REMARKS



The number of digits displayed on the operation panel is four. Only the upper four digits of values can be displayed and set. If the
values to be displayed have five digits or more including decimal places, the fifth or later numerals can not be displayed nor set.
(Example) For Pr. 1

When 60Hz is set, 60.00 is displayed.

When 120Hz is set, 120.0 is displayed and second decimal place is not displayed nor set.

4.1.5 Setting dial push

Push the setting dial (



) to display the set frequency* currently set.

^{*} Appears when PU operation mode or External/PU combined operation mode 1 is selected (Pr. 79 ="3").

4.2 Parameter list

4.2.1 Parameter list

For simple variable-speed operation of the inverter, the initial setting of the parameters may be used. Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check can be made from the operation panel.

• REMARKS

- lindicates simple mode parameters.
- The parameters surrounded by a black border in the table allow its setting to be changed during operation even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
	© 0	Torque boost	0 to 30%	0.1%	6/4/3/2% *1	75	
	© 1	Maximum frequency	0 to 120Hz	0.01Hz	120Hz	84	
	© 2	Minimum frequency	0 to 120Hz	0.01Hz	0Hz	84	
દ	© 3	Base frequency	0 to 400Hz	0.01Hz	60Hz	86	
Basic functions	© 4	Multi-speed setting (high speed)	0 to 400Hz	0.01Hz	60Hz	90	
oun	© 5	Multi-speed setting (middle speed)	0 to 400Hz	0.01Hz	30Hz	90	
i E	© 6	Multi-speed setting (low speed)	0 to 400Hz	0.01Hz	10Hz	90	
sas	© 7	Acceleration time	0 to 3600s	0.1s	5/10/15s *2	97	
ш	® 8	Deceleration time	0 to 3600s	0.1s	5/10/15s *2	97	
	© 9	Electronic thermal O/L relay	0 to 500A	0.01A	Rated inverter current	101	
tion	10	DC injection brake operation frequency	0 to 120Hz	0.01Hz	3Hz	110	
DC injection brake	11	DC injection brake operation time	0 to 10s	0.1s	0.5s	110	
20	12	DC injection brake operation voltage	0 to 30%	0.1%	6/4/2% *3	110	
_	13	Starting frequency	0 to 60Hz	0.01Hz	0.5Hz	99	
_	14	Load pattern selection	0 to 3	1	0	88	
JOG operation	15	Jog frequency	0 to 400Hz	0.01Hz	5Hz	92	
JC	16	Jog acceleration/deceleration time	0 to 3600s	0.1s	0.5s	92	
_	17	MRS input selection	0, 2, 4	1	0	116	
_	18	High speed maximum frequency	120 to 400Hz	0.01Hz	120Hz	84	
_	19	Base frequency voltage	0 to 1000V, 8888, 9999	0.1V	9999	86	
Acceleration/ deceleration time	20	Acceleration/deceleration reference frequency	1 to 400Hz	0.01Hz	60Hz	97	
Stall prevention	22	Stall prevention operation level	0 to 200%	0.1%	150%	80	
St	23	Stall prevention operation level compensation factor at double speed	0 to 200%, 9999	0.1%	9999	80	
Ъ	24	Multi-speed setting (speed 4)	0 to 400Hz, 9999	0.01Hz	9999	90	
ge Jg	25	Multi-speed setting (speed 5)	0 to 400Hz, 9999	0.01Hz	9999	90	
ulti-spee setting	26	Multi-speed setting (speed 6)	0 to 400Hz, 9999	0.01Hz	9999	90	
Multi-speed setting	27	Multi-speed setting (speed 7)	0 to 400Hz, 9999	0.01Hz	9999	90	
_	29	Acceleration/deceleration pattern selection	0, 1, 2	1	0	100	

- Symbol in the Remarks column
- **Ver.UP** ... Specifications differ according to the date assembled. *Refer to page 300* to check the SERIAL number.
- These instruction codes are used for parameter read and write by using Mitsubishi inverter protocol with the RS-485 communication. (Refer to page 184 for RS-485 communication)
- "O" indicates valid and "x" indicates invalid of "control mode-based correspondence table", "parameter copy", "parameter clear", and "all parameter clear".

Parameter	Remarks	Ins	truction C	ode		Control Mode-based Correspondence Table		Parameter			
		Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear		
⊚ 0		00	80	0	0	×	0	0	0		
© 1		01	81	0	0	0	0	0	0		
© 2		02	82	0	0	0	0	0	0		
⊚ 3		03	83	0	0	×	0	0	0		
© 4		04	84	0	0	0	0	0	0		
© 5		05	85	0	0	0	0	0	0		
© 6		06	86	0	0	0	0	0	0		
© 7		07	87	0	0	0	0	0	0		
© 8		08	88	0	0	0	0	0	0		
© 9		09	89	0	0	0	0	0	0		
10		0A	8A	0	0	0	0	0	0		
11		0B	8B	0	0	0	0	0	0		
12		0C	8C	0	0	0	0	0	0		
13		0D	8D	0	0	0	0	0	0		
14		0E	8E	0	0	×	0	0	0		
15		0F	8F	0	0	0	0	0	0		
16		10	90	0	0	0	0	0	0		
17		11	91	0	0	0	0	0	0		
18		12	92	0	0	0	0	0	0		
19		13	93	0	0	×	0	0	0		
20		14	94	0	0	0	0	0	0		
22		16	96	0	0	0	0	0	0		
23		17	97	0	0	0	0	0	0		
24		18	98	0	0	0	0	0	0		
25		19	99	0	0	0	0	0	0		
26		1A	9 <i>A</i>	0	0	0	0	0	0		
27		1B	9B	0	0	0	0	0	0		
29		1D	9D	0	0	0	0	0	0		

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
_	30	Regenerative function selection	0, 1, 2	1	0	111, 137	
<u>d</u>	31	Frequency jump 1A	0 to 400Hz, 9999	0.01Hz	9999	85	
Frequency jump	32	Frequency jump 1B	0 to 400Hz, 9999	0.01Hz	9999	85	
S	33	Frequency jump 2A	0 to 400Hz, 9999	0.01Hz	9999	85	
neu	34	Frequency jump 2B	0 to 400Hz, 9999	0.01Hz	9999	85	
req	35	Frequency jump 3A	0 to 400Hz, 9999	0.01Hz	9999	85	
正	36	Frequency jump 3B	0 to 400Hz, 9999	0.01Hz	9999	85	
_	37	Speed display	0, 0.01 to 9998	0.001	0	128	
	40	RUN key rotation direction selection	0, 1	1	0	238	
<u>ي</u> رخ	41	Up-to-frequency sensitivity	0 to 100%	0.1%	10%	124	
ctio	42	Output frequency detection	0 to 400Hz	0.01Hz	6Hz	124	
Frequency detection	43	Output frequency detection for reverse rotation	0 to 400Hz, 9999	0.01Hz	9999	124	
"	44	Second acceleration/deceleration time	0 to 3600s	0.1s	5/10/15s *2	97, 221	
ons	45	Second deceleration time	0 to 3600s, 9999	0.1s	9999	97, 221	
ncti	46	Second torque boost	0 to 30%, 9999	0.1%	9999	75	
ī fū	47	Second V/F (base frequency)	0 to 400Hz, 9999	0.01Hz	9999	86	
Second functions	48	Second stall prevention operation current	0 to 200%, 9999	0.1%	9999	80	
S	51	Second electronic thermal O/L relay	0 to 500A, 9999	0.01A	9999	101	
suo	52	DU/PU main display data selection	0, 5, 8 to 12, 14, 20, 23 to 25, 52 to 55, 61, 62, 64, 100	1	0	129	
Monitor functions	54	FM terminal function selection	1 to 3, 5, 8 to 12, 14, 21, 24, 52, 53, 61, 62	1	1	129	
itor	55	Frequency monitoring reference	0 to 400Hz	0.01Hz	60Hz	134	
Mon	56	Current monitoring reference	0 to 500A	0.01A	Rated inverter current	134	
Automatic restart functions	57	Restart coasting time	0, 0.1 to 5s, 9999	0.1s	9999	137	
Autor res fund	58	Restart cushion time	0 to 60s	0.1s	1s	137	
_	59	Remote function selection	0, 1, 2, 3	1	0	94	
_	60	Energy saving control selection	0, 9	1	0	148	
_	65	Retry selection	0 to 5	1	0	145	
_	66	Stall prevention operation reduction starting frequency	0 to 400Hz	0.01Hz	60Hz	80	
>	67	Number of retries at fault occurrence	0 to 10, 101 to 110	1	0	145	
Retry	68	Retry waiting time	0.1 to 600s	0.1s	1s	145	
<u>«</u>	69	Retry count display erase	0	1	0	145	
_	70	Special regenerative brake duty	0 to 30%	0.1%	0%	111	
_	71	Applied motor	0, 1, 3, 13, 23, 40, 43, 50, 53	1	0	76, 104,	
						106,	
_	72	PWM frequency selection	0 to 15	1	1	149	
_	73	Analog input selection	0, 1, 10, 11	1	1	151	
	74 75	Input filter time constant Reset selection/disconnected PU	0 to 8 0 to 3, 14 to 17	1	1 14	153 159	
		detection/PU stop selection					
	77	Parameter write selection	0, 1, 2	1	0	162	
	78	Reverse rotation prevention selection	0, 1, 2	1	0	163	
_	© 79	Operation mode selection	0, 1, 2, 3, 4, 6, 7	1	0	166, 176	

							Parame	eter list	
Remarks	Instruction Code			Control Mode-based Correspondence Table		Parameter			
	Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear	
	1E	9E	0	0	0	0	0	0	
	1F	9F	0	0	0	0	0	0	
	20	A0	0	0	0	0	0	0	
	21	A1	0	0	0	0	0	0	
	22	A2	0	0	0	0	0	0	
	23	A3	0	0	0	0	0	0	
	24	A4	0	0	0	0	0	0	
	25	A5	0	0	0	0	0	0	
	28	A8	0	0	0	0	0	0	
	29	A9	0	0	0	0	0	0	
	2Δ	ΔΔ	0	0	0	0	0	0	

Parameter	Remarks	instruction code		Correspondence Table		Farameter			
		Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
30		1E	9E	0	0	0	0	0	0
31		1F	9F	0	0	0	0	0	0
32		20	A0	0	0	0	0	0	0
33		21	A1	0	0	0	0	0	0
34		22	A2	0	0	0	0	0	0
35		23	A3	0	0	0	0	0	0
36		24	A4	0	0	0	0	0	0
37 40		25 28	A5 A8	0	0	0	0	0	0
41		29	A9	0	0	0	0	0	0
42		2A	AA	0	0	0	0	0	0
43		2B	AB	0	0	0	0	0	0
44		2C	AC	0	0	0	0	0	0
45		2D	AD	0	0	0	0	0	0
46		2E	AE	0	0	×	0	0	0
47		2F	AF	0	0	×	0	0	0
48		30	В0	0	0	0	0	0	0
51		33	В3	0	0	0	0	0	0
52		34	B4	0	0	0	0	0	0
54		36	В6	0	0	0	0	0	0
55		37	B7	0	0	0	0	0	0
56		38	В8	0	0	0	0	0	0
57		39	B9	0	0	0	0	0	0
58		3 <i>A</i>	BA	0	0	0	0	0	0
59		3B	BB	0	0	0	0	0	0
60		3C	BC	0	0	×	0	0	0
65		41	C1	0	0	0	0	0	0
66		42	C2	0	0	0	0	0	0
67		43	C3	0	0	0	0	0	0
68		44	C4	0	0	0	0	0	0
69 70		45	C5	0	0	0	0	0	0
70		46	C6	0	0	0	0	0	U
71		47	C7	0	0	0	0	0	0
72		48	C8	0	0	0	0	0	0
73		49	C9	0	0	0	0	×	0
74		4A	CA	0	0	0	0	0	0
75		4B	СВ	0	0	0	0	×	×
77		4D	CD *4	0	0	0	0	0	0
78		4E	CE	0	0	0	0	0	0
© 79		4F	CF *4	0	0	0	0	0	0

Parameter list

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
	80	Motor capacity	0.1 to 15kW, 9999	0.01kW	9999	76, 106	
ıts	82	Motor excitation current	0 to 500A, 9999	0.01A	9999	106	
Motor constants	83	Rated motor voltage	0 to 1000V	0.1V	200V/400V *5	106	
con	84	Rated motor frequency	10 to 120Hz	0.01Hz	60Hz	106	
tor	90	Motor constant (R1)	0 to 50Ω , 9999	0.001Ω	9999	106	
Mo	96	Auto tuning setting/status	0, 11, 21	1	0	106, 137	
	117	PU communication station number	0 to 31 (0 to 247)	1	0	184, 201	
PU connector communication	118	PU communication speed	48, 96, 192, 384	1	192	184, 201	
nnu	119	PU communication stop bit length	0, 1, 10, 11	1	1	184	
comr	120	PU communication parity check	0, 1, 2	1	2	184,	
ctor	121	Number of PU communication retries	0 to 10, 9999	1	1	201 185	
conne	121	PU communication check time interval	0, 0.1 to 999.8s, 9999	0.1s	0	185,	
ی ل						201	
ш	123 124	PU communication waiting time setting PU communication CR/LF selection	0 to 150ms, 9999	1	9999	184	
		Terminal 2 frequency setting gain	0, 1, 2		Ì	184	
_	© 125	frequency	0 to 400Hz	0.01Hz	60Hz	154	
_	© 126	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	154	
	127	PID control automatic switchover frequency	0 to 400Hz, 9999	0.01Hz	9999	213	
	128	PID action selection	0, 20, 21, 40 to 43	1	0	213, 221	
	129	PID proportional band	0.1 to 1000%, 9999	0.1%	100%	213, 221	
PID operation	130	PID integral time	0.1 to 3600s, 9999	0.1s	1s	213, 221	
ID ope	131	PID upper limit	0 to 100%, 9999	0.1%	9999	213, 221	
Ф	132	PID lower limit	0 to 100%, 9999	0.1%	9999	213, 221	
	133	PID action set point	0 to 100%, 9999	0.01%	9999	213, 221	
	134	PID differential time	0.01 to 10s, 9999	0.01s	9999	213, 221	
PU	145	PU display language selection	0 to 7	1	0	238	
_	146 *6	Built-in potentiometer switching	0, 1	1	1	243	
ent	150 151	Output current detection level Output current detection signal delay	0 to 200% 0 to 10s	0.1% 0.1s	150% 0s	125 125	
Current detection		time					
g မ	152	Zero current detection level	0 to 200%	0.1%	5%	125	
	153 156	Zero current detection time Stall prevention operation selection	0 to 1s 0 to 31, 100, 101	0.01s	0.5s 0	125 80	
_	157	OL signal output timer	0 to 25s, 9999	0.1s	0s	80	
_	© 160	Extended function display selection	0, 9999	1	9999	163	
_	161	Frequency setting/key lock operation selection	0, 1, 10, 11	1	0	239	
c restart ons	162	Automatic restart after instantaneous power failure selection	0, 1, 10, 11	1	1	137	
Automatic restart functions	165	Stall prevention operation level for restart	0 to 200%	0.1%	150%	137	

Parameter	Remarks	Inst	truction C	ode		ode-based dence Table	Parameter			
		Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear	
80		50	D0	0	×	0	0	0	0	
82		52	D2	0	×	0	0	×	0	
83		53	D3	0	×	0	0	0	0	
84		54	D4	0	×	0	0	0	0	
90		5A	DA	0	0	0	0	×	0	
96		60	E0	0	0	0	0	×	0	
117		11	91	1	0	0	0	O *8	O *8	
118		12	92	1	0	0	0	O *8	O *8	
119		13	93	1	0	0	0	O *8	O *8	
120		14	94	1	0	0	0	O *8	O *8	
121		15	95	1	0	0	0	O *8	O *8	
122		16	96	1	0	0	0	O *8	O *8	
123		17	97	1	0	0	0	O *8	O *8	
124		18	98		0		0	O *8	O *8	
© 125		19	99	1	0	0	0	×	0	
© 126		1A	9 <i>A</i>	1	0	0	0	×	0	
127		1B	9B	1	0	0	0	0	0	
128		1C	9C	1	0	0	0	0	0	
129		1D	9D	1	0	0	0	0	0	
130		1E	9E	1	0	0	0	0	0	
131		1F	9F	1	0	0	0	0	0	
132		20	A0	1	0	0	0	0	0	
133		21	A1	1	0	0	0	0	0	
134		22	A2	1	0	0	0	0	0	
145		2D	AD	1	0	0	0	×	×	
146		2E	AE	1	0 0	0	0 0	×	×	
150		32	B2	1	0	0	0	0	0	
151 152		33 34	B3 B4	1	0	0	0	0	0	
153		35	B5	1	0	0	0	0	0	
156		38	B8	1	0	0	0	0	0	
157		39	B9	1	0	0	0	0	0	
© 160		00	80	2	0	0	0	0	0	
161		01	81	2	0	0	0	×	0	
162		02	82	2	0	0	0	0	0	
165		05	85	2	0	0	0	0	0	

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Custome Setting
letection	166	Output current detection signal retention time	0 to 10s, 9999	0.1s	0.1s	125	
Current detection	Output current detection operation selection		0, 1	1	0	125	
_	168 169	Parameter for manufacturer setting. Do	o not set.				
Cumulative monitor clear	170	Watt-hour meter clear	0, 10, 9999	1	9999	129	
Cumulative monitor clear	171	Operation hour meter clear	0, 9999	1	9999	129	
nction t	178	STF terminal function selection	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 60, 62, 65 to 67, 9999	1	60	114	
Input terminal function assignment	179	STR terminal function selection	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 61, 62, 65 to 67, 9999	1	61	114	
teri ass	180	RL terminal function selection	0 to 5, 7, 8, 10, 12,	1	0	114	
put	181	RM terminal function selection	14, 16, 18, 24, 25,	1	1	114	
<u>u</u>	182	RH terminal function selection	62, 65 to 67, 9999	1	2	114	
nment	190	RUN terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 25, 26, 46, 47, 64, 70, 80, 81, 90, 91, 93, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 125, 126, 146, 147, 164, 170, 180, 181, 190, 191, 193, 195, 196, 198, 199, 9999	1	0	120	
Output terminal function assignment	192	A,B,C terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 25, 26, 46, 47, 64, 70, 80, 81, 90, 91, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 125, 126, 146, 147, 164, 170, 180, 181, 190, 191, 195, 196, 198, 199, 9999	1	99	120	
Output	197	SO terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 25, 26, 46, 47, 64, 70, 80, 81, 90, 91, 93, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 125, 126, 146, 147, 164, 170, 180, 181, 190, 191, 193, 195, 196, 198, 199	1	80	120	
_	232	Multi-speed setting (speed 8)	0 to 400Hz, 9999	0.01Hz	9999	90	
ting	233	Multi-speed setting (speed 9)	0 to 400Hz, 9999	0.01Hz	9999	90	
Multi-speed setting	234	Multi-speed setting (speed 10)	0 to 400Hz, 9999	0.01Hz	9999	90	
ed	235	Multi-speed setting (speed 11)	0 to 400Hz, 9999	0.01Hz	9999	90	
ds-	236 237	Multi-speed setting (speed 12) Multi-speed setting (speed 13)	0 to 400Hz, 9999 0 to 400Hz, 9999	0.01Hz 0.01Hz	9999 9999	90	
lulti	238	Multi-speed setting (speed 14)	0 to 400Hz, 9999	0.01Hz	9999	90	
Σ	239	Multi-speed setting (speed 14)	0 to 400Hz, 9999	0.01Hz	9999	90	
_	240	Soft-PWM operation selection	0, 1	1	1	149	
	240	Analog input display unit switchover	0, 1	1	0	154	
	241	Cooling fan operation selection	0, 1	1	1	229	
tion	245	Rated slip	0 to 50%, 9999	0.01%	9999	79	
Slip compensation	246	Slip compensation time constant	0.01 to 10s	0.01s	0.5s	79	
com	247	Constant-power range slip compensation selection	0, 9999	1	9999	79	

Par	ame	ter	list	1
. u	uiiiv			,

Parameter	Remarks	Inst	ruction C	ode	Control M Correspond	ode-based dence Table	Parameter						
T di dillotoi	Romano	Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear				
166		06	86	2	0	0	0	0	0				
167		07	87	2	0	0	0	0	0				
168 169	Parameter for manufacturer setting. Do not set.												
170		0A	8A	2	0	0	0	×	0				
171		0B	8B	2	0	0	×	×	×				
178		12	92	2	0	0	0	×	0				
179		13	93	2	0	0	0	×	0				
180		14	94	2	0	0	0	×	0				
181		15	95	2	0	0	0	×	0				
182		16	96	2	0	0	0	×	0				
190	(Ver.UP)	1E	9E	2	0	0	0	×	0				
192	(Ver.UP)	20	A0	2	0	0	0	×	0				
197	(Ver.UP)	25	A5	2	0	0	0	×	0				
232		28	A8	2	0	0	0	0	0				
233		29	A9	2	0	0	0	0	0				
234		2A	AA	2	0	0	0 (0	0				
235		2B	AB	2	0 0	0	0 0	0	0				
236 237		2C 2D	AC AD	2	0	0	0	0	0				
237		2D 2E	AD AE	2	0	0	0	0	0				
238		2E 2F	AF	2	0	0	0	0	0				
240		30	B0	2	0	0	0	0	0				
240		31	B1	2	0	0	0	0	0				
244		34	B4	2	0	0	0	0	0				
245		35	B5	2	0	0	0	0	0				
246		36	В6	2	0	0	0	0	0				
247		37	B7	2	0	0	0	0	0				

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
_	249	Earth (ground) fault detection at start	0, 1	1	0	147	
	250	Stop selection	0 to 100s, 1000 to 1100s, 8888, 9999	0.1s	9999	113, 118	
_	251	Output phase loss protection selection	0, 1	1	1	147	
is	255	Life alarm status display	(0 to 15)	1	0	230	
Life diagnosis	256	Inrush current limit circuit life display	(0 to 100%)	1%	100%	230	
iag	257	Control circuit capacitor life display	(0 to 100%)	1%	100%	230	
e d	258	Main circuit capacitor life display	(0 to 100%)	1%	100%	230	
Lif	259	Main circuit capacitor life measuring	0, 1 (2, 3, 8, 9)	1	0	230	
	260	PWM frequency automatic switchover	0, 1	1	0	149	
Power failure stop	261	Power failure stop selection	0, 1, 2	1	0	143	
_	267	Terminal 4 input selection	0, 1, 2	1	0	151	
_	268	Monitor decimal digits selection	0, 1, 9999	1	9999	129	
_	269	Parameter for manufacturer setting. Do				1	
_	295	Magnitude of frequency change setting	0, 0.01, 0.10, 1.00, 10.00	0.01	0	241	
Password function	296	Password lock level	1 to 6, 101 to 106, 9999	1	9999	164	
Pass	296 Password lock level 297 Password lock/unlock		1000 to 9998 (0 to 5, 9999)	1	9999	164	
	298	Frequency search gain	0 to 32767, 9999	1	9999	137	
1	299	Rotation direction detection selection at restarting	0, 1, 9999	1	0	137	
ation	338	Communication operation command source	0, 1	1	0	177	
munic	339	Communication speed command source	0, 1, 2	1	0	177	
om	340	Communication startup mode selection	0, 1, 10	1	0	176	
RS-485 communication	342	Communication EEPROM write selection	0, 1	1	0	188	
RS	343	Communication error count	_	1	0	201	
Second motor constant	450	Second applied motor	0, 1, 9999	1	9999	104	
Remote Output	495	Remote output selection	0, 1, 10, 11	1	0	127	
Rer	496	Remote output data 1	0 to 4095	1	0	127	
_	502	Stop mode selection at communication error	0, 1, 2	1	0	185, 201	
nance	503	Maintenance timer	0 (1 to 9998)	1	0	234	
Maintenance	504	Maintenance timer alarm output set time	0 to 9998, 9999	1	9999	234	
ıtion	549	Protocol selection	0, 1	1	0	201	
Communication	551	PU mode operation command source selection	2, 4, 9999	1	9999	177	



Parameter	Remarks	Inst	truction C	ode		ode-based dence Table		Paramete	r
T dramotor	Romano	Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
249		39	B9	2	0	0	0	0	0
250		3 <i>A</i>	BA	2	0	0	0	0	0
251		3B	BB	2	0	0	0	0	0
255		3F	BF	2	0	0	×	×	×
256		40	C0	2	0	0	×	×	×
257 258		41 42	C1 C2	2 2	0	0	×	×	×
259		43	C3	2	0	0	×	×	× 0
260		44	C3	2	0	0	0	0	0
261		45	C5	2	0	0	0	0	0
267		4B	CB	2	0	0	0	×	0
268		4C	CC	2	0	0	0	0	0
269	Parameter for manufa	cturer setting	g. Do not s	et.					
295		67	E7	2	0	0	0	0	0
296		68	E8	2	0	0	0	×	0
297		69	E9	2	0	0	0	×	0
298		6A	EA	2	0	0	0	×	0
299		6B	EB	2	0	0	0	0	0
338		26	A6	3	0	0	0	O *8	O *8
339		27	A7	3	0	0	0	O *8	O *8
340		28	A8	3	0	0	0	O *8	O *8
342		2A	AA	3	0	0	0	0	0
343		2B	AB	3	0	0	×	×	×
450		32	B2	4	0	0	0	0	0
495		5F	DF	4	0	0	0	0	0
496		60	E0	4	0	0	×	×	×
502		02	82	5	0	0	0	0	0
503		03	83	5	0	0	×	×	×
504		04	84	5	0	0	0	×	0
549		31	B1	5	0	0	0	O *8	O *8
551		33	В3	5	0	0	0	O *8	O *8

Func-	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
age or	555	Current average time	0.1 to 1s	0.1s	1s	235	
Current average time monitor	556	Data output mask time	0 to 20s	0.1s	0s	235	
Curre	557	Current average value monitor signal output reference current	0 to 500A	0.01A	Rated inverter current	235	
_	561	PTC thermistor protection level	0.5 to 30kΩ , 9999	0.01kΩ	9999	101	
_	563	Energization time carrying-over times	(0 to 65535)	1	0	129	
_	564	Operating time carrying-over times	(0 to 65535)	1	0	129	
_	571	Holding time at a start	0 to 10s, 9999	0.1s	9999	99	
ion	575	Output interruption detection time	0 to 3600s, 9999	0.1s	1s	213	
PID operation	576	Output interruption detection level	0 to 400Hz	0.01Hz	0Hz	213	
8	577	Output interruption cancel level	900 to 1100%	0.1%	1000%	213	
_	611	Acceleration time at a restart	0 to 3600s, 9999	0.1s	9999	137	
_	653	Speed smoothing control	0 to 200%	0.1%	0	150	
_	665	Regeneration avoidance frequency gain	0 to 200%	0.1%	100	227	
Protective functions	872 *9	Input phase loss protection selection	0, 1	1	0	147	
ınce	882	Regeneration avoidance operation selection	0, 1, 2	1	0	227	
avoida	883	Regeneration avoidance operation level	300 to 800V	0.1V	400VDC/ 780VDC *5	227	
ation av function	885	Regeneration avoidance compensation frequency limit value	0 to 10Hz, 9999	0.01Hz	6Hz	227	
Regeneration avoidance function	886	Regeneration avoidance voltage gain	0 to 200%	0.1%	100%	227	
Free	888	Free parameter 1	0 to 9999	1	9999	237	
Free	889	Free parameter 2	0 to 9999	1	9999	237	
_	891	Cumulative power monitor digit shifted times	0 to 4, 9999	1	9999	129	



Parameter	Remarks	Instruction Code		Control Mode-based Correspondence Table		Parameter			
		Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
555		37	В7	5	0	0	0	0	0
556		38	B8	5	0	0	0	0	0
557		39	В9	5	0	0	0	0	0
561		3D	BD	5	0	0	0	×	0
563		3F	BF	5	0	0	×	×	×
564		40	C0	5	0	0	×	×	×
571		47	C7	5	0	0	0	0	0
575		4B	CB	5	0	0	0	0	0
576		4C	cc	5	0	0	0	0	0
577		4D	CD	5	0	0	0	0	0
611		0B	8B	6	0	0	0	0	0
653		35	B5	6	0	0	0	0	0
665		41	C1	6	0	0	0	0	0
872		48	C8	8	0	0	0	0	0
882		52	D2	8	0	0	0	0	0
883		53	D3	8	0	0	0	0	0
885		55	D5	8	0	0	0	0	0
886		56	D6	8	0	0	0	0	0
888		58	D8	8	0	0	0	×	×
889		59	D9	8	0	0	0	×	×
891		5B	D8	8	0	0	0	0	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
	C0 (900) *7	FM terminal calibration	_	_	_	135	
,	C2 (902) *7	Terminal 2 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	154	
	C3 (902) *7	Terminal 2 frequency setting bias	0 to 300%	0.1%	0%	154	
	125 (903) *7	Terminal 2 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	154	
S	C4 (903) *7	Terminal 2 frequency setting gain	0 to 300%	0.1%	100%	154	
Calibration parameters	C5 (904) *7	Terminal 4 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	154	
on par	C6 (904) *7	Terminal 4 frequency setting bias	0 to 300%	0.1%	20%	154	
alibrati	126 (905) *7	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	60Hz	154	
O	C7 (905) *7	Terminal 4 frequency setting gain	0 to 300%	0.1%	100%	154	
	C22 (922) *6*7	Frequency setting voltage bias frequency (built-in potentiometer)	0 to 400Hz	0.01Hz	0	244	
	C23 (922) *6*7	Frequency setting voltage bias (built-in potentiometer)	0 to 300%	0.1%	0	244	
	C24 (923) *6*7	Frequency setting voltage gain frequency (built-in potentiometer)	0 to 400Hz	0.01Hz	60Hz	244	
	C25 (923) *6*7	Frequency setting voltage gain (built-in potentiometer)	0 to 300%	0.1%	100%	244	
PU	990	PU buzzer control	0, 1	1	1	242	
Д	991	PU contrast adjustment	0 to 63	1	58	242	
irs e list	Pr.CL	Parameter clear	0, 1	1	0	250	
amete chang	ALLC	All parameter clear	0, 1	1	0	250	
Clear parameters ial value change l	Er.CL	Faults history clear	0, 1	1	0	252	
Clear parameters Initial value change list	Pr.CH	Initial value change list	_			251	

*1 Differ according to capacities.

6%: 0.75K or less

4%: 1.5K to 3.7K

3%: 5.5K, 7.5K 2%: 11K, 15K

*2 Differ according to capacities. 5s: 3.7K or less

5s: 3.7K or less 10s: 5.5K, 7.5K

15s: 11K, 15K

*3 Differ according to capacities. 6%: 0.1K, 0.2K

4%: 0.4K to 7.5K

2%: 11K, 15K

*4 Write is disabled in the communication mode (Network operation mode) from the PU connector.

*5 The initial value differs according to the voltage class. (100V class, 200V class / 400V class)

*6 Set this parameter when calibrating the operation panel built-in potentiometer for the FR-E500 series operation panel (PA02) connected with cable.

*7 The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).

*8 These parameters are communication parameters that are not cleared when parameter clear (all clear) is executed from RS-485 communication. (*Refer to page 181* for RS-485 communication)

*9 Available only for the three-phase power input model.



Parameter	Remarks	Inst	ruction C	ode		ode-based dence Table		Parametei	
	rtomarko	Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
C0 (900)		5C	DC	1	0	0	0	×	0
C2 (902)		5E	DE	1	0	0	0	×	0
C3 (902)		5E	DE	1	0	0	0	×	0
125 (903)		5F	DF	1	0	0	0	×	0
C4 (903)		5F	DF	1	0	0	0	×	0
C5 (904)		60	E0	1	0	0	0	×	0
C6 (904)		60	E0	1	0	0	0	×	0
126 (905)		61	E1	1	0	0	0	×	0
C7 (905)		61	E1	1	0	0	0	×	0
C22 (922)		16	96	9	0	0	0	×	0
C23 (922)		16	96	9	0	0	0	×	0
C24 (923)		17	97	9	0	0	0	×	0
C25 (923)		17	97	9	0	0	0	×	0
990		5A	DA	9	0	0	0	0	0
991		5B	DB	9	0	0	0	×	0
Pr.CL		_	FC	_	_	_	_	_	_
ALLC		_	FC	_	_	_	_	_	_
Er.CL		_	F4	_	_	_	_	_	_
Pr.CH		_	_	_	_	_	_	_	_

■ Parameters according to purposes

4.3	Adjustment of the output torque (current) of the motor	75
4.3.1	Manual torque boost (Pr. 0, Pr. 46)	75
4.3.2	Acquiring large starting torque and low speed torque (General-purpose magnetic	
400	flux vector control (Pr. 71, Pr. 80))	
4.3.3 4.3.4	Slip compensation (Pr. 245 to Pr. 247)	
4.4 L	imiting the output frequency	84
4.4.1	Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	
4.4.2	Avoiding mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)	85
4.5	//F pattern	86
4.5.1	Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)	86
4.5.2	Load pattern selection (Pr. 14)	88
4.6 F	requency setting by external terminals	90
4.6.1	Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)	90
4.6.2	Jog operation (Pr. 15, Pr. 16)	
4.6.3	Remote setting function (Pr. 59)	
4.7	Setting of acceleration/deceleration time and acceleration/	
	leceleration pattern	97
4.7.1	Setting of the acceleration and deceleration time	
	(Pr. 7, Pr. 8, Pr. 20, Pr. 44, Pr. 45)	97
4.7.2	Starting frequency and start-time hold function (Pr. 13, Pr. 571)	
4.7.3	Acceleration/deceleration pattern (Pr. 29)	100
4.8	Selection and protection of a motor	101
4.8.1	Motor overheat protection (Electronic thermal O/L relay, PTC thermistor protection) (Pr.	9, Pr. 51,
	Pr. 561)	
4.8.2	Applied motor (Pr. 71, Pr. 450)	104
4.8.3	Exhibiting the best performance for the motor (offline auto tuning) (Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90, Pr. 96)	106
4.9 M	Motor brake and stop operation	110
	·	
4.9.1 4.9.2	DC injection brake (Pr. 10 to Pr. 12)	
4.9.2	Stop selection (Pr. 250)	
	Function assignment of external terminal and control	114
4.10.1	Input terminal function selection (Pr. 178 to Pr. 182)	
4.10.2	Inverter output shutoff signal (MRS signal, Pr. 17)	
4.10.3 4.10.4	Condition selection of function validity by second function selection signal (RT)	
4.10.4	Output terminal function selection (Pr. 190, Pr. 192, Pr. 197)	
4.10.6	Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)	
4.10.7	Output current detection function	
	(Y12 signal, Y13 signal, Pr. 150 to Pr. 153, Pr. 166, Pr. 167)	125

4.10.8	Remote output selection (REM signal, Pr. 495, Pr. 496)	127
4.11 I	Monitor display and monitor output signal	128
4.11.1	Speed display and speed setting (Pr. 37)	128
4.11.2	Monitor display selection of DU/PU and terminal FM	100
4.11.3	(Pr. 52, Pr. 54, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891)	
4.11.3		
	Operation selection at power failure and instantaneous power	
	ailure	137
4.12.1	Automatic restart after instantaneous power failure/flying start	
	(Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	
4.12.2	,	
4.13 (Operation setting at fault occurrence	145
4.13.1	Retry function (Pr. 65, Pr. 67 to Pr. 69)	145
4.13.2	Input/output phase loss protection selection (Pr. 251, Pr. 872)	
4.13.3	Earth (ground) fault detection at start (Pr. 249)	147
4.14 E	Energy saving operation	148
4.14.1	Optimum excitation control (Pr. 60)	148
4.15 I	Motor noise, EMI measures, mechanical resonance	149
4.15.1	PWM carrier frequency and Soft-PWM control (Pr. 72, Pr. 240, Pr. 260)	149
4.15.2	Speed smoothing control (Pr. 653)	150
4.16 F	Frequency setting by analog input (terminal 2, 4)	151
4.16.1	Analog input selection (Pr. 73, Pr. 267)	151
4.16.2	Response level of analog input and noise elimination (Pr. 74)	153
4.16.3	Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	154
4.17 I	Misoperation prevention and parameter setting restriction	159
4.17.1	Reset selection/disconnected PU detection/PU stop selection (Pr. 75)	159
4.17.2	Parameter write disable selection (Pr. 77)	162
4.17.3	Reverse rotation prevention selection (Pr. 78)	
4.17.4	Extended parameter display (Pr. 160)	
4.17.5	Password function (Pr. 296, Pr. 297)	164
4.18	Selection of operation mode and operation location	166
4.18.1	Operation mode selection (Pr. 79)	166
4.18.2	Operation mode at power-ON (Pr. 79, Pr. 340)	176
4.18.3	Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 551)	177
4.19 (Communication operation and setting	181
4.19.1	Wiring and configuration of PU connector	181
4.19.2	Initial settings and specifications of RS-485 communication	
	(Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)	184

4.19.3	Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)	185
4.19.4	Communication EEPROM write selection (Pr. 342)	188
4.19.5	Mitsubishi inverter protocol (computer link communication)	189
4.19.6	Modbus-RTU communication specifications (Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	201
4.20 S	special operation and frequency control	213
4.20.1	PID control (Pr. 127 to Pr. 134, Pr. 575 to Pr. 577)	213
4.20.2	Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)	221
4.20.3	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)	227
4.21 L	Jseful functions	229
4.21.1	Cooling fan operation selection (Pr. 244)	229
4.21.2	Display of the lives of the inverter parts (Pr. 255 to Pr. 259)	230
4.21.3	Maintenance timer alarm (Pr. 503, Pr. 504)	234
4.21.4	Current average value monitor signal (Pr. 555 to Pr. 557)	235
4.21.5	Free parameter (Pr. 888, Pr. 889)	237
4.22 \$	Setting the parameter unit and operation panel	238
4.22.1	RUN key rotation direction selection (Pr. 40)	238
4.22.2	PU display language selection(Pr.145)	238
4.22.3	Operation panel frequency setting/key lock selection (Pr. 161)	239
4.22.4	Magnitude of frequency change setting (Pr. 295)	241
4.22.5	Buzzer control (Pr. 990)	242
4.22.6	PU contrast adjustment (Pr. 991)	242
4.23 F	R-E500 series operation panel (PA02) setting	243
4.23.1	Built-in potentiometer switching (Pr. 146)	243
4.23.2	Bias and gain of the built-in frequency setting potentiometer (C22 (Pr. 922) to C25 (Pr. 923))	. 244
4.24 P	Parameter clear/ All parameter clear	250
4.25 I	nitial value change list	251
4.26 0	Check and clear of the faults history	252



4.3 Adjustment of the output torque (current) of the motor

Purpose	Parameter that	Refer to Page	
Set starting torque manually	Manual torque boost	Pr. 0, Pr. 46	75
Automatically control output current according to load	General-purpose magnetic flux vector control	Pr. 71, Pr. 80	76
Compensate for motor slip to secure low-speed torque	Slip compensation	Pr. 245 to Pr. 247	79
Limit output current to prevent inverter trip	Stall prevention operation	Pr. 22, Pr. 23, Pr. 66, Pr. 156, Pr. 157	80

4.3.1 Manual torque boost (Pr. 0, Pr. 46)

Motor torque reduction in the low-speed range can be improved by compensating a voltage drop in the low-frequency range.


- •Motor torque in the low-frequency range can be adjusted to the load to increase the starting motor torque.
- •Two kinds of start torque boosts can be changed by switching between terminals.

Parameter	Name	Initial Value		Setting	Description	
Number	Ivaille	iiillai value		Range	Description	
		0.75K or less	6%			
0	Torque boost	1.5K to 3.7K	4%	0 to 30%	Set the output voltage at 0Hz as %.	
		5.5K, 7.5K	3%	0 10 30 %	Set the output voltage at onz as 70.	
		11K, 15K	2%			
40.	Second torque	0000		0 to 30%	Set the torque boost when the RT signal is ON.	
46 *	boost	9999	9999		Without second torque boost	

^{*} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Starting torque adjustment

- •On the assumption that *Pr. 19 Base frequency voltage* is 100%, set the output voltage at 0Hz in % to *Pr. 0 (Pr. 46)*.
- •Adjust the parameter little by little (about 0.5%), and check the motor status each time. If the setting is too large, the motor will overheat. The guideline is about 10% at the greatest.



(2) Set two kinds of torque boosts (RT signal, Pr. 46)

- •When you want to change torque boost according to applications, switch multiple motors with one inverter, etc., use *Second torque boost*.
- •Pr. 46 Second torque boost is valid when the RT signal is ON.
- •For the terminal used for RT signal input, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.



REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 117)



NOTE

- The amount of current flows in the motor may become large according to the conditions such as the motor characteristics, load, acceleration/deceleration time, wiring length, etc., resulting in an overcurrent trip (OL (overcurrent alarm) then E.OC1 (overcurrent trip during acceleration), overload trip (E.THM (motor overload trip), or E.THT (inverter overload trip).
 - (When a fault occurs, release the start command, and decrease the Pr. 0 setting 1% by 1% to reset.) (Refer to page 256.)
- The $Pr. \ \theta, Pr. \ 46$ settings are valid only when V/F control is selected.
- When using the inverter dedicated motor (constant-torque motor) with the 5.5K, 7.5K, set torque boost value to 2%.

 When *Pr.* θ = "3%"(initial value), if *Pr.* 71 value is changed to the setting for use with a constant-torque motor, the *Pr.* θ setting changes to 2%.
- Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 3 Base frequency, Pr. 19 Base frequency voltage Refer to page 86 Pr. 71 Applied motor Refer to page 104

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

4.3.2 Acquiring large starting torque and low speed torque (General-purpose magnetic flux vector control (Pr. 71, Pr. 80))

General-purpose magnetic flux vector control is available.

Large starting torque and low speed torque are available with General-purpose magnetic flux vector control.

• What is General-purpose magnetic flux vector control ?

The low speed torque can be improved by providing voltage compensation to flow a motor current which meets the load torque. With setting slip compensation (*Pr. 245 to Pr. 247*), output frequency compensation (slip compensation) is made so that the actual motor speed goes closer to a speed command value. Effective when load fluctuates drastically, etc.

General-purpose magnetic flux vector control is the same function as the FR-E500 series.

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0, 1, 3, 13, 23, 40, 43 50, 53	By selecting a standard motor or constant-torque motor, thermal characteristic and motor constants of each motor are set.
80	Motor capacity	9999	0.1 to 15kW 9999	Applied motor capacity. (General-purpose magnetic flux vector control) V/F control

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



POINT


If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.

- The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity should be 0.1kW or more)
- Motor to be used is any of Mitsubishi standard motor, high efficiency motor (SF-JR, SF-HR 0.2kW or more) or Mitsubishi constant-torque motor (SF-JRCA 4P, SF-HRCA 0.2kW to 15kW). When using a motor other than the above (other manufacturer's motor), perform offline auto tuning without fail.
- Single-motor operation (one motor run by one inverter) should be performed.
- The wiring length from inverter to motor should be within 30m. (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m.)
 - Permissible wiring length between inverter and motor differs according to the inverter capacity and setting value of *Pr. 72 PWM frequency selection* (carrier frequency). *Refer to page 19* for the permissible wiring length.

(1) Control mode

- V/F control (initial setting) and General-purpose magnetic flux vector control are available with this inverter.
- V/F control is for controlling frequency and voltage so that the ratio of frequency (F) to voltage (V) is constant when changing frequency.
- General-purpose magnetic flux vector control divides the inverter output current into an excitation current and a torque current by vector calculation, and makes voltage compensation to flow a motor current which meets the load torque. (General-purpose magnetic flux vector control is the same function as the FR-E500 series.)

(2) Selection method of General-purpose magnetic flux vector control



Display the extended function parameters.

(Pr. 160) (Refer to page 163)



Set "0" in Pr. 160 to display the extended function parameters.

Set the motor. (Pr. 71)

	Motor	Pr. 71 Setting *1	Remarks
Mitsubishi standard	SF-JR	0 (initial value)	
motor	SF-HR	40	
Mitsubishi high efficiency motor	Others	3	Offline auto tuning is necessary. *2
Mitsubishi constant-	SF-JRCA 4P	1	
	SF-HRCA	50	
torque motor	Others (SF-JRC, etc.)	13	Offline auto tuning is necessary. *2
Other standard motor	_	3	Offline auto tuning is necessary. *2
Other constant-		13	Offline auto tuning is necessary. *2
torque motor	—	13	Online auto turning is flecessary. *2

- Refer to page 104 for other settings of Pr. 71.
- Refer to page 106 for offline auto tuning.



Set the motor capacity.

(Pr. 80) (Refer to page 76)



Set motor capacity (kW) in Pr. 80 Motor capacity.

(V/F control is performed when the setting is "9999" (initial value).

Set the operation command. (Refer to page 166)

Select the start command and speed command.

- (1)Start command
 - 1)Operation panel: Setting by pressing (RUN) of the operation panel
 - 2)External command: Setting by forward rotation or reverse rotation command (terminal STF or STR)
- (2)Speed command
 - 1)Operation panel: Setting by turning of the operation panel

- 2)External analog command (terminal 2 or 4):
 - Give a speed command using the analog signal input to terminal 2 (or terminal 4).
- 3)Multi-speed command:

The external signals (RH, RM, RL) may also be used to give speed

Test run

As required

- Perform offline auto tuning. (Pr. 96) (Refer to page 106)
- Set motor excitation current. (Pr. 82) (Refer to page 106)
- Set slip compensation. (Pr. 245, Pr. 246, Pr. 247) (Refer to page 79)



- Uneven rotation slightly increases as compared to the V/F control. (It is not suitable for machines such as grinding machine and wrapping machine which requires less uneven rotation at low speed.)
- When a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) is connected between the inverter and motor, output torque may decrease.

(3) Control method switching by external terminals (X18 signal)

- •Use the V/F switchover signal (X18) to change the control method (V/F control and General-purpose magnetic flux vector control) with external terminal.
- •Turn the X18 signal ON to change the currently selected control method (General-purpose magnetic flux vector control) to V/F control.

For the terminal used for X18 signal input, set "18" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.



• REMARKS

Switch the control method using external terminal (X18 signal) during an inverter stop. If control method between V/F control and General-purpose magnetic flux vector control is switched during the operation, the actual switchover does not take place until the inverter stops. In addition, if control method is switched to V/F control during the operation, only second function becomes valid as V/F control and second functions are selected simultaneously in V/F control.



NOTE

• Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr.3 Base frequency, Pr.19 Base frequency voltage Refer to page 86 Pr.71 Applied motor Refer to page 104 Pr.77 Parameter write selection Refer to page 162 Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114



Slip compensation (Pr. 245 to Pr. 247) 4.3.3

Inverter output current may be used to assume motor slip to keep the motor speed constant.

Parameter Number	Name	Initial Value	Setting Range	Description
245	Rated slip	9999	0.01 to 50%	Rated motor slip
245	Rated Slip	9999	0, 9999	No slip compensation
246	Slip compensation time constant	0.5s	0.01 to 10s	Slip compensation response time. When the value is made smaller, response will be faster. However, as load inertia is greater, a regenerative overvoltage fault (E.OV□) is more liable to occur.
247	Constant-power range slip compensation selection	9999	9999	Slip compensation is not made in the constant power range. (frequency range above the frequency set in <i>Pr. 3</i>) Slip compensation is made in the constant power range.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

• Slip compensation is validated when the motor rated slip calculated by the following formula is set in Pr. 245. Slip compensation is not made when Pr. 245 = "0" or "9999".



• REMARKS

· When performing slip compensation, the output frequency may become greater than the set frequency. Set the Pr. 1 Maximum frequency value a little higher than the set frequency.



Parameters referred to

Pr. 1 Maximum frequency Refer to page 84 Pr. 3 Base frequency Refer to page 86

4.3.4 Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157)

This function monitors the output current and automatically changes the output frequency to prevent the inverter from coming to trip due to overcurrent, overvoltage, etc.

It can also limit stall prevention and fast-response current limit operation during acceleration/deceleration, driving or regeneration.


- Stall prevention
 - If the output current exceeds the stall prevention operation level, the output frequency of the inverter is automatically changed to reduce the output current.
- •Fast-response current limit

If the current exceeds the limit value, the output of the inverter is shut off to prevent an overcurrent.


Parameter Number	Name	Initial Value	Setting Range	Description
	Stall prevention operation		0	Stall prevention operation invalid
22	level	150%	0.1 to 200%	Set the current value to start the stall
			0.1 to 20070	prevention operation.
	Stall prevention			The stall operation level can be reduced
	operation level		0 to 200%	when operating at a high speed above the
23	compensation factor	9999		rated frequency.
	at double speed		9999	Constant according to Pr. 22.
	Second stall prevention	9999	0	Stall prevention operation invalid
48	<u>-</u>		0.1 to 200%	Second stall prevention operation level
	operation current		9999	Same level as Pr. 22.
	Stall prevention		0 to 400Hz	Set the frequency at which the stall
66	operation reduction	60Hz		' '
	starting frequency			operation level is started to reduce.
	Stall prevention operation			Select whether stall prevention operation
156	selection	0	0 to 31, 100, 101	and fast-response current limit operation
	Selection			will be performed or not.
			0 to 25s	Output start time of the OL signal output
157	OL signal output timer	0s	0 10 258	when stall prevention is activated.
	-		9999	Without the OL signal output

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Block diagram



(2) Setting of stall prevention operation level (Pr. 22)



- •Set in Pr. 22 the percentage of the output current to the rated inverter current at which stall prevention operation will be performed. Normally set this parameter to 150% (initial value).
- •Stall prevention operation stops acceleration (makes deceleration) during acceleration, makes deceleration during constant speed, and stops deceleration (makes acceleration) during deceleration.
- •When stall prevention operation is performed, the OL signal is output.




If an overload status lasts long, an inverter trip (e.g. electronic thermal O/L relay (E.THM)) may occur.

(3) Stall prevention operation signal output and output timing adjustment (OL signal, Pr. 157)

- •When the output current exceeds the stall prevention operation level and stall prevention is activated, the stall prevention operation signal (OL signal) turns ON for longer than 100ms. When the output current falls to or below the stall prevention operation level, the output signal turns OFF.
- •Use Pr. 157 OL signal output timer to set whether the OL signal is output immediately or after a preset period of time.
- •This operation is also performed when the regeneration avoidance function or ϖL (overvoltage stall) is executed.
- •For the OL signal, set "3 (positive logic) or 103 (negative logic)" in Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection) and assign functions to the output terminal.


Pr. 157 Setting	Description			
0	Output immediately.			
(initial value)	Output infinediately.			
0.1 to 25	Output after the set time (s) has elapsed.			
9999	Not output.			






- If the frequency has fallen to 1Hz by stall prevention operation and remains for 3s, a fault (E.OLT) appears to trip the
- Changing the terminal assignment using Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

(4) Setting of stall prevention operation in high frequency range (Pr. 22, Pr. 23, Pr. 66)





- •During high-speed operation above the rated motor frequency, acceleration may not be made because the motor current does not increase. If operation is performed in a high frequency range, the current at motor lockup becomes smaller than the rated output current of the inverter, and the protective function (OL) is not executed even if the motor is at a stop. To improve the operating characteristics of the motor in this case, the stall prevention level can be reduced in the high frequency range. This function is effective for performing operation up to the high-speed range on a centrifugal separator, etc. Normally, set 60Hz in *Pr.* 66 and 100% in *Pr.* 23.
- •Formula for stall prevention operation level

Stall prevention operation level in high frequency range (%) = A + B
$$\times \left[\frac{Pr. 22 - A}{Pr. 22 - B} \right] \times \left[\frac{Pr. 23 - 100}{100} \right]$$

However, A =
$$\frac{Pr. 66 \text{ (Hz)} \times Pr. 22 \text{ (\%)}}{\text{Output frequency (Hz)}}, B = \frac{Pr. 66 \text{ (Hz)} \times Pr. 22 \text{ (\%)}}{400 \text{Hz}}$$

•By setting "9999" (initial value) in *Pr. 23 Stall prevention operation level compensation factor at double speed*, the stall prevention operation level is constant at the *Pr. 22* setting up to 400Hz.

(5) Set two types of stall prevention operation levels (Pr. 48)

- •Turning RT signal ON makes Pr. 48 Second stall prevention operation current valid.
- •For the terminal used for RT signal input, set "3" in any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the function.



NOTE

- Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.
- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 117)



(6) Limit the stall prevention operation and fast-response current limit operation according to the operating status (Pr. 156)

•Refer to the following table and select whether stall prevention operation and fast-response current limit operation will be performed or not and the operation to be performed at OL signal output.

Pr. 1	156	Current Limit *4		Output O:Operation Pr 156	Fast-Response Current Limit *4	Stall Prevention Operation Selection O: Activated •: Not activated			OL Signal Output O:Operation			
Setti	ing	O: Activated ●: Not activated	Acceleration	Constant	Deceleration	continued •: Operation not continued *1	Setting	O: Activated ●: Not activated	Acceleration	Constant	Deceleration	continued •: Operation not continued *1
0		_	_	_	_	_		_	_	_	_	
(init		0	0	0	0	0	16	0	0	0	0	•
1	,	•	0	0	0	0	17	•	0	0	0	•
2		0	•	0	0	0	18	0	•	0	0	•
3		•	•	0	0	0	19	•	•	0	0	•
4		0	0	•	0	0	20	0	0	•	0	•
5		•	0	•	0	0	21	•	0	•	0	•
6		0	•	•	0	0	22	0	•	•	0	•
7		•	•	•	0	0	23	•	•	•	0	•
8		0	0	0	•	0	24	0	0	0	•	•
9		•	0	0	•	0	25	•	0	0	•	•
10		0	•	0	•	0	26	0	•	0	•	•
11		•	•	0	•	0	27	•	•	0	•	•
12		0	0	•	•	0	28	0	0	•	•	•
13		•	0	•	•	0	29	•	0	•	•	•
14		0	•	•	•	— *2	30	0	•	•	•	— *2
15)	•	•	•	•	— *2	31	•	•	•	•	— *2
100	Power driving	0	0	0	0	0	Power driving	•	0	0	0	0
*3	Regeneration	•	•	•	•	— *2	*3 Regeneration	• nned by stall prevention	•	•	•	—*2


- When "Operation not continued for OL signal output" is selected, the 🗜 🚻 🗂 fault (stopped by stall prevention) is displayed and operation is stopped.
- Since stall prevention is not activated, OL signal and E.OLT are not output.

 The settings "100" and "101" allow operations to be performed in the driving and regeneration modes, respectively. The setting "101" disables the fast-*3 response current limit in the driving mode.
- OL signal is not output at fast-response current limit operation.



- When the load is heavy or the acceleration/deceleration time is short, stall prevention is activated and acceleration/ deceleration may not be made according to the preset acceleration/deceleration time. Set Pr. 156 and stall prevention operation level to the optimum values.
- In vertical lift applications, make setting so that the fast-response current limit is not activated. Torque may not be produced, causing a load drop due to gravity.





Test operation must be performed.

Stall prevention operation during acceleration may increase the acceleration time.

Stall prevention operation performed during constant speed may cause sudden speed changes.

Stall prevention operation during deceleration may increase the deceleration time, increasing the deceleration distance.



Parameters referred to

- Pr. 3 Base frequency Refer to page 86
- Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114
- Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120

Limiting the output frequency

Purpose	Parameter	Refer to Page	
Set upper limit and lower limit of output frequency	Maximum/minimum frequency	Pr. 1, Pr. 2, Pr. 18	84
Perform operation by avoiding mechanical resonance points	Frequency jump	Pr. 31 to Pr. 36	85


4.4.1 Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)

Motor speed can be limited.

Clamp the upper and lower limits of the output frequency.

Parameter Number	Name	Initial Value	Setting Range	Description
1	Maximum frequency	120Hz	0 to 120Hz	Upper limit of the output frequency.
2	Minimum frequency	0Hz	0 to 120Hz	Lower limit of the output frequency.
18 *	High speed maximum	120Hz	120 to 400Hz	Set when performing the operation at 120Hz
18 *	frequency	12002	120 (0 40002	or more.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



(1) Set maximum frequency

- maximum frequency Use Pr. 1 Maximum frequency to set the maximum frequency. If the frequency of the frequency command entered is higher than the setting, the output frequency is clamped at the maximum frequency.
 - To perform operation above 120Hz, set the upper limit of the output frequency to Pr. 18 High speed maximum frequency. (When Pr. 18 is set, Pr. 1 automatically switches to the frequency of Pr. 18. Also, when Pr. 1 is set, Pr. 18 is automatically changed to the frequency set in Pr. 1.

• REMARKS

When performing operation above 60Hz using the frequency setting analog signal, change Pr. 125 (Pr. 126) (frequency setting

(2) Set minimum frequency

- Use Pr. 2 Minimum frequency to set the minimum frequency.
- If the set frequency is less than Pr. 2, the output frequency is clamped at Pr. 2 (will not fall below Pr. 2).



> REMARKS

- When Pr. 15 Jog frequency is equal to or less than Pr. 2, the Pr. 15 setting has precedence over the Pr. 2 setting.
- When stall prevention is activated to decrease the output frequency, the output frequency may drop to Pr. 2 or below.



Note that when Pr. 2 is set to any value equal to or more than Pr. 13 Starting frequency, simply turning ON the start signal will run the motor at the preset frequency according to the set acceleration time even if the command frequency is not input.



Parameters referred to

Pr. 13 Starting frequency Refer to page 99 Pr. 15 Jog frequency Refer to page 92

Pr. 125 Terminal 2 frequency setting gain frequency, Pr. 126 Terminal 4 frequency setting gain frequency 🕼 Refer to page 154




4.4.2 Avoiding mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)


When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped.

Parameter Number	Name	Initial Value	Setting Range	Description
31	Frequency jump 1A	9999	0 to 400Hz, 9999	
32	Frequency jump 1B	9999	0 to 400Hz, 9999	44 45 04 4 05 04 4 05
33	Frequency jump 2A	9999	0 to 400Hz, 9999	1A to 1B, 2A to 2B, 3A to 3B are
34	Frequency jump 2B	9999	0 to 400Hz, 9999	frequency jumps 9999: Function invalid
35	Frequency jump 3A	9999	0 to 400Hz, 9999	3000. Fallotton myana
36	Frequency jump 3B	9999	0 to 400Hz, 9999	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



- Up to three areas may be set, with the jump frequencies set to either the top or bottom point of each area.
- The value set to 1A, 2A or 3A is a jump point, and operation in the jump zone is performed at these frequencies.



Example 1

To fix the frequency to 30Hz in the range of 30Hz to 35Hz, set 35Hz in Pr. 34 and 30Hz in Pr. 33.

Example 2 To jump the frequency to 35Hz in the range of 30Hz to 35Hz, set 35Hz in Pr. 33 and 30Hz in Pr. 34.



NOTE

During acceleration/deceleration, the running frequency within the set area is valid.

V/F pattern

Purpose	Parameter	Refer to Page	
Set motor ratings	Base frequency, Base frequency voltage	Pr. 3, Pr. 19, Pr. 47	86
Select a V/F pattern according to applications.	Load pattern selection	Pr. 14	88

4.5.1 Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)


Used to adjust the inverter outputs (voltage, frequency) to the motor rating.

Parameter Number	Name	Initial Value	Setting Range	Description
3	Base frequency	60Hz	0 to 400Hz	Rated motor frequency (50Hz/60Hz)
			0 to 1000V	Base voltage
				95% of power supply voltage
	Base frequency voltage	9999	8888	(95% of doubled power supply voltage for
19 *				single-phase 100V power input model.)
19 *			9999	Same as power supply voltage
				(Twice the amount of the power supply
				voltage for single-phase 100V power input
				model.)
47	Second V/F (base	0000	0 to 400Hz	Base frequency when the RT signal is ON
47 *	frequency)	9999	9999	Second V/F invalid

^{*} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Base frequency setting (Pr. 3)

- · When operating a standard motor, generally set the rated frequency of the motor to Pr. 3 Base frequency. When running the motor using commercial power supply-inverter switch-over operation, set Pr. 3 to the same value as the power supply frequency.
- If the frequency given on the motor rating plate is "50Hz" only, always set to "50Hz". Leaving the base frequency unchanged from "60Hz" may make the voltage too low and the torque insufficient. It may result in an inverter trip due to overload.
 - Special care must be taken when "1" (variable torque load) is set in Pr. 14 Load pattern selection.
- When using the Mitsubishi constant-torque motor, set Pr. 3 to 60Hz.




(2) Set two kinds of base frequencies (Pr. 47)

- To change the base frequency when switching two types of motors with one inverter, use the Pr. 47 Second V/F (base frequency).
- Pr. 47 Second V/F (base frequency) is valid when the RT signal is ON. Set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) and assign the RT signal.

• REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 117)



- Use Pr. 19 Base frequency voltage to set the base voltage (e.g. rated motor voltage).
- If the setting is less than the power supply voltage (Twice the amount of the power supply voltage for single-phase 100V power input model), the maximum output voltage of the inverter is as set in Pr. 19.
- Pr. 19 can be utilized in the following cases.
 - (a) When regeneration is high (e.g. continuous regeneration) During regeneration, the output voltage becomes higher than the reference and may cause an overcurrent trip (E.OC□) due to an increased motor current.
 - (b) When power supply voltage variation is large When the power supply voltage exceeds the rated voltage of the motor, speed variation or motor overheat may be caused by excessive torque or increased motor current.



• When General-purpose magnetic flux vector control is selected, Pr. 3, Pr. 47 and Pr. 19 are invalid and Pr. 83 and Pr. 84

Note that Pr. 3 or Pr. 47 value is valid as inflection points of S-pattern when Pr. 29 Acceleration/deceleration pattern selection = "1" (S-pattern acceleration/deceleration A).

Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to


Pr. 14 Load pattern selection Refer to page 88 Pr. 29 Acceleration/deceleration pattern selection Refer to page 100 Pr. 83 Rated motor voltage, Pr. 84 Rated motor frequency Refer to page 106 Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114 General-purpose magnetic flux vector control Refer to page 76

4.5.2 Load pattern selection (Pr. 14)

Optimum output characteristic (V/F characteristic) for the application and load characteristics can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	For constant-torque load
		0	1	For variable-torque load
14	Load pattern selection		0	For constant-torque elevators
14			2	(at reverse rotation boost of 0%)
			2	For constant-torque elevators
			3	(at forward rotation boost of 0%)

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)




(1) Constant-torque load application (setting "0", initial value)

- At or less than the base frequency, the output voltage varies linearly with the output frequency.
- Set this value when driving the load whose load torque is constant even if the speed varies, e.g. conveyor, cart or roll drive.

POINT


If the load is a fan or pump, select for constant-torque load (setting "0") in any of the following cases.


- · When a blower of large inertia moment (J) is accelerated in a short time
- · For constant-torque load such as rotary pump or gear pump
- · When load torque increases at low speed, e.g. screw pump



(2) Variable-torque load application (setting "1")

- At or less than the base frequency, the output voltage varies with the output frequency in a square curve.
- Set this value when driving the load whose load torque varies in proportion to the square of the speed, e.g. fan or pump.





(3) Constant-torque load application (setting "2, 3")

- Set "2" when a vertical lift load is fixed as power driving load at forward rotation and regenerative load at reverse rotation.
- Pr. 0 Torque boost is valid during forward rotation and torque boost is automatically changed to "0%" during reverse rotation. Pr. 46 Second torque boost is valid when the RT signal turns ON.
- Set "3" for an elevated load that is in the driving mode during reverse rotation and in the regenerative load mode during forward rotation according to the load weight, e.g. counterweight system.
- For the RT signal, set "3" in any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the function.



> REMARKS

- When torque is continuously regenerated as vertical lift load, it is effective to set the rated voltage in *Pr. 19 Base frequency voltage* to prevent trip due to current at regeneration.
- When the RT signal is ON, the other second functions are also valid.



NOTE

- Load pattern selection does not function under General-purpose magnetic flux vector control.
- Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 0, Pr. 46 (Torque boost) Refer to page 75
Pr. 3 Base frequency Refer to page 86
Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114
General-purpose magnetic flux vector control Refer to page 76

4.6 Frequency setting by external terminals

Purpose	Parameter	Refer to Page	
Make frequency setting by	Multi-speed operation	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27,	90
combination of terminals	wuiti-speed operation	Pr. 232 to Pr. 239	90
Perform Jog operation	Jog operation	Pr. 15, Pr. 16	92
Infinitely variable speed setting by terminals	Remote setting function	Pr. 59	94

4.6.1 Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)


Can be used to change the preset speed in the parameter with the contact signals.

Any speed can be selected by merely turning ON-OFF the contact signals (RH, RM, RL, REX signals).

Parameter	Name	Initial Value	Cotting Dance	Description	
Number	Name	initiai vaiue	Setting Range	Description	
4	Multi-speed setting (high	60Hz	0 to 400Hz	Frequency when RH turns ON	
7	speed)	00112	0 10 400112	Trequency when first turns on	
5	Multi-speed setting (middle	30Hz	0 to 400Hz	Frequency when RM turns ON	
o o	speed)	00112	0 10 400112	Trequency when two tame on	
6	Multi-speed setting (low	10Hz	0 to 400Hz	Frequency when RL turns ON	
	speed)	10112 0 to 400112		I requericy when RL turns ON	
24 *	Multi-speed setting (speed 4)	9999	0 to 400Hz, 9999		
25 *	Multi-speed setting (speed 5)	9999	0 to 400Hz, 9999		
26 *	Multi-speed setting (speed 6)	9999	0 to 400Hz, 9999		
27 *	Multi-speed setting (speed 7)	9999	0 to 400Hz, 9999		
232 *	Multi-speed setting (speed 8)	9999	0 to 400Hz, 9999	Frequency from 4 speed to 15 speed can	
233 *	Multi-speed setting (speed 9)	9999	0 to 400Hz, 9999	be set according to the combination of	
234 *	Multi-speed setting (speed 10)	9999	0 to 400Hz, 9999	the RH, RM, RL and REX signals.	
235 *	Multi-speed setting (speed 11)	9999	0 to 400Hz, 9999	9999: not selected	
236 *	Multi-speed setting (speed 12)	9999	0 to 400Hz, 9999		
237 *	Multi-speed setting (speed 13)	9999	0 to 400Hz, 9999		
238 *	Multi-speed setting (speed 14)	9999	0 to 400Hz, 9999		
239 *	Multi-speed setting (speed 15)	9999	0 to 400Hz, 9999		

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

^{*} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



(1) 3-Speed setting (Pr. 4 to Pr. 6)

•The inverter operates at frequencies set in $Pr.\ 4$ when RH signal is ON, $Pr.\ 5$ when RM signal is ON and $Pr.\ 6$ when RL signal is ON.


• REMARKS


- In the initial setting, if two or three of multi-speed settings are simultaneously selected, priority is given to the set frequency of the lower signal.
 - For example, when the RH and RM signals turn ON, the RM signal (Pr. 5) has a higher priority.
- The RH, RM, RL signals are assigned to the terminal RH, RM, RL in the initial setting. By setting "0 (RL)", "1 (RM)", "2 (RH)" in any of *Pr. 178 to Pr. 182 (input terminal function selection)*, you can assign the signals to other terminals.



(2) Multi-speed setting for 4th speed or more (Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)

- •Frequency from 4th speed to 15th speed can be set according to the combination of the RH, RM, RL and REX signals. Set the running frequencies in *Pr. 24 to Pr. 27, Pr. 232 to Pr. 239* (In the initial value setting, 4th speed to 15th speed are invalid).
- •For the terminal used for REX signal input, set "8" in any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the function.





Multi-speed operation connection example

*I When "9999" is set in Pr. 232 Multi-speed setting (speed 8), operation is performed at frequency set in Pr. 6 when RH, RM and RL are turned OFF and REX is turned ON.



REMARKS

 The priorities of the frequency commands by the external signals are "Jog operation > multi-speed operation > terminal 4 analog input > terminal 2 analog input".

(Refer to page 154 for the frequency command by analog input)

- Valid in the External operation mode or PU/External combined operation mode (Pr. 79 = "3" or "4").
- Multi-speed parameters can also be set in the PU or External operation mode.
- Pr. 24 to Pr. 27 and Pr. 232 to Pr. 239 settings have no priority between them.
- When Pr. 59 Remote function selection ≠ "0", multi-speed setting is invalid as RH, RM and RL signals are remote setting signals.



NOTE

• Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 15 Jog frequency Refer to page 92

Pr. 59 Remote function selection Refer to page 94
Pr. 79 Operation mode selection Refer to page 166

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

4.6.2 Jog operation (Pr. 15, Pr. 16)

The frequency and acceleration/deceleration time for Jog operation can be set. Jog operation can be performed in either of the external and the PU operation mode.


This operation can be used for conveyor positioning, test operation, etc.


Parameter Number	Name	Initial Value	Setting Range	Description
15	Jog frequency	5Hz	0 to 400Hz	Frequency for Jog operation.
16	Jog acceleration/ deceleration time	0.5s	0 to 3600s	Acceleration/deceleration time for Jog operation. Acceleration/ deceleration time is the time taken to reach the frequency set in <i>Pr. 20 Acceleration/deceleration reference frequency</i> (initial value is 60Hz). Acceleration/deceleration time can not be set separately.

These parameters are displayed as simple mode parameter only when the parameter unit (FR-PU04/FR-PU07) is connected. When the parameter unit is not connected, the above parameters can be set by setting *Pr. 160 Extended function display selection* = "0". (*Refer to page 163*)

(1) Jog operation from outside

- •When the JOG signal is ON, a start and stop can be made by the start signal (STF, STR).
- •For the terminal used for Jog operation selection, set "5" in any of *Pr.178 to Pr.182 (input terminal function selection)* to assign the function.





Connection diagram for external Jog operation

— Display ———



——— Operation


- 1. Screen at powering ON
 - Confirm that the External operation mode is selected. ([EXT] lit)

If not displayed, press $\frac{PU}{EXT}$ to change to the External (EXT) operation mode. If the operation mode still does not change, set Pr. 79 to change to the External operation mode.

2. Turn ON the JOG switch.



- 3. Turn the start switch (STF or STR) ON.
 - The motor runs while the start switch (STF or STR) is ON.
 - The motor runs at 5Hz. (initial value of Pr. 15)
- 4. Turn the start switch (STF or STR) OFF.




> REMARKS

- When you want to change the running frequency, change Pr. 15 Jog frequency. (initial value "5Hz")
- When you want to change the acceleration/deceleration time, change Pr. 16 Jog acceleration/deceleration time. (initial value "0.5s")
 The acceleration time and deceleration time cannot be set separately for Jog operation.

(2) Jog operation from PU

•Select Jog operation mode from the operation panel and PU (FR-PU04/FR-PU07). Operation is performed only while the start button is pressed.



Operation

——— Display ———

- Confirmation of the RUN indication and operation mode indication
 - The monitor mode should have been selected.
 - The inverter should be at a stop.
- 2. Press $\frac{PU}{EXI}$ to choose the PU Jog operation mode.
- 3. Press RUN
 - While (RUN) is pressed, the motor rotates.
 - The motor runs at 5Hz. (Pr. 15 initial value)
- 4. Release (RUN)

















[When changing the frequency of PU Jog operation]


 $\begin{tabular}{lll} 5. \ \mbox{Press} & \mbox{MODE} & to choose the parameter setting \\ \mbox{mode}. \end{tabular}$














9. Press (SET) to set.





appears.)





10. Perform the operations in steps 1 to 4. The motor rotates at 10Hz.

Flicker...Parameter setting complete!!



NOTE

- When *Pr. 29 Acceleration/deceleration pattern selection* = "1" (S-pattern acceleration/deceleration A), the acceleration/deceleration time is the period of time required to reach *Pr. 3 Base frequency*.
- The Pr. 15 setting should be equal to or higher than the Pr. 13 Starting frequency.
- The JOG signal can be assigned to the input terminal using any of Pr. 178 to Pr. 182 (input terminal function selection).
 When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.
- During Jog operation, the second acceleration/deceleration via the RT signal cannot be selected. (The other second functions are valid. (Refer to page 227))
- When $Pr. 79 \ Operation \ mode \ selection = "4", pressing RUN of the operation panel and FWD <math>I$ REV of the parameter unit (FR-PU04/FR-PU07) starts the inverter and pressing $\frac{\text{STOP}}{\text{RESET}}$ stops the inverter.
- This function is invalid when Pr. 79 = "3".



Parameters referred to


- Pr. 13 Starting frequency Refer to page 99
- Pr. 29 Acceleration/deceleration pattern selection Refer to page 100
- Pr. 20 Acceleration/deceleration reference frequency, Pr. 21 Acceleration/deceleration time increments 🖫 Refer to page 97
- Pr. 79 Operation mode selection Refer to page 166
- Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

4.6.3 Remote setting function (Pr. 59)

- •Even if the operation panel is located away from the enclosure, you can use contact signals to perform continuous variable-speed operation, without using analog signals.
- •By merely setting this parameter, you can use the acceleration, deceleration and setting clear functions of the motorized speed setter (FR-FK).

Parameter			Setting	Description	
Number	Name	Initial Value	Range	RH, RM, RL signal function	Frequency setting storage function
			0	Multi-speed setting	_
		0	1	Remote setting	With
	Remote function selection		2	Remote setting	Not used
59				Remote setting	Not used
			3		(Turning STF/STR OFF
			3		clears remotely-set
					frequency.)

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 156)



* External running frequency (other than multi-speed) or PU running frequency



(1) Remote setting function

•Use *Pr. 59* to select whether the remote setting function is used or not and whether the frequency setting storage function in the remote setting mode is used or not.

When *Pr.* 59 is set to any of "1 to 3" (remote setting function valid), the functions of the RH, RM and RL signals are changed to acceleration (RH), deceleration (RM) and clear (RL).

•When using the remote setting function, following frequencies can be compensated to the frequency set by RH and RM operation according to the operation mode.

During External operation (including Pr: 79 = "4") external frequency command other than multi-speed settings

(2) Frequency setting storage

• The frequency setting storage function stores the remotely-set frequency (frequency set by RH/RM operation) into the memory (EEPROM). When power is switched OFF once, then ON, operation is resumed with that output frequency value. (Pr. 59 = 1)


<Frequency setting storage conditions>

- Frequency at the point when the start signal (STF or STR) turns OFF
- Remotely-set frequency is stored every minute after turning OFF (ON) the RH (acceleration) and RM(deceleration) signals together. (The frequency is overwritten if the latest frequency is different from the previous frequency when comparing the two. The state of the RL signal does not affect writing.)



NOTE

 The range of frequency changeable by RH (acceleration) and RM (deceleration) is 0 to maximum frequency (Pr. 1 or Pr. 18 setting). Note that the maximum value of set frequency is (main speed + maximum frequency).



- When the acceleration or deceleration signal switches ON, acceleration/deceleration time is as set in *Pr. 44 Second acceleration/deceleration time* and *Pr. 45 Second deceleration time*. Note that when the time set in *Pr. 7 or Pr. 8* is longer than the time set in *Pr. 44 or Pr. 45*, the acceleration/deceleration time is as set in *Pr. 7 or Pr. 8*. (when RT signal is OFF) When the RT signal is ON, acceleration/deceleration is made in the time set in *Pr. 44* and *Pr. 45*, regardless of the *Pr. 7* or *Pr. 8* setting.
- Even if the start signal (STF or STR) is OFF, turning ON the acceleration (RH) or deceleration (RM) signal varies the preset frequency. (When *Pr.* 59 = "1" or "2")
- When switching the start signal from ON to OFF, or changing frequency by the RH or RM signal frequently, set the frequency setting value storage function (write to EEPROM) invalid (Pr. 59 = "2, 3"). If set valid (Pr. 59 = "1"), frequency is written to EEPROM frequently, this will shorten the life of the EEPROM.
- The RH, RM, RL signals can be assigned to the input terminal using any *Pr. 178 to Pr. 182 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.
- Also available for the Network operation mode.







> REMARKS

During Jog operation or PID control operation, the remote setting function is invalid.

Setting frequency is "0"

- Even when the remotely-set frequency is cleared by turning ON the RL (clear) signal after turn OFF (ON) of both the RH and RM signals, the inverter operates at the remotely-set frequency stored in the last operation if power is reapplied before one minute has elapsed since turn OFF (ON) of both the RH and RM signals
- When the remotely-set frequency is cleared by turning ON the RL (clear) signal after turn OFF (ON) of both the RH and RM signals, the inverter operates at the frequency in the remotely-set frequency cleared state if power is reapplied after one minute has elapsed since turn OFF (ON) of both the RH and RM signals.







Mhen selecting this function, re-set the maximum frequency according to the machine.



Parameters referred to

Pr. 1 Maximum frequency, Pr. 18 High speed maximum frequency Refer to page 84

Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 44 Second acceleration/deceleration time, Pr. 45 Second deceleration time 🕼 Refer to page 97

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114



4.7 Setting of acceleration/deceleration time and acceleration/deceleration pattern

Purpose	Parameter ti	Refer to Page	
Motor acceleration/deceleration time setting	Acceleration/deceleration times	Pr. 7, Pr. 8, Pr. 20, Pr. 44, Pr. 45	97
Starting frequency	Starting frequency and start- time hold	Pr. 13, Pr. 571	99
Set acceleration/deceleration pattern suitable for application	Acceleration/deceleration pattern	Pr. 29	100

4.7.1 Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 44, Pr. 45)

Used to set motor acceleration/deceleration time.

Set a larger value for a slower speed increase/decrease or a smaller value for a faster speed increase/decrease. For the acceleration time at automatic restart after instantaneous power failure, refer to *Pr. 611 Acceleration time at a restart (page 137)*.

Parameter	Name	Initial Value		Setting	Description	
Number	Name	illitiai value		Range	Description	
		3.7K or less	5s			
7	Acceleration time	5.5K and 7.5K	10s	0 to 3600s	Motor acceleration time.	
		11K and 15K	15s			
		3.7K or less	5s			
8	Deceleration time	5.5K and 7.5K	10s	0 to 3600s	Motor deceleration time.	
		11K and 15K	15s			
	Acceleration/	60Hz			Frequency that will be the basis of	
20 *1	deceleration			1 to 400Hz	acceleration/deceleration time.	
20 *1				1 10 40002	As acceleration/deceleration time, set the	
	reference frequency				frequency change time from stop to Pr. 20.	
	Second acceleration/	3.7K or less	5s		Acceleration/deceleration time when the RT	
44 *1		5.5K and 7.5K	10s	0 to 3600s		
	deceleration time	11K and 15K	15s		signal is ON.	
45 . 1	Second deceleration	0000	9999		Deceleration time when the RT signal is ON.	
45 *1	time	9999			Acceleration time = deceleration time	

^{*1} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

Pr. 20 (60Hz) Running frequency Time Acceleration time Pr. 7, Pr. 44 Pr. 8, Pr. 45

(1) Acceleration time setting (Pr. 7, Pr. 20)

- •Use *Pr. 7 Acceleration time* to set the acceleration time required to reach *Pr. 20 Acceleration/deceleration reference frequency* from 0Hz.
- •Set the acceleration time according to the following formula.

Acceleration time setting =
$$\frac{Pr. 20}{\text{Maximum operating frequency}} \times \text{Acceleration time from stop to maximum operating frequency}$$

Example) How to find the setting value for Pr.7 when increasing the output frequency to the maximum frequency of 50Hz in 10s with Pr.20=60Hz (initial setting) and Pr.13=0.5Hz.

$$Pr. 7 = \frac{60 \text{Hz}}{50 \text{Hz} - 0.5 \text{Hz}} \times 10 \text{s} = 12.1 \text{s}$$

Setting of acceleration/deceleration time and acceleration/ deceleration pattern

(2) Deceleration time setting (Pr. 8, Pr. 20)

- •Use Pr. 8 Deceleration time to set the deceleration time required to reach 0Hz from Pr. 20 Acceleration/deceleration reference frequency.
- •Set the deceleration time according to the following formula.

Deceleration Deceleration time from maximum operating frequency to stop Maximum operating frequency - Pr. 10 time setting

Example) How to find the setting value for Pr.8 when decreasing the output frequency from the maximum frequency of 50Hz in 10s with Pr.20=120Hz and Pr.10=3Hz.

$$Pr. 8 = \frac{120 \text{Hz}}{50 \text{Hz} - 3 \text{Hz}} \times 10 \text{s} = 25.5 \text{s}$$

(3) Set two kinds of acceleration/deceleration times (RT signal, Pr. 44, Pr. 45)

- •Pr. 44 and Pr. 45 are valid when the RT signal is ON.
- •When "9999" is set to Pr. 45, the deceleration time becomes equal to the acceleration time (Pr. 44).
- •For the RT signal, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.

- When the acceleration/deceleration pattern is S-pattern acceleration/deceleration A (refer to page 100), the acceleration/ deceleration time is the time required to reach Pr. 3 Base frequency.
- Acceleration/deceleration time formula when the set frequency is the base frequency or higher

$$t = \frac{4}{9} \times \frac{T}{(Pr. 3)^2} \times f^2 + \frac{5}{9} T$$

T: Acceleration/deceleration time setting (s)

f: Set frequency (Hz)

• Guideline for acceleration/deceleration time at the Pr. 3 Base frequency of 60Hz (0Hz to set frequency)

Frequency setting (Hz) Acceleration/ deceleration time (s)	60	120	200	400
5	5	12	27	102
15	15	35	82	305

Changing terminal assignment may affect the other functions. Make setting after confirming the function of each terminal.



• REMARKS

- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 117)
- If the Pr. 20 setting is changed, the Pr. 125 and Pr. 126 (frequency setting signal gain frequency) settings do not change. Set Pr. 125 and Pr. 126 to adjust the gains.
- When the Pr. 7, Pr. 8, Pr. 44 and Pr. 45 settings are 0.03s or less, the acceleration/deceleration time is 0.04s. At that time, set Pr.
- · Any value can be set to the acceleration/deceleration time, but the actual motor acceleration/deceleration time cannot be made shorter than the shortest acceleration/deceleration time determined by the mechanical system J (moment of inertia) and motor torque.



Parameters referred to

Pr. 3 Base frequency Refer to page 86

Pr. 10 DC injection brake operation frequency Refer to page 110

Pr. 29 Acceleration/deceleration pattern selection Refer to page 100

Pr. 125, Pr. 126 (frequency setting gain frequency) Refer to page 154

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114




4.7.2 Starting frequency and start-time hold function (Pr. 13, Pr. 571)

You can set the starting frequency and hold the set starting frequency for a certain period of time. Set these functions when you need the starting torque or want to smooth motor drive at a start.

Parameter Number	Name	Initial Value	Setting Range	Description
13	Starting frequency	0.5Hz	0 to 60Hz	Frequency at start can be set in the range of 0 to 60Hz. Starting frequency at which the start signal is turned ON.
571	Restart coasting time	9999	0 to 10s 9999	Holding time of <i>Pr. 13 Starting frequency</i> . Holding function at a start is invalid

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)




(1) Starting frequency setting (Pr. 13)

- •Frequency at start can be set in the range of 0 to 60Hz.
- You can set the starting frequency at which the start signal is turned ON.



NOTE

The inverter will not start if the frequency setting signal is less than the value set in *Pr. 13*. For example, when 5Hz is set in *Pr. 13*, the motor will not start running until the frequency setting signal reaches 5Hz.



(2) Start-time hold function (Pr. 571)

- •This function holds during the period set in *Pr. 571* and the output frequency set in *Pr. 13 Starting frequency*.
- •This function performs initial excitation to smooth the motor drive at a start.



When Pr. 13 = "0Hz", the starting frequency is held at 0.01Hz.



NOT

- When the start signal was turned OFF during start-time hold, deceleration is started at that point.
 - At switching between forward rotation and reverse rotation, the starting frequency is valid but the start-time hold function is invalid.



Note that when *Pr. 13* is set to any value equal to or lower than *Pr. 2 Minimum frequency*, simply turning ON the start signal will run the motor at the preset frequency even if the command frequency is not input.



Parameters referred to


Pr. 2 Minimum frequency 👺 Refer to page 84

4.7.3 Acceleration/deceleration pattern (Pr. 29)

You can set the acceleration/deceleration pattern suitable for application.


Parameter Number	Name	Initial Value	Setting Range	Description
	Acceleration/deceleration		0	Linear acceleration/ deceleration
29		0	1	S-pattern acceleration/deceleration A
	pattern selection		2	S-pattern acceleration/deceleration B

The above parameters can be set when Pr. 160 Extended function display selection ="0". (Refer to page 163)



(1) Linear acceleration/deceleration (Pr. 29 setting "0", initial value)

•For the inverter operation, the output frequency is made to change linearly (linear acceleration/deceleration) to prevent the motor and inverter from getting excessive stress to reach the set frequency during acceleration, deceleration, etc. when frequency changes. Linear acceleration/deceleration has a uniform frequency/time slope.



(2) S-pattern acceleration/deceleration A (Pr. 29 = "1")

•For machine tool spindle applications, etc.


Use this pattern when acceleration/deceleration is required in a short time to a high-speed range higher than the base frequency.

In this acceleration/deceleration pattern, *Pr. 3 Base frequency* (fb) is the inflection point of the S pattern, and you can set the acceleration/deceleration time appropriate for motor torque reduction in a constant-power operation range of base frequency (fb) or higher.



NOTE

As the acceleration/deceleration time of S-pattern acceleration/deceleration A, set the time taken until *Pr. 3 Base frequency* is reached, not *Pr. 20 Acceleration/deceleration reference frequency*.



(3) S-pattern acceleration/deceleration B (Pr. 29 = "2")

•For prevention of load shifting in conveyor and other applications.

Since acceleration/deceleration is always made in an S shape from current frequency (f2) to target frequency (f1), this function eases shock produced at acceleration/deceleration and is effective for load collapse prevention, etc.

Parameters referred to

Pr. 3 Base frequency Refer to page 86

Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 20 Acceleration/deceleration reference frequency 📭 Refer to page 97



4.8 Selection and protection of a motor

Purpose	Parameter that	Refer to Page	
Motor protection from overheat	Electronic thermal O/L relay	Pr. 9, Pr. 51, Pr. 561	101
motor protection from overneat	PTC thermistor protection	11. 3,11. 31,11. 301	101
Use the constant-torque motor	Applied motor	Pr. 71	104
The motor performance can be maximized for operation in magnetic flux vector control method.	Offline auto tuning	Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90, Pr. 96	106


4.8.1 Motor overheat protection (Electronic thermal O/L relay, PTC thermistor protection) (Pr. 9, Pr. 51, Pr. 561)

Set the current of the electronic thermal relay function to protect the motor from overheat. This feature provides the optimum protective characteristics, including reduced motor cooling capability, at low speed.

Parameter Number	Name	Initial Value	Setting Range	Description
9	Electronic thermal O/L relay	Inverter rated current	0 to 500A	Set the rated motor current.
51 *1	Second electronic thermal O/L relay *2	9999	0 to 500A	Valid when the RT signal is ON. Set the rated motor current. Second electronic thermal O/L relay invalid
561 *1	PTC thermistor protection level	9999	0.5 to 30kΩ 9999	Set the level (resistance value) for PTC thermistor protection activates. PTC thermistor protection is inactive.

- *1 The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)
- *2 When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.

(1) Electronic thermal O/L relay (Pr. 9) Electronic thermal O/L relay operation characteristic



- This function detects the overload (overheat) of the motor and trips. (The operation characteristic is shown on the left)
- Set the rated current (A) of the motor in Pr. 9.
 (If the motor has both 50Hz and 60Hz rating and the Pr. 3 Base frequency is set to 60Hz, set the 1.1 times of the 60Hz rated motor current.)
- Set "0" in *Pr. 9* when you do not want to operate the electronic thermal O/L relay, e.g. when using an external thermal relay with the motor. (Note that the output transistor protection of the inverter functions (E.THT).)
- When using a Mitsubishi constant-torque motor
 - 1) Set "1" or "13", "50", "53" in any of *Pr. 71*. (This provides a 100% continuous torque characteristic in the low-speed range.
 - 2) Set the rated current of the motor in Pr. 9.
- *1 When 50% of the inverter rated output current (current value) is set to Pr. 9
- *2 The % value denotes the percentage to the inverter rated output current. It is not the percentage to the motor rated current.
- *3 When you set the electronic thermal O/L relay dedicated to the Mitsubishi constant-torque motor, this characteristic curve applies to operation at 6Hz or higher.


NOTE

- The protective function performed by the electronic thermal O/L relay is reset by inverter power reset and reset signal input. Avoid unnecessary reset and power-OFF.
- When multiple motors are operated by a single inverter, protection cannot be provided by the electronic thermal function. Install an external thermal relay to each motor.
- When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In this case, use an external thermal relay.
- · A special motor cannot be protected by the electronic thermal relay function. Use an external thermal relay.
- The operation time of the transistor protection thermal shortens when the Pr. 72 PWM frequency selection setting value increases.
- · Electronic thermal relay may not function when 5% or less of inverter rated current is set to electronic thermal relay setting.

(2) Set two different electronic thermal O/L relays (Pr. 51)

Use this function when running two motors of different rated currents individually by a single inverter. (When running two motors together, use external thermal relays.)

- •Set the rated current of the second motor to Pr. 51.
- •When the RT signal is ON, thermal protection is provided based on the Pr. 51 setting.
- •For the terminal used for RT signal input, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.



Pr. 450	Pr. 9	Pr.51	RT =	OFF	RT =	= ON
Second applied motor	Electronic thermal O/L relay	Second electronic thermal O/L relay	First motor	Second motor	First motor	Second motor
		9999	×	×	×	×
9999	0	0	×	×	×	×
		0.01 to 500	×	Δ	×	0
		9999	0	×	0	×
9999	Other than 0	0	0	×	Δ	×
		0.01 to 500	0	Δ	Δ	0
		9999	×	×	×	×
Other than 9999	0	0	×	×	×	×
		0.01 to 500	×	Δ	×	0
		9999	0	Δ	Δ	0
Other than 9999	Other than 0	0	0	×	Δ	×
		0.01 to 500	0	Δ	Δ	0


- O... Output current value is used to perform integration processing.
- $\Delta...$ Output current is assumed as 0A to perform integration processing. (cooling processing)
- x... Electronic thermal relay function is not activated.

• REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 117)

(3) Electronic thermal relay function prealarm (TH) and alarm signal (THP signal)

100%: Electronic thermal O/L relay alarm operation value




- The alarm signal (THP) is output and electronic thermal relay function prealarm (TH) is displayed when the electronic thermal O/L relay cumulative value reaches 85% of the level set in Pr. 9 or Pr. 51. If it reaches 100% of the Pr. 9 Electronic thermal O/L relay setting electronic-thermal relay protection (E.THM/E.THT) occurs.
- The inverter does not trip even when the alarm signal (THP) is output.
- For the terminal used for the THP signal output, assign the function by setting "8 (positive logic) or 108 (negative logic)" in *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)* .



NOTE

• Changing the terminal assignment using *Pr.190*, *Pr.192*, *Pr.197* (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

(4) External thermal relay input (OH signal)



External thermal relay input connection example


- To protect the motor against overheat, use the OH signal when using an external thermal relay or the built-in thermal protector of the motor.
- When the thermal relay operates, the inverter trips and outputs the fault signal (E.OHT).
- For the terminal used for OH signal input, assign the function by setting "7" in any of *Pr. 178 to Pr.182 (input terminal function selection)* .




NOTE

• Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

(5) PTC thermistor protection (Pr. 561)



PTC thermistor input connection



TN: Rated operational temperature

- · Terminal 2 and terminal 10 are available for inputting of motor built-in PTC thermistor output. When the PTC thermistor input reaches to the resistance value set in Pr. 561 PTC thermistor protection level, inverter outputs PTC thermistor operation error signal (E.PTC) and trips.
- Check the characteristics of the using PTC thermistor, and set the resistance value within a protection providing temperature TN, just around the center of R1 and R2 in a left figure. If the Pr. 561 setting is closer to R1 or R2, the working temperature of protection goes higher (protection works later), or lower (protection works earlier).
- PTC thermistor resistance can be displayed in operation panel, parameter unit (FR-PU07) (Refer to page 129), or RS-485 communication (Refer to page 181) when PTC thermistor protection is active (Pr. $561 \neq$ "9999").

PTC thermistor characteristics



(I) REMARKS

When using terminal 2 as PTC thermistor input (Pr. 561 ≠ "9999"), terminal 2 is not available for analog frequency command. Also unavailable when using terminal 2 for PID control and Dancer control. When PID control and Dancer control is not active (Pr. 128 PID action selection = "0"), terminal 4 functions as follows.

When Pr. 79 = "4" or in External operation mode......Terminal 4 is active whether AU signal is ON/OFF When Pr. 79 = "3"......Terminal 4 is active for frequency command when AU signal is ON

For the power supply terminal of PTC thermistor input, do not use power supply other than terminal 10 (external power supply, etc). PTC thermistor does not work properly.



Parameters referred to

Pr. 71 Applied motor Refer to page 104

Pr. 72 PWM frequency selection Refer to page 149

Pr. 79 Operation mode selection Refer to page 166

Pr. 128 PID action selection Refer to page 213

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120

4.8.2 Applied motor (Pr. 71, Pr. 450)

Setting of the used motor selects the thermal characteristic appropriate for the motor.

Setting is required to use a constant-torque motor. Thermal characteristic of the electronic thermal relay function suitable for the motor is set.

When General-purpose magnetic flux vector is selected, the motor constants (SF-JR, SF-HR, SF-JRCA, SF-HRCA, etc.) necessary for control are selected as well.

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0, 1, 3, 13, 23, 40, 43, 50, 53	Selecting the standard motor or constant-torque motor sets the corresponding motor thermal characteristic.
			0, 1	Set when using the second motor.
450	450 Second applied motor	9999	9999	Second motor is invalid. (thermal characteristic of the first motor
				(Pr. 71)

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Set the motor to be used

Refer to the following list and set the parameter according to the motor used.

Pr. 71 (Pr. 450) Setting		Thousand Characteristic of the Electronic Thousand Bolov Euroption		Motor (O: Used motor)	
Pr. 71	Pr. 450	Thermal Characteristic of the Electronic Thermal Relay Function		Standard (SF-JR, etc.)	Constant-torque (SF-JRCA, etc.)
0 (Pr. 71 initial value)		Thermal characteristics of a standard motor		0	
1		Thermal characteristics of the Mitsubishi constant-torque motor			0
40	_	Thermal characteristic of Mitsubishi high efficie	ncy motor (SF-HR)	O *1	
50	_	Thermal characteristic of Mitsubishi constant-torque motor (SF-HRCA)			O *2
3	_	Standard motor	Select "Offline auto tuning setting"	0	
13	_	Constant-torque motor			0
23	_	Mitsubishi standard motor (SF-JR 4P 1.5kW or less)		0	
43	_	Mitsubishi high efficiency motor (SF-HR)		O *1	
53	_	Mitsubishi constant-torque motor (SF-HRCA)			O *2
_	9999 (initial value)	Without second applied motor			

^{*1} Motor constants of Mitsubishi high efficiency motor SF-HR

> REMARKS

- When performing offline auto tuning, set any of "3, 13, 23, 43, 53" in *Pr. 71*. (Refer to *page 106* for offline auto tuning.)
- For the 5.5K and 7.5K, the *Pr. 0 Torque boost* and *Pr. 12 DC injection brake operation voltage* settings are automatically changed according to the *Pr. 71* setting as follows.

Automatic Change Parameter	Standard Motor Setting *1	Constant-torque Motor Setting *2
Pr. 0	3%	2%
Pr. 12	4%	2%

^{*1} Pr. 71 setting: 0, 3, 23, 40, 43

*2 *Pr. 71* setting: 1, 13, 50, 53



NOTE

 Set the electronic thermal relay function to the thermal characteristic for the constant-torque motor when using a geared motor (GM-S, GM-D, GM-SY, GM-HY2 series) to perform General-purpose magnetic flux vector control.

^{*2} Motor constants of Mitsubishi constant-torque motor SF-HRCA.



(2) Use two motors (Pr. 450)

- Set Pr. 450 Second applied motor to use two different motors with one inverter.
- When "9999" (initial value) is set, no function is selected.
- When a value other than 9999 is set in Pr. 450, the second motor is valid with the RT signal ON.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.



• REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 117)



• Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect other functions. Make setting after confirming the function of each terminal.



Net this parameter correctly according to the motor used.

Incorrect setting may cause the motor to overheat and burn.



Parameters referred to

Pr. 0 Torque boost Refer to page 75

Pr. 12 DC injection brake operation voltage Refer to page 110
Pr. 80 Motor capacity Refer to page 106

4.8.3 Exhibiting the best performance for the motor (offline auto tuning) (Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90, Pr. 96)

The motor performance can be maximized with offline auto tuning.

•What is offline auto tuning?

When performing General-purpose magnetic flux vector control, the motor can be run with the optimum operating characteristics by automatically measuring the motor constants (offline auto tuning) even when each motor constants differs, other manufacturer's motor is used, or the wiring length is long.


Parameter Number	Name	Initial Value		Setting Range	Description
71	Applied motor	0		0, 1, 3, 13, 23, 40, 43, 50, 53	By selecting a standard motor or constant- torque motor, thermal characteristic and motor constants of each motor are set.
80	Motor capacity	9999		0.1 to 15kW	Applied motor capacity.
	motor capacity	0000		9999	V/F control
				0 to 500A	Set motor excitation current (no load current)
82	Motor excitation current	9999		9999	Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants.
83	Rated motor voltage	100V class, 200V class 400V class	200V 400V	0 to 1000V	Rated motor voltage (V).
84	Rated motor frequency	60Hz		10 to 120Hz	Rated motor frequency (Hz).
90	Motor constant (R1)	9999		0 to 50Ω, 9999	Tuning data (The value measured by offline auto tuning is automatically set.) 9999: Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants.
				0	Offline auto tuning is not performed.
96	Auto tuning setting/ status	0		11	For General-purpose magnetic flux vector control Offline auto tuning is performed without motor running. (motor constant (R1) only) Offline auto tuning for V/F control (automatic
				21	restart after instantaneous power failure (with frequency search)) (Refer to page 140)

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



POINT

- This function is valid only when a value other than "9999" is set in *Pr. 80* and General-purpose magnetic flux vector control is selected.
- You can copy the offline auto tuning data (motor constants) to another inverter with the PU (FR-PU07).
- Even when motors (other manufacturer's motor, SF-JRC, etc.) other than Mitsubishi standard motor, high
 efficiency motor (SF-JR, SF-HR 0.2kW or more), and Mitsubishi constant-torque motor (SF-JRCA 4P, SFHRCA 0.2kW to 15kW) are used or the wiring length is long, using the offline auto tuning function runs the
 motor with the optimum operating characteristics.
- Tuning is enabled even when a load is connected to the motor.
 - As the motor may run slightly, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs (caution is required especially in elevator). Note that tuning performance is unaffected even if the motor runs slightly.
- Reading/writing/copy of motor constants (Pr. 90) tuned by offline auto tuning are enabled.
- The offline auto tuning status can be monitored with the operation panel and PU (FR-PU04/FR-PU07).
- Do not connect a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) between the inverter and motor.



(1) Before performing offline auto tuning

Check the following before performing offline auto tuning.

- Make sure General-purpose magnetic flux vector control (Pr. 80) is selected. (Tuning can be performed even under V/F control selected by turning ON X18.)
- A motor should be connected. Note that the motor should be at a stop at a tuning start.
- · The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity should be 0.1kW or more)
- · A high-slip motor, high-speed motor and special motor cannot be tuned. (The maximum frequency is 120Hz.)
- As the motor may run slightly, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs (caution is required especially in elevator). Note that tuning performance is unaffected even if the motor runs slightly.
- · Offline auto tuning will not be performed properly if it is performed with a reactor or surge voltage suppression filter (FR-ASF-H/FR-BMF-H) connected between the inverter and motor. Remove it before start tuning.

(2) Setting

- 1) Select General-purpose magnetic flux vector control (Refer to page 76).
- 2) Set "11" in Pr. 96 Auto tuning setting/status. Tuning motor constants (R1) only without running the motor. (It takes approximately 9s until tuning is completed.)
- 3) Set the rated motor current (initial value is rated inverter current) in Pr. 9 Electronic thermal O/L relay. (Refer to page 101)
- 4) Set the rated voltage of motor (initial value is 200V/400V) in Pr. 83 Rated motor voltage and rated motor frequency (initial value is 60Hz) in Pr. 84 Rated motor frequency.
 - (For a Japanese standard motor, etc. which has both 50Hz and 60Hz rated values, use it with an initial value (200V/60Hz or 400V/60Hz).
- 5) Set Pr. 71 Applied motor according to the motor used.

Motor	Pr. 71 Setting	
	SF-JR	3
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	23
Mitsubishi high efficiency motor	SF-HR	43
	Others	3
	SF-JRCA 4P	13
Mitsubishi constant-torque motor	SF-HRCA	53
	Others (SF-JRC, etc.)	13
Other standard motor	_	3
Other constant-torque motor	_	13

(3) Execution of tuning



POINT

Before performing tuning, check the monitor display of the operation panel or parameter unit (FR-PU04/FR-PU07) if the inverter is in the status for tuning. (Refer to 2) below) When the start command is turned ON under V/F control, the motor starts.

1) When performing tuning for PU operation, press (RUN) of the operation panel or FWD or REV of the parameter unit (FR-PU04/FR-PU07).

For External operation, turn ON the run command (STF signal or STR signal). Tuning starts. (Excitation noise is produced during tuning.)



NOTE

- To force tuning to end, use the MRS or RES signal or press (STOP) of the operation panel. (Turning the start signal (STF signal or STR signal) OFF also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid: (initial value)
 - Input terminal <valid signal> STF, STR
 - Output terminal RUN, FM, A, B, C

Note that the progress status of offline auto tuning is output in five steps from FM when speed and output frequency are selected.

- · Since the RUN signal turns ON when tuning is started, caution is required especially when a sequence which releases a mechanical brake by the RUN signal has been designed.
- When executing offline auto tuning, input the run command after switching ON the main circuit power (R/L1, S/L2, T/ L3) of the inverter.
- Do not perform ON/OFF switching of the second function selection signal (RT) during execution of offline auto tuning. Auto tuning is not executed properly.
- 2) Monitor is displayed on the operation panel and parameter unit (FR-PU04/FR-PU07) during tuning as below.

	Parameter Unit (FR-PU04/FR-PU07) Display	Operation Panel Indication
Pr. 96 setting	11	11
(1) Setting	READ:List 11 STOP PU	I I MON
(2)Tuning in progress	TUNE 12 STF FWD PU	12 BXT BXT
(3)Normal end	IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	Flickering
(4)Error end (when inverter protective function operation is activated)	TUNE 9 ERROR STF STOP PU	3 = 3

• REMARKS

- It takes approximately 9s until tuning is completed.
- The set frequency monitor displayed during the offline auto tuning is 0Hz.



- 3) When offline auto tuning ends, press (STOP) of the operation panel during PU operation. For External operation, turn OFF the start signal (STF signal or STR signal) once.
 - This operation resets the offline auto tuning and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)
- 4) If offline auto tuning ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

Error	Error Cause	Remedy	
Display	=1101 50000		
8	Forced end	Set "11" in Pr. 96 and perform tuning again.	
9	Inverter protective function operation	Make setting again.	
91	Current limit (stall prevention) function was activated.	Set "1" in <i>Pr. 156</i> .	
92	Converter output voltage reached 75% of rated value.	Check for fluctuation of power supply voltage.	
93	Calculation error	Check the motor wiring and make setting again.	
93	A motor is not connected.	Set the rated current of the motor in <i>Pr. 9</i> .	

- 5) When tuning is ended forcibly by pressing (STOP) or turning OFF the start signal (STF or STR) during tuning, offline auto tuning does not end properly. (The motor constants have not been set.)

 Perform an inverter reset and restart tuning.
- 6) When using the motor corresponding to the following specifications and conditions, reset *Pr.9 Electronic thermal O/L relay* as below after tuning is completed.
 - a) When the rated power specifications of the motor is 200/220V (400/440V) 60Hz, set 1.1 times rated motor current value in Pr 9
 - b) When performing motor protection from overheat using a PTC thermistor or motor with temperature detector such as Klixon, set "0" (motor overheat protection by the inverter is invalid) in *Pr.9*.
- 7) When you know motor excitation current (no load current), set the value in Pr. 82 Motor excitation current.



NOTE

- The motor constants measured once in the offline auto tuning are stored as parameters, and their data are held until the offline auto tuning is performed again.
- An instantaneous power failure occurring during tuning will result in a tuning error.
 After power is restored, the inverter goes into the normal operation mode. Therefore, when STF (STR) signal is ON, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the ordinary mode. Note that if a fault retry has been set, retry is ignored.

! CAUTION

As the motor may run slightly during offline auto tuning, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs. Note that if the motor runs slightly, tuning performance is unaffected.



Parameters referred to

Pr. 9 Electronic thermal O/L relay Refer to page 101

Pr. 71 Applied motor Refer to page 101

Pr. 80 Motor capacity Refer to page 76

Pr. 156 Stall prevention operation selection Refer to page 80

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120

4.9 Motor brake and stop operation


Purpose	Parameter th	Refer to Page	
Motor braking torque adjustment	DC Injection brake	Pr. 10 to Pr. 12	110
Improve the motor braking torque with	Selection of a	Pr. 30, Pr. 70	111
an option	regenerative brake	P1. 30, P1. 70	111
Coast the motor to a stop	Selection of motor	Pr. 250	113
Coast the motor to a stop	stopping method	F1. 250	115

4.9.1 DC injection brake (Pr. 10 to Pr. 12)

The DC injection brake can be operated at a motor stop to adjust the stop timing and braking torque. In DC injection brake operation, DC voltage is directly applied to the motor to prevent the motor shaft from rotating. The motor will not return to the original position if the motor shaft rotates due to external force.

Parameter Number	Name	Initial Value		Setting Range	Description
10	DC injection brake operation frequency	3Hz		0 to 120Hz	Operation frequency of the DC injection brake.
11	DC injection brake			0	DC injection brake disabled
"	operation time	0.5s		0.1 to 10s	Operation time of the DC injection brake.
	DC injection brake	0.1K, 0.2K	6%		DC injection brake voltage (torque). When "0" is
12	operation voltage	0.4K to 7.5K	4%	0 to 30%	set, DC injection brake is disabled.
		11K, 15K	2%		Set, DO Injection brake is disabled.

The above parameters can be set when Pr. 160 Extended function display selection ="0". (Refer to page 163)



(1) Operation frequency setting (Pr. 10)

• When the frequency at which the DC injection brake will be operated is set to *Pr. 10*, the DC voltage is applied to the motor upon reaching to the set frequency during deceleration.

(2) Operation time setting (Pr. 11)

- •In Pr. 11, set the time of the DC injection brake.
- •When the motor does not stop due to large load moment (J), increasing the setting produces an effect.
- •When *Pr. 11* = "0s", the DC injection brake is disabled. (At a stop, the motor coasts.)

(3) Operation voltage (torque) setting (Pr. 12)

- •Use Pr. 12 to set the percentage to the power supply voltage.
- •When Pr. 12 = "0%", the DC injection brake is disabled. (At a stop, the motor coasts.)
- •When using the constant-torque motor (SF-JRCA) and energy saving motor (SF-HR, SF-HRCA), change the *Pr. 12* setting as follows:

SF-JRCA:

3.7K or less...4%, 5.5K or more...2%

SF-HR, SF-HRCA:

3.7K or less...4%, 5.5K and 7.5K...3%, 11K and 15K...2%





REMARKS

- For the 5.5K and 7.5K, when the Pr. 12 setting is the following, changing the Pr. 71 Applied motor setting automatically changes the Pr. 12 setting. Therefore, it is not necessary to change the Pr. 12 setting.
 - (a) When 4% (initial value) is set in Pr. 12
 - The Pr. 12 setting is automatically changed to 2% if the Pr. 71 value is changed from the value selecting the standard motor (0, 3, 23, 40, 43) to the value selecting the constant-torque motor (1, 13, 50, 53).
 - (b) When 2% is set in Pr. 12
 - The Pr. 12 setting is automatically changed to 4% (initial value) if the Pr. 71 value is changed from the value selecting the constant-torque motor (1, 13, 50, 53) to the value selecting the standard motor (0, 3, 23, 40, 43).
- Even if the value of Pr. 12 setting is increased, braking torque is limited so that the output current is within the rated inverter



As stop holding torque is not produced, install a mechanical brake.

Parameters referred to

Pr. 13 Starting frequency Refer to page 99 Pr. 71 Applied motor Refer to page 104

4.9.2 Selection of a regenerative brake (Pr. 30, Pr. 70)

- When making frequent starts/stops, use the optional brake resistor (MRS type, MYS type), high-duty brake resistor (FR-ABR) and brake unit (FR-BU2) to increase the regenerative brake duty.
- Use a power regeneration common converter (FR-CV) for continuous operation in regeneration status. Use the high power factor converter (FR-HC) to reduce harmonics, improve the power factor, or continuously use the regenerative status.

Parameter	Name	Initial	Setting	Description	
Number	Name	Value	Range	Description	
				Inverter without regenerative function,	
				Brake resistor (MRS type, MYS type),	
			0 Brake unit (FR-BU2) Power regeneration common converter	Brake unit (FR-BU2)	
	Regenerative function selection			Power regeneration common converter (FR-CV)	
30		0		High power factor converter (FR-HC)	
			1	Brake resistor (MYS type) used at 100% torque/6%ED,	
				High-duty brake resistor (FR-ABR)	
			2	High power factor converter (FR-HC) when automatic	
			2	restart after instantaneous power failure is selected	
70	Special regenerative	0%	0 to 30%	Brake duty when using the high-duty brake resistor	
70	brake duty	0%	0 10 30%	(FR-ABR)	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) When using the brake resistor (MRS type, MYS type), brake unit (FR-BU2), power regeneration common converter (FR-CV), and high power factor converter (FR-HC).

•Set Pr. 30 to "0" (initial value). The Pr. 70 setting is invalid.

At this time, the regenerative brake duty is as follows.

Туре	Regenerative brake duty
FR-D720-0.4K to 3.7K	
FR-D720S-0.4K or more	3%
FR-D710W-0.4K or more	
FR-D720-5.5K or more	2%
FR-D740-0.4K or more	∠%

- •Assign the inverter operation enable signal (X10) to the contact input terminal. To make protective coordination with the FR-HC and FR-CV, use the inverter operation enable signal to shut off the inverter output. Input the RDY signal of the FR-HC (RDYB signal of the FR-CV).
- •For the terminal used for X10 signal input, assign its function by setting "10" (X10) to any of Pr. 178 to Pr. 182.

(2) Brake resistor (MYS type) used at 100% torque/6%ED (FR-D720-3.7K only)

- •Set "1" in Pr. 30.
- •Set "6%" in Pr. 70.

(3) When using the high-duty brake resistor (FR-ABR) (0.4K or more)


- •Set "1" in Pr. 30.
- •Set Pr. 70 as follows.

(4) When a high power factor converter (FR-HC) is used and automatic restart after instantaneous power failure function is valid.

- •When automatic restart after instantaneous power failure function of both the FR-HC and inverter is valid (when a value other than "9999" is set in *Pr. 57 Restart coasting time*), set "2" in *Pr. 30*.
- •Set Pr. 70 to "0%" (initial value).
- •When the FR-HC detects power failure during inverter operation, the RDY signal turns ON, resulting in the motor coasting. Turning the RDY signal OFF after power restoration, the inverter detects the motor speed (depends on the *Pr.162 Automatic restart after instantaneous power failure selection*) and restarts automatically after instantaneous power failure.

(5) Regenerative brake duty alarm output and alarm signal (RBP signal)

100%: regenerative overvoltage protection operation value



- •[RB] appears on the operation panel and an alarm signal (RBP) is output when 85% of the regenerative brake duty set in Pr. 70 is reached. If the regenerative brake duty reaches 100% of the Pr. 70 setting, a regenerative overvoltage (E.OV1 to E.OV3) occurs. Note that [RB] is not displayed when Pr. 30 = "0".
- •The inverter does not trip even when the alarm (RBP) signal is output.
- •For the terminal used for the RBP signal output, assign the function by setting "7 (positive logic) or 107 (negative logic)" in *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)* .

> REMARKS

- The MRS signal can also be used instead of the X10 signal. (Refer to page 116)
- Refer to page 31 to 35 for connecting the brake resistor (MRS type, MYS type), high-duty brake resistor (FR-ABR), brake unit (FR-BU2), high power factor converter (FR-HC), and power regeneration common converter (FR-CV).



NOTE

• When terminal assignment is changed using *Pr. 178 to Pr. 182 (input terminal function selection) and Pr. 190, Pr. 192, Pr. 197 (output terminal function selection)*, the other functions may be affected. Make setting after confirming the function of each terminal. (*Refer to page 114*)



The value set in *Pr. 70* must not exceed the setting of the brake resistor used. Otherwise, the resistor can overheat.



Parameters referred to

Pr. 57 Restart coasting time Te Refer to page 137

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120





4.9.3 Stop selection (Pr. 250)

Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns OFF. Used to stop the motor with a mechanical brake, etc. together with switching OFF of the start signal. You can also select the operations of the start signals (STF/STR). (Refer to *page 118* for start signal selection)

Parameter				Description		
Number	Name	Initial Value	Setting Range	Start signal (STF/STR)	Stop operation	
Number				(Refer to page 118)	Stop operation	
					The motor is coasted to a stop	
			0 to 100s	STF signal: Forward rotation start	when the preset time elapses	
		9999	0 10 1003	STR signal: Reverse rotation start	after the start signal is turned	
					OFF.	
			1000s to 1100s	STF signal: Start signal	The motor is coasted to a stop	
250	Stop selection			STR signal: Forward/reverse signal	(Pr. 250 - 1000)s after the start	
				31K sigilai. I olwalu/levelse sigilal	signal is turned OFF.	
				STF signal: Forward rotation start	When the start signal is turned	
		9999	STR signal: Reverse rotation start	OFF, the motor decelerates to		
			8888	STF signal: Start signal	· · · · · · · · · · · · · · · · · · ·	
			0000	STR signal: Forward/reverse signal	stop.	

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)





(1) Decelerate the motor to a stop

- •Set Pr. 250 to "9999" (initial value) or "8888".
- •The motor decelerates to a stop when the start signal (STF/STR) turns OFF.

(2) Coast the motor to a stop

- •Use $Pr.\ 250$ to set the time from when the start signal turns OFF until the output is shut off. When any of "1000 to 1100" is set, the output is shut off in $(Pr.\ 250 1000)$ s.
- •The output is shut off when the time set in *Pr. 250* has elapsed after the start signal had turned OFF. The motor coasts to a stop.
- •The RUN signal turns OFF when the output stops.

REMARKS

- · Stop selection is invalid when the following functions are activated.
 - Power failure stop function (Pr. 261)
 - PU stop (Pr. 75)
 - Deceleration stop because of communication error (Pr. 502)
 - Jog operation mode
 - When setting of Pr. 250 is not 9999 nor 8888, acceleration/deceleration is performed according to the frequency command, until start signal is OFF and output is shut off.



NOTE

• When the start signal is turned ON again during motor coasting, the motor starts at Pr. 13 Starting frequency.



Parameters referred to

Pr. 7 Acceleration time, Pr. 8 Deceleration time Refer to page 97 Pr. 13 Starting frequency Refer to page 99

4.10 Function assignment of external terminal and control

Purpose	Parameter	that should be Set	Refer to Page
Assign function to input terminal	Input terminal function selection	Pr. 178 to Pr. 182	114
Set MRS signal (output shutoff) to NC contact specification	MRS input selection	Pr. 17	116
Assign start signal and forward/ reverse command to other signals	Start signal (STF/STR) operation selection	Pr. 250	118
Assign function to output terminal	Output terminal function assignment	Pr. 190, Pr. 192, Pr. 197	120
Detect output frequency	Up-to-frequency sensitivity Output frequency detection	Pr. 41 to Pr. 43	124
Detect output current	Output current detection Zero current detection	Pr. 150 to Pr. 153, Pr. 166, Pr. 167	125
Remote output function	Remote output	Pr. 495, Pr. 496	127

4.10.1 Input terminal function selection (Pr. 178 to Pr. 182)

Use these parameters to select/change the input terminal functions.

Parameter Number	Name	Initial Value	Initial Signal	Setting Range
178	STF terminal function selection	60	STF (forward rotation command)	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 60, 62, 65 to 67, 9999
179	STR terminal function selection	61	STR (reverse rotation command)	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 61, 62, 65 to 67, 9999
180	RL terminal function selection	0	RL (low-speed operation command)	
181	RM terminal function selection	1	RM (middle speed operation command)	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 62, 65 to 67, 9999
182	RH terminal function selection	2	RH (high-speed operation command)	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



(1) Input terminal function assignment

- •Using Pr. 178 to Pr. 182, set the functions of the input terminals.
- •Refer to the following table and set the parameters:

0	RL	Pr. 59 = 0 (initial value)			Page
	İ	P_r $0 = 0$ (initial value) 11 ow-speed operation command		Pr. 4 to Pr. 6, Pr. 24 to Pr. 27 Pr.232 to Pr.239	90
		<i>Pr</i> : 59 ≠ 0 *1	Remote setting (setting clear)	Pr. 59	94
1 1	RM	Pr. 59 = 0 (initial value)	Middle-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	90
		<i>Pr.</i> 59 ≠ 0 *1	Remote setting (deceleration)	Pr. 59	94
2	RH	<i>Pr.</i> 59 = 0 (initial value)	High-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	90
		<i>Pr.</i> 59 ≠ 0 *1	Remote setting (acceleration)	Pr. 59	94
3	RT	Second function selection	n	Pr. 44 to Pr. 51	117
4	AU	Terminal 4 input selection	1	Pr. 267	151
5	JOG	Jog operation selection		Pr. 15, Pr. 16	92
7	ОН	External thermal relay in	out *2	Pr. 9	101
8	REX	15-speed selection (com	bination with three speeds RL, RM, RH)	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	90
10	X10	Inverter run enable signa	I (FR-HC, FR-CV connection)	Pr. 30, Pr. 70	111
12	X12	PU operation external int	erlock	Pr. 79	166
14	X14	PID control valid termina		Pr. 127 to Pr. 134	213
16	X16	PU-External operation swoperation)	vitchover (turning ON X16 selects External	Pr. 79, Pr. 340	173
18	X18	V/F switchover (V/F cont	rol is performed when X18 is ON)	Pr. 80	76, 106
24	MRS	Output stop		Pr. 17	116
25	STOP	Start self-holding selection	n	_	118
60	STF		nd (assigned to STF terminal (Pr. 178) only)	_	118
61	STR	Reverse rotation comma	nd (assigned to STR terminal (Pr. 179) only)	_	118
62	RES	Inverter reset		_	_
65	X65	PU/NET operation switch operation)	nover (turning ON X65 selects PU	Pr. 79, Pr. 340	174
66	X66	External/NET operation soperation)	switchover (turning ON X66 selects NET	Pr. 79, Pr. 340	174
67	X67	Command source switch 339 commands valid)	over (turning ON X67 makes Pr. 338 and Pr.	Pr. 338, Pr. 339	177
9999	_	No function		_	_

- *1 When Pr. 59 Remote function selection ≠ "0", the functions of the RL, RM and RH signals are changed as given in the table.
- *2 The OH signal turns ON when the relay contact "opens".



NOTE

- Changing the terminal assignment using *Pr.178 to Pr.182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.
- Same function can be assigned to two or more terminals. In this case, the logic of terminal input is OR.
- The priorities of the speed commands are in order of jog > multi-speed setting (RH, RM, RL, REX) > PID (X14).
- When the X10 signal (FR-HC, FR-CV connection-inverter operation enable signal) is not set or when the PU operation external interlock (X12) signal is not assigned with Pr.79 Operation mode selection set to "7", the MRS signal shares this function.
- Same signal is used to assign multi-speed (7 speeds) and remote setting. These cannot be set individually.

 (Same signal is used since multi-speed (7 speeds) setting and remote setting are not used to set speed at the same time.)
- When V/F control is selected by V/F switchover (X18 signal), second function is also selected at the same time.
 Control between V/F and General-purpose magnetic flux can not be switched during operation. In case control is switched between V/F and General-purpose magnetic flux, only second function is selected.
- Turning the AU signal ON makes terminal 2 (voltage input) invalid.

(2) Response time of each signal


•The response time of the X10 signal and MRS signal is within 2ms. The response time of other signals is within 20ms.


4.10.2 Inverter output shutoff signal (MRS signal, Pr. 17)

The inverter output can be shut off by the MRS signal. Also, logic for the MRS signal can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Normally open input
		0	2	Normally closed input
17	MRS input selection			(NC contact input specifications)
17	WING IIIput Selection			External terminal: Normally closed input
			4	(NC contact input specifications)
				Communication: Normally open input

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)





(1) Output shutoff signal (MRS signal)

• Turning ON the output shutoff signal (MRS) during inverter running shuts off the output immediately.

Set "24" in any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign a function to the MRS signal.

- •MRS signal may be used as described below.
- (a) When mechanical brake (e.g. electromagnetic brake) is used to stop motor

The inverter output is shut off when the mechanical brake operates.

- (b) To provide interlock to disable operation by the inverter With the MRS signal ON, the inverter cannot be operated if the start signal is entered into the inverter.
- (c) Coast the motor to a stop.

When the start signal is turned OFF, the inverter decelerates the motor to a stop in the preset deceleration time, but when the MRS signal is turned ON, the motor coasts to a stop.

(2) MRS signal logic inversion (Pr. 17)

• When *Pr. 17* is set to "2", the MRS signal (output stop) can be changed to the normally closed (NC contact) input specification. When the MRS signal turns ON (opens), the inverter shuts off the output.

(3) Assign a different action for each MRS signal input from communication and external terminal (Pr. 17 = "4")

•When *Pr. 17* is set to "4", the MRS signal from external terminal (output stop) can be changed to the normally closed (NC contact) input, and the MRS signal from communication can be changed to the normally open (NO contact) input. This function is useful to perform operation by communication with MRS signal from external terminal remained ON.

External MRS	Communication MRS	Pr. 17 Setting				
External WRS	Communication MRS	0	2	4		
OFF	OFF	Operation enabled	Output shutoff	Output shutoff		
OFF	ON	Output shutoff	Output shutoff	Output shutoff		
ON	OFF	Output shutoff	Output shutoff	Operation enabled		
ON	ON	Output shutoff	Operation enabled	Output shutoff		



REMARKS

• The MRS signal can shut off the output, independently of the PU, External or Network operation mode.



NOTE

Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 178 to Pr. 182 (input terminal function selection) The Refer to page 114




4.10.3 Condition selection of function validity by second function selection signal (RT)

- You can select the second function using the RT signal.
- When the RT signal turns ON, the second function becomes valid.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.
- The second function has the following applications.
- (a) Switching between normal use and emergency use
- (b) Switching between heavy load and light load
- (c) Changing of acceleration/deceleration time by broken line acceleration/deceleration
- (d) Switching of characteristic between the main motor and sub motor

Second function connection diagram

Start Second function selection High speed Middle speed RM SD

Second acceleration/deceleration time



Function	First Function	Second Function	Refer to
Function	Parameter Number	Parameter Number	Page
Torque boost	Pr. 0	Pr. 46	75
Base frequency	Pr. 3	Pr. 47	86
Acceleration time	Pr. 7	Pr. 44	97
Deceleration time	Pr. 8	Pr. 44, Pr. 45	97
Electronic thermal O/L relay	Pr. 9	Pr. 51	101
Stall prevention	Pr. 22	Pr. 48	80
Applied motor	Pr. 71	Pr. 450	104



NOTE

- When the RT signal is ON, the above second function is selected at the same time.
- Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

4.10.4 Start signal operation selection (STF, STR, STOP signal, Pr. 250)

You can select the operation of the start signal (STF/STR).


Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns OFF. Used to stop the motor with a mechanical brake, etc. together with switching OFF of the start signal. (Refer to *page 113* for stop selection)

Parameter		Initial		Descr	iption
	Name		Setting Range	Start signal	Stop operation
Number		Value		(STF/STR)	Refer to page 113
				STF signal: Forward rotation start	The motor is coasted to a stop
			0 to 100s	STR signal: Reverse rotation start	when the preset time elapses after
			31K signal. Reverse rotation start	the start signal is turned OFF.	
		9999	1000s to 1100s	STF signal: Start signal	When the setting is any of 1000s to
250	Stop			STR signal: Forward/reverse signal	1100s, the inverter coasts to a stop in
230	selection			31K signal. I olward/reverse signal	(Pr. 250 - 1000)s.
			9999	STF signal: Forward rotation start	When the start signal is turned
			9999	STR signal: Reverse rotation start	OFF, the motor decelerates to
			8888	STF signal: Start signal	stop.
			0000	STR signal: Forward/reverse signal	σιορ.

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)


(1) Two-wire type connection (STF, STR signal)

- •The two-wire connection is shown below.
- •In the initial setting, the forward/reverse rotation signals (STF/STR) are used as start and stop signals. Turn ON either of the forward and reverse rotation signals to start the motor in the corresponding direction. Switch both OFF (or both ON) the start signal during operation to decelerate the inverter to a stop.
- •The speed setting signal may either be given by entering 0 to 10VDC across the speed setting input terminal 2-5, or by setting the required values in *Pr. 4 to Pr. 6 Multi-speed setting (high, middle, low speeds)*, etc. (For multi-speed operation, refer to *page 90*.)
- •When Pr. 250 is set to any of "1000 to 1100, 8888", the STF signal becomes a start command and the STR signal a forward/reverse command.




> REMARKS

- When Pr. 250 is set to any of "0 to 100, 1000 to 1100", turning OFF the start command coasts the inverter to a stop. (Refer to page 113)
- The STF and STR signals are assigned to the STF and STR terminals in the initial setting. The STF signal can be assigned to *Pr. 178 STF terminal function selection*, and the STR signal to *Pr. 179 STR terminal function selection* only.



(2) Three-wire type (STF, STR, STOP signal)

- •The three-wire connection is shown below.
- •Turning the STOP signal ON makes start self-holding function valid. In this case, the forward/reverse rotation signal functions only as a start signal.
- If the start signal (STF or STR) is turned ON and then OFF, the start signal is held and makes a start. When changing the direction of rotation, turn STR (STF) ON once and then OFF.
- •To stop the inverter, turning OFF the STOP signal once decelerates it to a stop.
- •When using the STOP signal, set "25" in any of Pr.178 to Pr.182 to assign function.



• REMARKS

- When the JOG signal is turned ON to enable Jog operation, the STOP signal becomes invalid.
- If the MRS signal is turned ON to stop the output, the self-holding function is not canceled.

(3) Start signal selection

STF	STR	Pr. 250 Setting	Inverter Status	
317	SIK	0 to 100s, 9999	1000s to 1100s 8888	
OFF	OFF	Stop	Ston	
OFF	ON	Reverse rotation	Stop	
ON	OFF	Forward rotation	Forward rotation	
ON	ON	Stop	Reverse rotation	



Parameters referred to

Pr. 4 to Pr. 6 (multi-speed setting) Refer to page 90
Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

4.10.5 Output terminal function selection (Pr. 190, Pr. 192, Pr. 197)

You can change the functions of the open collector output terminal and relay output terminal.

Parameter Number	Nar	me	Initial Value	Initial Signal	Setting Range
190 (Ver.UP)	RUN terminal function selection	Open collector output terminal	0	RUN (inverter running)	0, 1, 3, 4, 7, 8, 11 to 16, 25, 26, 46, 47, 64, 70, 80, 81, 90, 91,
192 (Ver.UP)	A,B,C terminal function selection	Relay output terminal	99	ALM (fault output)	93 •1, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 125, 126, 146, 147, 164, 170,
197 (Ver.UP)	SO terminal function selection	Open collector output terminal	80	SAFE (safety monitor output)	180, 181, 190, 191, 193 *1, 195, 196, 198, 199, 9999 *2

^{*1 &}quot;93" and "193" cannot be set in Pr. 192.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

Ver.UP Specifications differ according to the date assembled. Refer to page 300 to check the SERIAL number.

(1) Output signal list

- •You can set the functions of the output terminals.
- •Refer to the following table and set the parameters: (0 to 99: positive logic, 100 to 199: negative logic)

Set	ting				Deleted	Refer
Positive logic	Negative logic	Signal	Function	Operation	Related Parameter	to Page
0	100	RUN	Inverter running	Output during operation when the inverter output frequency rises to or above <i>Pr. 13 Starting frequency</i> .	_	122
1	101	SU	Up to frequency *1	Output when the output frequency is reached to the set frequency.	Pr. 41	124
3	103	OL	Overload alarm	Output while stall prevention function is activated.	Pr. 22, Pr. 23, Pr. 66	80
4	104	FU	Output frequency detection	Output when the output frequency reaches the frequency set in <i>Pr. 42</i> (<i>Pr. 43</i> for reverse rotation).	Pr. 42, Pr. 43	124
7	107	RBP	Regenerative brake pre-alarm	Output when 85% of the regenerative brake duty set in Pr . 70 is reached.	Pr. 70	111
8	108	THP	Electronic thermal O/L relay pre-alarm	Output when the electronic thermal value reaches 85% of the trip level. (Electronic thermal relay function protection (E.THT/E.THM) activates, when the value reached 100%.	Pr. 9, Pr. 51	101
11	111	RY	Inverter operation ready	I can be started by switching the start signal ON or while it is I		122
12	112	Y12	·		Pr. 150, Pr. 151	125
13	113	Y13	Zero current detection	Output when the output power is lower than the $Pr. 152$ setting for longer than the time set in $Pr. 153$.	Pr. 152, Pr. 153	125
14	114	FDN	PID lower limit	Output when the feedback value falls below the lower limit of PID control.	Pr. 127 to	
15	115	FUP	PID upper limit	Output when the feedback value rises above the upper limit of PID control	Pr. 134, Pr. 575 to Pr.	213
16	116	RL	PID forward/reverse rotation output	Output when forward rotation is performed in PID control.	577	
25	125	FAN	Fan fault output	Output at the time of a fan fault.	Pr. 244	229
26	126	FIN	Heatsink overheat pre-alarm	Output when the heatsink temperature reaches about 85% of the heatsink overheat protection providing temperature.	_	263
46	146	Y46	During deceleration at occurrence of power failure	Output when the power failure-time deceleration function is executed. (retained until release)	Pr. 261	143
47	147	PID	During PID control activated	Output during PID control.	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577	213
64	164	Y64	During retry	Output during retry processing.	Pr. 65 to Pr. 69	145

^{*2 &}quot;9999" cannot be set in Pr. 197.



Set	Setting				Related	Refer
Positive logic	Negative logic	Signal	Function	Operation	Parameter	to Page
70	170	SLEEP	PID output interruption	Output when the PID output interruption function is executed.	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577	213
80	180	SAFE	Safety monitor output	Output while safety stop function is activated.	_	27
81	181	SAFE2	Safety monitor output 2	Output while safety circuit fault (E.SAF) is not activated.	_	27
90	190	Y90	Life alarm	Output when any of the control circuit capacitor, main circuit capacitor and inrush current limit circuit or the cooling fan approaches the end of its service life.	Pr. 255 to Pr. 259	230
91	191	Y91	Fault output 3 (power-off signal)	Output when a fault occurs due to the internal circuit failure or the inverter wiring mistake, etc.	_	123
93	193	Y93	Current average value monitor signal	Average current value and maintenance timer value are output as pulses. The signal can not be set in <i>Pr. 192 A,B,C terminal function selection</i> .	Pr. 555 to Pr. 557	235
95	195	Y95	Maintenance timer signal	Output when Pr. 503 rises to or above the Pr. 504 setting.	Pr. 503, Pr. 504	234
96	196	REM	Remote output	Output to the terminal when a value is set to the parameter.	Pr. 495, Pr. 496	127
98	198	LF	Alarm output	Output when an alarm (fan failure or communication error warning) occurs.	Pr. 121, Pr. 244	184, 229
99	199	ALM	Fault output	Output when a fault occurs. The signal output is stopped when the fault is reset.	_	123
99	99	_	No function	_	_	_

*1 Note that when the frequency setting is varied using an analog signal or of the operation panel, the output of the SU (up to frequency) signal may alternate ON and OFF depending on that varying speed and the timing of the varying speed due to acceleration/deceleration time setting. (The output will not alternate ON and OFF when the acceleration/deceleration time setting is "0s".)



• REMARKS


- The same function may be set to more than one terminal.
- When the function is executed, the terminal conducts at the setting of any of "0 to 99", and does not conduct at the setting of any of "100 to 199".



NOTE

- Changing the terminal assignment using Pr.190, Pr.192, Pr. 197 (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.
- Do not assign signals which repeat frequent ON/OFF to A, B, and C. Otherwise, the life of the relay contact decreases.
- · The common terminal for terminal RUN is terminal SE. The common terminal for terminal SO is terminal SC. Terminal SC is connected to terminal SD inside of the inverter.

(2) Inverter operation ready signal (RY signal) and inverter running signal (RUN signal)



- When the inverter is ready to operate, the output of the operation ready signal (RY) is ON. (It is also ON during inverter running.)
- When the output frequency of the inverter rises to or above *Pr. 13 Starting frequency*, the output of the inverter running signal (RUN) is turned ON. During an inverter stop or DC injection brake operation, the output is OFF.
- When using the RY and RUN signals, assign functions to *Pr.190*, *Pr.192* or *Pr.197* (output terminal selection function) referring to the table below.

Output	Pr. 190, Pr. 192, Pr. 197 Setting		
Signal	Positive logic	Negative logic	
RY	11	111	
RUN	0	100	

Inverter	Inverter Start			Automatic Restart after				
Status	Signal	Start	Start		At Fault Occurrence	Instantar	eous Powe	r Failure
	OFF	Signal ON	Signal ON	ınal ON Under DC	or MRS Signal ON	Coasting		
Output	(during	(during	(during	Injection Brake	(output shutoff)	Start	Start	Restarting
signal	` •	stop)	operation)		(output silutoii)	signal	signal	Restarting
Signal	stop)					ON	OFF	
RY	ON	ON	ON	ON	OFF	NO.	l *1	ON
RUN	OFF	OFF	ON	OFF	OFF	0	FF	ON


^{*1} This signal turns OFF during power failure or undervoltage.

REMARKS

• The RUN signal (positive logic) is assigned to the terminal RUN in the initial setting.



(3) Fault output signal (ALM signal)



· If the inverter comes to trip, the ALM signal is output.

(I) REMARKS

- · The ALM signal is assigned to the ABC contact in the initial setting. By setting "99 (positive logic) or 199 (negative logic) in Pr.190, Pr.192 or Pr.197 (output terminal function selection), the ALM signal can be assigned to the other signal.
- Refer to page 258 for the inverter fault description.

(4) Fault output 3 (power-off signal) (Y91 signal)

- The Y91 signal is output at occurrence of a fault attributable to the failure of the inverter circuit or a fault caused by a wiring mistake.
- When using the Y91 signal, set "91 (positive logic)" or "191 (negative logic)" to Pr.190, Pr.192 or Pr.197 (output terminal function selection) to assign the function to the output terminal.
- The following table indicates the faults that will output the Y91 signal. (Refer to page 257 for the fault description.)

Operation Panel Indication		Name	
€. 6€	E. BE	Brake transistor alarm detection	
E. GF	E.GF	Output side earth (ground) fault overcurrent at start	
E. LF	E.LF	Output phase loss	
E. PE	E.PE	Parameter storage device fault	
E.C PU	E.CPU	CPU fault	
EJ OH	E.IOH	Inrush current limit circuit fault	

REMARKS

At occurrence of output side earth (ground) fault overcurrent (E.GF), overcurrent trip during acceleration(E.OC1) may be displayed. At this time, the Y91 signal is output.



Parameters referred to


Pr. 13 Starting frequency Refer to page 99


4.10.6 Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)

The inverter output frequency is detected and output at the output signals.

Parameter Number	Name	Initial Value	Setting Range	Description
41	Up-to-frequency sensitivity	10%	0 to 100%	Level where the SU signal turns ON.
42	Output frequency detection	6Hz	0 to 400Hz	Frequency where the FU signal turns ON.
43	Output frequency detection for reverse	9999	0 to 400Hz	Frequency where the FU signal turns ON in reverse rotation.
	rotation		9999	Same as Pr. 42 setting

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)





(1) Up-to-frequency sensitivity (SU signal, Pr. 41)

- •When the output frequency reaches the set frequency, the up-to-frequency signal (SU) is output.
- •The Pr.~41 value can be adjusted within the range 0% to $\pm 100\%$ on the assumption that the set frequency is 100%.
- •This parameter can be used to ensure that the running frequency has been reached to provide the operation start signal etc. for related equipment.
- •When using the SU signal, set "1 (positive logic) or 101 (negative logic)" in *Pr.190*, *Pr.192* or *Pr.197* (output terminal function selection) to assign function to the output terminal.

(2) Output frequency detection (FU signal, *Pr. 42*, *Pr. 43*)

- The output frequency detection signal (FU) is output when the output frequency reaches or exceeds the *Pr. 42* setting.
- This function can be used for electromagnetic brake operation, open signal, etc.
- Frequency detection that is dedicated to the reverse operation can be set by setting detection frequency to *Pr. 43*. This function is effective for switching the timing of electromagnetic brake operation between forward rotation (rise) and reverse rotation (fall) during vertical lift operation, etc.
- •When $Pr. 43 \neq$ "9999", the Pr. 42 setting is used for forward rotation and the Pr. 43 setting is used for reverse rotation.
- •When using the FU signal, set "4 (positive logic)" or "104 (negative logic)" to *Pr.190*, *Pr.192* or *Pr.197* (output terminal function selection) to assign the function to the output terminal.

• REMARKS

- · All signals are OFF during DC injection brake.
- The output frequency to be compared with the set frequency is the output frequency before slip compensation is performed.



NOTE

• Changing the terminal assignment using *Pr.190*, *Pr.192*, *Pr.197* (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) (Refer to page 120)




4.10.7 Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153, Pr. 166, Pr. 167)

The output current during inverter running can be detected and output to the output terminal.

Parameter Number	Name	Initial Value	Setting Range	Description
150	Output current detection level	150%	0 to 200%	100% is the rated inverter current.
151	Output current detection signal delay time	0s	0 to 10s	Output current detection period. The time from when the output current has risen above the setting until the output current detection signal (Y12) is output.
152	Zero current detection level	5%	0 to 200%	The rated inverter current is assumed to be 100%.
153	Zero current detection time	0.5s	0 to 1s	Period from when the output current drops below the <i>Pr. 152</i> value until the zero current detection signal (Y13) is output.
	Output current detection		0 to 10s	Set the retention time when the Y12 signal is ON.
166	signal retention time		9999	The Y12 signal ON status is retained. The signal is turned OFF at the next start.
	Output current detection		0	Operation continues when the Y12 signal is ON
167	operation selection	0	1	The inverter is brought to trip when the Y12 signal is ON. (E.CDO)


The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



(1) Output current detection (Y12 signal, *Pr. 150, Pr. 151, Pr. 166, Pr. 167*)

- •The output current detection function can be used for excessive torque detection, etc.
- •If the output current remains higher than the $Pr.\ 150$ setting during inverter operation for longer than the time set in $Pr.\ 151$, the output current detection signal (Y12) is output from the inverter's open collector or relay output terminal.
- •When the Y12 signal turns ON, the ON state is held for the time set in *Pr. 166*.
- •When Pr. 166 = "9999", the ON state is held until a next start.
- •At the *Pr. 167* setting of "1", the inverter trips, and the output current detection fault (E.CDO) is displayed when the Y12 signal turns ON. When fault occurs, the Y12 signal is ON for the time set in *Pr. 166* at the *Pr. 166* setting of other than 9999, and remains ON until a reset is made at the *Pr. 166* setting of 9999. E.CDO does not occur even if "1" is set in *Pr. 167* while Y12 is ON. The *Pr. 167* setting is valid after Y12 turns OFF.
- •For the Y12 signal, set "12 (positive logic) or 112 (negative logic)" in *Pr.190, Pr.192 or Pr.197 (output terminal function selection)* and assign functions to the output terminal.





The zero current detection signal (Y13) holds the signal for approximately 0.1s once turned ON.

(2) Zero current detection (Y13 signal, Pr. 152, Pr. 153)

- •If the output current remains lower than the Pr. 152 setting during inverter operation for longer than the time set in Pr. 153, the zero current detection (Y13) signal is output from the inverter's open collector or relay output terminal.
- •When the inverter's output current falls to "0", torque will not be generated. This may cause a drop due to gravity when the inverter is used in vertical lift application.

To prevent this, the Y13 signal can be output from the inverter to close the mechanical brake when the output current has fallen to "zero".

•For the Y13 signal, set "13 (positive logic) or 113 (negative logic)" in Pr.190, Pr.192 or Pr.197 (output terminal function selection) and assign functions to the output terminal.

• REMARKS

- · This function is also valid during execution of the offline auto tuning.
- The response time of Y12 and Y13 signals is approximately 0.1s. Note that the response time changes according to the load condition.
- When Pr. 152 = "0", detection is disabled.



Changing the terminal assignment using Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



too long. Otherwise, the detection signal may not be output when torque is not generated at a low output current.

 \bigwedge To prevent the machine and equipment from resulting in hazardous conditions detection signal, install a safety backup such as an emergency brake even the zero current detection function is set valid.



Parameters referred to

Offline auto tuning Refer to page 106 Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120



4.10.8 Remote output selection (REM signal, Pr. 495, Pr. 496)


You can utilize the ON/OFF of the inverter's output signals instead of the remote output terminal of the programmable logic controller.

Parameter	Name	Initial	Setting	Description		
Number	Name	Value	Range	Description		
			0	Remote output data clear at powering OFF	Remote output data	
	Remote output	emote output 0		Remote output data retention at powering OFF	clear at inverter reset	
495	selection			Remote output data clear at powering OFF	Remote output data	
				Remote output data retention at powering	retention at inverter	
			11	OFF	reset	
496*	Remote output data 1	0	0 to 4095	Refer to the following diagram.		

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

<Remote output data> (Ver.UP)

Pr. 496




* Any

Ver.UP ... Specifications differ according to the date assembled. Refer to page 300 to check the SERIAL number.

- The output terminal can be turned ON/OFF depending on the Pr. 496 setting. The remote output selection can be controlled ON/OFF by computer link communication from the PU connector.
- Set "96 (positive logic) or 196 (negative logic)" to Pr.190, Pr.192 or Pr.197 (output terminal function selection), and assign the remote output (REM) signal to the terminal used for remote output.
- When you refer to the diagram on the left and set 1 to the terminal bit (terminal where the REM signal has been assigned) of *Pr. 496*, the output terminal turns ON (OFF for negative logic). By setting 0, the output terminal turns OFF (ON for negative logic).

Example: When "96 (positive logic)" is set in *Pr. 190 RUN terminal function selection* and "1" (H01) is set in *Pr. 496*, the terminal RUN turns ON.

ON/OFF example for positive logic



- When Pr. 495 = "0 (initial value), 10", performing a power ON reset (including a power failure) clears the REM signal output. (The ON/OFF status of the terminals are as set in Pr. 190, Pr. 192, Pr.197) The Pr. 496 setting becomes also "0". When Pr. 495 = "1, 11", the remote output data before power OFF is stored into the EEPROM, so the signal output at power recovery is the same as before power OFF. However, it is not stored when the inverter is reset (terminal reset, reset request through communication). (See the chart on the left.)
- When *Pr. 495* = "10, 11", signal before rest is saved even at inverter reset.

REMARKS

- The output terminal where the REM signal is not assigned using *Pr.190*, *Pr.192* or *Pr.197* does not turn ON/OFF if 0/1 is set to the terminal bit of *Pr. 496* or *Pr. 497*. (It turns ON/OFF with the assigned function.)
- When the inverter is reset (terminal reset, reset request through communication), *Pr. 496* values turn to "0". When *Pr. 495* = "1, 11", however, these are the settings at power OFF. (The settings are stored at power OFF.)

 When *Pr. 495* ="10, 11", these are the same as before an inverter reset is made.

Parameters referred to

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120

^{*} The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

4.11 Monitor display and monitor output signal

Purpose	Parameter that	Refer to Page	
Display motor speed Set speed	Speed display and speed setting	Pr. 37	128
Change PU monitor display data	Monitor display/PU main display data selection Cumulative monitor clear	Pr. 52, Pr. 54, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891	129
Change the monitor output from terminal FM	Terminal FM function selection	Pr. 54	129
Set the reference of the monitor output from terminal FM	Terminal FM standard setting	Pr. 55, Pr. 56	134
Adjust terminal FM outputs	Terminal FM calibration	Pr. 900	135

4.11.1 Speed display and speed setting (Pr. 37)

The monitor display and frequency setting of the PU (FR-PU04/FR-PU07) can be changed to the machine speed.

Parameter Number	Name	Initial Value	Setting Range	Description
37	Speed display	0	0	Frequency display, setting
31	opeed display		0.01 to 9998*	Machine speed at 60Hz.

The above parameter can be set when *Pr. 160 Extended function display selection* = "0". (*Refer to page 163*)

Maximum setting value of
$$Pr. 37 < \frac{16777.215 \times 60 \text{ (Hz)}}{\text{Setting value of } Pr. 1 (Pr. 18) \text{ (Hz)}}$$

Note that the maximum setting value of Pr. 37 is 9998 if the result of the above formula exceeds 9998.

• To display the machine speed, set in Pr. 37 the machine speed for 60Hz operation.

For example, when Pr. 37 = "1000", "1000" is displayed on the output frequency and set frequency monitor when the running frequency is 60Hz. When running frequency is 30Hz, "500" is displayed.

Pr. 37 Setting	Output Frequency Monitor	Set Frequency Monitor	Frequency Setting	Parameter Setting
0 (initial value)	Hz	Hz	Hz	Hz
0.01 to 9998	Machine speed *1	Machine speed *1 Machine speed *1		TIZ

- *1 Machine speed conversion formulaPr. 37 × frequency/60Hz
- *2 Hz is displayed in 0.01Hz increments and machine speed is in 0.001.



NOTE

- Under V/F control, the output frequency of the inverter is displayed in terms of synchronous speed, and therefore, displayed value = actual speed + motor slip. The display changes to the actual speed (estimated value calculated based on the motor slip) when slip compensation was valid.
- Refer to Pr. 52 when you want to change the PU main monitor (PU main display).
- Since the panel display of the operation panel is 4 digits in length, the monitor value of more than "9999" is displayed as "----".
- When the machine speed is displayed on the FR-PU04/FR-PU07, do not change the speed by using an up/down key in the state where the set speed exceeding 65535 is displayed. The set speed may become arbitrary value.
- While the machine speed is displayed on the monitor, values of other parameters related to speed (*Pr. 1*, etc.) are in frequency increments. Set other parameters (*Pr.1*, etc.) related to speed in increments of frequency.
- Due to the limitations on the resolution of the set frequency, the indication in the second decimal place may differ from the setting.



Make sure that the running speed setting is correct.

Otherwise, the motor might run at extremely high speed, damaging the machine.



Parameters referred to

Pr. 1 Maximum frequency, Pr. 18 High speed maximum frequency Refer to page 84 Pr. 52 DU/PU main display data selection Refer to page 129

^{*} The maximum value of the setting range differs according to the Pr. 1 Maximum frequency (Pr. 18 High speed maximum frequency), and it can be calculated from the following formula.



4.11.2 Monitor display selection of DU/PU and terminal FM (Pr. 52, Pr. 54, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891)

The monitor to be displayed on the main screen of the operation panel and parameter unit (FR-PU04/FR-PU07) can be selected.

In addition, signal to be output from the terminal FM (pulse train output) can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
52 *	DU/PU main display data selection	0 (output frequency)	0, 5, 8 to 12, 14, 20, 23 to 25, 52 to 55, 61, 62, 64, 100	Select the monitor to be displayed on the operation panel and parameter unit. Refer to the following table for monitor description.
54 *	FM terminal function selection	1 (output frequency)	1 to 3, 5, 8 to 12, 14, 21, 24, 52, 53, 61, 62	Select the monitor output to terminal FM.
			0	Set "0" to clear the watt-hour meter monitor.
170	Watt-hour meter clear	9999	10	Sets the maximum value for monitoring from communication to 9999kWh.
			9999	Sets the maximum value for monitoring from communication to 65535kWh.
171	Operation hour meter clear	9999	0, 9999	Set "0" in the parameter to clear the operation time monitor. Setting 9999 does not clear.
	Monitor decimal digits		0	Displayed as integral value
268 *	selection	9999	1	Displayed in 0.1 increments
	00.000.0		9999	No function
563	Energization time carrying- over times	0	0 to 65535 (reading only)	The numbers of cumulative energization time monitor exceeded 65535h is displayed. (Reading only)
564	Operating time carrying- over times	0	0 to 65535 (reading only)	The numbers of operation time monitor exceeded 65535h is displayed. (Reading only)
891	Cumulative power monitor	9999	0 to 4	Set the number of times to shift the cumulative power monitor digit. Clamp the monitoring value at maximum.
891 di	digit shifted times	9999	9999	No shift Clear the monitor value when it exceeds the maximum value.

The above parameters can be set when Pr.~160 Extended function display selection = "0". (Refer to page 163)

(1) Monitor description list (Pr. 52)

- •Set the monitor to be displayed on the operation panel and parameter unit (FR-PU04/FR-PU07) in *Pr. 52 DU/PU main display data selection* .
- •Set the monitor to be output to the terminal FM (pulse train output) in Pr. 54 FM terminal function selection .
- •Refer to the following table and set the monitor to be displayed. (The monitor marked with × cannot be selected.)

		Pr. 52 Setting						
Types of Monitor	Unit	Operation	PU	Pr. 54 (FM)	Terminal FM Full Scale Value		Description	
Types of Monitor	Offic	panel	main	Setting			Description	
		LED	monitor					
Output frequency	0.01Hz	0/	100	1	Pr. 55		Displays the inverter output frequency.	
Output current	0.01A	0/100		2 Pr. 56			Displays the inverter output current	
Output current	0.017	O/	100	_	17.50		effective value.	
					100V class,	400V		
Output voltage	0.1V	0/	100	3	200V class	400 V	Displays the inverter output voltage.	
					400V class	800V		
Fault display	_	0/100		×	_		Displays past 8 faults individually.	
Frequency setting	0.01Hz	5	*1	5	Pr. 55		Displays the set frequency.	
value	0.01112	5	*1	5	F1. 33		Displays the set frequency.	

^{*} The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

		Pr. 52 S	Setting				
		Operation	PU	Pr. 54 (FM)	Terminal	FM	
Types of Monitor	Unit	panel LED	main monitor	Setting	Full Scale	Value	Description
Converter output voltage	0.1V	8	*1	8			Displays the DC bus voltage value.
Regenerative brake duty	0.1%	9	*1	9	400V class Pr. 70	800V	Brake duty set in Pr. 30, Pr. 70
Electronic thermal relay function load factor	0.1%	10	*1	10	100%		Displays the thermal cumulative value on the assumption that the thermal operation level is 100% (Larger thermal between the motor thermal and transistor thermal). *6
Output current peak value	0.01A	11	*1	11	Pr. 56		Holds and displays the peak value of the output power monitor. (Cleared at every start)
Converter output voltage peak value	0.1V	12	*1	12	100V class, 200V class 400V class	400V 800V	Holds and displays the peak value of the DC bus voltage value. (Cleared at every start)
Output power	0.01kW	14	*1	14	Rated invert power × 2	er	Displays the power on the inverter output side
Input terminal status	_		*1	×	_		Displays the input terminal ON/OFF status on the operation panel. (<i>Refer to page 132</i>)
Output terminal status	_		*1	×	_		Displays the output terminal ON/OFF status on the operation panel. (<i>Refer to page 132</i>)
Cumulative energization time *2	1h	20		×	_		Adds up and displays the energization time after inverter shipment. You can check the numbers of the monitor value exceeded 65535h with <i>Pr. 563</i> .
Reference voltage output	_	_	_	21	_		Terminal FM: Output 1440 pulse/s
Actual operation time *2, *3	1h	23		×	_		Adds up and displays the inverter operation time. You can check the numbers of the monitor value exceeded 65535h with <i>Pr. 564</i> . Can be cleared by <i>Pr. 171</i> . (<i>Refer to page 133</i>)
Motor load factor	0.1%	2	24	24	24 200%		Displays the output current value on the assumption that the inverter rated current value is 100%. Monitor value = output power monitor value/rated inverter current 100 [%]
Cumulative power *5	0.01kWh *4	2	25	×	_		Adds up and displays the power amount based on the output power monitor. Can be cleared by <i>Pr. 170. (Refer to page 132)</i>
PID set point	0.1%	5	52	52			Displays the set point, measured value and
PID measured value	0.1%	5	53	53			deviation during PID control (Refer to page
PID deviation	0.1%	5	54	×			218 for details)
Inverter I/O terminal monitor	_	55	×	×	_		Displays the ON/OFF status of the inverter input terminal and output terminal on the operation panel (<i>Refer to page 132</i> for details)
Motor thermal load factor	0.1%	6	31	61	Thermal relay operation level (100%)		Motor thermal heat cumulative value is displayed. (Motor overload trip (E.THM) at 100%)
Inverter thermal load factor	0.1%	6	32	62	Thermal relay		Transistor thermal heat cumulative value is displayed. (Inverter overload trip (E.THT) at 100%)



		Pr. 52 S	Setting			
Types of Monitor	Unit	Operation panel LED	PU main monitor	Pr. 54 (FM) Setting	Terminal FM Full Scale Value	Description
PTC thermistor resistance	0.01kΩ	64		×	_	Displays the PTC thermistor resistance at terminal 2 when PTC thermistor protection is active. (0.10k Ω to 31.5k Ω) (<i>Refer to page 101</i>)

- Frequency setting to output terminal status on the PU main monitor are selected by "other monitor selection" of the parameter unit (FR-PU04/FR-PU07).
- The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0. When the operation panel is used, the time is displayed up to 65.53 (65530h) in the indication of 1h = 0.001, and thereafter, it is added up from 0.
- *3 Actual operation time is not accumulated when the cumulative operation time is less than 1h until turning OFF of the power supply.
- When using the parameter unit (FR-PU04/FR-PU07), "kW" is displayed.
- Since the panel display of the operation panel is 4 digits in length, the monitor value of more than "9999" is displayed as "----". *5
- Larger thermal value between the motor thermal and transistor thermal is displayed.


A value other than 0% is displayed if the surrounding air temperature (heatsink temperature) is high even when the inverter is at a stop.

REMARKS


- By setting "0" in Pr. 52, the monitoring of output speed to fault display can be selected in sequence by (SET
- When the operation panel is used, the displayed units are Hz and A only, and the others are not displayed.
- The monitor set in Pr. 52 is displayed in the third monitor position. However, change the output current monitor for the motor load factor.

Initial Value

*The monitor displayed at powering ON is the first monitor. Display the monitor you want to display on the first monitor and hold down (SET) for 1s. (To return to the output frequency monitor, hold down (SET) for 1s after displaying the output frequency monitor.)



Example) When Pr. 52 is set to "20" (cumulative energization time), the monitor is displayed on the operation panel as described



(2) Display set frequency during stop (Pr. 52)

• When "100" is set in Pr. 52, the set frequency and output frequency are displayed during stop and operation respectively. (LED of Hz flickers during stop and is lit during operation.)

		Pr. 52				
	0	10	00			
	During	During oton	During			
	running/stop	During stop	running			
Output	Output	Set	Output			
frequency	frequency	frequency*	frequency			
Output current		Output current				
Output voltage	Output voltage					
Fault display	Fault display					


The set frequency displayed indicates the frequency to be output when the start command is ON. Different from the frequency setting displayed when Pr. 52 = "5". the value based on maximum/minimum frequency and frequency jump is displayed.

(I) REMARKS

- During an error, the output frequency at error occurrence appears.
- During MRS signal is ON, the values displayed are the same as during a stop.
- During offline auto tuning, the tuning status monitor has priority.

(3) Operation panel I/O terminal monitor (Pr. 52)

- •When Pr. 52 = "55", the I/O terminal status can be monitored on the operation panel.
- •The I/O terminal monitor is displayed on the third monitor.
- •The LED is ON when the terminal is ON, and the LED is OFF when the terminal is OFF. The center line of LED is always ON.
- •On the I/O terminal monitor (Pr. 52 = "55"), the upper LEDs denote the input terminal status and the lower the output terminal status.



(4) Cumulative power monitor and clear (Pr. 170, Pr. 891)

- •On the cumulative power monitor (Pr. 52 = "25"), the output power monitor value is added up and is updated in 1h increments.
- •The operation panel, parameter unit (FR-PU04/FR-PU07) and communication (RS-485 communication) display increments and display ranges are as indicated below.

Operation Panel *1		Parameter Unit	*2	Communication			
Range Unit		Range	Unit	R	Unit		
Kange	Oilit	Kange	Oilit	<i>Pr. 170</i> = 10	<i>Pr. 170</i> = 9999	Oilit	
0 to 99.99kWh	0.01kWh	0 to 999.99kWh	0.01kWh		0 to 65525kWh	1kWh/	
100.0 to 999.9kWh	0.1kWh	1000.0 to 9999.9kWh	0.1kWh	0 to 9999kWh	0 to 65535kWh	0.01kWh	
1000 to 9999kWh	1kWh	10000 to 99999kWh	1kWh		(initial value)	*3	

- Power is measured in the range of 0 to 9999.99kWh, and displayed in 4 digits.
 - When the monitor value exceeds "99.99", a carry occurs, e.g. "100.0", so the value is displayed in 0.1kWh increments.
- *2 Power is measured in the range of 0 to 99999.99kWh, and displayed in 5 digits.

 When the monitor value exceeds "999.99", a carry occurs, e.g. "1000.0", so the value is displayed in 0.1kWh increments.
- *3 In monitoring with communication, cumulative power is displayed in 1kWh increments. And cumulative power 2 is displayed in 0.01kWh. (Refer to page 189 for communication)
- •The monitor data digit can be shifted to the right by the number of *Pr.* 891 settings. For example, if the cumulative power value is 1278.56kWh when *Pr.* 891 = "2", the operation panel display or parameter unit (FR-PU04/FR-PU07) display is 12.78 (display in 100kWh increments) and the communication data is 12.
- •If the maximum value is exceeded at Pr. 891 = "0 to 4", the power is clamped at the maximum value, indicating that a digit shift is necessary. If the maximum value is exceeded at Pr. 891 = "9999", the power returns to 0 and is recounted. If the maximum value is exceeded at Pr. 891 = "9999", the power returns to 0 and is recounted.
- •Writing "0" in Pr. 170 clears the cumulative power monitor.

• REMARKS

• If "0" is written to Pr. 170 and Pr. 170 is read again, "9999" or "10" is displayed.



(5) Cumulative energization time and actual operation time monitor (Pr. 171, Pr. 563, Pr. 564)

- •Cumulative energization time monitor (Pr. 52 = "20") accumulates energization time from shipment of the inverter every one hour.
- •On the actual operation time monitor (Pr. 52 = "23"), the inverter running time is added up every hour. (Time is not added up during a stop.)
- •If the monitored value exceeds 65535, it is added up from 0. You can check the numbers of cumulative energization time monitor exceeded 65535h with Pr. 563 and the numbers of actual operation time monitor exceeded 65535h with Pr. 564.
- •Writing "0" to Pr. 171 clears the cumulative energization power monitor. (The cumulative time monitor can not be cleared.)



(I) REMARKS

- · The actual operation time is not added up unless the inverter is operated one or more hours continuously.
- If "0" is written to Pr. 171 and Pr. 171 is read again, "9999" is always displayed. Setting "9999" does not clear the actual operation

(6) You can select the decimal digits of the monitor (Pr. 268)

•As the operation panel display is 4 digits long, the decimal places may vary at analog input, etc. The decimal places can be hidden by selecting the decimal digits.

In such a case, the decimal digits can be selected by Pr. 268.

Pr. 268 Setting	Description
9999 (initial value)	No function
	For the first or second decimal places (0.1 increments or 0.01 increments) of the monitor, numbers in the first
0	decimal place and smaller are rounded to display an integral value (1 increments). The monitor value smaller than
	0.99 is displayed as 0.
1	When 2 decimal places (0.01 increments) are monitored, the 0.01 decimal place is dropped and the monitor
I	displays the first decimal place (0.1 increments). The monitored digits in 1 increments are displayed.



• REMARKS

• The number of display digits on the cumulative energization time (Pr. 52 = "20"), actual operation time (Pr. 52 = "23") and cumulative power (Pr. 52 = "25") does not change.



Parameters referred to

Pr. 30 Regenerative function selection, Pr. 70 Special regenerative brake duty 👺 Refer to page 111 Pr. 37 Speed display Refer to page 128

Pr. 55 Frequency monitoring reference, Pr. 56 Current monitoring reference Refer to page 134

4.11.3 Reference of the terminal FM (pulse train output) (Pr. 55, Pr. 56)


The pulse train output terminal FM is available for monitor output. Set the reference of the signal output from terminal FM.

Parameter Number	Name	Initial Value	Setting Range	Description
55*	Frequency monitoring reference	60Hz	0 to 400Hz	Full-scale value when frequency monitor value is output to terminal FM.
56*	Current monitoring reference	Inverter rated current	0 to 500A	Full-scale value when current monitor value is output to terminal FM.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)


(1) Frequency monitor reference (Pr. 55)

- •Set the full scale value when outputting the frequency monitor from terminal FM.
- •Set the frequency when the optional frequency meter (1mA analog meter), which is connected to the terminal FM and SD, shows 60Hz or 120Hz (shows full scale).
- •Set the inverter output frequency (set frequency) at which the pulse speed of the FM output is 1440 pulses/s.
- •The pulse speed and inverter output frequency are proportional to each other. (The maximum pulse train output is 2400 pulses/s.)



(2) Current monitor reference (Pr. 56)

- Set the full scale value when outputting the current monitor from terminal FM.
- Set the output current at which the pulse speed of the FM output is 1440 pulses/s.
- The pulse speed and output current monitor value are proportional to each other. (The maximum pulse train output is 2400 pulses/s.)



^{*} The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.



4.11.4 Terminal FM calibration (calibration parameter C0 (Pr. 900))


By using the operation panel or parameter unit, you can calibrate terminal FM to full scale deflection.

Parameter Number	Name	Initial Value	Setting Range	Description
C0 (900)	FM terminal calibration	_	_	Calibrates the scale of the meter connected to terminal FM.

- The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)
- The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).
- The above parameter allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

(1) FM terminal calibration (C0 (Pr. 900))

- •The terminal FM is preset to output pulses. By setting the FM terminal calibration C0 (Pr. 900), the meter connected to the inverter can be calibrated by parameter setting without use of a calibration resistor.
- •Using the pulse train output of the terminal FM, a digital display can be provided to connect a digital counter. The monitor value is 1440 pulses/s output at the full-scale value of monitor description list (page 129) (Pr. 54 FM terminal function selection).



Pulse width T1: Adjust using calibration parameter C0 Pulse cycle T2: Set with Pr. 55 (frequency monitor) Set with Pr. 56 (current monitor)

- Not needed when the operation panel or parameter unit (FR-PU04/FR-PU07) is used for calibration.
 - Use a calibration resistor when the indicator (frequency meter) needs to be calibrated by a neighboring device because the indicator is located far from the inverter.
 - However, the frequency meter needle may not deflect to full-scale if the calibration resistor is connected. In this case, perform calibration using the operation panel or parameter unit.
- The initial settings are 1mA full-scale and 1440 pulses/s terminal FM frequency at 60Hz.
- •Calibrate the terminal FM in the following procedure.
 - 1) Connect an indicator (frequency meter) across terminals FM-SD of the inverter. (Note the polarity. The terminal FM is positive)
 - 2) When a calibration resistor has already been connected, adjust the resistance to "0" or remove the resistor.
 - 3) Refer to the monitor description list (page 129) and set Pr. 54.
 - When you selected the running frequency or inverter output current at monitor, preset the running frequency or current value, at which the output signal will be 1440 pulses/s, to Pr. 55 Frequency monitoring reference or Pr. 56 Current monitoring reference.

At 1440 pulses/s, the meter generally deflects to full-scale.



(I) REMARKS

- When calibrating a monitor output signal, which cannot be adjusted to 100% value without an actual load and a measurement equipment, set Pr. 54 to "21" (reference voltage output). 1440 pulses/s are output from the terminal FM.
- The wiring length of the terminal FM should be 200m at maximum.



- The initial value of the calibration parameter C0 (Pr. 900) is set to 1mA full-scale and 1440 pulses/s FM output frequency at 60Hz. The maximum pulse train output of terminal FM is 2400 pulses/s.
- When a frequency meter is connected across terminals FM to SD to monitor the running frequency, the terminal FM output is filled to capacity at the initial value if the maximum output frequency reaches or exceeds 100Hz. In this case, the Pr. 55 setting must be changed to the maximum frequency.

How to calibrate the terminal FM when using the operation panel

1. Confirm the RUN indication and operation mode indication

Operation -

2. Press (MODE) to choose the parameter setting mode.

3. Turn (until [. . .

4. Turn (SET) until [- - - appears.

5. Turn (until [Set to C0 FM terminal calibration.

6. Press (SET) to enable setting.

7. If the inverter is at a stop, press the (RUN) key to start the inverter. (Motor needs not be connected.)

to adjust the indicator needle to the desired position

9. Press(SET) Setting is complete. Display

(When Pr. 54 = 1)

PRM indication is lit.



(The parameter number read previously appears.)

C0 to C25 settings are enabled.

The monitor set to Pr. 54 FM terminal function selection is displayed.





Flicker...Parameter setting complete!!

to read another parameter.

•Press (SET) to return to the [- - - indication (step 4).

•Press (SET) twice to show the next parameter (Pr.[]).

• REMARKS

- Calibration can also be made for External operation. Set the frequency in the External operation mode, and make calibration in
- Calibration can be made even during operation.
- For operation from the parameter unit (FR-PU04/FR-PU07), refer to the Instruction Manual of the parameter unit.

Parameters referred to

Pr. 54 FM terminal function selection Refer to page 129
Pr. 55 Frequency monitoring reference Refer to page 134

Pr. 56 Current monitoring reference Refer to page 134



4.12 Operation selection at power failure and instantaneous power failure

Purpose	Parameter ti	Refer to Page	
At instantaneous power failure	Automatic restart operation	Pr. 30, Pr. 57, Pr. 58, Pr. 96,	
occurrence, restart inverter without	after instantaneous power	Pr. 162, Pr. 165, Pr. 298, Pr. 299,	137
stopping motor	failure/flying start	Pr. 611	
When undervoltage or a power	Power failure-time		
failure occurs, the inverter can be	deceleration-to-stop	Pr. 261	143
decelerated to a stop.	function		

4.12.1 Automatic restart after instantaneous power failure/flying start (Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)


You can restart the inverter without stopping the motor in the following cases:

- When power comes back ON after an instantaneous power failure
- When motor is coasting at start

Parameter Number	Name	Initial Value	Setting Range	·	
30	Regenerative function	0	0, 1	The motor starts at the starting frequency when MRS (X1 turns ON then OFF	
	selection	Ü	2	Restart operation is performed when MRS (X10) turns ON then OFF	
			0	1.5K or less 1s 2.2K to 7.5K 2s 11K and 15K 3s	
57	Restart coasting time	9999		The above times are coasting time. Waiting time for inverter-triggered restart after an	
			0.1 to 5s 9999	instantaneous power failure. No restart	
58	Restart cushion time	1s	0 to 60s	Voltage starting time at restart.	
		0	0	Offline auto tuning is not performed	
96	Auto tuning setting/status		11	For General-purpose magnetic flux vector control Offline auto tuning is performed without motor running (motor constants (R1) only) (Refer to page 76)	
			21	Offline auto tuning (tuning performed without motor running) for V/F control and automatic restart after instantaneous	
	Automatic restart after		0	power failure (with frequency search) With frequency search	
4.00			1	Without frequency search (reduced voltage system)	
162	instantaneous power	1	10	Frequency search at every start	
	failure selection		11	Reduced voltage at every start	
165	Stall prevention operation level for restart	150%	0 to 200%	Considers the rated inverter current as 100% and sets the stall prevention operation level during restart operation.	
298	298 Frequency search gain		0 to 32767	When offline auto tuning is performed under V/F control, frequency search gain necessary for frequency search for automatic restart after instantaneous power failure is set as	
			9999	well as the motor constants (R1). Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants	
		0	0	Without rotation direction detection	
	Rotation direction detection selection at restarting		1	With rotation direction detection	
299			9999	When <i>Pr.</i> 78 = 0, With rotation direction detection When <i>Pr.</i> 78 = 1, 2	
	Acceleration time at a		0 to 3600s	Without rotation direction detection Acceleration time to reach <i>Pr.20 Acceleration/deceleration</i> reference frequency at a restart.	
611	restart	9999	9999	Acceleration time for restart is the normal acceleration time (e.g. <i>Pr.</i> 7)	
	L		·	1	


The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

When Pr. 162 = 1, 11 (without frequency search)



* The output shut off timing differs according to the load condition.

When Pr. 162 = 0, 10 (with frequency search)



(1) Automatic restart operation selection

(Pr. 30, Pr. 162, Pr. 299)

Without frequency search

When Pr. 162 = "1 (initial value) or 11", automatic restart operation is performed in a reduced voltage system, where the voltage is gradually risen with the output frequency unchanged from prior to an instantaneous power failure independently of the coasting speed of the

• REMARKS

This system stores the output frequency and rotation direction prior to an instantaneous power failure and restart using the stored value. Therefore, if the instantaneous power failure time exceeds 0.2s and the stored value cannot be retained, the inverter starts at Pr. 13 Starting frequency (initial value = 0.5Hz) in the starting direction upon power restoration.

With frequency search

When "0 or 10" is set in Pr. 162, the inverter smoothly starts after detecting the motor speed upon power restoration. (The motor capacity should be equal to or one rank lower than the inverter capacity)

When using the frequency search, perform offline auto tuning.

(Refer to page 106 for General-purpose magnetic flux vector control and page 140 for V/F control.)

- •During reverse rotation, the inverter can be restarted smoothly as the direction of rotation is detected.
- •You can select whether to make rotation direction detection or not with Pr. 299 Rotation direction detection selection at restarting.

When capacities of the motor and inverter differ, set "0" (without rotation direction detection) in Pr. 299.

Pr. 299 Setting	Pr. 78 Setting			
Fr. 299 Setting	0	1	2	
9999	0	×	×	
0 (initial value)	×	×	×	
1	0	0	0	

O: the rotation direction is detected.

• REMARKS

- · Speed detection time (frequency search) changes according to the motor speed. (maximum 100ms)
- When the inverter capacity is two rank or more larger than the motor capacity, the inverter may not start due to overcurrent trip (E.OC□).
- · If two or more motors are connected to one inverter, the function does not operate properly. (The inverter does not start smoothly.)
- When reverse rotation is detected under the condition of Pr. 78 = "1" (reverse rotation disabled), the rotation direction is changed to forward rotation after decelerates in reverse rotation when the start command is forward rotation. The inverter will not start when the start command is reverse rotation.

x: the rotation direction is not detected.





NOTE

- When automatic restart operation after instantaneous power failure is activated while the motor is running at a low speed (less than 10Hz), the motor restarts in the direction prior to instantaneous power failure without detecting the rotation direction (*Pr. 299 Rotation direction detection selection at restarting* = "1").
- If the frequency search result exceeds the set frequency, the output frequency is limited at the set frequency.
- When the wiring length exceeds below, select without frequency search (Pr. 162 = "1, 11").

Motor capacity	0.1K	0.2K	0.4K or more
Wiring length	20m	50m	100m

Restart operation at every start

When Pr. 162 = "10 or 11", automatic restart operation is also performed every start, in addition to the automatic restart after instantaneous power failure. When Pr. 162 = "0", automatic restart operation is performed at the first start after power supply ON, but not performed at the second time or later.

● Automatic restart operation selection of MRS (X10) signal (When Pr. 162 = "0, 1")

Restart operation after turning MRS (X10) signal ON then OFF using Pr.~30 can be selected as in the table below. When automatic restart after instantaneous power failure is selected while using the high power factor converter (FR-HC), normally set "2" in Pr.~30.

Pr. 30 Setting	Operation after MRS and X10 Signal Turns OFF, ON, then OFF.		
0, 1	Start at the Pr. 13 Starting frequency.		
2	Restart operation (Starts at the coasting speed)		



REMARKS

When output is shut off using terminal S1 and S2, the inverter restarts in the same way as when output is shut off by MRS (X10) signal.

(2) Restart coasting time (Pr. 57)

- •Coasting time is the time from when the motor speed is detected until automatic restart control is started.
- •Set Pr. 57 to "0" to perform automatic restart operation.

The coasting time is automatically set to the value below. Generally this setting will pose no problems.

1.5K or less 1s


2.2K to 7.5K 2s

11K and 15K 3s

•Operation may not be performed well depending on the magnitude of the moment of inertia (J) of the load or running frequency. Adjust the coasting time between 0.1s and 5s according to the load specifications.

(3) Restart cushion time (Pr. 58)

- Cushion time is the length of time taken to raise the voltage appropriate to detected motor speed (output frequency prior to instantaneous power failure when Pr. 162 = "1, 11") from OV.
- •Normally the initial value need not be changed for operation, but adjust it according to the magnitude of the moment of inertia (J) of the load or torque.



(4) Automatic restart operation adjustment (Pr. 165, Pr. 611)

- •Using *Pr. 165*, you can set the stall prevention operation level at a restart.
- •Using *Pr. 611*, you can set the acceleration time until *Pr. 20 Acceleration/deceleration reference frequency* is reached when automatic restart operation is performed besides the normal acceleration time.

(5) Frequency search gain (Pr. 298), offline auto tuning (Pr. 96)

- •When automatic restart after instantaneous power failure operation (with frequency search) is valid at V/F control, perform offline auto tuning.
- •Perform offline auto tuning during V/F control in the following order to set *Pr. 298 Frequency search gain* automatically. (Refer to *page 106* during General-purpose magnetic flux vector control.)

Before performing offline auto tuning

Check the following before performing offline auto tuning.

- •The inverter is under V/F control
- •A motor should be connected. Note that the motor should be at a stop at a tuning start.
- •The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity is 0.1kW or more)
- •A high-slip motor, high-speed motor and special motor cannot be tuned. (The maximum frequency is 120Hz.)
- •The motor may run slightly. Therefore, fix the motor securely with a mechanical brake, or before tuning, make sure that there will be no problem in safety if the motor runs (caution is required especially in vertical lift applications). Note that tuning performance is unaffected even if the motor runs slightly.
- •Offline auto tuning will not be performed properly if it is performed with a surge voltage suppression filter (FR-ASF-H, FR-BMF-H) connected between the inverter and motor. Remove it before starting tuning.

Setting

- 1) Set "21" in *Pr. 96 Auto tuning setting/status*. Tuning is performed without motor running.
- 2) Set the rated motor current (initial value is rated inverter current) in Pr. 9 Electronic thermal O/L relay. (Refer to page 101)
- 3) Set Pr. 71 Applied motor according to the motor used.

Motor	Pr.71 Setting *1	
	SF-JR	3
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	23
Mitsubishi high efficiency motor	SF-HR	43
	Others	3
Mitsubishi constant-torque	SF-JRCA 4P	13
motor	SF-HRCA	53
motor	Others (SF-JRC, etc.)	13
Other manufacturer's standard motor	_	3
Other manufacturer's constant- torque motor	_	13

^{*1} Refer to page 104, for other settings of Pr. 71.

Execution of tuning



POINT

Before performing tuning, check the monitor display of the operation panel or parameter unit (FR-PU04/FR-PU07) if the inverter is in the status for tuning. (Refer to 2) below)

1) When performing PU operation, press (RUN) of the operation panel.

For External operation, turn ON the start command (STF signal or STR signal). Tuning starts. (Excitation noise is produced during tuning.)



NOTE

- To force tuning to end, use the MRS or RES signal or press (STOP) of the operation panel. (Turning the start signal (STF signal or STR signal) OFF also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid: (initial value)
 - •Input terminal <Valid signal> STF, STR
 - Output terminal RUN, FM, A, B, C

Note that the progress status of offline auto tuning is output in five steps from FM when speed and output frequency are selected.

- Since the RUN signal turns ON when tuning is started, caution is required especially when a sequence which releases a mechanical brake by the RUN signal has been designed.
- When executing offline auto tuning, input the run command after switching ON the main circuit power (R/L1, S/L2, T/ L3) of the inverter.
- Do not perform ON/OFF switching of the second function selection signal (RT) during execution of offline auto tuning. Auto tuning is not executed properly.
- 2) Monitor is displayed on the operation panel and parameter unit (FR-PU04, FR-PU07) during tuning as below.

	Parameter Unit (FR-PU04, FR-PU07)	Operation Panel Indication
Pr. 96 setting	21	21
(1) Setting	READ:List 21 STOP PU	21 = 2
(2) Tuning in progress	TUNE 22 STFFWD PU	22 RUN MON
(3) Normal end	TUNE 23 COMPLETION STF STOP PU	Flickering
(4) Error end (when inverter protective function operation is activated)		9 <u>mm mon</u>



• REMARKS

It takes approximately 9s until tuning is completed.

3) When offline auto tuning ends, press (STOP) of the operation panel during PU operation. For External operation, turn OFF the start signal (STF signal or STR signal) once.

This operation resets the offline auto tuning and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)

7/

4) If offline auto tuning ended in error (see the table below), frequency search gain are not set. Perform an inverter reset and restart tuning.

Error Display	Error Cause	Remedy
8	Forced end	Set "21" in Pr. 96 and perform tuning again.
9	Inverter protective function operation	Make setting again.
91	Current limit (stall prevention) function was activated.	Set "1" in <i>Pr. 156</i> .
92	Converter output voltage reached 75% of rated value.	Check for fluctuation of power supply voltage.
Calculation error		Check the motor wiring and make setting again.
33	A motor is not connected.	Set the rated current of the motor in Pr. 9.

- 5) When tuning is ended forcibly by pressing (STP) or turning OFF the start signal (STF or STR) during tuning, offline auto tuning does not end properly. (The frequency search gain have not been set.)

 Perform an inverter reset and restart tuning.
- 6) When using the motor corresponding to the following specifications and conditions, reset *Pr.9 Electronic thermal O/L relay* as below after tuning is completed.
 - a) When the rated power specifications of the motor is 200/220V(400/440V) 60Hz, set 1.1 times rated motor current value in Pr 9.
 - b) When performing motor protection from overheat using a PTC thermistor or motor with temperature detector such as Klixon, set "0" (motor overheat protection by the inverter is invalid) in Pr.9.



NOTE

- The frequency search gain measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again.
- An instantaneous power failure occurring during tuning will result in a tuning error.
 After power is restored, the inverter goes into the normal operation mode. Therefore, when STF (STR) signal is ON, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the ordinary mode. Note that if a fault retry has been set, retry is
 ignored.
- · The set frequency monitor displayed during the offline auto tuning is 0Hz.
- Changing the terminal assignment using *Pr.178 to Pr.182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.
- The SU and FU signals are not output during a restart. These are output after the restart cushion time has elapsed.
- Automatic restart operation will also be performed after a reset or when a retry is made by the retry function.



(1) When automatic restart after instantaneous power failure has been selected, the motor and machine will start suddenly (after the reset time has elapsed) after occurrence of an instantaneous power failure.

Stay away from the motor and machine.

When you have selected automatic restart after instantaneous power failure function, apply in easily visible places the CAUTION stickers supplied to the Instruction Manual (Basic).

When the start signal is turned OFF or (RESE) is pressed during the restart cushion time after instantaneous power failure, deceleration starts after *Pr. 58 Restart cushion time* has elapsed.



Parameters referred to

Pr. 7 Acceleration time Refer to page 97
Pr. 13 Starting frequency Refer to page 99
Pr. 65, Pr. 67 to Pr. 69 Retry function Refer to page 145
Pr. 71 Applied motor Refer to page 104
Pr. 78 Reverse rotation prevention selection Refer to page 163
Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114





4.12.2 Power-failure deceleration stop function (Pr. 261)

When a power failure or undervoltage occurs, the inverter can be decelerated to a stop or can be decelerated and reaccelerated to the set frequency.

Parameter	Name	Initial	Setting	Description
Number	Name	Value	Range	Description
			0	Coasts to stop. When undervoltage or power failure occurs, the inverter output is shut off.
261	ower failure stop	0	1	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop.
	Selection		2	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop. If power is restored during a power failure, the inverter accelerates again.

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)





(1) Parameter setting


•When Pr. 261 is set to "1 or 2", the inverter decelerates to a stop if an undervoltage or power failure occurs.

(2) Operation outline of deceleration to stop at power

•When undervoltage or power failure occurs, the output frequency is decreased and controlled so that the converter circuit (DC bus) voltage is constant and decreased to 0Hz to stop.

(3) Power failure stop function (Pr. 261 = "1")


•If power is restored during power failure deceleration, deceleration to a stop is continued and the inverter remains stopped. To restart, turn OFF the start signal once, then turn it ON again.



Turn OFF STF once to make acceleration again

REMARKS


- When automatic restart after instantaneous power failure is selected (Pr. 57 \neq "9999"), power failure stop function is made invalid and automatic restart operation after instantaneous power failure is valid.
 - When the power failure deceleration stop function is active (Pr. 261 = "1"), the inverter will not start even if the power is turned ON with the start signal (STF/STR) ON. After switching ON the power, turn OFF the start signal once and then ON again to make a start.




7/

(4) Operation continuation at instantaneous power failure function (Pr. 261 = "2")

- •When power is restored during deceleration after a power failure, acceleration is made again up to the set frequency.
- •When this function is used in combination with the automatic restart after instantaneous power failure function($Pr.57 \neq$ "9999"), deceleration can be made at a power failure and acceleration can be made again after power restoration.







NOTE

When operation continuation at instantaneous power failure function is used, keep the starting signal (STF/STR) ON
even during instantaneous power failure. If the starting signal turns OFF during instantaneous power failure, the
inverter decelerates according to the deceleration time setting, causing the motor to coast if enough regenerative
energy is not obtained.

(5) Power failure deceleration signal (Y46 signal)

- •The Y46 signal is ON during deceleration at an instantaneous power failure or during a stop after deceleration at an instantaneous power failure.
- •After a power failure stop, the inverter can not start even if power is restored and the start command is given. In this case, check the power failure deceleration signal (Y46 signal). (at occurrence of input phase loss (E.ILF), etc.)
- •For the Y46 signal, set "46 (forward operation)" or "146 (reverse operation)" to *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)* to assign the function.



> REMARKS

During a stop or trip, the power failure stop selection is not performed.



NOTE

• Changing the terminal assignment using *Pr. 190, Pr. 192, Pr. 197 (output terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.



Even if the power failure stop function is valid, some loads may cause the inverter to trip and the motor to coast.

The motor will coast if enough regenerative energy is not given from the motor to the inverter.



Parameters referred to

Pr. 57 Restart coasting time Refer to page 137
Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120



4.13 Operation setting at fault occurrence


Purpose	Parameter th	Refer to Page	
Recover by retry operation at fault occurrence	Retry operation	Pr. 65, Pr. 67 to Pr. 69	145
Do not output input/output phase failure alarm	Input/output phase failure protection selection	Pr. 251, Pr. 872	147

4.13.1 Retry function (Pr. 65, Pr. 67 to Pr. 69)


If a fault occurs, the inverter resets itself automatically to restart. You can also select the fault for a retry. When you have selected automatic restart after instantaneous power failure ($Pr. 57 Restart coasting time \neq 9999$), restart operation is performed at the retry operation time which is the same of that of a power failure. (Refer to page 137 for the restart function.)

Parameter Number	Name	Initial Value	Setting Range	Description
65	Retry selection	0	0 to 5	A fault for retry can be selected. (Refer to the next page)
			0	No retry function
		1 to 10	Set the number of retries at fault occurrence.	
67	Number of retries at fault	0	1 10 10	A fault output is not provided during retry operation.
01	occurrence		101 to 110	Set the number of retries at fault occurrence. (The setting
				value of minus 100 is the number of retries.)
				A fault output is provided during retry operation.
68	Detro weiting time		0.1 to 600o	Set the waiting time from when an inverter fault occurs
00	Retry waiting time	1s	0.1 to 600s	until a retry is made.
69	Retry count display erase	0	0	Clear the number of restarts succeeded by retry.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



Retry failure example



- Retry operation automatically resets a fault and restarts the inverter at the starting frequency when the time set in *Pr.* 68 elapses after the inverter is tripped.
- Retry operation is performed by setting *Pr.67* to any value other than "0". Set the number of retries at fault occurrence in *Pr. 67*.
- When retries fail consecutively equal to or more than the number of times set in *Pr. 67*, a retry count excess fault (E.RET) occurs, resulting in inverter trip. (Refer to retry failure example)
- Use *Pr.* 68 to set the waiting time from when the inverter trips until a retry is made in the range of 0.1 to 600s.
- Reading the Pr. 69 value provides the cumulative number of successful restart times made by retry.
 The cumulative count in Pr. 69 is increased by 1 when a retry is regarded as successful after normal operation continues without faults occurring for more than four times longer than the time set in Pr. 68 after a retry start.
 (When retry is successful, cumulative number of retry failure is cleared.)
- Writing "0" to Pr. 69 clears the cumulative count.
- During a retry, the Y64 signal is ON. For the Y64 signal, assign the function by setting "64 (positive operation)" or "164 (negative operation)" to *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)*.

- 7/
- Using *Pr.* 65, you can select the fault that will cause a retry to be executed. No retry will be made for the fault not indicated. (*Refer to page 258* for the fault description.)
 - indicates the faults selected for retry.

Fault for		Pr. 65 Setting				
Retry	0	1	2	3	4	5
E.OC1	•	•		•	•	•
E.OC2	•	•		•	•	
E.OC3	•	•		•	•	•
E.OV1	•		•	•	•	
E.OV2	•		•	•	•	
E.OV3	•		•	•	•	
E.THM	•					
E.THT	•					
E. BE	•				•	
E. GF	•				•	
E.OHT	•					

Fault for		Pr. 65 Setting				
Retry	0	1	2	3	4	5
E.PTC	•					
E.OLT	•				•	
E. PE	•				•	
E.ILF	•				•	
E.CDO	•				•	



NOTE

- When terminal assignment is changed using *Pr. 190, Pr. 192, Pr. 197*, the other functions may be affected. Make setting after confirming the function of each terminal.
- The data stored as the error reset for retry is only that of the fault which occurred the first time.
- When an inverter fault is reset by the retry function at the retry time, the accumulated data of the electronic thermal relay function, regeneration brake duty etc. are not cleared. (Different from the power-ON reset.)
- Retry is not performed if E.PE (Parameter storage device fault) occurred at power ON.
- If a fault that is not selected for a retry occurs during retry operation (retry waiting time), the retry operation stops while the fault indication is still displayed.



When you have selected the retry function, stay away from the motor and machine in the case of the inverter is tripped. The motor and machine will start suddenly (after the reset time has elapsed) after the inverter trip. When you have selected the retry function, apply in easily visible places the CAUTION stickers supplied to the Instruction Manual (Basic).



Parameters referred to

Pr. 57 Restart coasting time (Refer to page 137)



4.13.2 Input/output phase loss protection selection (Pr. 251, Pr. 872)

You can choose whether to make Input/output phase loss protection valid or invalid.

- Output phase loss protection is a function to stop the inverter output if one of the three phases (U, V, W) on the inverter's output side is lost.
- Input phase loss protection is a function to stop the inverter output if one of the three phases (R/L1, S/L2, T/L3) on the inverter's input side is lost.

Parameter Number	Name	Initial Value	Setting Range	Description
254	Output phase loss	4	0	Without output phase loss protection
251 protect	protection selection	1	1	With output phase loss protection
070	Input phase loss protection	0	0	Without input phase loss protection
872 *	selection	0	1	With input phase loss protection

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Output phase loss protection selection (Pr. 251)

- If phase loss occurs during inverter operation (except for during DC brake operation, or output frequency is 1Hz or less), output phase loss protection (E.LF) activates, and inverter trips.
- When Pr. 251 is set to "0", output phase loss protection (E.LF) becomes invalid.

(2) Input phase loss protection selection (Pr. 872)

• When *Pr.* 872 is set to "1", input phase loss protection (E.ILF) is provided if a phase loss of one phase among the three phases is detected for 1s continuously.



NOTE

- If an input phase loss continues for a long time, the converter section and capacitor lives of the inverter will be shorter
- If the load is light or during a stop, lost phase cannot be detected because detection is performed based on the fluctuation of bus voltage. Large unbalanced phase-to-phase voltage of the three-phase power supply may also cause input phase loss protection (E.ILF).
- Phase loss can not be detected during regeneration load operation.
- If parameter copy is performed from single-phase power input model to three-phase power input model, *Pr. 872* setting may be changed. Check *Pr. 872* setting after parameter copy.

4.13.3 Earth (ground) fault detection at start (Pr. 249)

You can choose whether to make earth (ground) fault detection at start valid or invalid. Earth (Ground) fault detection is executed only right after the start signal is input to the inverter.

Protective function will not activate if an earth (ground) fault occurs during operation.

Parameter Number	Name	Initial Value	Setting Range	Description
249	Earth (ground) fault	0	0	Without earth (ground) fault detection
	detection at start		1	With earth (ground) fault detection

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



NOTE

- As detection is executed at start, output is delayed for approx. 20ms every start.
- If an earth (ground) fault is detected with "1" set in *Pr. 249*, output side earth (ground) fault overcurrent (E.GF) is detected and the inverter trips. (*Refer to page 264*)
- If the motor capacity is smaller than the inverter capacity when using the 5.5K or more, earth (ground) fault detection may not be provided.

^{*} Available only for the three-phase power input specification model.

4.14 Energy saving operation

Purpose	Parameter th	Refer to Page	
Energy saving operation	Optimum excitation control	Pr. 60	148

4.14.1 Optimum excitation control (Pr. 60)

Without a fine parameter setting, the inverter automatically performs energy saving operation. This operation is optimum for fan and pump applications

Parameter Number	Name	Initial Value	Setting Range	Description
60	Energy saving control	0	0	Normal operation mode
60	selection *	U	9	Optimum excitation control mode

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Optimum excitation control mode (setting "9")

- •When "9" is set in Pr. 60, the inverter operates in the Optimum excitation control mode.
- •The Optimum excitation control mode is a control system which controls excitation current to improve the motor efficiency to maximum and determines output voltage as an energy saving method.

• REMARKS

• When the motor capacity is too small as compared to the inverter capacity or two or more motors are connected to one inverter, the energy saving effect is not expected.



NOTE

- When the Optimum excitation control mode is selected, deceleration time may be longer than the setting value. Since
 overvoltage alarm tends to occur as compared to the constant-torque load characteristics, set a longer deceleration
 time.
- Optimum excitation control functions only under V/F control. Optimum excitation control does not function under General-purpose magnetic flux vector control.
- · Optimum excitation control will not be performed during an automatic restart after instantaneous power failure.
- · Since output voltage is controlled by Optimum excitation control, output current may slightly increase.



Parameters referred to

General-purpose magnetic flux vector control Refer to page 76

Pr. 57 Restart coasting time Refer to page 137

^{*} When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.



4.15 Motor noise, EMI measures, mechanical resonance

Purpose of Use	Parameter that	Refer to Page	
Reduction of the motor noise Measures against EMI and leakage currents	Carrier frequency and Soft-PWM selection	Pr. 72, Pr. 240, Pr. 260	149
Reduce mechanical resonance	Speed smoothing control	Pr. 653	150

4.15.1 PWM carrier frequency and Soft-PWM control (Pr. 72, Pr. 240, Pr. 260)

You can change the motor sound.

Parameter Number	Name	Initial Value	Setting Range	Description
72 *	PWM frequency selection	1	0 to 15	You can change the PWM carrier frequency. The setting is in [kHz]. Note that 0 indicates 0.7kHz and 15 indicates 14.5kHz.
240 *	Soft-PWM operation	_	0	Soft-PWM is invalid
240 *	selection	'	1	When $Pr. 72 = "0 to 5"$, Soft-PWM is valid.
260	PWM frequency		0	PWM carrier frequency is constant independently of load.
260	automatic switchover	0	1	Decreases PWM carrier frequency automatically when load increases.

The above parameters can be set when Pr.160 Extended function display selection = "0". (Refer to page 163)

(1) PWM carrier frequency changing (Pr. 72)

- •You can change the PWM carrier frequency of the inverter.
- •Changing the PWM carrier frequency produces an effect on avoiding the resonance frequency of a mechanical system or motor or on EMI measures or on leakage current reduction caused by the PWM switching.

(2) Soft-PWM control (Pr. 240)

•Soft-PWM control is a control method that changes the motor noise from a metallic tone into an unoffending complex tone.

(3) PWM carrier frequency automatic reduction function (Pr. 260)

- •When *Pr. 260* = "0" (initial value), the carrier frequency becomes constant (*Pr. 72* setting) independently of the load, making the motor sound uniform.
- •When continuous operation is performed at 85% or more of the inverter rated current with the carrier frequency of the inverter set to 3kHz or more ($Pr.72 \ge "3"$) while Pr.260 = "1", the carrier frequency is automatically reduced to 2kHz to avoid E.THT (inverter overload shutoff). (Motor noise increases, but it is not a failure.)



NOTE

- Decreasing the PWM carrier frequency affects on EMI measures and on leakage current reduction, but increases motor noise.
- When PWM carrier frequency is set to 1kHz or less ($Pr.72 \le 1$), fast response current limit may function prior to stall prevention operation due to increase in ripple currents, resulting in insufficient torque. In such case, set fast-response current limit operation invalid using Pr. 156 Stall prevention operation selection.



Parameters referred to

Pr. 156 Stall prevention operation selection Refer to page 80

^{*} The parameters in the table allow its setting to be changed during operation even if "0" (initial value) is set in Pr. 77 Parameter write selection.


4.15.2 Speed smoothing control (Pr. 653)

Vibration due to mechanical resonance influences the inverter control, causing the output current (torque) unstable. In this case, the output current (torque) fluctuation can be reduced to ease vibration by changing the output frequency.

Parameter Number	Name	Initial Value	Setting Range	Description
653	Speed smoothing control	0	0 to 200%	Increase or decrease the value using 100% as reference to check an effect.

The above parameter can be set when Pr.160 Extended function display selection = "0". (Refer to page 163)

(1) Control block diagram



(2) Setting method

If vibration due to mechanical resonance occurs, set 100% in *Pr. 653*, run the inverter at the frequency which generates maximum vibration and check if the vibration will be reduced or not after several seconds.

If effect is not produced, gradually increase the Pr. 653 setting and check the effect repeatedly until the most effective value is set in Pr. 653.

If vibration becomes large by increasing the Pr. 653 setting, gradually decrease the Pr. 653 setting than 100% to check the effect in a similar manner.



NOTE

Depending on the machine, vibration may not be reduced enough or an effect may not be produced.



4.16 Frequency setting by analog input (terminal 2, 4)

Purpose	Parameter tha	t should be Set	Refer to Page
Selection of voltage/current input			
(terminal 2, 4)	Analas innut calcation	D., 72 D., 207	151
Perform forward/reverse rotation by	Analog input selection	Pr. 73, Pr. 267	151
analog input.			
Adjustment (calibration) of analog	Bias and gain of frequency	Pr. 125, Pr. 126, Pr. 241,	154
input frequency and voltage (current)	setting voltage (current)	C2 to C7 (Pr. 902 to Pr. 905)	154

4.16.1 Analog input selection (Pr. 73, Pr. 267)

You can select the function that switches between forward rotation and reverse rotation according to the analog input terminal specifications and input signal.

Parameter	Name	Initial Value	Setting	Description		
Number	Nume	ilitiai value	Range	50	Bescription	
			0	Terminal 2 input 0 to 10V	Without reversible operation	
73	Analog input selection	1	1	Terminal 2 input 0 to 5V	Without reversible operation	
73	Analog input selection	'	10	Terminal 2 input 0 to 10V	With reversible operation	
			11	Terminal 2 input 0 to 5V	Will reversible operation	
				Voltage/current input		
				switch	Description	
267	Terminal 4 input	0	0	VII	Terminal 4 input 4 to 20mA	
			1		Terminal 4 input 0 to 5V	
			2	V I	Terminal 4 input 0 to 10V	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Selection of analog input specifications

- •For the terminal 2 for analog voltage input, 0 to 5V (initial value) or 0 to 10V can be selected.
- Either voltage input (0 to 5V, 0 to 10V) or current input (4 to 20mA initial value) can be selected for terminal 4 used for analog input.

Change the input specifications to change Pr. 267 and voltage/current input switch.

· Rated specifications of terminal 4 change according to the voltage/current input switch setting.


Voltage input: Input resistance $10k\Omega \pm 1k\Omega$,

Maximum permissible input voltage


20VDC

Current input: Input resistance $233\Omega \pm 5\Omega$,

Maximum permissible input voltage 30mA







151



Set Pr. 267 and a voltage/current input switch correctly, then input an analog signal in accordance with the setting. Incorrect setting as in the table below could cause component damage. Incorrect settings other than below can cause abnormal operation.

Setting Causing Component Damage		Operation	
Switch setting Terminal input		Operation	
		This could cause component damage to the analog signal output circuit of	
I (current input)	Voltage input	signal output devices.	
		(electrical load in the analog signal output circuit of signal output devices increases)	
V (voltage input) Current input		This could cause component damage of the inverter signal input circuit.	
v (voitage iriput)	Current input	(output power in the analog signal output circuit of signal output devices increases)	

•Refer to the following table and set Pr. 73 and Pr. 267.

indicates main speed setting)


Pr. 73	Terminal 2	Terminal 4 Input		Reversible
Setting	Input	AU signal		Operation
0	0 to 10V			
1	0 to 5V			Not function
(initial value)	0 10 0 1	OFF	_	
10	0 to 10V			Yes
11	0 to 5V			103
0			According to the Pr. 267 setting	
1	_		0:4 to 20mA (initial value)	Not function
(initial value)		ON	1:0 to 5V	
10				Yes
11	_ _		2:0 to 10V	100

•The terminal used for the AU signal input, set "4" in Pr. 178 to Pr. 182 (input terminal function selection) to assign functions.




NOTE

- Turn the AU signal ON to make terminal 4 valid.
- Make sure that the parameter and switch settings are the same. Different setting may cause a fault, failure or
- Use Pr. 125 (Pr. 126) (frequency setting gain) to change the maximum output frequency at input of the maximum output frequency command voltage (current). At this time, the command voltage (current) need not be input. Also, the acceleration/deceleration time, which is a slope up/down to the acceleration/deceleration reference frequency, is not affected by the change in Pr. 73 setting.
- When Pr. 561 PTC thermistor protection level ≠"9999", terminal 2 is not available for analog frequency command.
- Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Connection diagram using terminal 2 (0 to 5VDC)



Connection diagram using terminal 2 (0 to 10VDC)

(2) Perform operation by analog input selection


- The frequency setting signal inputs 0 to 5VDC (or 0 to 10VDC) across the terminals 2-5. The 5V (10V) input is the maximum output.
- •The power supply 5V can be input by either using the internal power supply or preparing an external power supply. Prepare an external power supply to input the power supply 10V. For the built-in power supply, terminals 10-5 provide 5VDC output.

Terminal	Inverter Built-in	Frequency	Pr.73
	Power Supply	Setting	(terminal 2 input
	Voltage	Resolution	power)
10	5VDC	0.12Hz/60Hz	0 to 5VDC input

- •When inputting 10VDC to the terminal 2, set "0" or "10" in Pr. 73. (The initial value is 0 to 5V)
- Setting "1 (0 to 5VDC)" or "2 (0 to 10VDC)" in Pr. 267 and a voltage/ current input switch in the "V" position changes the terminal 4 to the voltage input specification. When the AU signal turns ON, the terminal 4 input becomes valid.

• REMARKS


The wiring length of the terminal 10, 2, 5 should be 30m at maximum.



(3) Perform operation by analog input selection

- •When the pressure or temperature is controlled constantly by a fan, pump, etc., automatic operation can be performed by inputting the output signal 4 to 20mADC of the adjuster across the terminals 4-5.
- •The AU signal must be turned ON to use the terminal 4.

Connection diagram using terminal 4 (4 to 20mADC)



Reversible operation example

(4) Perform forward/reverse rotation by analog input (polarity reversible operation)

•Setting "10" or "11" in *Pr. 73* and adjusting *Pr. 125* (*Pr. 126*) *Terminal 2* frequency setting gain frequency (Terminal 4 frequency setting gain frequency) and *C2* (*Pr. 902*) *Terminal 2 frequency setting bias frequency* to *C7* (*Pr.905*) *Terminal 4 frequency setting gain* makes reverse operation by terminal 2 (terminal 4) valid.

Example)When performing reversible operation by terminal 2 (0 to 5V) input

- 1) Set "11" in *Pr. 73* to make reversible operation valid. Set frequency at maximum analog input in *Pr. 125 (Pr. 903)*
- 2) Set 1/2 of the value set in C4 (Pr. 903) in C3 (Pr. 902).
- 3) Reversible operation is performed when 0 to 2.5VDC is input and forward rotation when 2.5 to 5VDC.



NOTE

- When reversible operation is set, be aware of reverse rotation operation when analog input stops (only the start signal is input).
- When reversible operation is valid, reversible operation (0 to 4mA: reverse operation, 4mA to 20mA: forward operation) is performed by terminal 4 in the initial setting.



Parameters referred to

Pr. 125 Terminal 2 frequency setting gain frequency, Pr. 126 Terminal 4 frequency setting gain frequency Refer to page 154
Pr. 561 PTC thermistor protection level Refer to page 101
C2 (Pr. 902) Terminal 2 frequency setting bias frequency to C7 (Pr. 905) Terminal 4 frequency setting gain Refer to page 154

4.16.2 Response level of analog input and noise elimination (Pr. 74)

The time constant of the primary delay filter can be set for the external frequency command (analog input (terminal 2, 4) signal).

Parameter Number	Name	Initial Value	Setting Range	Description
74	Input filter time constant	1	0 to 8	Primary delay filter time constant for the analog input. A larger setting results in a larger filter.

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

- Valid for eliminating noise of the frequency setting circuit.
- Increase the filter time constant if steady operation cannot be performed due to noise.
 A larger setting results in slower response. (The time constant can be set between approximately 5ms to 1s with the setting of 0 to 8.)

4.16.3 Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))

You can set the magnitude (slope) of the output frequency as desired in relation to the frequency setting signal (0 to 5VDC, 0 to 10VDC or 4 to 20mADC).

Set Pr. 267 and voltage/current input switch to switch among 0 to 5VDC, 0 to 10VDC, and 0 to 20mADC input using terminal 4. (Refer to page 151)


[Frequency setting bias/gain parameter]


Parameter	Name	Initial	Setting	Description	
Number	Name	Value	Range	Description	
125	Terminal 2 frequency setting	60Hz	0 to 400Hz	Frequency of terminal 2 input gain (maximum).	
123	gain frequency	00112	0 10 400112	requerity of terminal 2 input gain (maximum).	
126	Terminal 4 frequency setting	60Hz	0 to 400Hz	Frequency of terminal 4 input gain (maximum).	
120	gain frequency	00112	0 10 400112	Trequency of terminal 4 input gain (maximum).	
241 *1, *3	Analog input display unit	0	0	Displayed in %	
241 *1, *3	switchover	U	1	Displayed in V/mA Unit for analog input display.	
C2 (902)	Terminal 2 frequency setting	0Hz	0 to 400Hz	Frequency on the bias side of terminal 2 input.	
*1, *2	bias frequency	0112	0 10 400112	r requericy on the bias side of terminal 2 input.	
C3 (902)	Terminal 2 frequency setting	0%	0 to 300%	Converted % of the bias side voltage (current) of	
*1, *2	bias	070	0 10 300%	terminal 2 input.	
C4 (903)	Terminal 2 frequency setting	100%	0 to 300%	Converted % of the gain side voltage (current) of	
*1, *2	gain	100%	0 10 300%	terminal 2 input.	
C5 (904)	Terminal 4 frequency setting	0Hz	0 to 400Hz	Frequency on the bias side of terminal 4 input.	
*1, *2	bias frequency	0112	0 10 400112	Frequency on the bias side of terminal 4 input.	
C6 (904)	Terminal 4 frequency setting	20%	0 to 300%	Converted % of the bias side current (voltage) of	
*1, *2	bias	20%	0 10 300%	terminal 4 input.	
C7 (905)	Terminal 4 frequency setting	100%	0 to 300%	Converted % of the gain side current (voltage) of	
*1, *2	gain	100%	0 10 300%	terminal 4 input.	

^{*1} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

^{*2} The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).

^{*3} The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.





(1) Change the frequency at maximum analog input (Pr. 125, Pr. 126)

•Set *Pr.* 125 (*Pr.* 126) when changing frequency setting (gain) of the maximum analog input voltage (current) only. (*C2* (*Pr.* 902) to *C7* (*Pr.*905) setting need not be changed)

(2) Analog input bias/gain calibration (C2 (Pr. 902) to C7 (Pr. 905))

- •The "bias" and "gain" functions are used to adjust the relationship between the input signal entered from outside the inverter to set the output frequency, e.g. 0 to 5VDC, 0 to 10VDC or 4 to 20mADC, and the output frequency.
- •Set the bias frequency of the terminal 2 input using *C2 (Pr. 902)*.

(It is initially set to the frequency at 0V)

- •Set the output frequency in *Pr. 125* for the frequency command voltage set with *Pr. 73 Analog input selection*
- •Set the bias frequency of the terminal 4 input using *C5* (*Pr.* 904).

(It is initially set to the frequency at 4mA)

- •Using *Pr. 126*, set the output frequency relative to 20mA of the frequency command current (4 to 20mA).
- •There are three methods to adjust the frequency setting voltage (current) bias/gain.
- a) Method to adjust any point by application of a voltage (current) across terminals 2-5 (4-5) ** page 156
- b) Method to adjust any point without application of a voltage (current) across terminals 2-5 (4-5)

 ## page 157
- c) Method to adjust frequency only without adjustment of voltage (current) ** page 158**



NOTE

• When voltage/current input signal for terminal 4 was switched using *Pr. 267* and voltage/current input switch, perform calibration without fail.

(3) Analog input display unit changing (Pr. 241)

- You can change the analog input display unit (%/V/mA) for analog input bias/gain calibration.
- Depending on the terminal input specification set to *Pr. 73*, *Pr. 267*, and voltage/current switch, the display units of *C3 (Pr. 902)*, *C4 (Pr. 903)*, *C6 (Pr. 904)*, *C7 (Pr. 905)* change as shown below.


Analog Command (terminal 2, 4) (depending on <i>Pr. 73, Pr. 267</i> , and voltage/current input switch)	<i>Pr. 241</i> = 0 (initial value)	<i>Pr. 241</i> = 1
0 to 5V input	0 to 5V → 0 to 100% (0.1%) display	0 to 100% → 0 to 5V (0.01V) display
0 to 10V input	0 to 10V → 0 to 100% (0.1%) display	0 to 100% → 0 to 10V (0.01V) display
0 to 20mA input	0 to 20mA → 0 to 100%(0.1%) display	0 to 100% → 0 to 20mA (0.01mA) display

(4) Frequency setting signal (current) bias/gain adjustment method

(a) Method to adjust any point by application of a voltage (current) across terminals 2-5 (4-5). Operation – Display -1. Confirm the RUN indication and operation mode indication The inverter should be at a stop. The inverter should be in the PU operation mode. (Using (PU PRM indication is lit. 2. Press (MODE) to choose the parameter setting mode. (The parameter number read previously appears.) 3. Turn (until [. . . 4. Turn (SET) until [- - - appears. C0 to C25 settings are enabled. 5. Turn (until (4 ([Set to C4 Terminal 2 frequency setting gain. Terminal 2 input is Terminal 4 input is

- 6. Press (SET) to display the analog voltage (current) value (%).
- 7. Apply a 5V (20mA) voltage (current). (Turn the external potentiometer connected across terminals 2-5 (across terminals 4-5) to maximum (any position).)







The value is nearly 100 (%) in the maximum position of the potentiometer.




8. Press (SET) to set.

After performing operation in step 6, do not touch until completion of calibration.




Terminal 2 input is selected





Flicker...Parameter setting complete!!

The value is nearly 100 (%) in the maximum position of the potentiometer.



- •Press (SET) to return to the [- indication (step 4).
- •Press (SET) twice to show the next parameter (Pr. []).

REMARKS


- If the frequency meter (display meter) connected across the terminals FM does not indicate exactly 60Hz, set the calibration parameter C0 FM terminal calibration. (Refer to page 135)
- If the gain and bias of frequency setting voltage (current) are too close, an error (٤ 3) may be displayed at setting.





(b) Method to adjust any point without application of a voltage (current) across terminals 2-5 (4-5) (To change from 4V (80%) to 5V (100%))

Operation -


- 1. Confirm the RUN indication and operation mode indication
 - The inverter should be at a stop.
 - The inverter should be in the PU operation mode.









5. Turn (の) until [ソ ([Set to C4 Terminal 2 frequency setting gain.











(The parameter number read previously appears.)











Analog voltage (current) value (%) across terminals 2-5 (across terminals 4-5)

The gain frequency is reached when the analog voltage (current) value across terminals 2-5 (across terminals 4-5) is 100%.



The current setting at the instant of turning

You can not check after performing operation in step 7.



8. Press(SET) to set.







Flicker...Parameter setting complete!!

(Adjustment completed)

- to read another parameter.
- •Press (SET) to return to the [- indication (step 4).
- •Press (SET) twice to show the next parameter (Pr.[].

(I) REMARKS

after step 6, you can confirm the current frequency setting bias/gain setting. You can not check after performing operation in step 7.

(c) Adjusting only the frequency without adjusting the gain voltage (current). (When changing the gain frequency from 60Hz to 50Hz)

Operation -

1. Turn until P. 125 (Pr. 125) or

P. 126 (Pr. 126) appears

2. Press (SET) to show the present set value. (60.00Hz)

3. Turn to change the set value to "5 [[[]] ". (50.00Hz)

4. Press (SET) to set.

Display











Terminal 2 input is selected

Terminal 4 input is selected



Flicker...Parameter setting complete!!

5. Mode/monitor check

Press (MODE) twice to choose the monitor/frequency monitor.

Apply a voltage across the inverter terminals 2-5 (across 4-5) and turn ON the start command (STF, STR).

Operation starts at 50Hz.







> REMARKS

- Changing C4 (Pr. 903) or C7 (Pr. 905) (gain adjustment) value will not change the Pr. 20 value.
- For operation from the parameter unit (FR-PU04/FR-PU07), refer to the Instruction Manual of the FR-PU04/FR-PU07.
- When setting the value to 120Hz or more, it is necessary to set *Pr. 18 High speed maximum frequency* to 120Hz or more. (Refer to page 84)
- Make the bias frequency setting using the calibration parameter C2 (Pr. 902) or C5 (Pr. 904). (Refer to page 155)
- Refer to page 244 to use the FR-E500 series operation panel (PA02).

⚠ CAUTION

⚠ Be cautious when setting any value other than "0" as the bias frequency at 0V (0mA). Even if a speed command is not given, merely turning ON the start signal will start the motor at the preset frequency.



Parameters referred to

Pr. 20 Acceleration/deceleration reference frequency Refer to page 97

Pr. 73 Analog input selection, Pr. 267 Terminal 4 input selection Refer to page 151

Pr. 79 Operation mode selection Refer to page 166

Bias and gain of built-in frequency setting potentiometer Refer to page 244



4.17 Misoperation prevention and parameter setting restriction

Purpose	Parameter that should	hat should be Set	
Limits reset function Trips when PU is disconnected Stops from PU	Reset selection/disconnected PU detection/PU stop selection	Pr. 75	159
Prevention of parameter rewrite	Parameter write disable selection	Pr. 77	162
Prevention of reverse rotation of the motor	Reverse rotation prevention selection	Pr. 78	163
Displays necessary parameters	Display of applied parameters	Pr. 160	163
Parameter restriction with using password	Password function	Pr. 296, Pr. 297	164
Control of parameter write by communication	EEPROM write selection	Pr. 342	188

4.17.1 Reset selection/disconnected PU detection/PU stop selection (Pr. 75)

You can select the reset input acceptance, disconnected PU (FR-PU04/FR-PU07) connector detection function and PU stop function.

Parameter Number	Name	Initial Value	Setting Range	Description
75	Reset selection/ disconnected PU detection/	14	0 to 3, 14 to 17	For the initial value, reset always enabled, without disconnected PU detection, and
	PU stop selection			with PU stop function.

[•]The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

[•]The Pr. 75 value can be set any time. Also, if parameter (all) clear is executed, this setting will not return to the initial value.

Pr. 75 Setting	Reset Selection	Disconnected PU Detection	PU Stop Selection
0	Reset input normally enabled	When the PU is disconnected,	
1	Reset input is enabled only when the fault occurs.	operation is continued.	Pressing (STOP) decelerates the motor
2	Reset input normally enabled	When the PU is disconnected, the	to a stop only in the PU operation
3	Reset input is enabled only when the fault occurs.	inverter trips.	mode.
14 (initial value)	Reset input normally enabled	When the PU is disconnected,	
15	Reset input is enabled only when the fault occurs.	operation is continued.	Pressing (STOP) decelerates the motor to a stop in any of the PU, external
16	Reset input normally enabled	When the PU is disconnected, the	, ,
17	Reset input is enabled only when the fault occurs.	inverter trips.	and communication operation modes.

(1) Reset selection

- •You can select the enable condition of reset function (RES signal, reset command through communication) input.
- •When Pr. 75 is set to any of "1, 3, 15, 17", a reset can be input only when the inverter is tripped.



NOTE

- When the reset signal (RES) is input during operation, the motor coasts since the inverter being reset shuts off the output.
- When reset is performed, cumulative values of electronic thermal O/L relay, and regenerative brake duty are cleared.
- The reset key of the PU is only valid when the inverter is tripped, independently of the Pr. 75 setting.

(2) Disconnected PU detection

- •This function detects that the PU (FR-PU04/FR-PU07) has been disconnected from the inverter for longer than 1s and causes the inverter to provide a fault output (E.PUE) and come to trip.
- •When Pr. 75 is set to any of "0, 1, 14, 15", operation is continued even if the PU is disconnected.

• REMARKS

- · When the PU has been disconnected since before power-ON, it is not judged as a fault.
- To make a restart, confirm that the PU is connected and then reset the inverter.
- The motor decelerates to a stop when the PU is disconnected during PU Jog operation with Pr. 75 set to any of "0, 1, 14, 15" (which selects operation to be continued if the PU is disconnected).
- When RS-485 communication operation is performed through the PU connector, the reset selection/PU stop selection function is valid but the disconnected PU detection function is invalid.

(3) PU stop selection

- •In any of the PU operation, External operation and Network operation modes, the motor can be stopped by pressing STOP key of the operation panel or parameter unit (FR-PU04/FR-PU07, operation panel for FR-E500 (PA02)).
- •When the inverter is stopped by the PU stop function, " 🗗 📮 " (PS) is displayed. A fault output is not provided.
- •After the motor is stopped from the PU, it is necessary to perform PU stop (PS) reset to restart. PS reset can be made from the unit from which PU stop is made (operation panel, parameter unit (FR-PU04/PU07, operation panel for FR-E500
- •The motor can be restarted by making PS cancel using a power supply reset or RES signal.
- •When Pr. 75 is set to any of "0 to 3", PU stop (PS display) is invalid, and deceleration to a stop by (STOP) is valid only in the PU operation mode.



> REMARKS

Speed


ON (STR) OFF

Operation panel

STF

During operation in the PU operation mode through RS-485 communication from the PU connector, the motor decelerates to stop (PU stop) when entered from the operation panel (STOP)

(4) How to restart the motor stopped by (STOP) input from the PU in External operation mode (PU stop (PS) reset method)



(PU) Key

Stop/restart example for External operation

Key

a) Operation panel

- 1)After completion of deceleration to a stop, switch OFF the STF or STR signal.
- 2)Press $\frac{PU}{EXT}$ to display $\frac{PU}{EXT}$ ($\frac{P}{5}$ reset)
- 3)Press $\frac{PU}{EXT}$ to return to EXT.
- 4) Switch ON the STF or STR signal.

b) Parameter unit (FR-PU04/FR-PU07)

- 1)After completion of deceleration to a stop, switch OFF the STF or STR signal.
- 2)Press EXT (**P** 5 reset)
- 3)Switch ON the STF or STR signal.
- •The motor can be restarted by making a reset using a power supply reset or RES signal.



> REMARKS

If Pr. 250 Stop selection is set to other than "9999" to select coasting to a stop, the motor will not be coasted to a stop but decelerated to a stop by the PU stop function during External operation.



(5) Restart (PS reset) method when PU stop (PS display) is made during PU operation

•PU stop (PS display) is made when the motor is stopped from the unit where control command source is not selected (operation panel, parameter unit (FR-PU04/FR-PU07, operation panel for FR-E500 (PA02)) in the PU operation mode. For example, when *Pr. 551 PU mode operation command source selection* = "9999" (initial value), the motor is stopped from

the PU (PS display) if entered from the operation panel (RESET) in PU operation mode with the parameter unit mounted.

When the motor is stopped from the PU while the parameter unit (FR-PU04/FR-PU07) is selected as control command source.

- 1) After the motor has decelerated to a stop, press (STOP) of the parameter unit (FR-PU04/FR-PU07).
- 2) Press $\frac{PU}{EXT}$ to display EXT .(P5 reset)
- 3) Press PU of the parameter unit (FR-PU04/FR-PU07) to select the PU operation mode.
- 4) Press FWD or REV of the parameter unit (FR-PU04/FR-PU07).

(I) REMARKS

• When Pr. 551 = "9999", the priorities of the PU control source is parameter unit (FR-PU04/FR-PU07) > operation panel.



⚠ Do not reset the inverter while the start signal is being input.

Otherwise, the motor will start instantly after resetting, leading to potentially hazardous conditions.



Parameters referred to

Pr. 250 Stop selection 🏵 Refer to page 113
Pr. 551 PU mode operation command source selection 🍽 Refer to page 177

4.17.2 Parameter write disable selection (Pr. 77)

You can select whether write to various parameters can be performed or not. Use this function to prevent parameter values from being rewritten by misoperation.

Parameter Number	Name	Initial Value	Setting Range	Description
	Parameter write selection	0	0	Write is enabled only during stop.
77			1	Parameter can not be written.
"			2	Parameter write is enabled in any operation
				mode regardless of operation status.

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Write parameters only during stop (setting "0" initial value)

- •Parameters can be written only during a stop in the PU operation mode.
- •The shaded parameters in the parameter list (page 58) can always be written regardless of the operation mode and operating status. However, Pr. 72 PWM frequency selection and Pr. 240 Soft-PWM operation selection can be written when the inverter is running in the PU operation mode, but cannot be written in the External operation mode.

(2) Inhibit parameter write (setting "1")

- •Parameter write is not enabled. (Read is enabled.)
- Parameter clear and all parameter clear cannot be performed, either.
- •The parameters given on the right can be written even if Pr. 77 = "1".

	Parameter Number	Name
Ī	22	Stall prevention operation level
75		Reset selection/disconnected PU detection/
•	75	PU stop selection
Ī	77	Parameter write selection
: [79	Operation mode selection
Ī	160	Extended function display selection
Ī	296	Password lock level
Ī	297	Password lock/unlock

(3) Write parameters during operation (setting "2")

- •Parameters can always be written.
- •The following parameters cannot be written when the inverter is running even if Pr: 77 = "2". Stop the inverter when changing their parameter settings.

Parameter	Name
Number	Name
23	Stall prevention operation level compensation
23	factor at double speed
40	RUN key rotation direction selection
48	Second stall prevention operation current
60	Energy saving control selection
66	Stall prevention operation reduction starting
00	frequency
71	Applied motor
79	Operation mode selection
80	Motor capacity
82	Motor excitation current
83	Rated motor voltage
84	Rated motor frequency
90	Motor constant (R1)

Parameter Number	Name
1101111001	
96	Auto tuning setting/status
178 to 182	(input terminal function selection)
190, 192, 197	(output terminal function selection)
255	Life alarm status display
256	Inrush current limit circuit life display
257	Control circuit capacitor life display
258	Main circuit capacitor life display
261	Power failure stop selection
298	Frequency search gain
343	Communication error count
450	Second applied motor
561	PTC thermistor protection level
563	Energization time carrying-over times
564	Operating time carrying-over times



Parameters referred to

Pr. 79 Operation mode selection 👺 Refer to page 166

Pr. 77 can be always set independently of the operation mode and operation status.



4.17.3 Reverse rotation prevention selection (Pr. 78)

This function can prevent reverse rotation fault resulting from the incorrect input of the start signal.

Parameter Number	Name	Initial Value	Setting Range	Description
	78 Reverse rotation prevention selection	0	0	Both forward and reverse rotations allowed
78			1	Reverse rotation disabled
			2	Forward rotation disabled

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

- Set this parameter when you want to limit the motor rotation to only one direction.
- This parameter is valid for all of the reverse rotation and forward rotation keys of the enclosure surface operation panel and of parameter unit (FR-PU04/FR-PU07), the start signals (STF, STR signals) via external terminals, and the forward and reverse rotation commands through communication.

4.17.4 Extended parameter display (Pr. 160)

Parameter which can be read from the operation panel and parameter unit can be restricted. In the initial setting, only the simple mode parameters are displayed.

Parameter Number	Name	Initial Value	Setting Range	Description
460	Extended function display	0000	9999	Displays only the simple mode parameters
160	selection	9999	0	Displays simple mode + extended parameters

(1) Display of simple mode parameters and extended parameters (Pr. 160)

- •When Pr. 160 = "9999"(initial value), only the simple mode parameters can be displayed on the operation panel and parameter unit (FR-PU04/FR-PU07). (Refer to the parameter list, page 58, for the simple mode parameters.)
- •When *Pr. 160* = "0", simple mode parameters and extended parameters can be displayed.

• REMARKS

- When RS-485 communication is used to read the parameters with *Pr. 551 PU mode operation command source selection* ≠ "2", all parameters can be read regardless of the *Pr. 160* setting.
- Pr. 15 Jog frequency, Pr. 16 Jog acceleration/deceleration time, and Pr. 991 PU contrast adjustment are displayed as simple mode parameter when the parameter unit (FR-PU04/FR-PU07) is fitted.



Parameters referred to

Pr. 15 Jog frequency Refer to page 92

Pr. 16 Jog acceleration/deceleration time Refer to page 92

Pr. 551 PU mode operation command source selection Refer to page 177

Pr. 991 PU contrast adjustment Refer to page 242

4.17.5 Password function (Pr. 296, Pr. 297)

Registering 4-digit password can restrict parameter reading/writing.

Parameter Number	Name	Initial Value	Setting Range	Description
296	Password lock level	9999	1 to 6, 101 to 106	Select restriction level of parameter reading/ writing when a password is registered.
230	1 assword look level	3000	9999	No password lock
		9999	1000 to 9998	Register a 4-digit password
				Displays password unlock error count. (Reading
297	Password lock/unlock		(0 to 5)	only)
				(Valid when Pr. 296 = "101" to "106")
			(9999)	No password lock (Reading only)

The above parameters can be set when Pr. 160 Extended function display selection = "0".

When $Pr.\ 296 \neq$ "9999" (with password lock), note that $Pr.\ 297$ is always available for setting regardless of $Pr.\ 160$ setting.

(1) Parameter reading/writing restriction level (Pr. 296)

•Level of reading/writing restriction by PU/NET mode operation command can be selected by Pr. 296.

Pr. 296 Setting	PU Mode Operat	ion Command *3	NET Mode Operation Command *4		
F1. 230 Setting	Read *1	Write *2	Read *1	Write *2	
9999	0	0	0	0	
1, 101	0	×	0	×	
2, 102	0	×	0	0	
3, 103	0	0	0	×	
4, 104	×	×	×	×	
5, 105	×	×	0	0	
6, 106	0	0	×	×	

O: enabled, x: restricted

- *1 If the parameter reading is restricted by the Pr. 160 setting, those parameters are unavailable for reading even when "O" is indicated.
- *2 If the parameter writing is restricted by the *Pr.* 77 setting, those parameters are unavailable for writing even when "O" is indicated.
- *3 Parameter access from unit where parameter is written in PU operation mode (initially set to operation panel, parameter unit) is restricted. (Refer to page 177 for PU mode operation command source selection)
- *4 Parameter access in NET operation mode with RS-485 communication is restricted.



(2) Password lock/unlock (Pr.296, Pr.297)

<Lock>

1) Set parameter reading/writing restriction level.(*Pr. 296* ≠ 9999)

Pr.296 Setting Value	Restriction of Password Unlock Error	<i>Pr.297</i> Display
1 to 6	No restriction	Always 0
101 to 106	Restricted at fifth error	Displays error count (0 to 5)

- * During [*Pr. 296* = "101 to 106"], if password unlock error has occurred 5 times, correct password will not unlock the restriction. Parameter all clear can unlock the restriction.
 - (In this case, parameter settings are cleared.)
- 2) Write four-digit numbers (1000 to 9998) in Pr. 297 as a password.

(When Pr. 296 = "9999", Pr. 297 cannot be written.)

When password is registered, parameter reading/writing is restricted with the restriction set level in Pr. 296 until unlocking.

(I) REMARKS

- After registering a password, a read value of Pr. 297 is always "0" to "5".
- When a password restricted parameter is read/written, 📙 📆 🗂 is displayed.
- Even if a password is registered, parameters which the inverter itself writes, such as inverter parts life, are overwritten as needed
- Even if a password is registered, Pr. 991 PU contrast adjustment can be read/written when a parameter unit (FR-PU04/FR-PU07) is connected.

<Unlock>

There are two ways of unlocking the password.

• Enter a password in Pr. 297.

Unlocked when a password is correct. If a password is incorrect, an error occurs and not unlocked.

During [Pr. 296] = "101 to 106"], if password unlock error has occurred 5 times, correct password will not unlock the restriction. (During password lock)

· Perform parameter all clear.

Password lock is unlocked. However, other parameter settings are cleared also.



NOTE

- If the password has been forgotten, perform parameter all clear to unlock the parameter restriction. In that case, other parameters are also cleared.
- Parameter all clear can not be performed during the operation.
- Do not use the FR Configurator under the conditions that parameter read is restricted (*Pr. 296* = "4, 5, 104, 105"). FR Configurator may not function properly.

(3) Parameter operation during password lock/unlock

Parameter operation		Unic	cked	Password registered	Locked
		Pr. 296 = 9999 Pr. 297 = 9999	Pr. 296 ≠ 9999 Pr. 297 = 9999	<i>Pr.</i> 296 ≠ 9999 <i>Pr.</i> 297 = 0 to 4 (Read value)	Pr. 296 = 101 to 106 Pr. 297 = 5 (Read value)
Pr. 296	Read	0 *1	0	0	0
Fr. 290	Write	0 *1	0 *1	×	×
Pr. 297	Read	0 *1	0	0	0
Fr. 297	Write	×	0	0	O *3
Performing parameter clear		0	0	×	×
Performing parameter all clear		0	0	O *2	O *2
Performing parameter copy		0	0	×	×

O: enabled, x: restricted

- *1 Reading/writing is unavailable when there is restriction to reading by the Pr. 160 setting.
- *2 Unavailable during the operation.
- *3 Correct password will not unlock the restriction.

REMARKS

- When Pr. 296 = "4, 5, 104, 105" and using the parameter unit (FR-PU04/FR-PU07), PUJOG operation is unavailable.
- When writing is restricted from PU mode operation command (*Pr. 296* = 1, 2, 4, 5, 101, 102, 104, 105), switching of operation mode by easy setting mode is unavailable.
- During password lock, parameter copy of the parameter unit (FR-PU07) cannot be performed.



Parameters referred to

Pr. 77 Parameter write selection Refer to page 162

Pr. 160 Extended function display selection Refer to page 163

Pr. 551 PU mode operation command source selection Refer to page 177

4.18 Selection of operation mode and operation location

Purpose	Parameter that should	Refer to Page	
Operation mode selection	Operation mode selection Pr. 79		166
Started in Network operation mode	Operation mode at power-on Pr. 79, Pr. 340		176
	Operation command source and		
Selection of operation location	speed command source during	Pr. 338, Pr. 339	177
Selection of operation location	communication operation, selection	Pr. 551	1//
	of operation location		

4.18.1 Operation mode selection (Pr. 79)


Used to select the operation mode of the inverter.

Mode can be changed as desired among operation using external command signals (External operation), operation from the operation panel and PU (FR-PU07/FR-PU04) (PU operation), combined operation of PU operation and External operation (External/PU combined operation), and Network operation (when RS-485 communication is used).

Parameter		Initial	Setting			LED Indication
Number	Name	Value	Range	Description		:OFF
Number		value	Range			□:ON
			0	Use External/PU switchover mode ((EXT)) to switch between the PU and External operation mode. At power ON, the inverter is in the External operation mode.		External operation mode EXT PU operation mode
			2	Fixed to PU operation mode		PU
				Fixed to External operation mode Operation can be performed by switching between the external and NET operation mode.		External operation mode EXT NET operation mode
				External/PU combined operation	mode 1	
		Operation mode 0 selection	3	Frequency command Operation panel and PU (FR-PU04/FR-PU07) setting or external signal input (multi-speed setting, across terminals 4-5 (valid when AU signal turns ON)). *	Start command External signal input (terminal STF, STR)	
79	-		6	External/PU combined operation mode 2		PU EXT
''				Frequency command	Start command	
				External signal input (terminal 2, 4, JOG, multi-speed selection, etc.)	Enter from RUN of the operation panel and FWD and REV of the PU (FR-PU04/FR-PU07)	
				Switchover mode Switchover among PU operation, External operation, and NET operation is available while keeping the same operation status.		PU operation mode External operation mode EXT NET operation mode
			7	External operation mode (PU operation interlock) X12 signal ON Operation mode can be switched to the PU operation mode. (output stop during External operation) X12 signal OFF Operation mode can not be switched to the PU operation mode.		PU operation mode PU External operation mode


The above parameter can be changed during a stop in any operation mode.

^{*} The priorities of the frequency commands when *Pr. 79* = "3" are "Multi-speed operation (RL/RM/RH/REX) > PID control (X14) > terminal 4 analog input (AU) > digital input from the operation panel".



(1) Operation mode basics


- The operation mode specifies the source of the start command and the frequency command for the inverter.
- · Basically, there are following operation modes.
 - · External operation mode: For inputting start command and frequency command with an external potentiometer and switches which are connected to the control circuit terminal.
 - · PU operation mode: For inputting start command and frequency command with the operation panel or parameter unit (FR-PU04 / FR-PU07).
 - · Network operation mode (NET operation mode): For inputting start command and frequency command with RS-485 communication through PU connector.
- The operation mode can be selected from the operation panel or with the communication instruction code.




REMARKS

- Either "3" or "4" may be set to select the PU/External combined mode. Refer to page 166 for details.
- The stop function (PU stop selection) activated by pressing (STOP) of the operation panel and parameter unit (FR-PU04/FR-PU07) is valid even in other than the PU operation mode in the initial setting. (Refer to Pr. 75 Reset selection/disconnected PU detection/PU stop selection (page 159))

(2) Operation mode switching method





• REMARKS

Pu operation external interlock signal (X12) Refer to page 172

Pu-External operation switch-over signal (X16) Refer to page 173


External-NET operation switchover signal (X65), NET-PU operation switchover signal (X66) Refer to page 174

Pr. 340 Communication startup mode selection Refer to page 176




(3) Operation mode selection flow

In the following flowchart, select the basic parameter setting and terminal connection related to the operation mode.



(4) External operation mode (setting "0" (initial value), "2")




- •Select the External operation mode when the start command and the frequency command are applied from a frequency setting potentiometer, start switch, etc. which are provided externally and connected to the control circuit terminals of the inverter.
- •Basically, parameter changing is disabled in the External operation mode. (Some parameters can be changed. Refer to *page 58* for the parameter list.)
- When "0 or 2" is selected for *Pr. 79*, the inverter enters the External operation mode at power-ON. (When using the Network operation mode, refer to *page 176*.)
- When parameter changing is seldom necessary, setting
 "2" fixes the operation mode to the External operation mode.

When frequent parameter changing is necessary, setting "0" (initial value) allows the operation mode to be changed easily to the PU operation mode by pressing

- PU operation mode, always return to the External operation mode.
- The STF and STR signal are used as a start command, and the voltage or current signal to terminal 2, 4, multispeed signal, JOG signal, etc. are used as a frequency commands.

(5) PU operation mode (setting "1")





Operation panel



- •Select the PU operation mode when applying start and frequency command by only the key operation of the operation panel (FR-PU04/FR-PU07). Also select the PU operation mode when making communication using the PU connector.
- •When "1" is selected for *Pr. 79*, the inverter enters the PU operation mode at power-ON. You cannot change to the other operation mode.
- •The setting dial of the operation panel can be used for setting like a potentiometer. (Refer to Pr. 161 Frequency setting/key lock operation selection (page 239))


(6) PU/External combined operation mode 1 (setting "3")





- •Select the PU/External combined operation mode 1 when applying frequency command from the operation panel or parameter unit (FR-PU04/FR-PU07) and inputting the start command with the external start switch.
- •Select "3" for *Pr. 79*. You cannot change to the other operation mode.
- •When a frequency is applied from the external signal by multi-speed setting, it has a higher priority than the frequency command from the PU. When AU is ON, the command signal to terminal 4 is used.

(7) PU/External combined operation mode 2 (setting "4")



- •Select the PU/External combined operation mode 2 when applying frequency command from the external potentiometer, multi-speed or JOG signal and inputting the start command by key operation of the operation panel or parameter unit (FR-PU04/FR-PU07).
- •Select "4" for *Pr.* 79. You cannot change to the other operation mode.

(8) Switchover mode (setting "6")

•While continuing operation, you can switch among the PU operation, External operation and Network operation (NET operation).

Operation Mode Switching	Switching Operation/Operating Status
External operation → PU operation	Select the PU operation mode with the operation panel or parameter unit. •Rotation direction is the same as that of External operation. •The frequency set with the potentiometer (frequency command) or like is used unchanged. (Note that the setting will disappear when power is switched OFF or the inverter is reset.)
External operation → NET operation	Send the mode change command to the Network operation mode through communication. •Rotation direction is the same as that of External operation. •The value set with the setting potentiometer (frequency command) or like is used unchanged. (Note that the setting will disappear when power is switched OFF or the inverter is reset.)
PU operation → External operation	Press the external operation key of the operation panel or parameter unit. •The rotation direction is determined by the input signal of the External operation. •The set frequency is determined by the external frequency command signal.
PU operation → NET operation	Send the mode change command to the Network operation mode through communication. •Rotation direction and set frequency are the same as those of PU operation.
NET operation → External operation	Send the mode change command to the External operation mode through communication. •The rotation direction is determined by the input signal of the External operation. •The set frequency is determined by the external frequency command signal.
NET operation → PU operation	Select the PU operation mode with the operation panel or parameter unit. •The rotation direction and frequency command in the Network operation mode are used unchanged.

(9) PU operation interlock (setting "7")

•The PU operation interlock function is designed to forcibly change the operation mode to the External operation mode when the PU operation interlock signal (X12) input turns OFF.

This function prevents the inverter from being inoperative by the external command if the mode is accidentally left unswitched from PU operation mode.

- •Set "7" (PU operation interlock) in Pr. 79.
- •For the terminal used for X12 signal (PU operation interlock signal) input, set "12" to any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the function. (Refer to *page 114* for *Pr.178 to Pr.182*.)
- •When the X12 signal is not assigned while MRS signal is assigned, function of the MRS signal switches from output stop to PU operation interlock signal.

X12 (MRS)	Function/Operation			
Signal	Operation Mode	Parameter Write		
	Operation mode (External, PU, NET) switching	Parameter write enabled (depending on Pr. 77 Parameter		
ON	enabled	write selection and each parameter write conditions		
	Output stop during External operation	(Refer to page 58 for the parameter list))		
	Forcibly switched to External operation mode			
OFF	External operation allowed	Parameter write disabled with exception of Pr. 79		
OFF	Switching between the PU and Network operation			
	mode is enabled			

<Function/operation changed by switching ON/OFF the X12 (MRS) signal>

Operating Condition			Operation		Switching to PU,
Operation	Status	X12 (MRS) Signal	Mode	Operating Status	NET Operation
Mode	Status		Wode		Mode
	During	ON → OFF *1		If external operation frequency setting and	Not allowed
PU/NET	stop	ON 7 OIT *1	External *2	start signal are entered, operation is	Not allowed
	Running	$ON \rightarrow OFF *1$		performed in that status.	Not allowed
	During OFF → ON		During stop	Allowed	
External	stop	ON → OFF	External *2	During stop	Not allowed
LAGINAI	Running	OFF → ON	LAGITIAI *2	During operation → output stop	Not allowed
	Rullillig	ON → OFF		Output stop → operation	Not allowed

^{*1} The operation mode switches to the External operation mode independently of whether the start signal (STF, STR) is ON or OFF. Therefore, the motor is run in External operation mode when the X12 (MRS) signal is turned OFF with either of STF and STR ON.

*2 At fault occurrence, pressing $(\overline{\text{RESET}})$ of the operation panel resets the inverter.



- If the X12 (MRS) signal is ON, the operation mode cannot be switched to the PU operation mode when the start signal (STF, STR) is ON.
- When the MRS signal is used as the PU interlock signal, the MRS signal serves as the normal MRS function (output stop) by turning ON the MRS signal and then changing the Pr. 79 value to other than "7" in the PU operation mode. As soon as "7" is set to Pr. 79, the MRS signal acts as the PU interlock signal.
- When the MRS signal is used as the PU interlock signal, the logic of the signal is as set in Pr. 17. When Pr. 17 = "2", read ON as OFF and OFF as ON in the above explanation.
- Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

(10) Switching of operation mode by external signal (X16 signal)

- •When External operation and operation from the operation panel are used together, use of the PU-External operation switching signal (X16) allows switching between the PU operation mode and External operation mode during a stop (during a motor stop, start command OFF).
- •When Pr. 79 = any of "0, 6, 7", the operation mode can be switched between the PU operation mode and External operation mode. (Pr. 79 = "6" At Switchover mode, operation mode can be changed during operation)
- •For the terminal used for X16 signal input, set "16" to any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.

	Pr. 79	X16 Signal State	Operation Mode	Remarks	
	Setting	ON (External) OFF (PU)		Remarks	
0 (initial value)		External operation mode	PU operation mode	Can be switched to External, PU or NET operation mode	
	1	PU opera	tion mode	Fixed to PU operation mode	
2		External ope	eration mode	Fixed to External operation mode (can be switched to NET operation mode)	
	3, 4	External/PU combined operation mode		External/PU combined mode fixed	
6		External operation mode PU operation mode		Switching among the External, PU, and NET operation mode is enabled while running.	
	X12 (MRS)	External operation	PU operation mode	Can be switched to External, PU or NET operation mode (output stop	
7	ON	mode PO operation mode		in External operation mode)	
'	X12 (MRS) OFF	External operation mode		Fixed to External operation mode (forcibly switched to External operation mode)	



• REMARKS

- · The operation mode status changes depending on the setting of Pr. 340 Communication startup mode selection and the ON/OFF status of the X65 and X66 signals. (For details, refer to page 174)
- The priorities of Pr. 79, Pr. 340 and signals are Pr. 79 > \times X12 > \times X66 > \times X65 > \times X16 > Pr. 340.



• Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

(11) Switching of operation mode by external signals (X65, X66 signals)

- •When Pr. 79 = any of "0, 2, 6", the operation mode switching signals (X65, X66) can be used to change the PU or External operation mode to the Network operation mode during a stop (during a motor stop or start command OFF). (Pr. 79 = "6" Switchover mode can be changed during operation)
- •When switching between the Network operation mode and PU operation mode
 - 1)Set Pr. 79 to "0" (initial value) or "6".
 - 2)Set "10" in Pr. 340 Communication startup mode selection.
 - 3)Set "65" in any of Pr. 178 to Pr. 182 to assign the NET-PU operation switching signal (X65) to the terminal.
 - 4)The operation mode changes to the PU operation mode when the X65 signal turns ON, or to the Network operation mode when the X65 signal turns OFF.

Pr. 340		Pr. 79	X65 Signal State		Remarks	
Setting	Setting		ON (PU)	OFF (NET)	Remarks	
	0 (initial value)		PU operation mode *1	NET operation mode *2	Cannot be switched to External operation mode	
		1	PU operation mode		Fixed to PU operation mode	
	2		NET oper	ation mode	Fixed to NET operation mode	
	3, 4		External/PU combi	ned operation mode	External/PU combined mode fixed	
10		6	PU operation mode *1	NET operation mode	Operation mode can be switched with operation continued	
			PO operation mode *1	*2	Cannot be switched to External operation mode	
		X12 (MRS)	Switching among t	he External and PU	Output stop in External operation mode	
	7	ON	operation mod	le is enabled *3	Output stop in External operation mode	
	,	X12 (MRS) OFF	External op	eration mode	Forcibly switched to External operation mode	

- NET operation mode when the X66 signal is ON.
- *2 PU operation mode when the X16 signal is OFF.
- External operation mode when the X16 signal is ON.
 - •When switching between the Network operation mode and External operation mode
 - 1) Set Pr. 79 to "0 (initial value), 2, 6 or 7". (At the Pr. 79 setting of "7", the operation mode can be switched when the X12 (MRS) signal is ON.)
 - 2) Set "0 (initial value) or 1" in *Pr. 340 Communication startup mode selection*.
 - 3) Set "66" in any of Pr. 178 to Pr. 182 to assign the NET-PU operation switching signal (X66) to the terminal.
 - 4) The operation mode changes to the Network operation mode when the X66 signal turns ON, or to the External operation mode when the X66 signal turns OFF.

Pr. 340		Pr. 79	X66 Sigi	nal State	Remarks	
Setting	Setting Setting		ON (NET)	OFF (external)	Remarks	
	0 (initial value)		NET operation mode	External operation mode *1		
		1	PU operation mode		Fixed to PU operation mode	
		2	NET operation mode	External operation mode	Cannot be switched to PU operation mode	
0 (initial	3, 4		External/PU combined operation mode		External/PU combined mode fixed	
value), 1	6		NET operation mode	External operation	Operation mode can be switched with	
			NET operation mode	mode *1	operation continued	
	7	X12 (MRS) ON	NET operation mode	External operation mode *1	Output stop in External operation mode	
	,	X12 (MRS) OFF	'	eration mode	Forcibly switched to External operation mode	

^{*1} PU operation mode when the X16 signal is OFF. When the X65 signal has been assigned, the operation mode changes with the ON/OFF state of the X65 signal.



REMARKS

• The priorities of Pr. 79, Pr. 340 and signals are Pr. 79 > X12 > X66 > X65 > X16 > Pr. 340.



NOTE

Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 15 Jog frequency Refer to page 92

Pr. 4 to 6, Pr. 24 to 27, Pr. 232 to Pr. 239 Multi-speed operation Refer to page 90

Pr. 75 Reset selection/disconnected PU detection/PU stop selection Refer to page 159

Pr. 161 Frequency setting/key lock operation selection Refer to page 239

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) 🕮 Refer to page 120

Pr. 340 Communication startup mode selection Te Refer to page 176

4.18.2 Operation mode at power-ON (Pr. 79, Pr. 340)

When power is switched ON or when power comes back ON after instantaneous power failure, the inverter can be started up in the Network operation mode.

After the inverter has started up in the Network operation mode, parameter write and operation can be performed from a program.

Set this mode for communication operation using PU connector.

Parameter Number	Name	Initial Value	Setting Range	Description
79	Operation mode selection	0	0 to 4, 6, 7	Operation mode selection (Refer to page 169)
			0 1	As set in <i>Pr. 79</i> . Network operation mode
340 *	Communication startup mode selection	0	10	Network operation mode Operation mode can be changed between the PU operation mode and Network operation mode from the operation panel.

The above parameters can be changed during a stop in any operation mode.

(1) Specify operation mode at power-ON (Pr. 340)

•Depending on the Pr. 79 and Pr. 340 settings, the operation mode at power-ON (reset) changes as described below.

Pr. 340 Setting	Pr. 79 Setting	Operation Mode at Power-ON, Power Restoration, Reset	Operation Mode Switching	
	0 (initial value)	External operation mode	Switching among the External, PU and NET operation mode is enabled *1	
	1	PU operation mode	Fixed to PU operation mode	
0 (initial	2	External operation mode	Switching between the External and NET operation mode is enabled Switching to PU operation mode disabled	
value)	3, 4	External/PU combined mode	Operation mode switching disabled	
value)	6	External operation mode	Switching among the External, PU, and NET operation mode is enabled while running.	
	7	External operation mode when X12 (MRS) signal ON	Switching among the External, PU and Net operation mode is enabled *1	
	,	External operation mode when X12 (MRS) signal	Fixed to External operation mode (Forcibly switched to	
		OFF	External operation mode.)	
	0	NET operation mode		
	1	PU operation mode		
	2	NET operation mode		
1	3, 4	External/PU combined mode	Same as when <i>Pr. 340</i> = "0"	
	6	NET operation mode	•	
	7	NET operation mode when X12 (MRS) signal ON External operation mode when X12(MRS) signal		
	0	NET operation mode	Switching between the PU and NET operation mode is enabled *2	
	1	PU operation mode	Same as when <i>Pr. 340</i> = "0"	
40	2	NET operation mode	Fixed to NET operation mode	
10	3, 4	External/PU combined mode	Same as when <i>Pr. 340</i> = "0"	
	6	NET operation mode	Switching between the PU and NET operation mode is enabled while running *2	
	7	External operation mode	Same as when <i>Pr. 340</i> = "0"	

^{*1} Operation mode can not be directly changed between the PU operation mode and Network operation mode

^{*2} Operation mode can be changed between the PU operation mode and Network operation mode with $\frac{PU}{EXT}$ key of the operation panel and X65 signal.



Parameters referred to

Pr. 79 Operation mode selection 👺 Refer to page 166

^{*} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



4.18.3 Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 551)

When the RS-485 communication with the PU connector is used, the external start command and frequency command can be valid. Command source in the PU operation mode can be selected.

From the communication device, parameter unit, etc. which have command source, parameter write or start command can be executed. Parameter read or monitoring can be performed in any operation mode.

Parameter	Name	Initial	Setting	Description
Number			Range	Description
338	Communication operation	0	0	Start command source communication
330	command source	0	1	Start command source external
			0	Frequency command source communication
	Communication speed		1	Frequency command source external
339	command source	0		Frequency command source external (Frequency command from
			2	communication is valid, frequency command from terminal 2 is
				invalid)
			2	PU connector is the command source when PU operation mode.
	PU mode operation		4	Operation panel is the command source when PU operation mode.
551 *	command source	9999		Parameter unit automatic recognition
33 I *	selection	9999	9999	Normally, operation panel is the command source. When the
			3339	parameter unit is connected to the PU connector, PU is the
				command source.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Selects the command source of the PU operation mode (Pr. 551)

- •Any of the operation panel, PU connector can be specified as the command source in the PU operation mode.
- •In the PU operation mode, set *Pr. 551* to "2" when executing parameter write, start command or frequency command during the RS-485 communication with PU connector.
- PU...PU operation mode, NET...Network operation mode, —...without command source

Pr. 551		Command Source		
Setting	Operation	Parameter	RS-485	Remarks
Octung	panel	unit	communication	
2		PU	PU *1	Switching to NET operation mode
	_	10	10*1	disabled
4	PU	_	NET	
9999	PU *2	PU *2	NET	
(initial value)	1 0 *2	1 0 *2	INLI	

- *1 The Modbus-RTU protocol cannot be used in the PU operation mode. When using the Modbus-RTU protocol, set Pr. 551 ≠ "2".
- *2 When Pr. 551 = "9999", the priorities of the PU control source is parameter unit (FR-PU04/FR-PU07) > operation panel.



NOTE

- When performing the RS-485 communication with the PU connector when *Pr. 551* = "9999", PU mode command source does not automatically change to the PU connector.
 - When Pr. 551 = "2" (PU mode PU connector), the operation mode cannot be switched to the Network operation mode.
- Changed setting value is valid when powering ON or resetting the inverter.
- The Modbus-RTU protocol cannot be used in the PU operation mode. Select Network operation mode (NET mode command source).
- All of the operation mode indicator (PU_EXT NI) of the operation panel turns OFF when command source is not operation panel.

^{*} Pr. 551 is always write-enabled.

(2) Controllability through communication

- •Controllability through communication in each operation mode is shown below.
- •Monitoring and parameter read can be performed from any operation regardless of operation mode.

Operation Location	Condition (Pr. 551 Setting)	Operation Mode Item	PU Operation	External Operation	External/PU Combined Operation Mode 1 (Pr. 79 = 3)	External/PU Combined Operation Mode 2 (Pr. 79 = 4)	NET Operation
		Run command (start)	0	×	×	0	×
		Run command (stop)	0	Δ *3	Δ *3	0	×
Control by	2 (PU connector)	Running frequency setting	0	×	0	×	×
Control by RS-485		Parameter write	O*4	× *5	O*4	O *4	× *5
communication		Inverter reset	0	0	0	0	×
from PU		Run command (start)	×	×	×	×	O *1
connector		Run command (stop)	×	×	×	×	O *1
Connector	Other than the above	Running frequency setting	×	×	×	×	O *1
		Parameter write	× *5	× *5	× *5	× *5	O *4
		Inverter reset	×	×	×	×	O *2
Control circuit		Inverter reset	0	0	0	0	0
external	_	Run command (start, stop)	×	0	0	×	×*1
terminals		Frequency setting	×	0	Δ *6	0	×*1

O: Enabled, ×: Disabled, Δ: Some are enabled

- *1 As set in Pr.338 Communication operation command source and Pr. 339 Communication speed command source (Refer to page 177)
- *2 At occurrence of RS-485 communication error, the inverter cannot be reset from the computer.
- *3 Enabled only when stopped by the PU. At a PU stop, PS is displayed on the operation panel. As set in Pr. 75 PU stop selection. (Refer to page 159)
- *4 Some parameters may be write-disabled according to the Pr. 77 Parameter write selection setting and operating status. (Refer to page 162)
- *5 Some parameters are write-enabled independently of the operation mode and command source presence/absence. When Pr. 77 = "2", write is enabled. (Refer to the parameter list on page 58) Parameter clear is disabled.
- *6 Available with multi-speed setting and terminal 4-5 (valid when AU signal is ON).

(3) Operation at error occurrence

Error Definition	Operation Mode Condition (Pr. 551 setting)		External Operation	External/PU Combined Operation Mode 1 (Pr. 79 = 3)	External/PU Combined Operation Mode 2 (Pr. 79 = 4)	NET Operation		
Inverter fault	_	Stop						
PU disconnection of	2 (PU connector) 9999 (automatic recognition)	Stop/continued *1, *3						
the PU	Other than the above	Stop/continued*1						
RS-485 communication	2 (PU connector)	Stop/ continued*2						
error of the PU connector above Continued Stop					Stop/continued*2			

- *1 Can be selected using Pr. 75 Reset selection/disconnected PU detection/PU stop selection.
- *2 Can be selected using Pr. 122 PU communication check time interval.
- *3 In the PU JOG operation mode, operation is always stopped when the PU is disconnected. Whether fault (E.PUE) occurrence is allowed or not is as set in Pr. 75 Reset selection/disconnected PU detection/PU stop selection.



(4) Selection of control source in Network operation mode (Pr. 338, Pr. 339)

•There are two control sources: operation command source, which controls the signals related to the inverter start command and function selection, and speed command source, which controls signals related to frequency setting.

•In Network operation mode, the commands from the external terminals and communication are as listed below.

_	Operation Location Selection Pr. 338 Communication operation command source Pr. 339 Communication speed command source			0: NET			1: Externa	al	Remarks			
			Pi	*		1: External	2: External	0: NET	1: External	2: External	Remarks	
Fix fun	ed ctio	n		ing frequency from nunication	NET	_	NET	NET	_	NET		
(ter	mina	al-	Termi	inal 2	_	External	_	_	External	_		
	iival ctioi		Termi	inal 4	_	Exte	ernal	_	Exte	ernal		
		0	RL	Low-speed operation command/remote setting clear	NET	Exte	ernal	NET	Exte	ernal	Pr. 59 = "0"	
		1	RM	Middle-speed operation command/remote setting function	NET	Exte	ernal	NET	Exte	ernal	(multi-speed) Pr: 59 ≠ "0" (remote)	
		2	RH	High-speed operation command/remote setting function	NET		ernal	NET		ernal	(1 11,	
		3	RT	Second function selection		NET			External			
		4	AU	Terminal 4 input selection	_	Com	bined	_		bined		
		5		Jog operation selection				L	External			
		7	ОН	External thermal relay input			Exte	ernal			Pr. 59 = "0"	
		8	REX	15-speed selection	NET	Exte	ernal	NET	Exte	ernal	Pr. 39 = 0 (multi-speed)	
_	ing	10	X10	Inverter run enable signal		•	Exte	rnal	•			
Selective function	Pr. 178 to Pr. 182 setting	12	X12	PU operation external interlock			Exte	ernal				
Į	18.	14	X14	PID control valid terminal	NET	Exte	ernal	NET	Exte	ernal		
ctive	to Pr.	16	X16	PU-External operation switchover			Exte	ernal				
ele	178	18	X18	V/F switchover		NET		External				
0)	Pr.			Output stop	Combined External						Pr. 79 ≠ "7"	
		24	MRS	PU operation interlock	Exte			ernal			Pr. 79 = "7" When the X12 signal is not assigned	
		25		Start self-holding selection		_			External			
		60		Forward rotation command		NET			External			
		61	_	Reverse rotation command		NET			External			
		62	RES	Inverter reset	Exte		ernal					
	65 X65 PU/NET operation switchover				Exte	ernal						
		66	X66	External/NET operation switchover	Externa			rnal				
		67	X67	Command source switchover			Exte	ernal				
ſΕx	nlai	anation of table]										

[Explanation of table]

: Command is valid only from control terminal. External NET : Command only from communication is valid.

Combined: Command from both control terminal and communication is valid. : Command from either of control terminal and communication is invalid.

• REMARKS

• The command source of communication is as set in Pr. 551.

The Pr. 338 and Pr. 339 settings can be changed while the inverter is running when Pr. 77 = "2". Note that the setting change is reflected after the inverter has stopped. Until the inverter has stopped, communication operation command source and communication speed command source before the setting change are valid.

(5) Switching of command source by external signal (X67)

- •In the Network operation mode, the command source switching signal (X67) can be used to switch the start command source and speed command source.
- Set "67" to any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the X67 signal to the control terminal.
- •When the X67 signal is OFF, the start command source and speed command source are control terminal.

X67 Signal State	Start Command Source	Speed Command Source		
No signal assignment	According to Pr. 338	According to Pr. 339		
ON				
OFF	Command is valid only from control terminal.			



• REMARKS

- The ON/OFF state of the X67 signal is reflected only during a stop. It is reflected after a stop when the terminal is switched while the inverter is running.
- When the X67 signal is OFF, a reset via communication is disabled.



• Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 59 Remote function selection 👺 Refer to page 94

Pr. 79 Operation mode selection 🎏 Refer to page 166



4.19 Communication operation and setting


Purpose	Parameter that s	Refer to Page		
	Initial setting of computer link	Pr. 117 to Pr. 124	104	
Communication operation from PU	communication (PU connector)	Pr. 117 to Pr. 124	184	
connector	Modbus-RTU communication	Pr. 117, Pr. 118, Pr. 120, Pr.	201	
	specifications	122, Pr. 343, Pr. 502, Pr. 549	201	
Restrictions on parameter write	Communication EEPROM write	Pr. 342	100	
through communication	selection	F1. 342	188	

4.19.1 Wiring and configuration of PU connector

Using the PU connector, you can perform communication operation from a personal computer, etc.

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

(1) PU connector pin-outs



Pin Number Name		Description		
1)	SG	Earth (ground)		
''	36	(connected to terminal 5)		
2)	_	Parameter unit power supply		
3)	RDA	Inverter receive+		
4)	SDB	Inverter send-		
5)	SDA	Inverter send+		
6)	RDB	Inverter receive-		
7)	SG	Earth (ground)		
')	50	(connected to terminal 5)		
8) — Parai		Parameter unit power supply		



NOTE

Pins No. 2 and 8 provide power to the parameter unit. Do not use these pins for RS-485 communication.

When making RS-485 communication between the FR-D700 series, FR-E500 series and FR-S500 series, incorrect connection of pins No.2 and No.8 (parameter unit power supply) of the above PU connector may result in the inverter malfunction or failure.

When multiple inverters are connected using pins No.2 and No.8, power is provided from the inverter which is powered ON to the inverters which are powered OFF in case inverters which are powered ON and OFF are mixed. In such case, a protective circuit of the inverter, which is ON, functions to stop communication.


When connecting multiple inverters for RS-485

Battery supply mode Protective ON OFF OFF circuit Inverter Inverter Inverter operation PU PU PU (shut-off) connector connector connecto Û Communication stop : Power supply

< When pins No.2 and No.8 are connected>

communication, make sure to disconnect cables from No.2 and No.8 so that pins No.2 and No.8 are not connected between inverters.


When using the RS-485 converter which receives power from the inverter, make sure that power is provided from one inverter only. (*Refer to the figure below.*)




• Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector. The product could be damaged due to differences in electrical specifications.

(2) PU connector communication system configuration

Connection of a computer to the inverter (1:1 connection)



● Combination of computer and multiple inverters (1:n connection)



* The inverters may be affected by reflection depending on the transmission speed or transmission distance. If this reflection hinders communication, provide a terminating resistor. If the PU connector is used to make a connection, use a distributor since a terminating resistor cannot be fitted. Connect the terminating resistor to only the inverter remotest from the computer. (Terminating resistor: 100Ω)

> REMARKS

Refer to the following when fabricating the cable on the user side.
 Examples of products available on the market (as of October 2008)


	Product	Туре	Maker	
1)	Communication cable	SGLPEV-T (Cat5e/300m) 24AWG × 4P *1	Mitsubishi Cable Industries, Ltd.	
2)	RJ-45 connector	5-554720-3	Tyco Electronics Corporation	

^{*1} Do not use pins No. 2, 8 of the communication cable. (Refer to page 181)




(3) Connection with RS-485 computer

Wiring of one RS-485 computer and one inverter



Wiring of one RS-485 computer and "n" (multiple) inverters




- Make connection in accordance with the Instruction Manual of the computer to be used with. Fully check the terminal numbers of the computer since these vary with the model
- The inverters may be affected by reflection depending on the transmission speed or transmission distance. If this reflection hinders communication, provide a terminating resistor. If the PU connector is used to make a connection, use a distributor since a terminating resistor cannot be fitted. Connect the terminating resistor to only the inverter remotest from the computer. (Terminating resistor: 100Ω)



- Do not use pins No. 2, 8 of the communication cable. (Refer to page 181)
- When making RS-485 communication among the FR-D700 series, FR-E500 series and FR-S500 series, incorrect connection of pins No.2 and 8 (parameter unit power supply) of the above PU connector may result in the inverter malfunction or failure. (Refer to page 181)

(4) Two-wire type connection

If the computer is 2-wire type, a connection from the inverter can be changed to 2-wire type by passing wires across reception terminals and transmission terminals of the PU connector pin.





• REMARKS

- A program should be created so that transmission is disabled (receiving state) when the computer is not sending and reception is disabled (sending state) during sending to prevent the computer from receiving its own data.
- The passed wiring length should be as short as possible.

4.19.2 Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)

Used to perform required settings for RS-485 communication between the inverter and personal computer.

- Use PU connector of the inverter for communication.
- You can perform parameter setting, monitoring, etc. using Mitsubishi inverter protocol or Modbus-RTU protocol.
- To make communication between the personal computer and inverter, setting of the communication specifications must be made to the inverter in advance.

Data communication cannot be made if the initial settings are not made or there is any setting error.

Parameter Number	Name	Initial Value	Setting Range	Desc	cription	
	PU communication		0 to 31 (0 to 247)	Inverter station number s	specification	
117	station number	0	*1	Set the inverter station is	numbers when two or more	
	Station number		*1	inverters are connected	to one personal computer.	
				Communication speed		
118	PU communication speed	192	48, 96, 192, 384	The setting value X 100	equals to the	
	1 6 communication opeca	102	40, 00, 102, 004	communication speed.		
				Example)19200bps if 192	2	
				Stop bit length	Data length	
	PU communication stop bit length	1	0	1bit	- 8bit	
119			1	2bit	ODIL	
			10	1bit	- 7bit	
			11	2bit	7 Dit	
	PU communication parity		0	Without parity check		
120	check	2	1	With odd parity check		
	CHECK		2	With even parity check		
	PU communication		0 to 150ms	Set the waiting time between data transmission to		
123	waiting time setting	9999	0 to 1501115	the inverter and response.		
	waiting time setting		9999	Set with communication	data.	
	PU communication CR/LF		0	Without CR/LF		
124	selection	1	1	With CR		
	selection		2	With CR/LF		
549	Protocol selection	0	0	Mitsubishi inverter (comp	outer link operation) protocol	
543	i iotocoi selection	3	1	Modbus-RTU protocol		

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

^{*1} When "1" (Modbus-RTU protocol) is set in Pr. 549, the setting range within parenthesis is applied.



NOTE

 Always reset the inverter after making the initial settings of the parameters. After you have changed the communication-related parameters, communication cannot be made until the inverter is reset.



4.19.3 Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)

You can select the inverter operation when a communication line error occurs during RS-485 communication from the PU connector.


Parameter	Name	Initial	Setting		Danas	el mél m m		
Number	Name	Range		Description				
121	Number of PU communication retries	1	0 to 10	consecutive erro come to trip (de Valid only Mitsu	Number of retries at data receive error occurrence. If the number of consecutive errors exceeds the permissible value, the inverter will come to trip (depends on <i>Pr. 502</i>). Valid only Mitsubishi inverter (computer link operation) protocol If a communication error occurs, the inverter will not come to trip.			
			9999	(NET operation	mode at initial va	lue)		
122	PU communication	0	0	fault (E.PUE) of operation mode initial value)	11 11,			
122	check time interval	U	0.1 to 999.8s 9999	Communication check (signal loss detection) time interval If a no-communication state persists for longer than the permissible time, the inverter will come to trip (depends on <i>Pr. 502</i>). No communication check (signal loss detection)				
				At fault occurrence	Indication	Fault output	At fault removal	
	Stop mode selection		0	Coasts to stop	E.PUE	Output	Stop (E.PUE)	
502	at communication error	0	1	Decelerates to stop	After stop E.PUE	Output after stop	Stop (E.PUE)	
	amotors can be set when Pr. 160		2	Decelerates to stop	After stop E.PUE	Without output	Automatic restart functions	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)


(1) Retry count setting (Pr.121)

- •Set the permissible number of retries at data receive error occurrence. (Refer to page 193 for data receive error for retry)
- •When data receive errors occur consecutively and exceed the permissible number of retries set, an inverter trips (E.PUE) and a motor stops (as set in *Pr. 502*).
- •When "9999" is set, an inverter fault is not provided even if data receive error occurs but an alarm signal (LF) is output. For the terminal used for the LF signal output, assign the function by setting "98 (positive logic) or 198 (negative logic)" in *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)*.

Example: PU connector communication, Pr. 121 = "1" (initial value)



Example: PU connector communication, Pr. 121 = "9999"




REMARKS

• Pr. 121 is valid only when Mitsubishi inverter (computer link operation) protocol is selected. Pr. 121 is not valid when Modbus-RTU communication protocol is selected.

(2) Signal loss detection (Pr.122)

- •If a signal loss (communication stop) is detected between the inverter and computer as a result of a signal loss detection, a communication fault (E.PUE) occurs and the inverter trips. (as set in *Pr. 502*).
- •When the setting is "9999", communication check (signal loss detection) is not made.
- •When the setting value is "0" (initial value), RS-485 communication can be made. However, a communication fault (E.PUE) occurs as soon as the inverter is switched to the operation mode (Network operation mode in the initial setting) with the control.
- •A signal loss detection is made when the setting is any of "0.1s to 999.8s". To make a signal loss detection, it is necessary to send data (refer to Mitsubishi inverter protocol control code (page 192), Modbus-RTU communication protocol (page 202)) from the computer within the communication check time interval. (The inverter makes communication check (clearing of communication check counter) regardless of the station number setting of the data sent from the master).
- •Communication check is made from the first communication in the operation mode with control source valid (Network operation mode in the initial setting).

Example: PU connector communication, Pr. 122 = "0.1 to 999.8s"



CAUTION

Always set the communication check time interval before starting operation to prevent hazardous conditions. Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal cable breakage etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter trips (E.PUE).

The inverter can be coasted to a stop by turning ON its RES signal or by switching power OFF.

If communication is broken due to signal cable breakage, computer fault, etc, the inverter does not detect such a fault. This should be fully noted.



(3) Stop operation selection at occurrence of communication fault (Pr. 502)

•Stop operation when retry count exceeds (Mitsubishi inverter protocol only) or signal loss detection error occurs can be selected. Operation at fault occurrence


Pr. 502 Setting	Operation	Indication	Fault Output
0 (initial value)	Coasts to stop	E. PUE lit	Provided
1	Decelerates to stop	E. PUE lit after stop	Provided after stop
2	Decelerates to stop	E. FOE III allel slop	Not provided


Operation at fault removal

Pr.502 Setting	Operation	Indication	Fault Output		
0 (initial value)	Kept stopped	E. PUE	Kept provided		
1	Kept stopped	L. FOL	Kept provided		
2	Automatic restart functions	Normal display	Not provided		


● Pr. 502 setting "0" (initial value)







● Pr. 502 setting "2"



• REMARKS

- The fault output indicates fault output signal (ALM signal) or alarm bit output.
 - When the setting was made to provide a fault output, the fault description is stored into the faults history. (The fault description is written to the faults history when a fault output is provided.)

When no fault output is provided, the fault definition overwrites the fault indication of the faults history temporarily, but is not

After the fault is removed, the fault indication returns to the ordinary monitor, and the faults history returns to the preceding fault

- When the Pr. 502 setting is "1 or 2", the deceleration time is the ordinary deceleration time setting (e.g. Pr. 8, Pr. 44, Pr. 45). In addition, acceleration time for restart is the normal acceleration time (e.g. Pr. 7, Pr. 44).
- When "2" is set in Pr. 502, run command/speed command at restart follows the command before an fault occurrence.
- When "2" is set in Pr. 502 at occurrence of a communication error and the error is removed during deceleration, the inverter accelerates again at that point.



Parameters referred to

Pr. 7 Acceleration time, Pr. 8 Deceleration time Refer to page 97 Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120

4.19.4 Communication EEPROM write selection (Pr. 342)

When parameter write is performed from RS-485 communication with the inverter PU connector, parameters storage device can be changed from EEPROM + RAM to RAM only. Set when a frequent parameter change is necessary.

Parameter Number	Name	Initial Value	Setting Range	Description
342	Communication EEPROM write selection	0	0	Parameter values written by communication are written to the EEPROM and RAM.
342		U	1	Parameter values written by communication are written to RAM.

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

• When changing the parameter values frequently, set "1" in Pr. 342 to write them to the RAM only. The life of the EEPROM will be shorter if parameter write is performed frequently with the setting unchanged from "0 (initial value)" (EEPROM write).



• REMARKS

• When "1" (write to RAM only) is set in Pr. 342, powering OFF the inverter will erase the changed parameter values. Therefore, the parameter values available when power is switched ON again are the values stored in EEPROM previously.



4.19.5 Mitsubishi inverter protocol (computer link communication)


You can perform parameter setting, monitoring, etc. from the PU connector of the inverter using the Mitsubishi inverter protocol (computer link communication).

(1) Communication

•The communication specifications are given below.

14	em	Description	Related
II.	em	Description	Parameter
Communication p	orotocol	Mitsubishi protocol (computer link)	Pr. 549
Conforming stand	dard	EIA-485 (RS-485)	_
Number of conne	ctable devices	1:N (maximum 32 units), setting is 0 to 31 stations	Pr. 117
Communication	PU connector	Selected among 4800/9600/19200/38400bps	Pr. 118
speed	r o connector	Selected among 4000/9000/19200/30400bps	11.110
Control procedur	e	Asynchronous	_
Communication r	nethod	Half-duplex	_
	Character system	ASCII (7 bits or 8 bits can be selected)	Pr. 119
	Start bit	1bit	_
Communication	Stop bit length	1 bit or 2 bits can be selected	Pr. 119
Communication	Parity check	Check (with even or odd parity) or no check can be selected	Pr. 120
	Error check	Sum code check	_
	Terminator	CR/LF (presence/absence selectable)	Pr. 124
Waiting time setti	ing	Selectable between presence and absence	Pr. 123

(2) Communication procedure



- Data communication between the computer and inverter is made in the following procedure.
 - Request data is sent from the computer to the inverter. (The inverter will not send data unless requested.)
 - 2) After waiting for the waiting time
 - The inverter sends reply data to the computer in response to the computer request.
 - After waiting for the inverter data processing time
 - Answer from the computer in response to reply data 3) of the inverter is transmitted.
 (Even if 5) is not sent, subsequent communication is made properly.)
- *1 If a data error is detected and a retry must be made, execute retry operation with the user program. The inverter comes to trip if the number of consecutive retries exceeds the parameter setting.
 - On receipt of a data error occurrence, the inverter returns reply data 3) to the computer again. The inverter comes to trip if the number of consecutive data errors reaches or exceeds the parameter setting.

(3) Communication operation presence/absence and data format types

- •Data communication between the computer and inverter is made in ASCII code (hexadecimal code).
- •Communication operation presence/absence and data format types are as follows:

No.	Operat	ion	Run	Operation	Multi	Parameter	Inverter	Monitor	Parameter
NO.	Operat	1011	Command	Frequency	command	Write	Reset	MOTITOR	Read
1)	Communication requeinverter in accordance program in the computer	e with the user		A, A2 *3	A3	A, A2 *3	Α	В	В
2)	nverter data processing time		Present	Present	Present	Present	Present	Present	Present
3)	Reply data from the inverter (Data 1) is	No error *1 (Request accepted)	С	С	C1*4	С	C *2	E, E1, E2, E3 *3	E, E2 *3
	checked for error)	With error (Request rejected)	D	D	D	D	D *2	D	D
4)	Computer processing	delay time				10ms or mo	re		
5)	Answer from computer in response to reply data 3).	No error *1 (No inverter processing)	Absent	Absent	Absent (C)	Absent	Absent	Absent (C)	Absent (C)
ĺ	(Data 3) is checked for error)	With error (Inverter outputs 3) again.)	Absent	Absent	F	Absent	Absent	F	F

^{*1} In the communication request data from the computer to the inverter, 10ms or more is also required after "no data error (ACK)". (Refer to page 192)

Data writing format

Communication request data from the computer to the inverter 1)

Format								Nι	ımber	of Ch	aracte	rs							
lomat	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
Α	ENQ *1	Inve stat numb	tion		uction ode	*3		Data		Su		*4							
A1	ENQ *1	Inve stat numb	tion		uction de	*3	Data Sum *4 check					•							
A2	ENQ *1	Inve stat numb	-		uction ode	*3		Data				Su che		*4					
А3	ENQ *1	Inve stat numb	-		uction ode	*3	Send data type	Receive data type		Da	ta1			Da	ta2		Sui che		*4

Reply data from the inverter to the computer 3) (No data error detected)

Format	Format Number of Characters																
Ulliat	1 2 3 4 5 6 7 8 9 10 11 12 13								13	14	15	16	17	18	19		
С	ACK *1	Inverter station number *2															
C1	STX *1	Inverter station number *2	Send data type	Receive data type	Error code 1	Error code 2		Da	ıta1		Da	ta2		ETX *1	Sum		*4

Reply data from the inverter to the computer 3) (With data error)

Format	Number of Characters								
Office	1	2	3	4	5				
D	NAK *1	Inve stat numb	ion	Error code	*4				

^{*1} Indicate a control code

^{*2} Reply from the inverter to the inverter reset request can be selected. (Refer to page 196)

^{*3} When any of "0.01 to 9998" is set in Pr. 37 and "01" in instruction code, HFF sets data format to A2 or E2. In addition, data format is always A2 and E2 for read or write of Pr. 37.

^{*4} At mode error, and data range error, C1 data contains an error code. (Refer to page 200) Except for those errors, the error is returned with data format D.

^{*2} Specify the inverter station numbers between H00 and H1F (stations 0 to 31) in hexadecimal.

Set waiting time. When the *Pr. 123 PU communication waiting time setting* is other than "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)

^{*4} CR, LF code

When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must also be made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using *Pr. 124 PU communication CR/LF selection*.



Data reading format

Communication request data from the computer to the inverter 1)

Format		Number of Characters											
Torritat	1	2	3	4	5	6	7	8	9				
В	ENQ *1	Inverter station number *2		Instructi	on code	*3		ım eck	*4				

Reply data from the inverter to the computer 3) (No data error detected)

Format		Number of Characters												
Format	1	2	3	4	5	6	7	8	9	10	11	12	13	
Е	STX		erter		Read	d data ETX				ım	*4			
_	*1	station no	umber *2		iteac	uala	*1	che	eck	***				
E1	STX	Inve	erter	Pear	Read data ETX		Sı	ım	*4			•		
	*1	station no	umber *2	rteat	uala	*1	*1 check		***					
E2	STX	Inve	erter			Read	data		ETX		Sı	ım	*4	
LZ	*1	station no	umber *2			Neau	uala			*1	che	eck	*4	

Format		Number of Characters										
Torritat	1	1 2 3 4 to 23 24 25 26 27										
E3	STX *1	Inverter station number *2		Read data (Inverter model information)	ETX *1		ım eck	*4				

Reply data from the inverter to the computer 3) (With data error)

Format	Number of Characters								
Tornat	1	2	3	4	5				
D	NAK	Inve	erter	Error	*4				
5	*1	station no	umber *2	code	*4				

Send data from the computer to the inverter 5)

Format	Nu	Number of Characters								
Torrilat	1	4								
C (Without data error)	/ithout ACK Inverter *1 station number *2									
(With data error)	NAK *1	Inve	*4							

- Indicate a control code
- Specify the inverter station numbers between H00 and H1F (stations 0 to 31) in hexadecimal.
- Set waiting time. When the Pr. 123 PU communication waiting time setting is other than 9999, create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- CR, LF code

When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must also be made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using Pr. 124 PU communication CR/LF selection.

(4) Data definitions

1) Control code

Signal	ASCII Code	Description
STX	H02	Start of Text (Start of data)
ETX	H03	End of Text (End of data)
ENQ	H05	Enquiry (Communication request)
ACK	H06	Acknowledge (No data error detected)
LF	H0A	Line Feed
CR	H0D	Carriage Return
NAK	H15	Negative Acknowledge (Data error detected)

2) Inverter station number

Specify the station number of the inverter which communicates with the computer.

3) Instruction code

Specify the processing request, for example, operation or monitoring, given by the computer to the inverter. Hence, the inverter can be run and monitored in various ways by specifying the instruction code as appropriate. (*Refer to page 58*)

4) Data

Indicates the data such as frequency and parameters transferred to and from the inverter. The definitions and ranges of set data are determined in accordance with the instruction codes. (Refer to page 58)

5) Waiting time

Specify the waiting time between the receipt of data at the inverter from the computer and the transmission of reply data. Set the waiting time in accordance with the response time of the computer between 0 and 150ms in 10ms increments. (example: 1 = 10ms, 2 = 20ms).




• REMARKS


- When the *Pr. 123 PU communication waiting time setting* setting is other than "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- The data check time changes depending on the instruction code. (Refer to page 193)

6) Sum check code

Sum check code is 2-digit ASCII (hexadecimal) representing the lower 1 byte (8 bits) of the sum (binary) derived from the checked ASCII data.



* When the *Pr. 123 Waiting time setting* ≠ "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)






7) Error code


If any error is found in the data received by the inverter, its definition is sent back to the computer together with the NAK code.

Error Code	Error Item	Error Description	Inverter Operation
Н0	Computer NAK error	The number of errors detected consecutively in communication request data from the computer is greater than allowed number of retries.	
H1	Parity error	The parity check result does not match the specified parity	
H2	Sum check error	The sum check code in the computer does not match that of the data received by the inverter.	Brought to trip (E. PUE) if error occurs
НЗ	Protocol error	The data received by the inverter has a grammatical mistake. Alternatively, data reception is not completed within the predetermined time. CR or LF is not as set in the parameter.	continuously more than the allowable number of retry times.
H4	Framing error	The stop bit length differs from the initial setting.	
H5	Overrun error	New data has been sent by the computer before the inverter completes receiving the preceding data.	
H6	_	_	_
H7	Character error	The character received is invalid (other than 0 to 9, A to F, control code).	Does not accept received data but is not brought to trip.
H8	_	_	_
H9	_	_	_
НА	Mode error	Parameter write was attempted in other than the computer link operation mode, when operation command source is not selected or during inverter operation.	Does not accept
НВ	Instruction code error	The specified command does not exist.	
НС	Data range error	Invalid data has been specified for parameter write, frequency setting, etc.	
HD	_	_	_
HE	_	-	_
HF	_	_	_

(5) Response time



[Formula for data sending time]



Communication specifications

Name		Number of		
Name	Name			
Stop bit longth		1 bits		
Stop bit length	Stop bit length			
Data langth		7 bits		
Data length	Data length			
Parity check	Present	1 bits		
Failty Check	Absent	0		

●Data check time

Item	Check Time
Various monitors, operation command,	< 12ms
frequency setting (RAM)	121115
Parameter read/write, frequency setting	< 30ms
(EEPROM)	< 30IIIS
Parameter clear/all clear	< 5s
Reset command	No answer


(6) Instructions for the program

- 1) When data from the computer has any error, the inverter does not accept that data. Hence, in the user program, always insert a retry program for data error.
- 2) All data communication, for example, run command or monitoring, are started when the computer gives a communication request. The inverter does not return any data without the computer's request. Hence, design the program so that the computer gives a data read request for monitoring, etc. as required.
- 3) Program example
 - To change the operation mode to computer link operation

Programming example of Microsoft® Visual C++® (Ver.6.0)

```
#include <stdio.h>
#include <windows.h>
void main(void){
     HANDLE
                       hCom:
                                        //Communication handle
     DCB
                       hDcb:
                                        //Structure for communication setting
     COMMTIMEOUTS
                               hTim:
                                        // Structure for time out setting
     char
                       szTx[0x10];
                                                 // Send buffer
     char
                       szRx[0x10];
                                                 // Receive buffer
     char
                       szCommand[0x10];// Command
                                                 // For buffer size storing
     int
                       nTx,nRx;
     int
                       nSum;
                                                 // For sum code calculation
     BOOL
                       bRet;
                       nRet;
     int
     //**** Opens COM1 port****
     hCom = CreateFile ("COM1", (GENERIC_READ | GENERIC_WRITE), 0, NULL, OPEN_EXISTING, FILE_ATTRIBUTE_NORMAL, NULL);
              //**** Makes a communication setting of COM1 port****
              GetCommState(hCom,&hDcb);
                                                                                     // Retrieves current communication information
              hDcb.DCBlength = sizeof(DCB);
                                                                                     // Structure size setting
                                                                                    // Communication speed=19200bps
              hDcb.BaudRate = 19200;
              hDcb.ByteSize = 8;
                                                                                     // Data length=8bit
              hDcb.Parity = 2;
                                                                                     // Even parity
              hDcb.StopBits = 2;
                                                                                     // Stop bit=2bit
              bRet = SetCommState(hCom,&hDcb);
                                                                                     // Sets the changed communication data
              if (bRet == TRUE) {
                       //*** Makes a time out setting of COM1 port***
                       Get CommTimeouts(hCom,&hTim);
                                                                                    // Obtains the current time out value
                       hTim.WriteTotalTimeoutConstant = 1000;
                                                                                    // Write time out 1s
                       hTim.ReadTotalTimeoutConstant = 1000:
                                                                                     // Read time out 1s
                                                                                    // Changed time out value setting
                       SetCommTimeouts(hCom,&hTim):
                       //**** Sets the command to switch the operation mode of the station 1 inverter to the Network operation mode ****
                       sprintf(szCommand,"01FB10000");
                                                                                     // Send data (NET operation write)
                       nTx = strlen(szCommand);
                                                                                     //Send data size
                       //**** Generates sum code****
                                                                                     // Initialization of sum data
                       nSum = 0:
                       for (i = 0; i < nTx; i++) {
                                                                                     // Calculates sum code
                                nSum += szCommand[i];
                                nSum &= (0xff);
                                                                                     // Masks data
                       }
                       //**** Generates send data****
                       memset(szTx,0,sizeof(szTx));
                                                                                     // Initialization of send buffer
                       memset(szRx,0,sizeof(szRx));
                                                                                     // Initialization of receive buffer
                       sprintf(szTx,"\5%s%02X",szCommand,nSum);// ENQ code+send data+sum code
                       nTx = 1 + nTx + 2;
                                                                                     // Number of ENQ code+number of send data+number of sum code
                       nRet = WriteFile(hCom,szTx,nTx,&nTx,NULL);
                       //**** Sending >
                       if(nRet != 0) {
                               nRet = ReadFile(hCom,szRx,sizeof(szRx),&nRx,NULL);
                       //**** Receiving ***
                                if(nRet != 0) {
                                         //**** Displays the receive data ****
                                         for(i = 0; i < nRx; i++) \{
                                                 printf("%02X ",(BYTE)szRx[i]);// Consol output of receive data
                                                 // Displays ASCII coder in hexadecimal. Displays 30 when "0"
                                        printf("\n\r");
                               }
              CloseHandle(hCom);
                                                                                    // Close communication port
     }
```

General flowchart



! CAUTION

Always set the communication check time interval before starting operation to prevent hazardous conditions. Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal cable breakage etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter will come to trip (E.PUE).

The inverter can be coasted to a stop by switching ON its RES signal or by switching power OFF.

If communication is broken due to signal cable breakage, computer fault etc., the inverter does not detect such a fault. This should be fully noted.

(7) Setting items and set data

After completion of parameter settings, set the instruction codes and data then start communication from the computer to allow various types of operation control and monitoring.

No.	o. Item		Read/ Write	Instruction Code	Data Definition	Number of Data Digits (Format)
1	Оре	eration mode	Read Write	H7B HFB	H0000: Network operation H0001: External operation H0002: PU operation	4 digits (B, E/D) 4 digits (A, C/D)
		Output frequency /speed	Read	H6F	H0000 to HFFFF: Output frequency in 0.01Hz increments Speed increments 1/0.001 (when $Pr. 37 = 0.01$ to 9998) When "0.01 to 9998" is set in $Pr. 37$ and "01" in instruction code HFF, the increments change to 0.001 and the data format is E2. When "100" is set in $Pr. 52$, the monitor value is different depending on whether the inverter is at a stop or running. (<i>Refer to page 129</i>)	4 digits (B, E/D), 6 digits (B, E2/D)
		Output current	Read	H70	H0000 to HFFFF: Output current (hexadecimal) in 0.01A increments	4 digits (B, E/D)
		Output voltage	Read	H71	H0000 to HFFFF: Output voltage (hexadecimal) in 0.1V increments	4 digits (B, E/D)
2	Monitor	Special Read H72 When "0.01 to 9998" is set in <i>Pr. 37</i> and "01" in in	H0000 to HFFFF: Monitor data selected in instruction code HF3 When "0.01 to 9998" is set in $Pr.\ 37$ and "01" in instruction code HFF, the data format is E2.	4 digits (B, E/D), 6 digits (B, E2/D)		
	M		Read	H73		2 digits (B, E1/D)
			Write	HF3	Refer to the special monitor No. table (page 198)	2 digits (A1, C/D)
		Fault description	Read	H74 to H77	H0000 to HFFFF: Two latest fault definitions b15 b8b7 b0 H74 First fault in past Latest fault H75 Third fault in past Second fault in past H76 Fifth fault in past Fourth fault in past H77 Seventh fault in past Sixth fault in past Refer to the alarm data table (page 199)	4 digits (B, E/D)
3	Run command (expansion)		Write	HF9	Control input commands such as forward rotation signal (STF)	4 digits (A, C/D)
		command	Write	HFA	and reverse rotation signal (STR). (For details, refer to page 199)	2 digits (A1, C/D)
4	moni (expa	ter status tor ansion) ter status	Read	H79	Monitor the states of the output signals such as forward rotation, reverse rotation and inverter running (RUN). (For details, <i>refer to page 199</i>)	4 digits (B, E/D) 2 digits
	moni	tor	Read	H7A		(B, E1/D)
	(RAN	requency requency PROM)	Read	H6D H6E	Read set frequency/speed from RAM or EEPROM. H0000 to HFFFF: Set frequency in 0.01Hz increments Speed increments 1/0.001 (when <i>Pr. 37</i> = 0.01 to 9998) When "0.01 to 9998" is set in <i>Pr. 37</i> and "01" in instruction code HFF, the increments change to 0.001 and the data format is E2.	4 digits (B, E/D), 6 digits (B, E2/D)
5	Set fi	requency //)		HED	Write set frequency/speed to RAM or EEPROM. H0000 to H9C40 (0 to 400.00Hz): Frequency increments 0.01Hz Speed increments 1/0.001 (when <i>Pr. 37</i> = 0.01 to 9998)	4 digits
	Set frequency (RAM, EEPROM)		Write	HEE	 When "0.01 to 9998" is set in <i>Pr. 37</i> and "01" in instruction code HFF, the increments change to 0.001 and the data format is A2. To change the set frequency consecutively, write data to the inverter RAM. (instruction code: HED) 	(A, C/D), 6 digits (A2, C/D)

Refer to page 190 for data format (A, A1, A2, A3, B, C, C1, D, E, E1, E2, E3)



No.		Item	Read/ Write	Instruction Code			Data Defini	tion	Number of Data Digits (Format)
6	6 Inverter reset		Write HFD		H9696: Inverter reset As the inverter is reset at start of communication by the computer, the inverter cannot send reply data back to the computer. H9966: Inverter reset		4 digits (A, C/D)		
							•	s returned to the computer	4 digits (A, D)
7	Fault clear	t definition all	Write	HF4	Н	9696: Faults history a	II clear		4 digits (A, C/D)
					Se Re	elected according to d	unication para ata. (O: Clea	ameters or not can be	
						Clear Type	Data	Communication Pr.	
						Parameter clear	H9696	0	
8		meter clear	Write	HFC			H5A5A	×	4 digits
	All cl	ear				All parameter clear	H9966 H55AA	O ×	(A, C/D)
					re re E:	lated parameter setti suming operation, se xecuting clear will clea	ngs also retur t the paramete ar the instruction word lock, o	or H9966, communication- n to the initial values. When ers again. on code HEC, HF3, and HFF nly all parameter clear is	
9	— Parameter		Read	H00 to H63	re	ad parameter values	as required.	to page 58) and write and/or parameter extended setting	4 digits (B, E/D), 6 digits (B, E2/D)
10			Write	H80 to HE3	m	must be set. Data format of <i>Pr. 37</i> read and write is E2 and A2		4 digits (A, C/D), 6 digits (A2, C/D)	
11	Link	Read H7F Parameter description is changed according to the H00 to H09 setting.		2 digits (B, E1/D)					
11	ехра	insion setting			2 digits (A1, C/D)				
		ond parameter	Read	H6C	H	etting calibration para 00: Frequency *2 01: Parameter-set an	alog value		2 digits (B, E1/D)
12	2 changing (instruction code HFF = 1, 9)		Write	HEC	*1 *2	calibration parameter The gain frequency of	calibration par s. an also be writte	ameters on the next page for $\frac{125}{125}$ (instruction code:	2 digits (A1, C/D)
13	Multi	command	Write/ Read	HF0		H99) or <i>Pr.</i> 126 (instruction code: H9A). Available for writing 2 commands, and monitoring 2 items for reading data (<i>Refer to page 200</i> for detail)		d monitoring 2 items for	10 digits (A3, C1/D)
	nonitor	Inverter model	Read	Н7С	Ri "H Ei H	eading inverter mode 120" (blank code) is s xample of FR-D740 46, H52, H2D, H44, F	in ASCII code et for blank are 137, H34, H30	e. ea , H20H20	20 digits (B, E3/D)
14	Inverter model monitor	Capacity	Read	H7D	Di in "H Ei 0.	crements H20" (blank code) is s xample 4K" 4" (nts of 0.1kW, and the for blank are (H20, H20, H20, H20, H20, H20, H20, H20,	and rounds down to 0.01kW	6 digits (B, E2/D)



• REMARKS

- Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999".
- For the instruction codes HFF, HEC and HF3, their values are held once written but cleared to zero when an inverter reset or all

Example) When reading the C3 (Pr. 902) and C6 (Pr. 904) settings from the inverter of station 0

	Computer Send Data	Inverter Send Data	Description
1)	ENQ 00 FF 0 01 82	ACK 00	Set "H01" to the expansion link parameter.
2)	ENQ 00 EC 0 01 7E	ACK 00	Set "H01" to second parameter changing.
3)	ENQ 00 5E 0 0F	STX 00 0000 ETX 25	C3 (Pr. 902) is read. 0% is read.
4)	ENQ 00 60 0 FB	STX 00 0000 ETX 25	C6 (Pr. 904) is read. 0% is read.

To read/write C3 (Pr. 902) and C6 (Pr. 904) after inverter reset or parameter clear, execute from 1) again.

List of calibration parameters

	Name		Instruction Code		
Parameter			Write	Extended	
C2 (902)	Terminal 2 frequency setting bias frequency	5E	DE	1	
C3 (902)	Terminal 2 frequency setting bias	5E	DE	1	
125 (903)	Terminal 2 frequency setting gain frequency	5F	DF	1	
C4 (903)	Terminal 2 frequency setting gain	5F	DF	1	
C5 (904)	Terminal 4 frequency setting bias frequency	60	E0	1	
C6 (904)	Terminal 4 frequency setting bias	60	E0	1	
126 (905)	Terminal 4 frequency setting gain frequency	61	E1	1	
C7 (905)	Terminal 4 frequency setting gain	61	E1	1	

			Instruction		
Parameter	Name	Code			
raiailletei	Name		Write	Extended	
C22(922)	Frequency setting voltage bias frequency	16	96	9	
	(built-in potentiometer)	۲	90	•	
C23(922)	Frequency setting voltage bias (built-in	16	96	9	
023(322)	potentiometer)	2		9	
C24(923)	Frequency setting voltage gain frequency	17	97	9	
024(923)	(built-in potentiometer)	17	97	9	
C25(923)	Frequency setting voltage gain (built-in	17	97	9	
023(923)	potentiometer)	17	9/	9	

[Special monitor selection No.]

Refer to page 129 for details of the monitor description.

Data	Description	Unit
H01	Output frequency/speed *1	0.01Hz/
ПОТ	Output frequency/speed *1	0.001
H02	Output current	0.01A
H03	Output voltage	0.1V
H05	Frequency setting/speed setting *1	0.01Hz/
поэ	Frequency setting/speed setting *1	0.001
H08	Converter output voltage	0.1V
H09	Regenerative brake duty	0.1%
HOA	Electronic thermal relay function	0.1%
HUA	load factor	0.176
H0B	Output current peak value	0.01A
H0C	Converter output voltage peak value	0.1V
H0E	Output power	0.01kW
H0F	Input terminal status *2	_

Data	Description	Unit
H10	Output terminal status *3	
H14	Cumulative energization time	1h
H17	Actual operation time	1h
H18	Motor load factor	0.1%
H19	Cumulative power	1kWh
H34	PID set point	0.1%
H35	PID measured value	0.1%
H36	PID deviation	0.1%
H3D	Motor thermal load factor	0.1%
H3E	Inverter thermal load factor	0.1%
H3F	Cumulative power 2	0.01kWh
H40	PTC thermistor resistance	0.01kΩ

When "0.01 to 9998" is set in Pr. 37 and "01" in instruction code HFF, the data format is 6 digits (E2).

Input terminal monitor details b15 b0 RH RM RL STR STF

Output terminal monitor details b15 b0 ABC RUN




[Fault data]

Refer to page 257 for details of fault description

Data	Definition
H00	No fault
1100	present
H10	E.OC1
H11	E.OC2
H12	E.OC3
H20	E.OV1
H21	E.OV2
H22	E.OV3
H30	E.THT

Data	Definition
H31	E.THM
H40	E.FIN
H52	E.ILF
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT
H91	E.PTC

Data	Definition
HB0	E.PE
HB1	E.PUE
HB2	E.RET
HC0	E.CPU
HC4	E.CDO
HC5	E.IOH
HC7	E.AIE
HC9	E.SAF
HF5	E.5



[Run command]

Item	Instruction	Bit	Decarintian	Evennle
item	Code	Length	Description	Example
Run command	HFA	8bit	b0: AU (terminal 4 input selection) *2 b1: forward rotation command b2: reverse rotation command b3: RL (low-speed operation command) *1*2 b4: RM (middle-speed operation command) *1*2 b5: RH (high-speed operation command) *1*2 b6: RT (second function selection)*2 b7: MRS (output stop) *2	[Example 1] H02 Forward rotation b7
Run command (expansion)	HF9	16bit	b0: AU (terminal 4 input selection) *2 b1: forward rotation command b2: reverse rotation command b3: RL (low-speed operation command) *1*2 b4: RM (middle-speed operation command) *1*2 b5: RH (high-speed operation command) *1*2 b6: RT (second function selection)*2 b7: MRS (output stop) *1*2 b8 to b15: —	[Example 1] H0002 Forward rotation b15

^{*1} The signal within parentheses is the initial setting. The description changes depending on the setting of *Pr. 180 to Pr. 182 (input terminal function selection) (page 114).*

[Inverter status monitor]

Instruction Dit											
Item	Instruction	Bit	Description	Example							
item	Code	Length	Description	Example							
Inverter status monitor	Н7А	8bit	b0: RUN (inverter running) * b1: Forward rotation b2: Reverse rotation b3: SU (up-to-frequency) b4: OL (overload) b5: — b6: FU (frequency detection) b7: ABC (fault) *	[Example 1] H02 During forward rotation b7 b0 0 0 0 0 1 0 1 0							
Inverter status monitor (expansion)	H79	16bit	b0: RUN (inverter running) * b1: Forward rotation b2: Reverse rotation b3: SU (up-to-frequency) b4: OL (overload) b5: — b6: FU (frequency detection) b7: ABC (fault) * b8 to b14: — b15: Fault occurrence	[Example 1] H0002 During forward rotation b15 b0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0							

^{*} The signal within parentheses is the initial setting. The description changes depending on the Pr. 190, Pr. 192 (output terminal function selection).

^{*2} When Pr. 551 = "2" (PU mode control source is PU connector), only forward rotation and reverse rotation can be used.

[Multi command (HF0)]

Sending data format from computer to inverter

Format		Number of Characters																	
Tormat	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
А3	ENQ	Inve stat num	ion	Co	uction ode F0)	Waiting time	data	Receive data type*2		Data	a1*3				ta2 ×3		St che	ım eck	CR/LF

Reply data format from inverter to computer (No data error detected)

Forma		Number of Characters																	
1 Office	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
C1	STX	Inve stat num	tion	Send data type*1	data	code 1	Error code2 *5		Data	a1*4			Da *	ta2 4		ETX	St che	ım eck	CR/LF

- *1 Specify the data type of sending data (from computer to inverter).
- *2 Specify the data type of reply data (from inverter to computer).
- *3 Combination of data 1 and data 2 for sending

Data Type	Data 1	Data 2	Remarks				
0	Run command Set frequency		Run command (expansion) is same as instruction code HF9				
	(expansion) (RAM)		(Refer to page 199)				
1	Run command	Set frequency	The unit of set frequency is always by four digits, even when "0.01				
	(expansion)	(RAM, EEPROM)	to 9998" is set in Pr. 37 and "01" is set in instruction code HFF.				

*4 Combination of data 1 and data 2 for reply

Data Type	Data 1	Data 2	Remarks				
0	Inverter status	Output frequency	Inverter status monitor (expansion) is same as instruction code				
0	monitor (expansion)	(speed)	H79 (Refer to page 199)				
1	Inverter status monitor (expansion)	Special monitor	The unit of speed monitor is always by four digits (rounds down after the decimal point), even when "0.01 to 9998" is set in <i>Pr. 37</i> and "01" is set in instruction code HFF. Replies the monitor item specified in instruction code HF3 for special monitor.(<i>Refer to page 198</i>)				

^{*5} Error code for sending data 1 is set in error code 1, and error code for sending data 2 is set in error code 2. Mode error (HA), instruction code error (HB), data range error (HC) or no error (HF) is replied.



4.19.6 Modbus-RTU communication specifications (Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)

Using the Modbus-RTU communication protocol, communication operation or parameter setting can be performed from the PU connector of the inverter.

Parameter Number	Name	Initial Value	Setting Range		Desci	ription			
	PU communication		0	No reply to the n	naster *				
117	station number	0	1 to 247	Set the inverter s	Inverter station number specification Set the inverter station numbers when two or more inverters are connected to one personal computer.				
118	PU communication speed	96	48, 96, 192, 384	Communication speed The setting value × 100 equals the communication speed. Example) 9600bps if 96					
			0	Without parity ch Stop bit length 2	bit				
120	PU communication parity check	2	1		With odd parity check Stop bit length 1bit				
			2	With even parity check Stop bit length 1bit					
	PU communication		0	RS-485 communication can be made. Note that a communication fault (E.PUE) occurs as soon as the inverter is switched to the operation mode with command source.					
122	check time interval	0	0.1 to 999.8s	Communication check (signal loss detection) time interval If a no-communication state persists for longer than the permissible time, the inverter will come to trip (depends on <i>Pr. 502</i>).					
			9999	No communication check (signal loss detection)					
343	Communication error count	0	_	Displays the nur	mber of communi (reading only)	cation errors dur	ing Modbus-RTU		
				At Fault Occurrence	Indication	Fault Output	At Fault Removal		
502	Stop mode selection at communication	0	0	Coasts to stop.	E.PUE	Output	Stop (E.PUE)		
332	error		1	Decelerates to stop	After stop E.PUE	Output after stop	Stop (E.PUE)		
			2	Decelerates to stop	After stop E.PUE	Without output	Automatic restart functions		
549	Protocol selection	0	0		er (computer link	operation) protoc	ol		
1 Modbus-RTU protocol									

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

Some functions are invalid for broadcast communication. (Refer to page 204)



• When "1" (Modbus-RTU protocol) is set in Pr. 549 and "384" (38400bps) in Pr. 118, parameter unit (FR-PU04/FR-PU07) is disabled. When using the parameter unit (FR-PU04/FR-PU07), change parameter using the operation panel.



• REMARKS

- Set Pr. 549 Protocol selection to "1" to use the Modbus-RTU protocol.
- When PU connector is selected as NET mode operation source (when Pr. 551 PU mode operation command source selection ≠"2"), Modbus-RTU communication operation can be performed. (Refer to page 177)

When Modbus-RTU communication is performed from the master with address 0 (station number 0) set, broadcast communication is selected and the inverter does not send a response message. When response from the inverter is necessary, set a value other than "0" (initial value is 0) in Pr. 117 PU communication station number.

(1) Communication specification

•The communication specifications are given below.

Item		Description	Related Parameter
Communication protocol		Modbus-RTU protocol	Pr. 549
Conforming stand	dard	EIA-485(RS-485)	_
Number of conne	ctable devices	1:N (maximum 32 units), setting is 0 to 247 stations	Pr. 117
Communication speed		Selected among 4800/9600/19200 and 38400bps	Pr. 118
Control procedure		Asynchronous	_
Communication method		Half-duplex	_
	Character system	Binary (always 8 bits)	_
	Start bit	1bit	_
	Stop bit length	Select from the following three types	
Communication	Stop bit leligtii	 No parity, stop bit length 2 bits 	Pr. 120
Communication	Parity check	 No odd parity, stop bit length 1 bits 	P1. 120
	railty check	Even parity, stop bit length 1 bit	
	Error check	CRC code check	_
	Terminator	Not used	_
Waiting time setting		Not used	_

(2) Outline

The Modbus protocol is the communication protocol developed by Modicon for PLC.


The Modbus protocol performs serial communication between the master and slave using the dedicated message frame. The dedicated message frame has the functions that can perform data read and write. Using the functions, you can read and write the parameter values from the inverter, write the input command of the inverter, and check the operating status. In this product, the inverter data are classified in the holding register area (register addresses 40001 to 49999). By accessing the assigned holding register address, the master can communicate with the inverter which is a slave.



• REMARKS

There are two different serial transmission modes: ASCII (American Standard Code for Information Interchange) mode and RTU (Remote Terminal Unit) mode. This product supports only the RTU mode in which 1-byte (8-bit) data is transmitted as it is. Only the communication protocol is defined by the Modbus protocol, and the physical layer is not stipulated.

(3) Message format



Data check time

Item	Check Time		
Various monitors, operation command,	<20ms		
frequency setting (RAM)	~201115		
Parameter read/write, frequency setting	<50ms		
(EEPROM)	\ 501118		
Parameter clear/all clear	<5s		
Reset command	No answer		

1) Query

The master sends a message to the slave (= inverter) at the specified address.

2) Normal Response

After receiving the query from the master, the slave executes the requested function and returns the corresponding normal response to the master.

3) Error Response

If an invalid function code, address or data is received, the slave returns it to the master.

When a response description is returned, the error code indicating that the request from the master cannot be executed is

No response is returned for the hardware-detected error, frame error and CRC check error.

4) Broadcast

By specifying address 0, the master can send a message to all slaves. All slaves that received the message from the master execute the requested function. In this communication, the slaves do not return a response to the master.




The inverter performs the function independently of the inverter station number setting (Pr. 117) during broadcast communication.

Message frame (protocol)

Communication method

Basically, the master sends a query message (question) and the slave returns a response message (response). When communication is normal, Device Address and Function Code are copied, and when communication is abnormal (function code or data code is illegal), bit 7 (= 80h) of Function Code is turned ON and the error code is set to Data Bytes.

Query message from Master



The message frame consists of the four message fields as shown above.

By adding the no-data time (T1: Start, End) of 3.5 characters to the beginning and end of the message data, the slave recognizes it as one message.

Protocol details

The four message fields will be explained below.

Start	1) ADDRESS	2) FUNCTION	3) DATA	4) CRC	CHECK	End
T1	8bit	8bit	n×8bit	L 8bit	H 8bit	T1

Message Field			Description					
	The addres	s code is 1 byte long (8 bits) a	nd any of 0 to 247 can be set. Set 0	to send a broadcast				
1) ADDRESS field	message (all-address instruction) or any of 1 to 247 to send a message to each slave.							
1)ADDITEOU IICIU	When the slave responds, it returns the address set from the master.							
			station number is the slave address.					
		• • •	nd any of 1 to 255 can be set. The m					
			he slave performs the requested ope	_				
	_	• • •	An error response is returned if the	set function code is				
		hose in the following table.						
		•	e, it returns the function code set by	the master. When the				
	slave return	s an error response, it returns	H80 + function code.					
	Code	Function Name	Outline	Broadcast				
	Jouc	T diletion Name	Gutille	Communication				
o) FUNCTION	H03	Read Holding Register	Reads the holding register data.	Not allowed				
2) FUNCTION field	H06	Preset Single Register	Writes data to the holding register.	Allowed				
	H08	Diagnostics	Function diagnosis (communication check only)	Not allowed				
	H10	Preset Multiple Registers	Writes data to multiple consecutive holding registers.	Allowed				
	H46	Read Holding Register Access Log	Reads the number of registers that succeeded in communication last time.	Not allowed				
		Table	1:Function code list					
0) 5 4 7 4 5 1 1	The format	changes depending on the fun	ction code (Refer to page 205). Data in	cludes the byte count,				
3) DATA field		oytes, description of access to	, , , ,					
	The receive	d message frame is checked	for error. CRC check is performed, a	nd 2 byte long data is				
	added to the	e end of the message. When	CRC is added to the message, the lo	w-order byte is added				
4) CRC CHECK	first and is f	followed by the high-order byte	9.					
field	The CRC va	alue is calculated by the sendi	ng side that adds CRC to the messa	ge. The receiving side				
IICIU	recalculates	CRC during message receiving	ing, and compares the result of that of	calculation and the				
	actual value	received in the CRC CHECK	field. If these two values do not mato	h, the result is defined				
	as error.							



(5) Message format types

The message formats corresponding to the function codes in Table 1 on page 204 will be explained.

• Read holding register data (H03 or 03)

Can read the description of **1)** system environment variables, **2)** real-time monitor, **3)** faults history, and **4)** inverter parameters assigned to the holding register area (refer to the register list (page 210))

Query message

1) Slave Address	2) Function	Starting	Address	No. of	Points	CRC (Check
(0hit)	H03	Н	L	Н	L	L	Н
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

1) Slave Address	2) Function	Byte Count		Data	CRC	Check	
(8bit)	H03 (8bit)	(8bit)	H (8bit)	L (8bit)	 (n × 16bit)	L (8bit)	H (8bit)

Query message setting

Message	Setting Description				
1) Slave Address	Address to which the message will be sent				
1) Slave Address	Broadcast communication cannot be made (0 is invalid).				
2) Function	Set H03.				
	Set the address at which holding register data read will be started.				
2) Starting Address	Starting address = Starting register address (decimal)-40001				
3) Starting Address	For example, setting of the starting address 0001 reads the data of the holding				
	register 40002.				
A) No. of Points	Number of holding registers from which data will be read				
4) No. of Points	The number of registers from which data can be read is a maximum of 125.				

Description of normal response

Message	Setting Description
5) Byte Count	The setting range is H02 to H14 (2 to 20).
5) Byte Count	Twice greater than the No. of Point specified at 4) is set.
	The number of data specified at 4) is set. Data are read in order of Hi byte and Lo
6) Data: Read data	byte, and set in order of starting address data, starting address + 1 data, starting
	address + 2 data,

Example: To read the register values of 41004 (Pr. 4) to 41006 (Pr. 6) from the slave address 17 (H11)

Query message

	Slave Address	Function	Starting Address		No. of F	Points	CRC Check		
ſ	H11	H03	H03	HEB	H00	H03	H77	H2B	
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

Slave Address	Function	Byte Count		Data					CRC C	Check
H11	H03	H06	H17	H70	H0B	HB8	H03	HE8	H2C	HE6
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Read value

Register 41004(*Pr. 4*): H1770 (60.00Hz) Register 41005(*Pr. 5*): H0BB8 (30.00Hz) Register 41006(*Pr. 6*): H03E8 (10.00Hz)



• Write holding register data (H06 or 06)

Can write the description of 1) system environment variables and 4) inverter parameters assigned to the holding register area (refer to the register list (page 210)).

Query message

1) Slave Address	2) Function	3) Register Address		nction 3) Register Address 4) Preset Data		CRC Check	
(8bit)	H06	Н	L	Н	L	L	Н
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

1) Slave Address	2) Function	3) Register Address		on 3) Register Address 4) Preset Data		CRC Check	
(8bit)	H06	Н	L	Н	L	L	Н
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Query message setting

Message	Setting Description					
1) Slave Address	Address to which the message will be sent					
1) Slave Address	Setting of address 0 enables broadcast communication					
2) Function	Set H06.					
	Address of the holding register to which data will be written					
2) Degister Address	Register address = Holding register address (decimal)-40001					
3) Register Address	For example, setting of register address 0001 writes data to the holding register					
	address 40002.					
A) Procet Date	Data that will be written to the holding register					
4) Preset Data	The written data is always 2 bytes.					

Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message. No response is made for broadcast communication.

Example: To write 60Hz (H1770) to 40014 (running frequency RAM) at slave address 5 (H05).

Query message

Slave Address	Function	Register Address		Preset Data		CRC Check	
H05	H06	H00	H0D	H17	H70	H17	H99
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

Same data as the query message



NOTE

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.



• Function diagnosis (H08 or 08)

A communication check can be made since the query message sent is returned unchanged as a response message (function of sub function code H00).

Sub function code H00 (Return Query Data)

Query message

1) Slave Address	2) Function	3) Subfunction		4) Date		CRC Check	
(8bit)	H08	H00	H00	Н	L	L	Н
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

1) Slave Address	2) Function	3) Subfunction		4) Date		CRC Check	
(8bit)	H08	H00	H00	Н	L	L	Н
(obit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

•Query message setting

Message	Setting Description				
1) Slave Address	Address to which the message will be sent				
1) Slave Address	Broadcast communication cannot be made (0 is invalid).				
2) Function	Set H08.				
3) Subfunction	Set H0000.				
4) Data	Any data can be set if it is 2 bytes long. The setting range is H0000 to HFFFF				

• Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message.



NOTE

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.

• Write multiple holding register data (H10 or 16)

You can write data to multiple holding registers.

Query message

1)Slave Address	2) Function	3 Star Add	,	_) . of sters	5) ByteCount		6) Data		CRC Check	
(8bit)	H10 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	(8bit)	H (8bit)	L (8bit)	 (n×2×8bit)	L (8bit)	H (8bit)

Normal response (Response message)

1)Slave Address	2)Function	3)Starting Address		4)No. of Registers		CRC Check	
(8bit)	H10 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	L (8bit)	H (8bit)

· Query message setting

Message	Setting Description			
1) Clave Address	Address to which the message will be sent			
1) Slave Address	Setting of address 0 enables broadcast communication			
2) Function	Set H10.			
	Address where holding register data write will be started			
2) Starting Address	Starting address = Starting register address (decimal)-40001			
3) Starting Address	For example, setting of the starting address 0001 reads the data of the holding			
	register 40002.			
4) No. of Dointo	Number of holding registers where data will be written			
4) No. of Points	The number of registers where data can be written is a maximum of 125.			
F) Duta Count	The setting range is H02 to HFA (0 to 250).			
5) Byte Count	Set a value twice greater than the value specified at 4).			
	Set the data specified by the number specified at 4). The written data are set in			
6) Data	order of Hi byte and Lo byte, and arranged in order of the starting address data,			
	starting address + 1 data, starting address + 2 data			

\mathbb{Z}

• Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message.

Example: To write 0.5s (H05) to 41007 (Pr. 7) at the slave address 25 (H19) and 1s (H0A) to 41008 (Pr.8).

Query message

Slave Address	Function	Star Add	ting ress	No. of	Points	Byte Count	Data			CRC	Check	
H19	H10	H03	HEE	H00	H02	H04	H00	H05	H00	H0A	H86	H3D
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

Slave Address	Function		Starting Address No. of Point		Points	CRC (Check
H19	H10	H03	HEE	H00	H02	H22	H61
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

• Read holding register access log (H46 or 70)

A response can be made to a query made by the function code H03 or H10.

The starting address of the holding registers that succeeded in access during previous communication and the number of successful registers are returned.

In response to the query for other than the above function code, 0 is returned for the address and number of registers.

Query message

1) Slave Address	2) Function	CRC Check			
(8bit)	H46	L	H		
	(8bit)	(8bit)	(8bit)		

Normal response (Response message)

1) Slave Address	2) Function	3) Starting Address		4) No. o	4) No. of Points		CRC Check	
(8bit)	H46	H	L	H	L	L	H	
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Query message setting

Message	Setting Description
1) Clave Address	Address to which the message will be sent
1) Slave Address	Broadcast communication cannot be made (0 is invalid).
2) Function	Set H46.

· Description of normal response

Message	Setting Description
	The starting address of the holding registers that succeeded in access is returned.
2) Starting Address	Starting address = Starting register address (decimal)-40001
3) Starting Address	For example, when the starting address 0001 is returned, the address of the
	holding register that succeeded in access is 40002.
4) No. of Points	The number of holding registers that succeeded in access is returned.

Example: To read the successful register starting address and successful count from the slave address 25 (H19).

Query message

Slave Address	Function	CRC Check			
H19	H46	H8B HD2			
(8bit)	(8bit)	(8bit)	(8bit)		

Normal response (Response message)

Slave Address	Function	Starting	Address	No. of	Points	CRC	Check
H19	H10	H03	HEE	H00	H02	H22	H61
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Success of two registers at starting address 41007 (Pr. 7) is returned.



• Error response

An error response is returned if the query message received from the master has an illegal function, address or data. No response is returned for a parity, CRC, overrun, framing or busy error.



NOTE

No response message is sent in the case of broadcast communication also.

Error response (Response message)

1) Slave Address	2) Function	3) Exception Code	CRC Check		
(Obit)	H80 + Function	(Obit)	L	Н	
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Message	Setting Description
1) Slave Address	Address received from the master
2) Function	Master-requested function code + H80
3) Exception Code	Code in the following table

Error code list

Code	Error Item	Error Description					
01	ILLEGAL FUNCTION	The set function code in the query message from the master cannot be					
01	ILLEGAL FUNCTION	handled by the slave.					
		The set register address in the query message from the master cannot be					
02	ILLEGAL DATA ADDRESS *1	handled by the inverter.					
		(No parameter, parameter read disabled, parameter write disabled)					
		The set data in the query message from the master cannot be handled by the					
03	ILLEGAL DATA VALUE inverter.						
		(Out of parameter write range, mode specified, other error)					

- *1 An error will not occur in the following cases.
 - 1) Function code H03 (Read holding register data)
 - When the No. of Points is 1 or more and there is one or more holding registers from which data can be read
 - 2) Function code H10 (Write multiple holding register data)
 - When the No. of Points is 1 or more and there is 1 or more holding registers to which data can be written

Namely, when the function code H03 or H10 is used to access multiple holding registers, an error will not occur if a non-existing holding register or read disabled or write disabled holding register is accessed.



> REMARKS

An error will occur if all accessed holding registers do not exist.

Data read from a non-existing holding register is 0, and data written there is invalid.

· Message data mistake detection

To detect the mistakes of message data from the master, error item are checked for the following errors. If an error is detected, a trip will not occur.

Error check item

Error Item	Error Description	Inverter Operation
Darity orror	The data received by the inverter differs from the	
Parity error	specified parity (Pr.120 setting).	
	The data received by the inverter differs from the	
Framing error	specified stop bit length (Pr.120).	
Overrun error	The following data was sent from the master before	1) Pr.343 is increased by 1 at error
Overruit error	the inverter completes data receiving.	occurrence.
	The message frame data length is checked, and the	2)The terminal LF is output at error
Message frame error	received data length of less than 4 bytes is regarded	occurrence.
	as an error.	
	A mismatch found by CRC check between the	
CRC check error	message frame data and calculation result is	
	regarded as an error.	

(6) Modbus registers

System environment variable

Register	Definition	Read/write	Remarks
40002	Inverter reset	Write	Any value can be written
40003	Parameter clear	Write	Set H965A as a written value.
40004	All parameter clear	Write	Set H99AA as a written value.
40006	Parameter clear *1	Write	Set H5A96 as a written value.
40007	All parameter clear *1	Write	Set HAA99 as a written value.
40009	Inverter status/control input instruction*2	Read/write	See below.
40010	Operation mode/inverter setting *3	Read/write	See below.
40014	Running frequency (RAM value)	Read/write	According to the <i>Pr. 37</i> settings, the frequency
	3 1411 19 (1111)		and selectable speed are in 1r/min
40015	Running frequency (EEPROM value)	Write	increments.

- The communication parameter values are not cleared.
- For write, set the data as a control input instruction.
 - For read, data is read as an inverter operating status.
- For write, set data as the operation mode setting. For read, data is read as the operation mode status.

<Inverter status/control input instruction>

Control input instruction Inverter status	Bit Definition											
0 Stop command RUN (inverter running) *2 1 Forward rotation command Forward rotation 2 Reverse rotation command During reverse rotation 3 RH (high-speed operation command)*1 SU (up-to-frequency) 4 RM (middle-speed operation command)*1 OL (overload) 5 RL (low-speed operation command)*1 0 6 0 FU (frequency detection) 7 RT (second function selection) ABC (fault) *2 8 AU (terminal 4 input selection) 0 9 0 0 10 MRS (output stop) 0 11 0 0	0											
1 Forward rotation command Forward rotation 2 Reverse rotation command During reverse rotation 3 RH (high-speed operation command)*1 SU (up-to-frequency) 4 RM (middle-speed operation command)*1 OL (overload) 5 RL (low-speed operation command)*1 0 6 0 FU (frequency detection) 7 RT (second function selection) ABC (fault) *2 8 AU (terminal 4 input selection) 0 9 0 0 10 MRS (output stop) 0 11 0 0		•										
2 Reverse rotation command During reverse rotation 3 RH (high-speed operation command)*1 SU (up-to-frequency) 4 RM (middle-speed operation command)*1 OL (overload) 5 RL (low-speed operation command)*1 0 6 0 FU (frequency detection) 7 RT (second function selection) ABC (fault) *2 8 AU (terminal 4 input selection) 0 9 0 0 10 MRS (output stop) 0 11 0 0	0	Stop command	RUN (inverter running) *2									
3	1	Forward rotation command	Forward rotation									
SU (up-to-frequency)	2	Reverse rotation command	During reverse rotation									
Command)*1	2	RH (high-speed operation	SII (up to fraguency)									
4 command)*1 OL (overload) 5 RL (low-speed operation command)*1 0 6 0 FU (frequency detection) 7 RT (second function selection) ABC (fault) *2 8 AU (terminal 4 input selection) 0 9 0 0 10 MRS (output stop) 0 11 0 0	3	command)*1	(up-to-frequency)									
command)*1 command)*1 5 RL (low-speed operation command)*1 0 6 0 FU (frequency detection) 7 RT (second function selection) ABC (fault) *2 8 AU (terminal 4 input selection) 0 9 0 0 10 MRS (output stop) 0 11 0 0	1	RM (middle-speed operation	OL (overload)									
5 command)*1 0 6 0 FU (frequency detection) 7 RT (second function selection) ABC (fault) *2 8 AU (terminal 4 input selection) 0 9 0 0 10 MRS (output stop) 0 11 0 0	7	,	OL (overload)									
command)*1 FU (frequency detection) 7 RT (second function selection) ABC (fault) *2 8 AU (terminal 4 input selection) 0 9 0 0 10 MRS (output stop) 0 11 0 0	5	RL (low-speed operation	0									
7 RT (second function selection) ABC (fault) *2 8 AU (terminal 4 input selection) 0 9 0 0 10 MRS (output stop) 0 11 0 0	3	command)*1										
8 AU (terminal 4 input selection) 0 9 0 0 10 MRS (output stop) 0 11 0 0	6	0	FU (frequency detection)									
9 0 0 10 MRS (output stop) 0 11 0 0	7	RT (second function selection)	ABC (fault) *2									
10 MRS (output stop) 0 11 0 0	8	AU (terminal 4 input selection)	0									
11 0 0	9	0	0									
-	10	MRS (output stop)	0									
	11	0	0									
12 0 0	12	0	0									
13 0 0	13	0	0									
14 0 0	14	0	0									
15 0 Fault occurrence	15	0	Fault occurrence									

<Operation mode/inverter setting>

Mode	Read Value	Written
WIOGE	Reau value	Value
EXT	H0000	H0010
PU	H0001	_
EXT	H0002	
JOG	H0002	_
NET	H0004	H0014
PU+EXT	H0005	_

The restrictions depending on the operation mode changes according to the computer link specifications.

Real time monitor

Refer to page 129 for details of the monitor description.

Register	Description	Unit
40201	Output frequency/speed	0.01Hz/1 *1
40202	Output current	0.01A
40203	Output voltage	0.1V
40205	0.01Hz/1 *1	
40208	setting Converter output voltage	0.1V
40209	Regenerative brake duty	0.1%
40210	Electronic thermal relay function load factor	0.1%
40211	Output current peak value	0.01A
40212	Converter output voltage peak value	0.1V
40214	Output power	0.01kW
40215	Input terminal status *2	_

Register	Description	Unit
40216	Output terminal status *3	_
40220	Cumulative energization time	1h
40223	Actual operation time	1h
40224	Motor load factor	0.1%
40225	Cumulative power	1kWh
40252	PID set point	0.1%
40253	PID measured value	0.1%
40254	PID deviation	0.1%
40261	Motor thermal load factor	0.1%
40262	Inverter thermal load factor	0.1%
40263	Cumulative power 2	0.01kWh
40264	PTC thermistor resistance	0.01kΩ
40204	1 TO thermistor resistance	0.01K22

When Pr.37 = "0.01 to 9998", displayed in integral number.

Input terminal monitor details

	b15															b0
	_	_	_	_	_	_	_	_	_	RH	RM	RL	_	_	STR	STF
•	<u> </u>			4.												

b15	illilliai illo	ilitor detai	15											b0
_	_	_	_	_	_	_	_	_	_	ABC	_	_	_	RUN

The signal within parentheses is the initial setting. Definitions change according to the Pr. 180 to Pr. 182 (input terminal function selection) (refer to

Each assigned signal is valid or invalid depending on NET. (Refer to page 177)

The signal within parentheses is the initial setting. Definitions change according to the Pr. 190, Pr. 192 (output terminal function selection) (refer to page 120).



Parameter

Parameter	Register	Parameter Name	Read/ Write	Remarks	
0 to 999	41000 to 41999	Refer to the parameter list (page 58) for the parameter names.	Read/write	The parameter number + 41000 is the register number.	
C2(902)	41902	Terminal 2 frequency setting bias frequency	Read/write		
C3(902)	42092	Terminal 2 frequency setting bias (Analog value)	Read/write	The analog value (%) set to C3 (902) is read.	
00(302)	43902	Terminal 2 frequency setting bias (Terminal analog value)	Read	The analog value (%) of the voltage (current) applied to the terminal 2 is read.	
125(903)	41903	Terminal 2 frequency setting gain frequency	Read/write		
C4(903)	42093	Terminal 2 frequency setting gain (Analog value)	Read/write	The analog value (%) set to C4 (903) is read.	
04(303)	43903	Terminal 2 frequency setting gain (Terminal analog value)	Read	The analog value (%) of the voltage (current) applied to the terminal 2 is read.	
C5(904)	41904	Terminal 4 frequency setting bias frequency	Read/write		
C6(904)	42094	Terminal 4 frequency setting bias (Analog value)	Read/write	The analog value (%) set to C6 (904) is read.	
00(304)	43904	Terminal 4 frequency setting bias (Terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.	
126(905)	41905	Terminal 4 frequency setting gain frequency	Read/write		
C7(905)	42095	Terminal 4 frequency setting gain (Analog value)	Read/write	The analog value (%) set to C7 (905) is read.	
07(303)	43905	Terminal 4 frequency setting gain (Terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.	
C22(922)	41922	Frequency setting voltage bias frequency (built-in potentiometer)	Read/write		
C23(922)	42112	Frequency setting voltage bias (built-in potentiometer)	Read/write	The analog value (%) set to C23 (922) is read.	
C24(923)	41923	Frequency setting voltage gain frequency (built-in potentiometer)	Read/write		
C25(923)	42113	Frequency setting voltage gain (built-in potentiometer)	Read/write	The analog value (%) set to C25(923) is read.	

Faults history

Register Definition		Read/write	Remarks	
40501	Fault history 1	Read/write		
40502	Fault history 2	Read	Being 2 bytes in length, the data is stored as	
40503	Fault history 3	Read	"H0000".	
40504	Fault history 4	Read	Refer to the lowest 1 byte for the error code.	
40505	Fault history 5	Read	Performing write using the register 40501 batch-	
40506	Fault history 6	Read	clears the faults history.	
40507	Fault history 7	Read	Set any value as data.	
40508	Fault history 8	Read	7	

Fault code list

Data	Definition	
H00	No fault	
1100	present	
H10	E.OC1	
H11	E.OC2	
H12	E.OC3	
H20	E.OV1	
H21	E.OV2	
H22	E.OV3	
H30	E.THT	

Data	Definition
H31	E.THM
H40	E.FIN
H52	E.ILF
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT
H91	E.PTC

Data	Definition	
HB0	E.PE	
HB1	E.PUE	
HB2	E.RET	
HC0	E.CPU	
HC4	E.CDO	
HC5	E.IOH	
HC7	E.AIE	
HC9	E.SAF	
HF5	E.5	

^{*} Refer to page 257 for details of fault definition.

(7) Pr. 343 Communication error count

You can check the cumulative number of communication errors.

Parameter	Setting Range	Minimum Setting Range	Initial Value
343	(Reading only)	1	0




NOTE

The number of communication errors is temporarily stored into the RAM. As it is not stored into the EEPROM performing a power supply reset or inverter reset clears the value to 0.

(8) Output terminal LF "alarm output (communication error warnings)"

During a communication error, the alarm signal (LF signal) is output by open collector output. Assign the used terminal using *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)*.





NOTE

The LF signal can be assigned to the output terminal using Pr.~190, Pr.~192 or Pr.~197. Changing the terminal assignment may affect the other functions. Make setting after confirming the function of each terminal.



4.20 Special operation and frequency control

Purpose	Parameter ti	Refer to Page	
Perform process control such as pump and air volume.	PID control	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577	213
Dancer control	PID control (dancer control setting)	Pr. 44, Pr. 45, Pr. 128 to Pr. 134	221
Avoid overvoltage alarm due to regeneration by automatic adjustment of output frequency	Regeneration avoidance function	Pr. 882, Pr. 883, Pr. 885, Pr. 886	227

4.20.1 PID control (Pr. 127 to Pr. 134, Pr. 575 to Pr. 577)

The inverter can be used to perform process control, e.g. flow rate, air volume or pressure.

The terminal 2 input signal or parameter setting is used as a set point and the terminal 4 input signal used as a feedback value to constitute a feedback system for PID control.


Parameter	Name	Initial	Setting	Description			
Number	Name	Value	Range				
127	PID control automatic	9999	0 to 400Hz	Frequency at which	the control is auto	omatically changed to PID control.	
127	switchover frequency	9999	9999	Without PID automat	tic switchover fun	ction	
			0	PID action is not performed			
			20	PID reverse action	Measured value	(terminal 4)	
			21	PID forward action	Set value (termir	nal 2 or <i>Pr. 133</i>)	
128	PID action selection	0	40	PID reverse action	Addition	For dancer control	
			41	PID forward action	method: fixed	set point (Pr. 133),	
			42	PID reverse action	Addition	measured value (terminal 4) main speed (frequency	
			43	PID forward action	method: ratio	command of the operation mode)	
				If the proportional ba	nd is narrow (par	rameter setting is small), the	
			0.1 to	manipulated variable	varies greatly wi	ith a slight change of the	
129 *1	PID proportional band	100%	1000%			ortional band narrows, the	
1 - 2			.00070	•		out the stability deteriorates, for	
			9999		le, hunting occurs. Gain Kp= 1/proportional band		
			9999	No proportional cont		is the time required for integral (I)	
			0.1 to	When deviation step is input, time (Ti) is the time required for integral (I) action to provide the same manipulated variable as the proportional (P)			
130 *1	PID integral time	1s	3600s	action. As the integral time decreases, the set point is reached earlier			
				but hunting occurs more easily.			
			9999	No integral control.			
				Maximum value			
			0 to	If the feedback value exceeds the setting, the FUP signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4) is			
131	PID upper limit	9999	100%				
			0000	equivalent to 100%. No function			
			9999	Minimum frequency			
			0 to	. ,	falls below the se	tting range, the FDN signal is	
132	PID lower limit	9999	100%			0 0	
				terminal 4) is equiva			
			9999	No function			
133 *1	PID action set point	9999	0 to 100%	Used to set the set p		rol.	
100 1	Tib dotton oot point		9999	Terminal 2 input is th			
			0.01 to	· ·		required for providing only the	
134 *1	PID differential time	9999	10s	manipulated variable for the proportional (P) action. As the differential time increases, greater response is made to a deviation change.			
			9999	No differential contro		iade to a deviation change.	
	Outrout into		0 to			ut frequency after PID operation	
575	Output interruption	1s	3600s			for longer than the time set in <i>Pr. 575</i> .	
	detection time		9999	Without output interruption function		-	
E76	Output interruption	01.1-	0 to 4001 !-	Set the frequency at	which the output	interruption processing is	
576	detection level	0Hz	0 to 400Hz	performed.	-	-	
577	Output interruption	10000/	900 to	Set the level (Pr. 577	minus 1000%) at	t which the PID output interruption	
577	cancel level	1000%	1100%	function is canceled.	•		
<u></u>	motors can be set when Pr. 160	E . 1.10	. 7. 7		* **:		

The above parameters can be set when Pr. 160 Extended function display selection ="0". (Refer to page 163)

^{*1} Pr. 129, Pr. 130, Pr. 130, Pr. 134 can be set during operation. These can also be set independently of the operation mode.

(1) PID control basic configuration

•Pr. 128 = "20, 21" (measured value input)



Kp: Proportionality constant Ti: Integral time S: Operator Td: Differential time


(2) PID action overview

1)PI action

A combination of proportional control action (P) and integral control action (I) for providing a manipulated variable in response to deviation and changes with time.

[Operation example for stepped changes of process value]

(Note) PI action is the sum of P and I actions.




2)PD action

A combination of proportional control action (P) and differential control action (D) for providing a manipulated variable in response to deviation speed to improve the transient characteristic.

[Operation example for proportional changes of process value]

(Note) PD action is the sum of P and D actions.






3)PID action

The PI action and PD action are combined to utilize the advantages of both actions for control.

(Note) PID action is the sum of P, I and D actions.




4)Reverse operation

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is positive, and decreases the manipulated variable if deviation is negative.



5)Forward action

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is negative, and decreases the manipulated variable if deviation is positive.




Relationships between deviation and manipulated variable (output frequency)

	Deviation			
	Positive	Negative		
Reverse action	71	ĸ		
Forward action	ĸ	7		

(3) Connection diagram

- •Sink logic
- •Pr. 128 = 20
- •Pr. 182 = 14
- •*Pr.* 190 = 15



- *1 The power supply must be selected in accordance with the power specifications of the detector used.
- *2 The used output signal terminal changes depending on the Pr. 190, Pr. 192, Pr. 197 (output terminal selection) setting.
- *3 The used input signal terminal changes depending on the Pr. 178 to Pr. 182 (input terminal selection) setting.
- *4 The AU signal need not be input.



(4) I/O signals and parameter setting

- •Set "20, 21" in *Pr. 128* to perform PID operation.
- •Set "14" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign PID control selection signal (X14) to turn the X14 signal ON.

When the X14 signal is not assigned, only the Pr. 128 setting makes PID control valid.

•Enter the set point using the inverter terminal 2 or Pr. 133 and enter the measured value to terminal 4.



(I) REMARKS

- When Pr. 128 = "0" or X14 signal is OFF, normal inverter operation is performed without PID action.
- Turning ON/OFF of bit of the terminal, to which X14 signal is assigned through network as RS-485 communication, enables

Signal		Terminal Used	Function	Description	Parameter Setting			
	X14	X14 Depending on		Turn ON X14 signal to perform PID	Set 14 in any of <i>Pr. 178</i> to <i>Pr.</i>			
	XIT	Pr. 178 to Pr. 182	selection	control. *1	182.			
				You can input the set point for PID	<i>Pr. 128</i> = 20, 21,			
	2	2	Cat paint input	control.*4	Pr. 133 = 9999			
	2	2	Set point input	0 to 5V 0 to 100%	<i>Pr.</i> 73 = 1 *2, 11			
				0 to 10V 0 to 100%	<i>Pr.</i> 73 = 0, 10			
Input	PU		Set point input	Set the set point (Pr. 133) from the	<i>Pr. 128</i> = 20, 21			
	FU	_	Set point input	operation panel.	Pr. 133 = 0 to 100%			
				Input the signal from the detector	Pr. 128 = 20, 21			
			Measured value	(measured value signal).	17. 120 – 20, 21			
	4	4		4 to 20mA 0 to 100%	<i>Pr. 267</i> = 0 *2			
			input	0 to 5V 0 to 100%	Pr. 267 = 1			
				0 to 10V 0 to 100%	Pr. 267 = 2			
				Output to indicate that the process value	<i>Pr. 128</i> = 20, 21			
	FUP		l lana an linais accioncis	Output to indicate that the process value signal exceeded the maximum value (Pr.	<i>Pr. 131</i> ≠ 9999			
	FUP		Upper limit output	,	Set 15 or 115 in Pr. 190,			
				131).	Pr. 192, or Pr. 197. *3			
					<i>Pr. 128</i> = 20, 21			
	FDN		Lower limit output	Output when the process value signal	<i>Pr.</i> 132 ≠ 9999			
	FUN		Lower IIIIII output	falls below the minimum value (Pr. 132).	Set 14 or 114 in Pr. 190,			
		Depending on			Pr. 192, or Pr. 197. *3			
		Pr. 190, Pr. 192,		"Hi" is output to indicate that the output				
Output		Pr. 197	Forward (reverse)	indication of the parameter unit is	Set 16 or 116 in <i>Pr. 190</i> ,			
Out	RL	17, 197	rotation direction	forward rotation (FWD) or "Low" to	Pr. 192, or Pr. 197. *3			
-			output	indicate that it is reverse rotation (REV)	Fr. 192, 0r Fr. 197. *3			
				or stop (STOP).				
	PID		During PID control	Turns ON during PID control.	Set 47 or 147 in Pr. 190,			
	FID		activated	Turns On during FID control.	Pr. 192, or Pr. 197. *3			
			PID output	Turns ON when the PID output	Pr. 575 ≠9999			
	SLEEP		interruption	interruption function is performed.	Set 70 or 170 in Pr. 190,			
			•	,	Pr. 192, or Pr. 197. *3			
	SE	SE	Output terminal	Common terminal for open collector				
			common	output terminal.				
*1	When the X14 signal is not assigned, only the <i>Pr. 128</i> setting makes PID control valid.							


- When the X14 signal is not assigned, only the Pr. 128 setting makes PID control valid.
- *2 The shaded area indicates the parameter initial value.
- *3 When 100 or larger value is set in any of Pr.190, Pr.192, and Pr.197 (output terminal function selection), the terminal output has negative logic. (Refer to page 120 for
- When Pr. 561 PTC thermistor protection level ≠"9999", terminal 2 is not available for set point input. Use Pr. 133 for set point input.



- · Changing the terminal function using any of Pr. 178 to Pr. 182, Pr. 190, Pr. 192, and Pr. 197 may affect the other functions. Make setting after confirming the function of each terminal.
- When the Pr. 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (Refer to page 151 for setting)


(5) PID automatic switchover control (Pr. 127)

- •The system can be started up without PID control only at a start.
- •When the frequency is set to *Pr. 127 PID control automatic switchover frequency* within the range 0 to 400Hz, the inverter starts up without PID control from a start until output frequency is reached to the set frequency of *Pr. 127*, and then it shifts to PID control. Once the system has entered PID control operation, it continues PID control even if the output frequency falls to or below *Pr.127*.



(6) PID output suspension function (SLEEP function) (SLEEP signal, Pr. 575 to Pr. 577)

- •The inverter stops operation if the output frequency after PID operation remains at less than the *Pr. 576 Output interruption detection level* setting for longer than the time set in *Pr. 575 Output interruption detection time*. This function can reduce energy consumption in the low-efficiency, low-speed range.
- •When the deviation (= set value measured value) reaches the PID output shutoff cancel level (*Pr. 577* setting -1000%) while the PID output interruption function is ON, the PID output interruption function is canceled and PID control operation is resumed automatically.
- •While the PID output interruption function is ON, the PID output interruption signal (SLEEP) is output. At this time, the inverter running signal (RUN) is OFF, and the PID control operating signal (PID) is ON.
- •For the terminal used for the SLEEP signal output, assign the function by setting "70" (positive logic) or "170" (negative logic) in *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)*.




(7) PID monitor function

- •The PID control set point, measured value and deviation value can be displayed on the operation panel and output from terminal FM.
- •Integral value indicating a negative % can be displayed on the deviation monitor. 0% is displayed as 1000. (The deviation monitor cannot be output from the terminal FM.)
- •For each monitor, set the following value in Pr. 52 DU/PU main display data selection and Pr. 54 FM terminal function selection.

Setting	Monitor Description	Minimum Increments	Terminal FM Full Scale	Remarks
52	PID set point	0.1%	100%	
53	PID measured value	0.1%	100%	_
54	PID deviation	0.1%	_	Value cannot be set to <i>Pr. 54</i> . Displays 1000 when the PID deviation is 0%.




(8) Adjustment procedure



(9) Calibration example

(A detector of 4mA at 0°C and 20mA at 50°C is used to adjust the room temperature to 25°C under PID control. The set point is given to across inverter terminals 2-5 (0 to 5V).)



*When calibration → Using calibration *Pr. 902* and *Pr. 903* (terminal 2) or *Pr. 904* and *Pr. 905* (terminal is required 4), calibrate the detector output and target setting input.

Make calibration in the PU mode during an inverter stop.

<Set point input calibration>

- 1. Apply the input voltage of 0% set point setting (e.g. 0V) across terminals 2-5.
- 2. Enter in C2 (Pr. 902) the frequency which should be output by the inverter at the deviation of 0% (e.g. 0Hz).
- 3. In C3 (Pr.902), set the voltage value at 0%.
- 4. Apply the voltage of 100% set point (e.g. 5V) across terminals 2-5.
- 5. Enter in Pr.125 the frequency which should be output by the inverter at the deviation of 100% (e.g. 60Hz).
- 6. In C4 (Pr.903), set the voltage value at 100%.

<Measured value calibration>


- 1. Apply the input current of 0% measured value (e.g. 4mA) across terminals 4-5.
- 2. Make calibration using C6 (Pr. 904).
- 3. Apply the input current of 100% measured value (e.g. 20mA) across terminals 4-5.
- 4. Make calibration using C7 (Pr. 905).



REMARKS

• The frequency set in C5 (Pr. 904) and Pr. 126 should be the same as set in C2 (Pr. 902) and Pr. 125.

The results of the above calibration are as shown below:





NOTE

- If the multi-speed (RH, RM, RL, REX signal) or Jog operation (JOG signal) is entered with the X14 signal ON, PID control is stopped and multi-speed or Jog operation is started.
- If the setting is as follows, PID control becomes invalid.


Pr. 79 Operation mode selection ="6" (Switchover mode)

The inverter is at a stop with Pr. 261 Power failure stop selection selected.

- Changing the terminal function using any of *Pr. 178 to Pr. 182, Pr. 190, Pr. 192, Pr. 197* may affect the other functions. Make setting after confirming the function of each terminal.
- When PID control is selected, the minimum frequency is the frequency set in *Pr. 902* and the maximum frequency is the frequency set in *Pr. 903*.

(Pr. 1 Maximum frequency and Pr. 2 Minimum frequency settings are also valid.)

- The remote operation function is invalid during PID operation.
- When the control is switched to PID control during normal operation, the frequency command value calculated by PID operation using 0Hz as standard is used without the frequency during the operation.



Operation when control is switched to PID control during normal operation



Parameters referred to

Pr. 59 Remote function selection Refer to page 94

Pr. 73 Analog input selection The Refer to page 151

Pr. 79 Operation mode selection Refer to page 166

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120

Pr. 261 Power failure stop selection Refer to page 143

Pr. 561 PTC thermistor protection level Refer to page 101

C2 (Pr. 902) to C7 (Pr. 905) Frequency setting voltage (current) bias/gain 👺 Refer to page 154



4.20.2 Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)


Performs PID control by feedbacking the position detection of the dancer roller, controlling the dancer roller is in the specified position.

Parameter Number	Name	Initial Value		Setting Range		Description	on	
	Second	3.7K or less 5s 5.5K and 7.5K 10s 11K and 15K 15s						
44	acceleration/			0 to 3600s	speed during		ation time of the main t will not function as	
	deceleration time				3ccoria accere	Ji ation/accordiat	ion unic.	
	Second			0 to 3600s	This parameter is the deceleration time of the main			
45	deceleration time	9999		9999	t will not function as			
				0	PID action is r	not performed		
				20	PID reverse action	Measured valu	` '	
				21	PID forward action	Set value (tern	ninal 2 or <i>Pr. 133</i>)	
128	PID action	0		40	PID reverse action	Addition method: fixed	For dancer control	
	selection			41	PID forward action	Addition method: fixed	set point (Pr. 133), measured value	
				42	PID reverse action	Addition method: ratio	(terminal 4) main speed (speed command of the	
				43	PID forward action	Addition method: ratio	operation mode)	
129 *1	PID proportional band	100%		0.1 to 1000%	setting is sma greatly with a Hence, as the response sens	slight change of proportional ban sitivity (gain) imporates, e.g. hunt	ted variable varies the measured value. nd narrows, the	
				9999	No proportional control			
130 *1	PID integral time	1s		0.1 to 3600s	required for in manipulated v As the integra reached earlie	tegral (I) action to ariable as the pro- I time decreases ar but hunting oc	time (Ti) is the time to provide the same oportional (P) action. s, the set point is curs more easily.	
				9999	No integral control.			
131	PID upper limit	9999		0 to 100%	Maximum value If the feedback value exceeds the setting, the FUF signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4) is equivalent to 100%.		n input (20mA/5V/	
				9999	No function			
132	PID lower limit	9999		0 to 100%	Minimum value If the process value falls below the setting range, the FDN signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4 is equivalent to 100%.		maximum input	
				9999	No function			
133 *1	PID action set	9999		0 to 100%		e set point for P	ID control.	
	point			9999	Always 50%	romp input time-	(Td) required for	
134 *1	PID differential time	9999		0.01 to 10s	For deviation ramp input, time (Td) required for providing only the manipulated variable for the proportional (P) action. As the differential time increases, greater respons is made to a deviation change.		d variable for the es, greater response	
				9999	No differential	No differential control.		

The above parameters can be set when Pr.160 Extended function display selection ="0". (Refer to page 163)

^{*1} Pr. 129, Pr. 130, Pr. 133 and Pr.134 can be set during operation. These can also be set independently of the operation mode.

(1) Dancer control block diagram



*1 The main speed can be selected from all operation mode such as external (analog voltage input, multi-speed), PU (digital frequency setting), and communication (RS-485).

Set point and measured value of PID control

	Input	Input Signal	Pr.267 Setting	Voltage/Current Input Switch
Set point	Pr. 133	0 to 100%	_	_
Measured	When measured value is input as current (4 to 20mA)	4mA 0%, 20mA100%	0	V
value	When measured value is input as voltage	0V 0%, 5V100%	1	
		0V 0%, 10V100%	2	VI



NOTE


- Changing the terminal function using any of *Pr.178 to Pr.182* may affect the other functions. Make setting after confirming the function of each terminal.
- When the *Pr. 267* setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (*Refer to page 151* for setting)



(2) Dancer control overview


Performs dancer control by setting 40 to 43 in *Pr. 128 PID action selection*. The main speed command is the speed command of each operation mode (External, PU, Network). Performs PID control by the position detection signal of the dancer roller, then the result is added to the main speed command. For acceleration/deceleration of the main speed, set the acceleration time in *Pr. 44 Second acceleration/deceleration time/Pr. 45 Second deceleration time*.

* Set 0s normally to Pr. 7 Acceleration time and Pr.8 Deceleration time. When the Pr. 7 and Pr. 8 setting is large, response of dancer control during acceleration/ deceleration is slow.



(3) Connection diagram

- •Sink logic
- Pr. 128 = 41
- •Pr. 182 = 14
- •Pr. 190 = 15



- *1 The main speed command differs according to each operation mode (External, PU, Network)
- *2 The used output signal terminal changes depending on the Pr. 190, Pr. 192, Pr. 197 (output terminal selection) setting.
- *3 The used input signal terminal changes depending on the Pr. 178 to Pr. 182 (input terminal selection) setting.
- *4 The AU signal need not be input.

(4) I/O signals and parameter setting

- •Set "40 to 43" in Pr. 128 to perform dancer control.
- •Set "14" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign PID control selection signal (X14) to turn the X14 signal ON.

When the X14 signal is not assigned, only the Pr. 128 setting makes dancer control valid.

- •Input the main speed command (External, PU, Network). The main speed command in any operation mode can be input. (Note that terminal 4 can not be used as the main speed command.)
- •Input the set point using Pr. 133, then input the measured value signal (dancer roller position detection signal) across terminal 4 and 5 of the inverter.



• REMARKS

- When Pr. 128 = "0" or X14 signal is OFF, normal inverter operation is performed without dancer control.
- Turning ON/OFF of bit of the terminal, to which X14 signal is assigned through network as RS-485 communication, enables

S	ignal	Terminal Used	Function	Description	Parameter Setting
	X14	Depending on	PID control	Turn ON X14 signal to perform dancer	Set 14 in any of <i>Pr. 178 to Pr. 182</i> .
	A14	Pr. 178 to Pr. 182	selection	control. *1	Set 14 III ally 01 Fr. 178 to Fr. 182.
				Input the signal from the dancer roller	<i>Pr.128</i> = 40, 41, 42, 43
Input			Measured value	detector (measured value signal).	77.120 - 40, 41, 42, 43
=	4	4		4 to 20mA 0 to 100%	<i>Pr.267</i> = 0 *2
			input	0 to 5V 0 to 100%	<i>Pr.267</i> = 1
				0 to 10V 0 to 100%	Pr.267 = 2
				Output to indicate that the measured	<i>Pr.128</i> = 40, 41, 42, 43
	FUP		Upper limit output	value signal exceeded the maximum	<i>Pr.131</i> ≠ 9999
	FUF		Opper illriit output	value	Set 15 or 115 in Pr. 190, Pr. 192, or
				(Pr. 131).	Pr. 197. *3
					<i>Pr.128</i> = 40, 41, 42, 43
	FDN	Depending on	Lower limit output	Output when the measured value signal	<i>Pr.132</i> ≠ 9999
	I DIN	Pr. 190, Pr. 192,	Lower IIIIII output	falls below the minimum value (Pr. 132).	Set 14 or 114 in Pr. 190, Pr. 192, or
Output		Pr. 197			Pr. 197. *3
Out		17.19/	Forward (reverse)	Output is "ON" when the output	
	RL		rotation direction	indication of the parameter unit is	Set 16 or 116 in Pr. 190, Pr. 192, or
	output			forward rotation (FWD) and "OFF" when	Pr. 197. *3
			'	reverse rotation (REV) or stop (STOP).	
			During PID control	Turns ON during PID control.	Set 47 or 147 in Pr. 190, Pr. 192, or
			activated		Pr. 197. *3
	SE	SE	Output terminal	Common terminal for open collector	
)	,	common	output terminal	


- When the X14 signal is not assigned, only the Pr. 128 setting makes dancer control valid.
- The shaded area indicates the parameter initial value.
- When 100 or larger value is set in any of Pr. 190, Pr. 192, and Pr. 197 (output terminal function selection), the terminal output has negative logic. (Refer to page 120



- Changing the terminal function using any of Pr. 178 to Pr. 182, Pr. 190, Pr. 192, and Pr. 197 may affect the other functions. Make setting after confirming the function of each terminal.
- When the Pr. 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (Refer to page 151 for setting)
- Turn OFF PID output suspension function (*Pr. 575* = "9999") while using dancer control.
- When Pr. 561 PTC thermistor protection level ≠ "9999", terminal 2 is not available for main speed command. Terminal 2 is used as PTC thermistor input terminal.



(5) Parameter details



•When ratio ($Pr.\ 128$ = "42, 43") is selected for addition method, PID control × (ratio of main speed) is added to the main speed. The ratio is determined by the $Pr.\ 125$ Terminal 2 frequency setting gain frequency and C2 ($Pr.\ 902$) Terminal 2 frequency setting bias frequency. The frequency setting signal is set to 0 to 60Hz in the range between 0 to 100% in the initial setting. The ratio is (×100%) when the main speed is 60Hz and (×50%) when 30Hz.



NOTE

- Even when C4 (Pr. 903) is set to other than 100%, the frequency setting signal is considered as 100%.
- Even when C3 (Pr. 903) is set to other than 0%, the frequency setting signal is considered as 0%.
- When C2 (Pr. 902) is set to other than 0Hz, the frequency setting signal is 0% when C2 (Pr. 902) is less than the set frequency
- •Turning X14 signal ON/OFF during operation by assigning X14 signal results in the following operation.

When X14 signal is ON: Uses output frequency unchanged as the main speed command and continues operation by dancer control.

When X14 signal is OFF: Ends dancer control and continues operation at the set frequency valid.

Pr. 128 Setting	PID Action	Addition Method	Set Point	Measured Value	Main Speed Command	
40	Reverse action	Fixed				
41	Forward action	TIXEG	Pr. 133	Terminal 4	Speed command for each operation mode	
42	Reverse action	Ratio				
43	Forward action	Natio			-	

- •Action of *Pr. 129 PID proportional band, Pr. 130 PID integral time, Pr. 131 PID upper limit, Pr. 132 PID lower limit, Pr. 134 PID differential time* is the same as PID control. For the relationship of controlled variable (%) of PID control and frequency, 0% is equivalent to the set frequency of *Pr. 902* and 100% to *Pr. 903*.
- •For the *Pr. 133 PID action set point* setting, set frequency of *Pr. 902* is equivalent to 0% and *Pr. 903* to 100%. When *9999* is set in *Pr. 133*, 50% is the set point.



> REMARKS

Pr. 127 PID control automatic switchover frequency is invalid.

(6) Output signal

•Output terminal assignment during dancer control (PID control) operation

PID signal turns ON during dancer control (PID control) or at a stop by PID control (in the status PID operation being performed inside) (The signal is OFF during normal operation.)

For the terminal used for PID signal output, assign the function by setting "47 (positive logic) or 147 (negative logic)" in *Pr.* 190, *Pr.* 192, or *Pr.* 197 (output terminal function selection).



NOTE

Changing the terminal function using any of *Pr. 178* to *Pr. 182*, *Pr. 190*, *Pr. 192*, *and Pr. 197* may affect the other functions. Make setting after confirming the function of each terminal.

(7) PID monitor function

- •The PID control set point and measured value can be output to the operation panel monitor display and terminal FM.
- •For each monitor, set the following value in Pr. 52 DU/PU main display data selection and Pr. 54 FM terminal function selection.

Setting	Setting Monitor Description		Terminal FM	Remarks	
Octaing	monitor Becomption	Increments Full Scale		Romano	
52	PID set point	0.1%	100%		
53	PID measured value	0.1%	100%	_	
54	PID deviation	0.1%		Value cannot be set in Pr. 54.	
54	PID deviation	0.1%	_	Displays 1000 when the PID deviation is 0%.	


(8) Priorities of main speed command

- •The priorities of the main speed speed command source when the speed command source is external are as follows. JOG signal > multi-speed setting signal (RL/RM/RH/REX) > terminal 2
- •The priorities of the main speed speed command source when "3" is set in *Pr. 79*. Multi-speed setting signal (RL/RM/RH/REX) > set frequency (digital setting by PU, operation panel)
- •Terminal 4 can not be selected as the main speed speed command even when AU terminal is turned ON.
- •Even when a remote operation function is selected by setting a value other than "0" in *Pr. 59*, compensation of the remote setting frequency to the main speed is ignored (changes to 0).

(9) Adjustment procedure

Dancer roller position detection signal adjustment

When terminal 4 input is voltage input, 0V is the minimum position and 5V(10V) is the maximum position. When current is input, 4mA is the minimum position and 20mA is the maximum position. (initial value) When 0 to 7V is output from the potentiometer, it is necessary to calibrate C7 (Pr. 905) at 7V.



(Example) Control at a dancer center position using a 0 to 7V potentiometer

- 1) After changing the current/voltage input switch to "V", set "2" in Pr. 267 to change terminal 4 input to voltage input.
- 2) Input 0V to across terminal 4 and 5 to calibrate C6 (Pr. 904). (% display displayed at analog calibration is independent to % of the feed back value.)
- 3) By inputting 7V to across terminal 4 to 5, calibrate C7(Pr. 905) (% display displayed at analog calibration is independent to % of the feed back value.)
- 4) Set 50% in Pr.133.



NOTE

When the Pr. 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (Refer to page 151 for setting)



• REMARKS

- PID control stops when RH, RM, RL, and REX signals (for multi-speed operation) or JOG signal is input during normal PID control. However, PID control continues when those signals are input during dancer control since these are treated as speed commands.
- During dancer control, Second acceleration/deceleration time of Pr.44 and Pr.45 are the parameters for acceleration/deceleration time setting to the main speed command source. These do not function as the second function.
- When switchover mode is set with "6" in Pr. 79, dancer control (PID control) is invalid.
- Speed command to terminal 4 by turning AU signal ON is invalid during dancer control.
- Acceleration/deceleration of the main speed command is the same operation as when frequency command is increased/ decreased by analog input
- Therefore, SU signal remains ON even if the starting signal is turned ON/OFF.(always in the constant speed state)
- The DC brake operation starting frequency when turning OFF the starting signal is not Pr. 10 but a smaller value of either Pr. 13
- The set frequency monitor is always variable as "main speed command+PID control".
- The main speed setting frequency accelerates for the acceleration/deceleration time set in Pr. 44 and Pr. 45 and the output frequency accelerates/decelerates for the acceleration/deceleration time set in Pr. 7 and Pr. 8. Therefore, when the set time of Pr. 7 and Pr. 8 is longer than Pr. 44 and Pr. 45, the output frequency accelerates/decelerates for the acceleration/deceleration time set in Pr. 7 and Pr. 8.
- For the integral term limit, a smaller value of either the PID manipulated variable (%) value converted from the linear interpolated Pr. 1 Maximum frequency with Pr. 902 and Pr. 903, or 100% is used for limit.
- Although the output frequency is limited by the minimum frequency, operation limit of the integral term is not performed.



Parameters referred to

Pr. 59 Remote function selection Refer to page 94

Pr. 73 Analog input selection Refer to page 151

Pr. 79 Operation mode selection Refer to page 166

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 114

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120

Pr. 561 PTC thermistor protection level Refer to page 101

C2 (Pr. 902) to C7 (Pr. 905) Frequency setting voltage (current) bias/gain Refer to page 154



4.20.3 Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)

This function detects a regeneration status and increases the frequency to avoid the regenerative status.


 Possible to avoid regeneration by automatically increasing the frequency to continue operation if the fan happens to rotate faster than the set speed due to the effect of another fan in the same duct.


Parameter Number	Name	Initia	l Value	Setting Range	Description
	Regeneration			0	Regeneration avoidance function invalid
882	avoidance operation		0	1	Regeneration avoidance function is always valid
302	selection		J	2	Regeneration avoidance function is valid only during a constant speed operation
883	Regeneration avoidance operation level	100V class, 200V class 400V class	400 VDC 780 VDC	300 to 800V	Bus voltage level at which regeneration avoidance operates. When the bus voltage level is set to low, overvoltage error will be less apt to occur. However, the actual deceleration time increases. The set value must be higher than the "power supply voltage \times $\sqrt{2}$ " *.
	Regeneration avoidance			0 to 10Hz	Limit value of frequency which rises at activation of regeneration avoidance function.
885	compensation frequency limit value	6	Hz	9999	Frequency limit invalid
886	Regeneration avoidance voltage gain	100%		0 to 200%	Responsiveness at activation of regeneration avoidance. A larger setting will improve responsiveness to the bus voltage change. However, the output frequency could become unstable.
665	Regeneration avoidance frequency gain		00%	0 to 200%	When vibration is not suppressed by decreasing the $Pr.~886$ setting, set a smaller value in $Pr.~665$.


The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) What is regeneration avoidance function? (Pr. 882, Pr. 883)

- •When the regeneration load is large, the DC bus voltage rises and an overvoltage fault (E. OV□) may occur. When this bus voltage rise is detected and the bus voltage level reaches or exceeds Pr. 883, increasing the frequency avoids the regeneration status.
- •The regeneration avoidance function is always ON when "1" is set in Pr. 882, and activated only during a constant speed when "2" is set in Pr. 882.







^{*} For Single-phase 100V power input model, power input voltage \times 2 \times $\sqrt{2}$.





REMARKS

- The acceleration/deceleration ramp while the regeneration avoidance function is operating changes depending on the regeneration load.
- The DC bus voltage of the inverter is about √2 times of normal input voltage. (For 100V class, twice the amount of the power input voltage.)


When the input voltage is 100VAC, bus voltage is approximately 283VDC.

When the input voltage is 220VAC, bus voltage is approximately 311VDC.

When the input voltage is 440VAC, bus voltage is approximately 622VDC.

However, it varies with the input power supply waveform.

- The *Pr. 883* setting should be kept higher than the DC bus voltage level. Otherwise, the regeneration avoidance function is always ON even in the non-regeneration status and the frequency increases.
- While overvoltage stall () is activated only during deceleration and stops the output frequency, the regeneration avoidance function is always ON (*Pr.* 882 = 1) or activated only during a constant speed (*Pr.* 882 = 2) and increases the frequency according to the regeneration amount.



(2) Limit regeneration avoidance operation frequency (Pr. 885)

You can limit the output frequency compensated (increased) by the regeneration avoidance function.

- •The frequency is limited to the output frequency (frequency prior to regeneration avoidance operation) + *Pr. 885 Regeneration avoidance compensation frequency limit value* during acceleration or constant speed. If the regeneration avoidance frequency exceeds the limit value during deceleration, the limit value is held until the output frequency falls to 1/2 of *Pr. 885*.
- •When the frequency increased by regeneration avoidance function has reached *Pr. 1 Maximum frequency*, it is limited to the maximum frequency.
- •When *Pr. 885* is set to "9999", regeneration avoidance function operation frequency setting is invalid.

(3) Regeneration avoidance function adjustment (Pr. 665, Pr. 886)

•If the frequency becomes instable during regeneration avoidance operation, decrease the setting of *Pr. 886 Regeneration avoidance voltage gain*. Reversely, if sudden regeneration causes an overvoltage alarm, increase the setting.

When vibration is not suppressed by decreasing the *Pr. 886* setting, set a smaller value in *Pr. 665 Regeneration avoidance frequency gain*.



NOTE

- When regeneration avoidance operation is performed, stall prevention is also activated at the same time.
- The regeneration avoidance function cannot shorten the actual deceleration time taken to stop the motor. The actual
 deceleration time depends on the regeneration energy consumption capability. To shorten the deceleration time,
 consider using the regeneration unit (FR-BU2, FR-CV, FR-HC) and brake resistor (MRS type, MYS type, FR-ABR etc.)
 to consume regeneration energy at constant speed.
- When using the regeneration unit (FR-BU2, FR-CV, FR-HC) and brake resistor (MRS type, MYS type, FR-ABR etc.), set Pr. 882 to "0 (initial value)" (regeneration avoidance function invalid). When using the regeneration unit, etc. to consume regeneration energy at deceleration, set Pr. 882 to "2" (regeneration avoidance function valid only at a constant speed).
- When regeneration avoidance operation is performed, the OL signal output item of *Pr. 156* also becomes the target of \Box (overvoltage stall). *Pr. 157 OL signal output timer* also becomes the target of \Box (overvoltage stall).



Parameters referred to

Pr. 1 Maximum frequency Refer to page 84

Pr. 8 Deceleration time Refer to page 97

Pr. 22 Stall prevention operation level Refer to page 80



4.21 Useful functions

Purpose	Parameter th	Refer to Page	
To increase cooling fan life	Cooling fan operation Pr. 244		229
To determine the maintenance time	Inverter part life display	Pr. 255 to Pr. 259	230
	Maintenance output function	Pr. 503, Pr. 504	234
of parts	Current average value monitor signal	Pr. 555 to Pr. 557	235
Freely available parameter	Free parameter	Pr. 888, Pr. 889	237

4.21.1 Cooling fan operation selection (Pr. 244)

You can control the operation of the cooling fan (1.5K or more) built in the inverter.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Operates in power-ON status. Cooling fan ON/OFF control invalid (the cooling fan is always ON at power-ON)
244	Cooling fan operation selection	1	1	Cooling fan ON/OFF control valid The fan is always ON while the inverter is running. During a stop, the inverter status is monitored and the fan switches ON/OFF according to the temperature.

The above parameter can be set when Pr.160 Extended function display selection = "0". (Refer to page 163)

- In either of the following cases, fan operation is regarded as faulty as [FN] is shown on the operation panel, and the fan fault (FAN) and alarm (LF) signals are output.
 - Pr. 244 = "0"

When the fan comes to a stop with power ON.

•Pr. 244 = "1"

When the inverter is running and the fan stops during fan ON command.

• For the terminal used for FAN signal output, set "25 (positive logic) or 125 (negative logic)" to *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)*, and for the LF signal, set "98 (positive logic) or 198 (negative logic)".



NOTE

• Changing the terminal assignment using *Pr. 190, Pr. 192, and Pr. 197 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120

4.21.2 Display of the lives of the inverter parts (Pr. 255 to Pr. 259)

Degrees of deterioration of main circuit capacitor, control circuit capacitor, cooling fan and inrush current limit circuit can be diagnosed by a monitor.

When any part has approached to the end of its life, an alarm can be output by self diagnosis to prevent a fault.

(Use the life check of this function as a guideline since the life except the main circuit capacitor is calculated theoretically.)

For the life check of the main circuit capacitor, the alarm signal (Y90) will not be output if a measuring method of (4) is not performed.

Parameter	Name	Initial Value	Setting	Description
Number	Name	iiiitiai value	Range	Description
				Displays whether the control circuit capacitor,
255	Life alarm status display	0	(0 to 15)	main circuit capacitor, cooling fan, and each parts
255	Life diaini status display	U	(0 to 13)	of the inrush current limit circuit have reached the
				life alarm output level or not. (Reading only)
	Inrush current limit circuit			Displays the deterioration degree of the inrush
256		100%	(0 to 100%)	current limit circuit.
	life display			(Reading only)
	Control circuit capacitor life			Displays the deterioration degree of the control
257	display	100%	(0 to 100%)	circuit capacitor.
				(Reading only)
				Displays the deterioration degree of the main
258	Main circuit capacitor life	100%	(0 to 100%)	circuit capacitor.
250	display	100%	(0 to 100%)	(Reading only)
				The value measured by Pr. 259 is displayed.
				Setting "1" and turning the power supply OFF
				starts the measurement of the main circuit
259	Main circuit capacitor life	0	0, 1	capacitor life.
259	measuring	U	(2, 3, 8, 9)	When the Pr. 259 value is "3" after powering ON
				again, the measuring is completed.
				Writes deterioration degree in Pr. 258.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)




(I) REMARKS

Since repeated inrush currents at power ON will shorten the life of the converter circuit, frequent starts and stops of the magnetic contactor must be avoided.



(1) Life alarm display and signal output (Y90 signal, Pr. 255)

•Whether any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit has reached the life alarm output level or not can be checked by *Pr. 255 Life alarm status display* and life alarm signal (Y90).



Pr. 255 (decimal)	Bit (binary)	Inrush Current Suppression Circuit Life	Cooling Fan Life	Main Circuit Capacitor Life	Control Circuit Capacitor Life
15	1111	0	0	0	0
14	1110	0	0	0	×
13	1101	0	0	×	0
12	1100	0	0	×	×
11	1011	0	×	0	0
10	1010	0	×	0	×
9	1001	0	×	×	0
8	1000	0	×	×	×
7	0111	×	0	0	0
6	0110	×	0	0	×
5	0101	×	0	×	0
4	0100	×	0	×	×
3	0011	×	×	0	0
2	0010	×	×	0	×
1	0001	×	×	×	0
0	0000	×	×	×	×

O: With warnings, \times : Without warnings

- •The life alarm signal (Y90) turns ON when any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit reaches the life alarm output level.
- •For the terminal used for the Y90 signal, set "90" (positive logic) or "190" (negative logic) to *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)*.



NOTE

• Changing the terminal assignment using *Pr. 190*, *Pr. 192*, *Pr. 197 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

(2) Inrush current limit circuit life display (Pr. 256)

- •The life of the inrush current limit circuit (relay, contactor and inrush resistor) is displayed in Pr. 256.
- •The number of contact (relay, contactor, thyristor) ON times is counted, and it is counted down from 100% (0 time) every 1%/10,000 times.

As soon as 10% (900,000 times) is reached, Pr. 255 bit 3 is turned ON and also an alarm is output to the Y90 signal.

(3) Control circuit capacitor life display (Pr. 257)

- •The deterioration degree of the control circuit capacitor is displayed in Pr. 257 as a life.
- In the operating status, the control circuit capacitor life is calculated from the energization time and temperature, and is counted down from 100%.

As soon as the control circuit capacitor life falls below 10%, *Pr. 255* bit 0 is turned ON and also an alarm is output to the Y90 signal.

(4) Main circuit capacitor life display (Pr. 258, Pr. 259)

- •The deterioration degree of the control circuit capacitor is displayed in Pr. 258 as a life.
- •On the assumption that the main circuit capacitor capacitance at factory shipment is 100%, the capacitor life is displayed in *Pr. 258* every time measurement is made.

When the measured value falls to or below 85%, Pr. 255 bit 1 is turned ON and also an alarm is output to the Y90 signal.

- Measure the capacitor capacity according to the following procedure and check the deterioration level of the capacitor capacity.
 - 1) Check that the motor is connected and at a stop.
 - 2) Set "1" (measuring start) in Pr. 259.
 - 3) Switch power OFF. The inverter applies DC voltage to the motor to measure the capacitor capacity while the inverter is OFF
 - 4) After confirming that the LED of the operation panel is OFF, power ON again.
 - 5) Check that "3" (measuring completion) is set in *Pr. 259*, read *Pr. 258*, and check the deterioration degree of the main circuit capacitor.

Pr. 259	Description	Remarks
0	No measurement	Initial value
1	Measurement start	Measurement starts when the power
'	weasurement start	supply is switched OFF.
2	During measurement	
3	Measurement complete	Only displayed and cannot be set
8	Forced end	Only displayed and Calliot be set
9	Measurement error	



> REMARKS

- When the main circuit capacitor life is measured under the following conditions, "forced end" (Pr. 259 = "8") or "measuring error" (Pr. 259 = "9") occurs or it remains in "measuring start" (Pr. 259 = "1"). Therefore, do not measure in such case.
 - In addition, even when "measurement completion" (Pr. 259 = "3") is confirmed under the following conditions, normal measurement can not be done.
 - (a)FR-HC or FR-CV is connected.
 - (b)DC power supply is connected to the terminal P/+ and N/-.
 - (c)The power supply switched ON during measurement.
 - (d)The motor is not connected to the inverter.
 - (e)The motor is running (coasting)
 - (f)The motor capacity is two rank smaller as compared to the inverter capacity.
 - (g)The inverter is tripped or a fault occurred when power is OFF.
 - (h)The inverter output is shut off with the MRS signal.
 - (i)The start command is given while measuring.
 - (j)The parameter unit (FR-PU04/FR-PU07) is connected.
 - (k)Use terminal PC as power supply.
 - (I)I/O terminal of the control terminal block is ON (continuity).
- Turning the power ON during measuring before LED of the operation panel turns OFF, it may remain in "measuring" (*Pr. 259* = "2") status. In such case, carry out operation from step 2.



POINT

For accurate life measurement of the main circuit capacitor, wait 3 hours or longer after turning OFF. The temperature left in the main circuit capacitor affects measurement.



When measuring the main circuit capacitor capacity (*Pr. 259 Main circuit capacitor life measuring* = "1"), the DC voltage is applied to the motor for 1s at powering OFF. Never touch the motor terminal, etc. right after powering OFF to prevent an electric shock.



(5) Cooling fan life display

•The cooling fan speed of 50% or less is detected and "FN" is displayed on the operation panel and parameter unit (FR-PU04/FR-PU07). As an alarm display, Pr. 255 bit2 is turned ON and also an alarm is output to the Y90 signal.



• REMARKS

• When the inverter is mounted with two or more cooling fans, "FN" is displayed with one or more fans with speed of 50% or less.



• For replacement of each part, contact the nearest Mitsubishi FA center.


4.21.3 Maintenance timer alarm (Pr. 503, Pr. 504)

When the cumulative energization time of the inverter reaches the parameter set time, the maintenance timer output signal (Y95) is output. $\Pi \Gamma$ (MT) is displayed on the operation panel.

This can be used as a guideline for the maintenance time of peripheral devices.

Parameter Number	Name	Initial Value	Setting Range	Description
503	Maintenance timer	0	0 (1 to 9998)	Displays the cumulative energization time of the inverter in 100h increments. (Reading only) Writing the setting of "0" clears the cumulative energization time.
504	Maintenance timer alarm output set time	9999	0 to 9998	Time taken until when the maintenance timer alarm output signal (Y95) is output.
	output out time		9999	No function

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



- The cumulative energization time of the inverter is stored into the EEPROM every hour and is displayed in *Pr. 503 Maintenance timer* in 100h increments. *Pr. 503* is clamped at 9998 (999800h).
- When the *Pr. 503* value reaches the time set to *Pr. 504 Maintenance timer alarm output set time* (100h increments), the maintenance timer alarm output signal (Y95) is output.
- For the terminal used for the Y95 signal output, assign the function by setting "95" (positive logic) or "195" (negative logic) to *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection)*.



NOTE

- The cumulative energization time is counted every hour. The energization time of less than 1h is not counted.
- Changing the terminal assignment using *Pr. 190, Pr. 192, and Pr. 197 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Refer to page 120




4.21.4 Current average value monitor signal (Pr. 555 to Pr. 557)

The average value of the output current during constant speed operation and the maintenance timer value are output as a pulse to the current average value monitor signal (Y93).

The pulse width output to the I/O module of the programmable controller or the like can be used as a guideline to know abrasion of machines, elongation of belt and the maintenance time for aged deterioration of devices.


The current average value monitor signal (Y93) is output as pulse for 20s as 1 cycle and repeatedly output during constant speed operation.



Parameter Number	Name	Initial Value	Setting Range	Description
555	Current average time	1s	0.1 to 1s	Time taken to average the current during start pulse output (1s).
556	Data output mask time	0s	0 to 20s	Time for not obtaining (mask) transient state data.
557	Current average value monitor signal output reference current	Rated inverter current	0 to 500A	Reference (100%) for outputting the signal of the current average value.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.



- The pulse output of the current average value monitor signal (Y93) is shown above.
- For the terminal used for the Y93 signal output, assign the function by setting "93" (positive logic) or "193" (negative logic) to any of *Pr. 190 or Pr. 197 (Output terminal function selection)*. The function can not be assigned to *Pr. 192 A,B,C terminal function selection*.

1) Setting of Pr. 556 Data output mask time

The output current is unstable (transient state) right after the operation is changed from the acceleration/deceleration state to the constant speed operation. Set the time for not obtaining (mask) transient state data in *Pr.* 556.

2) Setting of Pr. 555 Current average time

The average output current is calculated during Hi output of start pulse (1s). Set the time taken to average the current during start bit output in *Pr.* 555.

3) Setting of Pr.557 Current average value monitor signal output reference current


Set the reference (100%) for outputting the signal of the current average value. Obtain the time to output the signal from the following calculation.

$\frac{\text{Output current average value}}{Pr. 557 \text{ setting}} \times 5s \text{ (Output current average value 100\%/5s)}$

Note that the output time range is 0.5 to 9s and the output time is either of the following values when the output current average value is the corresponding percentage of the Pr. 557 setting.

Less than 10% ... 0.5s, more than 180% ... 9s


Example) when Pr. 557 = 10A and the average value of output current is 15A As 15A/10A x 5s=7.5, the current average value monitor signal is output as low pulse shape for 7.5s.



4) Setting of Pr. 503 Maintenance timer


After the output current average value is output as low pulse shape, the maintenance timer value is output as high pulse shape. The output time of the maintenance timer value is obtained from the following calculation.

Note that the output time range is 2 to 9s, and it is 2s when the Pr. 503 setting is less than 16000h and 9s when exceeds 72000h.



REMARKS

- · Mask of data output and sampling of output current are not performed during acceleration/deceleration.
- When the speed is changed to acceleration/deceleration from constant speed during start pulse output, the data is judged as
 invalid. The start pulse is output as high pulse shape for 3.5s, and the end signal is output as low pulse shape for 16.5s.
 The signal is output for at least 1 cycle even when acceleration/deceleration state continues after the start pulse output is
 completed.



- When the output current value (inverter output current monitor) is 0A on completion of the 1 cycle signal output, the signal is not
 output until the speed becomes constant next time.
- The current average value monitor signal (Y93) is output as low pulse shape for 20s (without data output) under the following conditions.
- (a) When the motor is in the acceleration/deceleration state on completion of the 1 cycle signal output
- (b) When 1-cycle signal output was ended during restart operation with the setting of automatic restart after instantaneous power failure (*Pr.* 57 ≠ "9999")
- (c) When restart operation was being performed at the point of data output mask end with the setting of automatic restart after instantaneous power failure (*Pr.* 57 ≠ "9999")



NOTE

Changing the terminal assignment using *Pr. 190, Pr. 192, and Pr. 197 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 57 Restart coasting time Refer to page 137

Pr. 190, Pr. 192, Pr. 197 (output terminal function selection) Terminal Refer to page 120

Pr. 503 Maintenance timer Refer to page 234



You can input any number within the setting range of 0 to 9999.

For example, the number can be used:

- As a unit number when multiple units are used.
- As a pattern number for each operation application when multiple units are used.
- As the year and month of introduction or inspection.

Parameter Number	Name	Initial Value	Setting Range	Description
888	Free parameter 1	9999	0 to 9999	Any values can be set. Data is held even
889	Free parameter 2	9999	0 to 9999	if the inverter power is turned OFF.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr.77 Parameter write selection*.



Pr. 888 and Pr. 889 do not influence the inverter operation.

4.22 Setting the parameter unit and operation panel

Purpose	Parameter	that should be Set	Refer to Page
Selection of rotation direction by	RUN key rotation direction selection	Pr. 40	238
Switch the display language of the parameter unit	PU display language selection	Pr. 145	238
Use the setting dial of the operation panel like a potentiometer for frequency setting Key lock of operation panel	Operation panel operation selection	Pr. 161	239
Change the magnitude of change of frequency setting by the setting dial of the operation panel	Magnitude of frequency change setting	Pr. 295	241
Control of the parameter unit buzzer	PU buzzer control	Pr. 990	242
Adjust LCD contrast of the parameter unit	PU contrast adjustment	Pr. 991	242

4.22.1 RUN key rotation direction selection (Pr. 40)

Used to choose the direction of rotation by operating (RUN) of the operation panel.

Parameter Number	Name	Initial Value	Setting Range	Description
40	RUN key rotation direction	0	0	Forward rotation
40	selection	0	1	Reverse rotation

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

4.22.2 PU display language selection(Pr.145)

You can switch the display language of the parameter unit (FR-PU04/FR-PU07) to another.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Japanese
	PU display language		1	English
		0	2	German
145			3	French
145	selection		4	Spanish
			5	Italian
			6	Swedish
			7	Finnish

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)



4.22.3 Operation panel frequency setting/key lock selection (Pr. 161)

The setting dial of the operation panel can be used for setting like a potentiometer. The key operation of the operation panel can be disabled.

Parameter Number	Name	Initial Value	Setting Range	Description	
			0	Setting dial frequency setting mode	· Key lock invalid
161	Frequency setting/key lock operation selection	0	1	Setting dial potentiometer mode	Rey lock invalid
101			10	Setting dial frequency setting mode	Key lock valid
			11	Setting dial potentiometer mode	Rey lock vallu

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Using the setting dial like a potentiometer to set the frequency Operation example Changing the frequency from 0Hz to 60Hz during operation Operation -Display -1. Screen at powering ON The monitor display appears PU indication is lit. 2. Press $\frac{PU}{FXT}$ to choose the PU operation mode. PRM indication is lit. 3. Press (MODE) to choose the parameter setting (MODE mode. (The parameter number read previously 4. Turn until P. 15 (Pr. 160) appears. **5.** Press(SET) to read the present set value. " 9999" (initial value) appears. 6. Turn (***) to change it to the set value " []". 7. Press(SET to set. Flicker Parameter setting complete!! 8. Change *Pr. 161* to the setting value of " ¦ " (SET) in the similar manner. (Refer to step 4 to 7.) Flicker Parameter setting complete!! 9. Mode/monitor check (MODE Press (MODE) twice to choose the monitor/ frequency monitor. 10.Press (RUN) to start the inverter. 11. Turn (until " $\mathcal{E} \mathcal{Q} \mathcal{Q} \mathcal{Q}$ " appears.

The flickering frequency is the set frequency.

You need not press (SET)

The frequency flickers for about 5s.





• REMARKS

- If the display changes from flickering "60.00" to "0.00", the setting of Pr. 161 Frequency setting/key lock operation selection may not
- Independently of whether the inverter is running or at a stop, the frequency can be set by merely turning the dial.
- When the frequency is changed, it will be stored in EEPROM as the set frequency after 10s.



• When setting frequency by turning setting dial, the frequency goes up to the set value of *Pr.1 Maximum frequency* (initial value: 120Hz). Adjust *Pr.1 Maximum frequency* setting according to the application.

(2) Disable the setting dial and key operation of the operation panel (Press [MODE] long (2s))

- •Operation using the setting dial and key of the operation panel can be invalid to prevent parameter change, and unexpected start or frequency setting.
- •Set "10 or 11" in Pr. 161, then press (MODE) for 2s to make the setting dial and key operation invalid.
- •When the setting dial and key operation are invalid, **\\[\\[\]** appears on the operation panel. If dial or key operation is attempted while dial and key operation are invalid, **Hill** appears. (When dial or key is not touched for 2s, monitor display appears.)
- •To make the setting dial and key operation valid again, press (MODE) for 2s.



• REMARKS

Even if the setting dial and key operation are disabled, the monitor display and (STOP) are valid.



NOTE

Release the operation lock to release the PU stop by key operation.



4.22.4 Magnitude of frequency change setting (Pr. 295)

When setting the set frequency with the setting dial, frequency changes in 0.01Hz increments in the initial status. Setting this parameter increases the magnitude of frequency which changes according to the rotated amount of the setting dial, improving operability.


Parameter Number	Name	Initial Value	Setting Range	Description
			0	Function invalid
	Magnitude of frequency		0.01	The minimum varying width when the set
295	change setting	0	0.1	frequency is changed by the setting dial can
	Change Setting		1	be set.
			10	DE 361.

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

(1) Basic operation

When a value other than "0" is set in Pr. 295, the minimum varying width when the set frequency is changed by the setting dial

For example, when "1.00Hz" is set in Pr. 295, one click (one dial gauge) of the setting dial changes the frequency in increments of 1.00Hz→2.00Hz→3.00Hz.





*One rotation of the setting dial equals to 24 clicks (24 dial gauges).

• REMARKS

- When machine speed display is selected with Pr. 37, the minimum increments of the magnitude of change is determined by Pr.295 as well. Note that the setting value may differ as speed setting changes the set machine speed and converts it to the speed display again.
- When the set frequency (speed) is 100 or more, frequency is displayed in 0.1 increments. Therefore, the minimum varying width is 0.1 even when Pr. 295 < 0.1.
- When the machine speed setting is 1000 or more, frequency is displayed in 1 increments. Therefore, the minimum varying width is 1 even when Pr. 295 < 1.



NOTE

- For Pr. 295, unit is not displayed.
- This parameter is valid only in the set frequency mode. When other frequency-related parameters are set, it is not
 - When 10 is set, frequency setting changes in 10Hz increments. Be cautions for the excess speed. (in potentiometer mode)

4.22.5 Buzzer control (Pr. 990)

You can make the buzzer "beep" when you press the key of the parameter unit (FR-PU04/FR-PU07).

Parameter Number	Name	Initial Value	Setting Range	Description
990	PU buzzer control	1	0	Without buzzer
			1	With buzzer

The above parameter can be set when Pr. 160 Extended function display selection = "0". (Refer to page 163)

4.22.6 PU contrast adjustment (Pr. 991)

Contrast adjustment of the LCD of the parameter unit (FR-PU04/FR-PU07) can be performed. Decreasing the setting value makes contrast light.

Parameter Number	Name	Initial Value	Setting Range	Description
991	PU contrast adjustment	58	0 to 63	0: Light ↓ 63: Dark

The above parameter is displayed as simple mode parameter only when the parameter unit FR-PU04/FR-PU07 is connected.

The above parameter allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

The above parameter allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.



4.23 FR-E500 series operation panel (PA02) setting

The operation panel (PA02) for the FR-E500 series can be hooked up with the PU cable for use. (The inverter can not be directly connected.)

Purpose	Parameter th	Refer to Page	
Select the frequency setting method of the operation panel (built-in potentiometer, key)	Frequency setting command selection	Pr. 146	243
Set the magnitude (slope) of the output frequency by the built-in potentiometer as desired.	Built-in frequency setting potentiometer bias/gain	C22(Pr. 922), C23(Pr. 922), C24(Pr. 923), C25(Pr. 923)	244

4.23.1 Built-in potentiometer switching (Pr. 146)

Switches the frequency setting method between the PA02 built-in frequency setting potentiometer and digital frequency setting by the / v key.

Parameter Number	Name	Initial Value	Setting Range	Description
146	Built-in potentiometer switching	1	0 *1	PA02 built-in frequency setting potentiometer valid Frequency setting by the built-in frequency setting potentiometer
			1	PA02 built-in frequency setting potentiometer invalid Digital frequency setting by the key. Changing frequency continuously by pressing the key. Hold down the key key to perform operation.

^{*1} Set when performing operation using the built-in frequency setting potentiometer using the operation panel (PA02) for the FR-E500 series.

Operation from the inverter operation panel or communication is not available.

The above parameter can be set when Pr.160 Extended function display selection = "0". (Refer to page 163)


4.23.2 Bias and gain of the built-in frequency setting potentiometer (C22 (Pr. 922) to C25 (Pr. 923))

When the operation panel (PA02) for the FR-E500 series is hooked up with the PU cable, the magnitude (slope) of the output frequency to the frequency setting potentiometer of the operation panel can be set as desired.

Parameter	Name	Initial	Setting	Description	
No.	Name	Value	Range		
	Frequency setting voltage bias	0Hz	0 to 400Hz	Frequency on the bias side of PA02 built-in	
	frequency (built-in potentiometer)			frequency setting potentiometer.	
1 (:73/477) * I	Frequency setting voltage bias (built-	0%	0 to 300%	Converted % of the bias side setting level of	
	in potentiometer)			PA02 built-in frequency setting potentiometer.	
	Frequency setting voltage gain	60Hz	0 to 400Hz	Frequency on the gain side of PA02 built-in	
	frequency (built-in potentiometer)			frequency setting potentiometer.	
1 7 5 1 4 1 X 1 X 1	Frequency setting voltage gain (built-in potentiometer)	100%	0 to 300%	Converted % of the bias side setting level of	
				PA02 built-in frequency setting potentiometer.	

^{*1} The parameter numbers in parentheses are for the operation panel (PA02) of the FR-E500 series or parameter unit (FR-PU04/FR-PU07).

Adjust the bias of the potentiometer of the operation panel using *Pr. 922 (C22, C23)* and gain with *Pr. 923 (C24, C25)*.




Frequency setting signal (Built-in frequency setting potentiometer)

<Setting>

[Setting from the FR-E500 series operation panel (PA02)]

Bias/gain adjustment methods using the built-in potentiometer are shown below.

- · Method to adjust any point by turning the potentiometer.
- · Method to adjust any point without turning the potentiometer.
- Method to adjust the bias/gain frequency only.




The above parameters can be set when Pr. 160 Extended function display selection ="0". (Refer to page 163)




Pr. 923 "Built-in frequency setting potentiometer gain"

(Pr. 922 can be adjusted in a similar manner.)

Set the magnitude (slope) of the output frequency by the built-in potentiometer as desired using the built-in frequency setting potentiometer.




2. Make sure that the inverter is in PU mode with MODE key.



If $\[PU\]$ cannot be displayed by pressing the $\[Alpha\]$ / $\[V\]$ key in the External operation mode $\[Black]$ ($\[Pr. 79\]$ operation mode selection $\[Pr. 79\]$ operation mode selection.


3. Read *Pr. 923* to display the present set gain frequency. (*Pr. 922* can be adjusted in a similar manner.)






Operation

4. Set the gain frequency in *Pr.923* to display the analog voltage value of the built-in frequency setting potentiometer in %. (80Hz maximum)




Method to adjust any point by turning the built-in frequency setting potentiometer. (application of 5V)




- **6.** Pressing SET shifts to the next parameter.
- 7. Set the Pr. 79 Operation mode selection value according to the operation mode being used.

• Method to adjust any point without turning the potentiometer (changing from 4V(80%) to 5V(100%))



- 3. Pressing SET shifts to the next parameter.
- **4.** Set the *Pr.79 Operation mode selection* value according to the operation mode being used.

• Method to adjust only the gain frequency and not to adjust the voltage



- 3. Pressing SET shifts to the next parameter.
- 4. Set the Pr. 79 Operation mode selection value according to the operation mode being used.




Take care when setting any value other than "0" as the bias speed at 0V. Even if a speed command is not given, simply turning ON the start signal will start the motor at the preset frequency.


FR-E500 series operation panel (PA02) setting


[Setting with the inverter operation panel without fitting the FR-E500 series operation panel (PA02)]

a) Method to adjust any point (to change to 80% from 100%)

- Confirm the RUN indication and operation mode indication
 - The inverter should be at a stop.
 - The inverter should be in the PU operation mode (depends on (PU)/FXT)).







5. Turn until [25 appears. Turn the dial to C25 (Pr. 923) Frequency setting voltage gain (built-in potentiometer)

6. Press (SET) to show the analog-to digital conversion value (%).

Turn to set gain voltage (%).
 "minimum value of the potentiometer is 0%, maximum value is 100%"



(The parameter number read previously appears.



SET C0 to C25 settings are enabled.



Analog voltage value (%) of built-in frequency setting potentiometer



The gain frequency is reached when analog voltage value (%) of built-in frequency setting potentiometer is 80%.

- Display ———



The current setting at the instant of turning is displayed.

8. Press (SET) to set





Flicker...Parameter setting complete!!

(Adjustment completed)

- •Turn to read another parameter.
- •Press (SET) to return to the [- indication (step 4).
- •Press (SET) twice to show the next parameter (Pr.[]).

• REMARKS


By pressing after step 6, you can confirm the present frequency setting bias/gain setting. It cannot be confirmed after execution of step 7.

b) Method to set frequency only without adjusting gain analog value (When changing the gain frequency from 60Hz to 50Hz)

Operation -

- Display -
- 1. Confirm the RUN indication and operation mode indication
 - •The inverter should be at a stop.
 - •The inverter should be in the PU operation mode









The parameter number read previously appears.

- 3. Turn until [appears.
- 4. Press (SET) until [- appears.



- 5. Turn until [24 appears. Turn the dial to C24 (Pr.923) Frequency setting voltage gain frequency (built-in potentiometer)
- **6.** Press (SET) to show the present set value.



- to change the set value to "50.00".
- 8. Press (SET) to set.







Flicker...Parameter setting complete!!

(Adjustment completed)

- to read another parameter.
- •Press (SET) to return to the [- indication (step 4).
- •Press (SET) twice to show the next parameter (Pr.[].

> REMARKS


- To run the inverter at 60Hz or more using the built-in frequency setting potentiometer (Pr. 146 = 0), change C24 and C25 (Pr. 923) . If only Pr. 1 or Pr. 18 is changed, the inverter cannot run above 60Hz.
- Setting Pr. 146, C22 (Pr. 922), C23 (Pr. 922), C24 (Pr. 923), C25 (Pr. 923) can be performed from the inverter operation panel. However, it functions only when the operation panel PA02 for the FR-E500 is connected.
- When setting frequency, parameter, etc. using the operation panel PA02, it is necessary to hold down the SET key for 1.5s.
- Past four faults are stored in the faults history when the operation panel PA02 is connected.
- All faults (E.ILF, E.IOH. E.AIE, E.CDO, E.PTC, E.SAF) added to the FR-D700 series are displayed as E.14.

4.24 Parameter clear/ All parameter clear



POINT

- Set "1" in Pr.CL Parameter clear, ALLC all parameter clear to initialize all parameters. (Parameters are not cleared when "1" is set in Pr. 77 Parameter write selection.)
- Refer to the extended parameter list on *page 58* for parameters cleared with this operation.



- 🔌 to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.

Setting	Description			
0	Not executed.			
	Set parameters back to the initial values. (Parameter clear sets back all parameters except			
1	calibration parameters, terminal function selection parameters to the initial values.) Refer to the			
	parameter list on page 58 for availability of parameter clear and all parameter clear.			



• REMARKS

and Ery are displayed alternately ... Why?

The inverter is not in the PU operation mode.

- 1. Press $\frac{PU}{EXT}$. [PU] is lit and the monitor (4 digit LED) displays "1". (When Pr: 79 = "0" (initial value))
- 2. Carry out operation from step 6 again.



4.25 Initial value change list

Displays and sets the parameters changed from the initial value.

Operation -

Screen at powering ON
 The monitor display appears.

- 2. Press $\frac{PU}{EXT}$ to choose the PU operation mode.
- Press (MODE) to choose the parameter setting mode.





PU indication is lit.



PRM indication is lit.



(The parameter number read previously appears.)

- 4. Turn until Pr.[H appears.
- 5. Pressing (SET) changes to the initial value change list screen.
- Turning displays the parameter number changed.
 - ●Press (SET) to read the present set value.



(refer to step 6 and 7 on page 57)

- •Turn to read another parameter.
- •The display returns to ₱ - after all parameters are displayed.
- 7. Pressing (SET) in P_{\cdot} - status returns to the parameter setting mode.
 - Turning sets other parameters.
 - Pressing (SET) displays the change list again.







It may take several seconds for creating the initial value change list. " - - - " flickers while creating the list.
























NOTE

- Calibration parameters (C0 (Pr. 900) to C7 (Pr. 905), C22 (Pr. 922) to C25 (Pr. 923)) are not displayed even when these are changed from the initial settings.
- Only simple mode parameter is displayed when simple mode is set (Pr. 160 = "9999" (initial value))
- Pr. 160 is displayed independently of whether the setting value is changed or not.
- When parameter setting is changed after creating the initial value change list, the setting will be reflected to the initial value change list next time.



Parameters referred to

Pr. 160 Extended function display selection Refer to page 163


C0 (Pr. 900) FM terminal calibration Refer to page 135

C2(Pr. 902) to C7(Pr. 905) (Frequency setting bias/gain parameter) Refer to page 154

C22(Pr. 922) to C25(Pr. 923) (Bias and gain of built-in frequency setting potentiometer) Refer to page 244

4.26 Check and clear of the faults history

(1) Check for the faults history



^{*} The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0. When the operation panel is used, the time is displayed up to 65.53 (65530h) in the indication of 1h = 0.001, and thereafter, it is added up from 0.





POINT

• Set "1" in Er.CL Fault history clear to clear the faults history.

Operation -

Screen at powering ON
 The monitor display appears.

2. Press (MODE) to choose the parameter setting mode.



Display -



PRM indication is lit.



(The parameter number read previously appears.)

- 3. Turn until $\mathcal{E} r.\mathcal{E} \mathcal{L}$ (faults history clear) appears.
- **4.** Press (SET) to read the present set value. " \mathcal{L} " (initial value) appears.
- 5. Turn to change it to the set value " /".
- 6. Press (SET) to set.



















Flicker...Faults history clear complete!!

- Turn to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.



Parameters referred to

Pr. 77 Parameter write selection Refer to page 162

MEMO

5 TROUBLESHOOTING

This chapter provides the "TROUBLESHOOTING" of this product.

Always read the instructions before using the equipment.

5.1	Reset method of protective function	256
	List of fault or alarm indications	
	Causes and corrective actions	
5.4	Correspondences between digital and actual characters	267
	Check first when you have a trouble	

When a fault occurs in the inverter, the inverter trips and the PU display automatically changes to any of the following fault or alarm indications.

If the fault does not correspond to any of the following faults or if you have any other problem, please contact your sales representative.

- Retention of fault output signal...When the magnetic contactor (MC) provided on the input side of the inverter is opened when a fault occurs, the inverter's control power will be lost and the fault output will not be
- Fault or alarm indication When a fault or alarm occurs, the operation panel display automatically switches to the fault or alarm indication.
- When any fault occurs, take the appropriate corrective action, then reset the inverter, and resume operation. Not doing so may lead to the inverter fault and damage.

Inverter fault or alarm indications are roughly categorized as below.

- (1) Error message
 - A message regarding operational fault and setting fault by the operation panel and parameter unit (FR-PU04 /FR-PU07) is displayed. The inverter does not trip.
- (2) Warnings
 - The inverter does not trip even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.
- (3) Alarm
 - The inverter does not trip. You can also output an alarm signal by making parameter setting.
- (4) Faul
 - When a fault occurs, the inverter trips and a fault signal is output.

5.1 Reset method of protective function

The inverter can be reset by performing any of the following operations. Note that the internal thermal integrated value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the inverter. Inverter recovers about 1s after the reset is released.

Operation 1: Using the operation panel, press (STOP) to reset the inverter.

(This may only be performed when a fault occurs (*Refer to page 261* for

fault.))

Operation 2: Switch power OFF once. After the indicator of the operation panel turns OFF, switch it ON again.

Operation 3: Turn ON the reset signal (RES) for more than 0.1s. (If the RES signal is kept ON, "Err." appears (flickers) to indicate that the inverter is in a reset status.)





Inverter RES SD



5.2 List of fault or alarm indications

Operation Panel Indication			Name	Refer to Page
	E	E	Faults history	252
age	HOLd	HOLD	Operation panel lock	258
nessa	L004	LOCd	Password locked	258
Error message	Er 1 to Er 4	Er1 to 4	Parameter write error	258
	Enr.	Err.	Inverter reset	259
	ÐΕ	OL	Stall prevention (overcurrent)	259
	οL	oL	Stall prevention (overvoltage)	259
	rЬ	RB	Regenerative brake prealarm	260
Warnings	ſН	тн	Electronic thermal relay function prealarm	260
W	<i>P</i> S	PS	PU stop	260
-	ΠΓ	МТ	Maintenance signal output	260
	Uo	UV	Undervoltage	260
	58	SA	Safety stop	261
Alarm	Fn	FN	Fan alarm	261
	E.D.C. 1	E.OC1	Overcurrent trip during acceleration	261
	E.002	E.OC2	Overcurrent trip during constant speed	261
	E.003	E.OC3	Overcurrent trip during deceleration or stop	262
	E.D o 1	E.OV1	Regenerative overvoltage trip during acceleration	262
It	E.D u 2	E.OV2	Regenerative overvoltage trip during constant speed	262
Fault	E.O u 3	E.OV3	Regenerative overvoltage trip during deceleration or stop	262
	Е.Г.Н.Г	E.THT	Inverter overload trip (electronic thermal relay function)	263
	Е.Г НП	E.THM	Motor overload trip (electronic thermal relay function)	263
	E.FIN E.FIN		Fin overheat	263

Operation Panel Indication			Name	Refer to Page
	EJ LF	E.ILF *	Input phase loss	264
	E.0 L F	E.OLT	Stall prevention	264
	Е. ЬЕ	E. BE	Brake transistor alarm detection	264
	E. GF	E.GF	Output side earth (ground) fault overcurrent at start	264
	E. LF	E.LF	Output phase loss	264
	E.0HF	E.OHT	External thermal relay operation	265
	E.P.C.C	E.PTC*	PTC thermistor operation	265
Fault	E. PE	E.PE	Parameter storage device fault	265
Ä	E.PUE	E.PUE	PU disconnection	265
	8,585	E.RET	Retry count excess	265
	E. 5 / E.E.P.U	E.5 / E.CPU	CPU fault	266
	06 J.3	E.CDO*	Output current detection value exceeded	266
	EJ 0H	E.IOH *	Inrush current limit circuit fault	266
	E.RT E	E.AIE *	Analog input fault	266
	<i>E.SRF</i> E.SAF *		Safety circuit fault	266

^{*} If a fault occurs when using with the FR-PU04, "Fault 14" is displayed on the FR-PU04.

5.3 Causes and corrective actions

(1) Error message

A message regarding operational troubles is displayed. Output is not shut off.

Operation panel	HOLD	HOLd			
indication	HOLD				
Name	Operation pan	Operation panel lock			
Description	Operation lock mode is set. Operation other than (STOP) is invalid. (Refer to page 240)				
Check point					
Corrective action	Press MODE for	for 2s to release lock.			

Operation panel indication	rocq f 0[q						
Name	Password lock	Password locked					
Description	Password function is active. Display and setting of parameter is restricted.						
Check point							
Corrective action	Enter the pass	sword in Pr. 297 Password lock/unlock to unlock the password function before operating. (Refer to page					
Corrective action	164).						

Operation panel	Er1				
indication	En	CC I			
Name	Write disable	error			
	1. You attempted to make parameter setting when <i>Pr. 77 Parameter write selection</i> has been set to disable parameter write.				
Description	2. Frequency jump setting range overlapped.				
	3. The PU and inverter cannot make normal communication.				
	1. Check the setting of Pr. 77 Parameter write selection. (Refer to page 162).				
Check point	2. Check the settings of Pr. 31 to Pr. 36 (frequency jump). (Refer to page 85)				
	3. Check the connection of the PU and inverter.				

Operation panel indication	Er2				
Name	Write error du	ring operation			
Description	When parame	When parameter write was performed during operation with a value other than "2" (writing is enabled independently			
Description	of operation status in any operation mode) is set in Pr. 77 and the STF (STR) is ON.				
Check point 1. Check the Pr. 77 setting. (Refer to page 162).					
Officer point	2. Check that the inverter is not operating.				
Corrective action	1. Set "2" in <i>Pr.</i> 77.				
Corrective action	2. After stopping operation, make parameter setting.				

Operation panel indication	Er3	Er3	
Name	Calibration error		
Description	Analog input bias and gain calibration values are too close.		
Check point	Check the settings of C3, C4, C6 and C7 (calibration functions). (Refer to page 154).		

Operation panel	Erd C_U				Er4		
indication	E14	[ריי					
Name	Mode designa	tion error					
Description		 Appears if a parameter setting is attempted in the External or NET operation mode with <i>Pr.</i> 77 ≠ "2". Appears if a parameter setting is attempted when the command source is not at the operation panel. 					
Check point	1. Check that operation mode is PU operation mode. 2. Check the <i>Pr. 77</i> setting. (<i>Refer to page 162</i>). 3. Check if a parameter unit (FR-PU04/FR-PU07) is connected when <i>Pr. 551</i> = "9999 (initial setting)." 4. Check the <i>Pr. 551</i> setting.						
Corrective action	 After setting the operation mode to the "PU operation mode", make parameter setting. (Refer to page 166) After setting Pr. 77 = "2", make parameter setting. Disconnect the parameter unit (FR-PU04/FR-PU07), and make parameter setting. After setting Pr. 551 = "4", make parameter setting. (Refer to page 177). 						



Operation panel indication	Err.	Err.			
Name	Inverter reset	Inverter reset			
Description	Executing reset using RES signal, or reset command from communication or PU				
Description	Displays at powering OFF.				
Corrective action	Turn OFF the reset command				

(2) Warnings

When a warning occurs, the output is not shut off.

Operation panel	FR-PU04				
indication	OL	0L	FR-PU07	OL	
Name	Stall prevention	n (overcurrent)			
	During acceleration	prevention operation decreases to prevention	level, etc.), then the inverte	nverter exceeds the stall prevention operation level (<i>Pr. 22 Stall</i> his function stops the increase in frequency until the overload current r from resulting in overcurrent trip. When the overload current has peration level, this function increases the frequency again.	
Description	During constant-speed operation	prevention operation prevent the inverte	level, etc.), the from resulting	nverter exceeds the stall prevention operation level (<i>Pr. 22 Stall</i> is function reduces frequency until the overload current decreases to g in overcurrent trip. When the overload current has reduced below this function increases the frequency up to the set value.	
	During deceleration	When the output current of the inverter exceeds the stall prevention operation level (<i>Pr. 22 Stall prevention operation level</i> , etc.), this function stops the decrease in frequency until the overload current decreases to prevent the inverter from resulting in overcurrent trip. When the overload current has decreased below stall prevention operation level, this function decreases the frequency again.			
Check point	 1. Check that the <i>Pr. 0 Torque boost</i> setting is not too large. 2. Check that the <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i> settings are not too small. 3. Check that the load is not too heavy. 4. Are there any failure in peripheral devices? 5. Check that the <i>Pr. 13 Starting frequency</i> is not too large. 6. Check that the <i>Pr. 22 Stall prevention operation level</i> is appropriate 				
Corrective action	 Increase or decrease the <i>Pr. 0 Torque boost</i> setting by 1% and check the motor status. (<i>Refer to page 75</i>) Set a larger value in <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i>. (<i>Refer to page 97</i>) Reduce the load weight. Try General-purpose magnetic flux vector control. Change the <i>Pr. 14 Load pattern selection</i> setting. Set stall prevention operation current in <i>Pr. 22 Stall prevention operation level</i>. (The initial value is 150%.) The acceleration/deceleration time may change. Increase the stall prevention operation level with <i>Pr. 22 Stall prevention operation level</i>, or disable stall prevention with <i>Pr. 156 Stall prevention operation selection</i>. (Operation at OL occurrence can be selected using <i>Pr. 156</i>.) 				

Operation panel	-1	1	FR-PU04			
indication	oL	OL	FR-PU07	oL		
Name	Stall prevention	n (overvoltage)				
Description	During deceleration	 If the regenerative energy of the motor becomes excessive to exceed the regenerative energy consumption capability, this function stops the decrease in frequency to prevent overvoltage trip. As soon as the regenerative energy has reduced, deceleration resumes. If the regenerative energy of the motor becomes excessive when regeneration avoidance function is selected (<i>Pr.</i> 882 =1), this function increases the speed to prevent overvoltage trip. (<i>Refer to page</i> 227). 				
Check point		for sudden speed reduction. that regeneration avoidance function (<i>Pr. 882, Pr. 883, Pr. 885, Pr. 886</i>) is used. (<i>Refer to page 227</i>).				
Corrective action	The decelerat	ion time may chang	e. Increase th	e deceleration time using Pr. 8 Deceleration time.		

	Τ	T		T	
Operation panel	PS	Qς	FR-PU04	PS	
indication	. 0	' _'	FR-PU07	. 0	

indication	PS	25	FR-PU07	PS				
Name	PU stop	² U stop						
Description	Stop with (STOP) of the PU is set in <i>Pr. 75 Reset selection/disconnected PU detection/PU stop selection</i> . (For <i>Pr. 75 refer to page 159</i> .)							
Check point	Check for a stop made by pressing (STOP) of the operation panel.							
Corrective action	Turn the start	signal OFF and re	elease with EXT).				

Operation panel	D.D.		FR-PU04	55			
indication	RB		FR-PU07	RB			
Name	Regenerative	Regenerative brake prealarm					
	Appears if the	Appears if the regenerative brake duty reaches or exceeds 85% of the Pr. 70 Special regenerative brake duty value.					
	When the sett	ing of Pr. 70 Special	regenerative bro	<i>ake duty</i> is the initial value ($Pr. 70 = "0"$), this warning does not occur. If			
Description	the regenerative brake duty reaches 100%, a regenerative overvoltage (E. OV_) occurs.						
Description	The RBP signal can be simultaneously output with the [RB] display. For the terminal used for the RBP signal output,						
	assign the function by setting "7 (positive logic) or 107 (negative logic)" in Pr. 190, Pr. 192 or Pr. 197 (output terminal						
	function selection						
Check point	1. Check that	the brake resistor of	luty is not high				
Check point	2. Check that the Pr. 30 Regenerative function selection and Pr. 70 Special regenerative brake duty settings are						
Corrective action	1. Increase the	e deceleration time	-				
Confective action	2. Check that	the Pr. 30 Regeneral	ive function sele	ection and Pr. 70 Special regenerative brake duty settings.			

Operation panel	TH	[H	FR-PU04	TH			
indication	In	1 17	FR-PU07	тн			
Name	Electronic ther	mal relay function	prealarm				
	Appears if the	Appears if the cumulative value of the Pr. 9 Electronic thermal O/L relay reaches or exceeds 85% of the preset level. If					
	it reaches 100% of the Pr. 9 Electronic thermal O/L relay setting, a motor overload trip (E. THM) occurs.						
Description The THP signal can be simultaneously output with the [TH] display. For the terminal used for TH				vith the [TH] display. For the terminal used for THP signal output,			
	assign the function by setting "8 (positive logic) or 108 (negative logic)" in Pr. 190, Pr. 192 or Pr. 197 (output terminal						
	function selection). (Refer to page 120).						
Check point	1. Check for la	irge load or sudder	n acceleration.				
Check point	2. Is the Pr. 9 I	Electronic thermal O	/L relay setting	is appropriate? (Refer to page 101)			
Corrective action	1. Reduce the	load and frequenc	y of operation.				
Corrective action	2. Set an appr	opriate value in Pr	9 Electronic the	ermal O/L relay. (Refer to page 101)			

Operation panel	мт П		FR-PU04					
indication	MT	111	FR-PU07	MT				
Name	Maintenance s	Maintenance signal output						
	Indicates that	Indicates that the cumulative energization time of the inverter has reached a given time.						
Description	When the setting of Pr. 504 Maintenance timer alarm output set time is the initial value (Pr. 504 = "9999"), this warning							
	does not occur.							
The Pr. 503 Maintenance timer setting is larger than the Pr. 504 Maintenance timer alarm		an the Pr. 504 Maintenance timer alarm output set time setting. (Refer to						
Check point	page 234).							
Corrective action	Setting "0" in I	Pr. 503 Maintenance	timer erases th	ne signal.				

Operation panel	UV	11	FR-PU04				
indication	UV	ÜÜ	FR-PU07				
Name	Undervoltage	Undervoltage					
Description	If the power supply voltage of the inverter decreases, the control circuit will not perform normal functions. In addition, the motor torque will be insufficient and/or heat generation will increase. To prevent this, if the power supply voltage decreases below about 115VAC (about 230VAC for 400V class, about 58VAC for 100V class), this function stops the inverter output and displays U_U . An alarm is reset when the voltage returns to normal.						
Check point	Check that the power supply voltage is normal.						
Corrective action	Check the pov	ver supply system	equipment suc	n as power supply.			



Operation panel indication	SA	58	FR-PU04 FR-PU07			
Name	Safety stop					
Description	Appears when	safety stop functio	n is activated	(during output shutoff). (Refer to page 27)		
Check point	Check if the shorting wire between S1 and SC or between S2 and SC is disconnected when not using the safety stop function.					
Corrective action	 When not using the safety stop function, short across terminals S1 and SC and across S2 and SC with shorting wire for the inverter to run. If 5 P is indicated when across S1 and SC and across S2 and SC are both shorted while using the safety stop function (drive enabled), internal failure might be the cause. Check the wiring of terminals S1, S2 and SC and contact your sales representative if the wiring has no fault. 					

(3) Alarm

When an alarm occurs, the output is not shut off. You can also output an alarm signal by making parameter setting. (Set "98" in *Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection). Refer to page 120*).

Operation panel	FN	En	FR-PU04	FN			
indication	114	1 11	FR-PU07	T N			
Name	Fan alarm	-an alarm					
Description		For the inverter that contains a cooling fan, \digamma_{\Box} appears on the operation panel when the cooling fan stops due to an alarm or different operation from the setting of $Pr. 244$ Cooling fan operation selection.					
Check point	Check the cooling fan for an alarm.						
Corrective action	Check for fan	alarm. Please conta	act your sales	representative.			

(4) Fault

When a fault occurs, the inverter trips and a fault signal is output.

Operation panel	E 004	E.D.C	1	FR-PU04	OC During Acc			
indication	E.OC1	こ.いし	1	FR-PU07	OC During Acc			
Name	Overcurrent tr	Overcurrent trip during acceleration						
Description		When the inverter output current reaches or exceeds approximately 200% of the rated current during acceleration, the protective circuit is activated and the inverter trips.						
	2. Check that	 Check for sudden acceleration. Check that the downward acceleration time is not long for the lift. Check for output short-circuit/ground fault. 						
Check point	 4. Check that the <i>Pr. 3 Base frequency</i> setting is not 60Hz when the motor rated frequency is 50Hz. 5. Check that stall prevention operation is appropriate. 6. Check that regeneration is not performed frequently. (Check that the output voltage becomes larger than t reference value at regeneration and overcurrent occurs due to increase in motor current.) 							
Corrective action	 Increase the acceleration time. (Shorten the downward acceleration time for the lift.) When "E.OC1" is always lit at starting, disconnect the motor once and start the inverter. If "E.OC1" is still lit, contact your sales representative. Check the wiring to make sure that output short circuit/ground fault does not occur. Set 50Hz in <i>Pr. 3 Base frequency. (Refer to page 86)</i> Perform stall prevention operation appropriately. (Refer to page 80). Set base voltage (rated voltage of the motor, etc.) in <i>Pr. 19 Base frequency voltage. (Refer to page 86)</i> 							

Operation panel	E.OC2	8.002	FR-PU04	Stady Sad OC			
indication	E.002	C.U.L. C	FR-PU07	Stedy Spd OC			
Name	Overcurrent tri	Overcurrent trip during constant speed					
Description	When the inve	When the inverter output current reaches or exceeds approximately 200% of the rated current during constant speed					
Description	operation, the	operation, the protective circuit is activated and the inverter trips.					
	1. Check for sudden load change.						
Check point	2. Check for output short-circuit/ground fault.						
	3. Check that s	stall prevention oper	ration is appro	priate.			
	1. Keep load s	1. Keep load stable.					
Corrective action	3						
	3. Perform sta	Il prevention operati	on appropriate	ely. (Refer to page 80).			

Operation panel	E.OC3	E.0.C.3	FR-PU04	OC During Dec			
indication	E.0C3	C.U.L 3	FR-PU07	OC During Dec			
Name	Overcurrent tr	p during deceleration	on or stop				
Description	When the inve	When the inverter output current reaches or exceeds approximately 200% of the rated inverter current during					
Description	deceleration (other than acceleration or constant speed), the protective circuit is activated and the inverter trips.						
	1. Check for si	Check for sudden speed reduction.					
Check point	2. Check for output short-circuit/ground fault.						
Check point	3. Check for to	3. Check for too fast operation of the motor's mechanical brake.					
	4. Check that stall prevention operation is appropriate.						
	1. Increase the	1. Increase the deceleration time.					
Corrective action	ort circuit/ground fault does not occur.						
Corrective action	3. Check the n	nechanical brake op	eration.				
	4. Perform sta	Il prevention operati	on appropriat	ely. (Refer to page 80).			

Operation panel	E.OV1	EOu	1	FR-PU04	OV During Acc				
indication	E.OV1	ב.ט.ט	1	FR-PU07	OV During Acc				
Name	Regenerative	Regenerative overvoltage trip during acceleration							
	If regenerative	f regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value,							
Description	the protective	the protective circuit is activated and the inverter trips. The circuit may also be activated by a surge voltage produced							
	in the power s	1177							
Check point	1. Check for to	1. Check for too slow acceleration. (e.g. during downward acceleration in vertical lift load)							
Check point	2. Check that t	2. Check that the setting of <i>Pr. 22 Stall prevention operation level</i> is not too small.							
	1. • Decrease	1. • Decrease the acceleration time.							
Corrective action	• Use regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886). (Refer to page 227).								
	2. Set the Pr.2.	2 Stall prevention	on ope	ration level COI	rrectly.				

Operation panel	E.OV2	8.002	FR-PU04	Stady Cod OV					
indication	E.0V2	C.UUC	FR-PU07	Stedy Spd OV					
Name	Regenerative	overvoltage trip duri	ing constant s	peed					
	If regenerative	f regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value,							
Description	the protective	the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage							
	produced in the power supply system.								
Check point	1. Check for s	Check for sudden load change.							
Check point	2. Check that	2. Check that the setting of Pr. 22 Stall prevention operation level is not too small.							
	1. • Keep load	d stable.							
Corrective action	• Use regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886). (Refer to page 227).								
• Use the brake resistor, brake unit or power regeneration common converter (FR-CV) as required.									
	2. Set the Pr.2.	2 Stall prevention ope	ration level co	rrectly.					

Operation panel	E.OV3	E.O. 3	FR-PU04	OV During Dec				
indication	E.OV3	C.UU3	FR-PU07	OV burning Dec				
Name	Regenerative	overvoltage trip duri	ing deceleration	on or stop				
Description	the protective	If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.						
Check point	Check for sud	Check for sudden speed reduction.						
Corrective action	 Increase the deceleration time. (Set the deceleration time which matches the moment of inertia of the load) Make the brake cycle longer. Use regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886). (Refer to page 227). Use the brake resistor, brake unit or power regeneration common converter (FR-CV) as required. 							

C TUT		FR-PU04	Inv. Overload					
E.1H1	<i>E.</i> ; <i>m</i> ;	FR-PU07	iliv. Overload					
Inverter overlo	nverter overload trip (electronic thermal relay function)							
If the temperat	f the temperature of the output transistor element exceeds the protection level under the condition that a current not							
less than the r	ated inverter curre	nt flows and ov	vercurrent trip does not occur (200% or less), the electronic thermal					
relay activates to stop the inverter output. (Overload capacity 150% 60s, 200% 0.5s)								
Check that acceleration/deceleration time is not too short.								
2. Check that t	torque boost setting	g is not too lar	ge (small).					
3. Check that I	load pattern selecti	on setting is a	ppropriate for the load pattern of the using machine.					
4. Check the n	notor for use under	overload.						
5. Check for to	oo high surrounding	air temperatu	re.					
1. Increase ac	celeration/decelera	tion time.						
2. Adjust the to	orque boost setting							
3. Set the load	pattern selection s	setting according	ng to the load pattern of the using machine.					
4. Reduce the load weight.								
5. Set the surr	ounding air temper	ature to within	the specifications.					
	If the tempera less than the r relay activates 1. Check that 2. Check that 3. Check that 4. Check the r 5. Check for to 1. Increase ac 2. Adjust the to 3. Set the load 4. Reduce the	Inverter overload trip (electronic to less than the rated inverter currer relay activates to stop the inverter 1. Check that acceleration/deceler 2. Check that torque boost setting 3. Check that load pattern selection 4. Check the motor for use under 5. Check for too high surrounding 1. Increase acceleration/decelera 2. Adjust the torque boost setting 3. Set the load pattern selection set.	Inverter overload trip (electronic thermal relay for the temperature of the output transistor elements than the rated inverter current flows and overlay activates to stop the inverter output. (Ove 1. Check that acceleration/deceleration time is 2. Check that torque boost setting is not too largest and the company of the					

Operation panel	E.THM	E.C.H.C.	FR-PU04	Motor Ovrload			
indication	L. 1111VI	<u>L</u> .; ; ; ; ;	FR-PU07	Motor Ovridad			
Name	Motor overload	d trip (electronic the	rmal relay fun	ction) *1			
Description	The electronic thermal relay function in the inverter detects motor overheat due to overload or reduced cooling capability during constant-speed operation, and pre-alarm (TH display) is output when the integrated value reaches 85% of the <i>Pr. 9 Electronic thermal O/L relay</i> setting, and the protection circuit is activated to stop the inverter output when the integrated value reaches the specified value. When running a special motor such as a multi-pole motor or multiple motors, provide a thermal relay on the inverter output side since such motor(s) cannot be protected by the electronic thermal relay function.						
Check point	2. Check that 3. Check that	 Check the motor for use under overload. Check that the setting of <i>Pr. 71 Applied motor</i> for motor selection is correct. (<i>Refer to page 104</i>). Check that stall prevention operation setting is correct. 					
Corrective action	3. Check that	ant-torque motor, se	ration setting i	-torque motor in <i>Pr. 71 Applied motor</i> . s correct. <i>(Refer to page 80)</i> .			

^{*1} Resetting the inverter initializes the internal thermal integrated data of the electronic thermal relay function.

Operation panel	E.FIN	E.F.I	_	FR-PU04	H/Sink O/Temp				
indication	E.FIN	<u>_</u>		FR-PU07	n/Silik O/Tellip				
Name	Fin overheat								
	If the heatsink	f the heatsink overheats, the temperature sensor is actuated and the inverter trips.							
	The FIN signa	l can be out	out whe	n the temperat	ture becomes approximately 85% of the heatsink overheat protection				
Description	operation temperature.								
For the terminal used for the FIN signal output, assign the function by setting "26 (positive logic) or 126									
	logic)" in any o	logic)" in any of Pr. 190, Pr. 192 or Pr. 197 (output terminal function selection). (Refer to page 120).							
	1. Check for to	o high surre	ounding	air temperatu	re.				
Check point	2. Check for he	eatsink clogo	jing.						
3. Check that the cooling fan is not stopped (Check that $F_{\mathbf{n}}$ is not displayed on the operation panel).									
	1. Set the surr	Set the surrounding air temperature to within the specifications.							
Corrective action	2. Clean the heatsink.								
	3. Replace the	cooling far							

Operation panel	E.ILF	ELLE	FR-PU04	Fault 14				
indication	E.ILF	C.1 L. C	FR-PU07	Input phase loss				
Name	Input phase lo)SS *						
Description	Inverter trips when function valid setting (=1) is selected in <i>Pr. 872 Input phase loss protection selection</i> and one phase of the three phase power input is lost. (<i>Refer to page 147</i>). It may function if phase-to-phase voltage of the three-phase power input becomes largely unbalanced. When the setting of <i>Pr. 872 Input phase loss protection selection</i> is the initial value (<i>Pr. 872</i> ="0"), this warning does not occur.							
Check point		 Check for a break in the cable for the three-phase power supply input. Check that phase-to-phase voltage of the three-phase power input is not largely unbalanced. 						
Corrective action	Repair a breCheck the F	 Wire the cables properly. Repair a break portion in the cable. Check the <i>Pr. 872 Input phase loss protection selection</i> setting. Set <i>Pr. 872</i> = "0" (without input phase loss protection) when three-phase input voltage is largely unbalanced. 						

^{*} Available only for three-phase power input specification model.

Operation panel indication	E.OLT	E.DLT	FR-PU04 FR-PU07	Stll Prev STP (OL shown during stall prevention operation)					
Name	Stall preventio	Stall prevention							
Description	the inverter tri	If the output frequency has fallen to 1Hz by stall prevention operation and remains for 3s, a fault (E.OLT) appears and the inverter trips. OL appears while stall prevention is being activated. E.OLT may not occur if stall prevention (OL) is activated during output phase loss.							
Check point	Check the motor for use under overload. (Refer to page 81).								
Corrective action	 Reduce the 	load weight. (Check	the Pr. 22 Sta	all prevention operation level setting.)					

Operation panel indication	E.BE	Ε.	<i>68</i>	FR-PU04 FR-PU07	Br. Cct. Fault			
Name	Brake transiste	rake transistor alarm detection						
Description	transistor aları	When a brake transistor alarm has occurred due to the large regenerative energy from the motor etc., the brake transistor alarm is detected and the inverter trips. In this case, the inverter must be powered OFF immediately.						
Check point	Check that the state of th	 Reduce the load inertia. Check that the frequency of using the brake is proper. Check that the brake resistor selected is correct. 						
Corrective action	Replace the in	verter.						

Operation panel	E.GF	Ę	<u>G</u> F	FR-PU04	Ground Fault			
indication	2.01	L .		FR-PU07	Ground Fault			
Name	Output side ea	output side earth (ground) fault overcurrent at start						
Description	the inverter's of fault detection of	The inverter trips if an earth (ground) fault overcurrent flows at start due to an earth (ground) fault that occurred on the inverter's output side (load side). Whether this protective function is used or not is set with $Pr. 249 Earth (ground)$ fault detection at start. When the setting of $Pr. 249 Earth (ground)$ fault detection at start is the initial value ($Pr. 249 = "0"$), this warning does not occur.						
Check point	Check for a gr	Check for a ground fault in the motor and connection cable.						
Corrective action	Remedy the g	round fa	ult portion.					

Operation panel	E.LF	<u>_</u>	! [FR-PU04	E.LF				
indication	E.LF	L .	<u>_</u> '	FR-PU07	ELLF				
Name	Output phase	Dutput phase loss							
Description	during DC inje	If one of the three phases (U, V, W) on the inverter's output side (load side) is lost during inverter operation (except during DC injection brake operation and when output frequency is under 1Hz), inverter stops the output. Whether the protective function is used or not is set with <i>Pr.251 Output phase loss protection selection</i> .							
Check point		 Check the wiring. (Check that the motor is normal.) Check that the capacity of the motor used is not smaller than that of the inverter. 							
Corrective action	Wire the calCheck the F		. ,	oss protection s	selection setting.				

Operation panel indication	E.OHT	E.0HF	FR-PU04 FR-PU07	OH Fault						
Name	External therm	External thermal relay operation								
Description	motor, etc. swi	If the external thermal relay provided for motor overheat protection or the internally mounted temperature relay in the motor, etc. switches ON (contacts open), the inverter output is stopped. Functions when "7" (OH signal) is set in any of <i>Pr. 178 to Pr. 182 (input terminal function selection)</i> .								
	This protective	e function does not f	unction in the	initial status (OH signal is not assigned).						
Check point	 Check for m 	notor overheating.								
Check point	• Check that the value of 7 (OH signal) is set correctly in any of <i>Pr. 178 to Pr. 182 (input terminal function selection)</i> .									
Corrective action	 Reduce the 	Reduce the load and frequency of operation.								
Corrective action	Even if the r	Even if the relay contacts are reset automatically, the inverter will not restart unless it is reset.								

Operation panel	E.PTC	FPCC	FR-PU04	Fault 14
indication	E.PTC		FR-PU07	PTC activated
Name	PTC thermisto	•		
Description	Inverter trips when resistance of PTC thermistor connected between terminal 2 and terminal 10 is more than the value set in <i>Pr. 561 PTC thermistor protection level</i> . This protective function does not function when <i>Pr. 561</i> setting is initial value (<i>Pr. 561</i> = "9999").			
Check point	 Check the connection of the PTC thermistor. Check the <i>Pr. 561 PTC thermistor protection level</i> setting. Check the motor for operation under overload. 			
Corrective action	Reduce the loa	ad weight.		

Operation panel	E.PE & P&		FR-PU04	Corrupt Memry				
indication	L.FL	L .		FR-PU07	Corrupt Merin y			
Name	Parameter sto	Parameter storage device fault (control circuit board)						
Description	Appears when	Appears when a fault occurred in the stored parameters. (EEPROM fault)						
Check point	Check for too	Check for too many number of parameter write times.						
	Please contac	Please contact your sales representative.						
Corrective action	When performing parameter write frequently for communication purposes, set "1" in <i>Pr. 342</i> to enable RAM write. Note							
	that powering	OFF retu	urns the inve	erter to the stat	tus before RAM write.			

Operation panel	E.PUE	<i>E.P.</i> 118	FR-PU04	PU Leave Out	
indication	E.PUE	C.F U.C	FR-PU07	FO Leave Out	
Name	PU disconnec	tion			
Description	 This function stops the inverter output if communication between the inverter and PU is suspended, e.g. the parameter unit (FR-PU04/FR-PU07) is disconnected, when "2", "3", "16" or "17" was set in <i>Pr. 75 Reset selection/disconnected PU detection/PU stop selection.</i> This function stops the inverter output when communication errors occurred consecutively for more than permissible number of retries when a value other than "9999" is set in <i>Pr. 121 Number of PU communication retries</i> during the RS-485 communication with the PU connector (use <i>Pr. 502 Stop mode selection at communication error</i> to change). This function also stops the inverter output if communication is broken within the period of time set in <i>Pr. 122 PU communication check time interval</i> during the RS-485 communication with the PU connector. 				
Check point	 Check that the parameter unit cable is connected properly. Check the <i>Pr.</i> 75 setting. Check that RS-485 communication data is correct. And check that the settings of communication parameter at inverter match settings of the computer. Check that data is transmitted from the computer within a time set in <i>Pr.</i> 122 PU communication check time interval. 				
Corrective action	Check the con	arameter unit cable nmunication data ar Pr. 122 PU communica	nd communica	tion settings. e interval setting. Or set "9999" (no communication check).	

Operation panel indication	E.RET	E E.T	FR-PU04 FR-PU07	Retry No Over				
Name	Retry count ex	Retry count excess						
Description	If operation cannot be resumed properly within the number of retries set, this function trips the inverter. Functions only when $Pr. 67$ Number of retries at fault occurrence is set. When the initial value ($Pr. 67 = 0$) is set, this protective function does not function.							
Check point	Find the cause of fault occurrence.							
Corrective action	Eliminate the	cause of the error pr	receding this e	error indication.				

Operation panel	E.5	Ei	5	FR-PU04	Fault 5			
indication	E.CPU	E.C	PU	FR-PU07	CPU Fault			
Name	CPU fault	CPU fault						
Description	Stops the inverter output if the communication fault of the built-in CPU occurs.							
Check point	Check for devices producing excess electrical noises around the inverter.							
Corrective action	Take measures against noises if there are devices producing excess electrical noises around the inverter.							
Corrective action	 Please cont 	act your sa	ales repre	sentative.				

Operation panel	tion panel E.CDO	8.6 80	FR-PU04	Fault 14		
indication	L.CDO		FR-PU07	OC detect level		
Name	Output current detection value exceeded					
Description	This function is activated when the output current exceeds the <i>Pr. 150 Output current detection level</i> setting.					
Check point	Check the settings of Pr. 150 Output current detection level, Pr. 151 Output current detection signal delay time, Pr. 166 Output					
Oneck point	current detectio	n signal retention tim	e, Pr. 167 Outp	ut current detection operation selection. (Refer to page 125)		

Operation panel	E IOU	EJ 8H	FR-PU04	Fault 14		
indication	E.IOH	FR-PL	FR-PU07	Inrush overheat		
Name	Inrush current limit circuit fault					
Description	This function is activated when the resistor of the inrush current limit circuit overheats. The inrush current limit circuit fault					
Check point	Check that frequent power ON/OFF is not repeated.					
Corrective action	Configure a circuit where frequent power ON/OFF is not repeated.					
Corrective action	If the problem still persists after taking the above measure, please contact your sales representative.					

Operation panel	E.AIE	EBI E	FR-PU04	Fault 14		
indication	E.AIE	c.n, c	FR-PU07	Analog in error		
Name	Analog input fault					
Description	Appears if voltage(current) is input to terminal 4 when the setting in Pr.267 Terminal 4 input selection and the setting					
Description	voltage/curren	t input switch are				
Check point	Check the setting of Pr. 267 Terminal 4 input selection and voltage/current input switch. (Refer to page 151).					
Corrective action	Either give a frequency command by current input or set Pr. 267 Terminal 4 input selection, and voltage/current input					
Corrective action	switch to volta	ge input.				

Operation panel		FR-PU04	Fault 14				
Operation panel	E.SAF	8.588	ED DU07	Fault			
indication			FR-PU07	E.SAF			
Name	Safety circuit t	fault					
Description	Appears when safety circuit is malfunctioning.						
Description	Appears wher	one of the lines between S1 and SC, or between S2 and SC is opened.					
 Check if the shorting wire between S1 and SC or between S2 and SC is disconnected wh 				C or between S2 and SC is disconnected when not using the safety			
Check point	stop functio	n.					
	Check that the safety relay module or the connection has no fault when using the safety stop function.						
	When not using the safety stop function, short across terminals S1 and SC and across S2 and SC with shorting						
	wire. (Refer to page 27)						
Corrective action	When using the safety stop function, check that wiring of terminal S1, S2 and SC is correct and the safety stop						
	input signal	source such as saf	ety relay mod	ule is operating properly. Refer to the Safety stop function instruction			
	manual (BCN-211508-000) for causes and countermeasures.						



NOTE

• If protective functions of E.ILF, E.AIE, E.IOH, E.PTC, E.CDO, E.SAF are activated when using the FR-PU04, "Fault 14" is displayed.

Also when the faults history is checked on the FR-PU04, the display is "E.14".

• If faults other than the above appear, contact your sales representative.



5.4 Correspondences between digital and actual characters

There are the following correspondences between the actual alphanumeric characters and the digital characters displayed on the operation panel:

Actual	Digital
0	$\bar{\mathcal{D}}$
1	
2	<u>,='</u>
3	3
4	[/]
5	5
6	[5]
7	7
8	
9	9

Actual	Digital
A	
В	
C	
D	<u>-</u>
E	E
F	F
G	
Н	H
J	
L	

Digital
[7]
,-,
ø
<u> </u>
5
<u></u>
<u>[7</u>]
<u></u>
<u></u>
-

5.5 Check first when you have a trouble



POINT

• If the cause is still unknown after every check, it is recommended to initialize the parameters (initial value) then set the required parameter values and check again.

5.5.1 Motor does not start

Check points	Possible Cause	Countermeasures	Refer to page
Main	Appropriate power supply voltage is not applied. (Operation panel display is not provided.)	Power ON moulded case circuit breaker (MCCB), an earth leakage circuit breaker (ELB), or a magnetic contactor (MC). Check for the decreased input voltage, input phase loss, and wiring.	
Circuit	Motor is not connected properly.	Check the wiring between the inverter and the motor.	15
	The jumper across P/+ to P1 is disconnected.	Securely fit a jumper across P/+ to P1. When using a DC reactor (FR-HEL), remove the jumper across P/+ to P1, and then connect the DC reactor.	35
	Start signal is not input.	Check the start command source, and input a start signal. PU operation mode: RUN External operation mode: STF/STR signal	169
	Both the forward and reverse rotation start signals (STF, STR) are input simultaneously.	Turn ON only one of the forward and reverse rotation start signals (STF or STR). If the STF and STR signals are turned ON simultaneously in the initial setting, a stop command is given.	20
	Frequency command is zero. (RUN LED on the operation panel is flickering.)	Check the frequency command source and enter a frequency command.	169
	AU signal is not ON when terminal 4 is used for frequency setting. (RUN LED on the operation panel is flickering.)	Turn ON the AU signal. Turning ON the AU signal activates terminal 4 input.	151
Input Signal	Output stop signal (MRS) or reset signal (RES) is ON. (RUN LED on the operation panel flickers while MRS signal is ON.)	Turn MRS or RES signal OFF. Inverter starts the operation with a given start command and a frequency command after turning OFF MRS or RES signal. Before turning OFF, ensure the safety.	116, 256
	Jumper connector of sink - source is wrongly selected. (RUN LED on the operation panel is flickering.)	Check that the control logic switchover jumper connector is correctly installed. If it is not installed correctly, input signal is not recognized.	22
	Shorting wires between S1 and SC, S2 and SC are disconnected.	Short between S1 and SC, S2 and SC with shorting wires.	27
	Voltage/current input switch is not correctly set for analog input signal (0 to 5V/0 to 10V, 4 to 20mA). (RUN LED on the operation panel is flickering.)	Set <i>Pr. 73, Pr. 267</i> , and a voltage/current input switch correctly, then input an analog signal in accordance with the setting.	20
	(Operation panel indication is \$P\$ (PS).)	During the External operation mode, check the method of restarting from a (STOP) input stop from PU.	260
	Two-wire or three-wire type connection is wrong.	Check the connection. Connect STOP signal when three-wire type is used.	118



Check points	Possible Cause	Countermeasures	Refer to page
	Pr. 0 Torque boost setting is improper when V/F control is used.	Increase <i>Pr. 0</i> setting by 0.5% increments while observing the rotation of a motor. If that makes no difference, decrease the setting.	75
	Pr. 78 Reverse rotation prevention selection is set.	Check the <i>Pr.</i> 78 setting. Set <i>Pr.</i> 78 when you want to limit the motor rotation to only one direction.	163
	Pr. 79 Operation mode selection setting is wrong.	Select the operation mode which corresponds with input methods of start command and frequency command.	169
	Pr. 146 Built-in potentiometer switching setting is improper.	Set <i>Pr. 146</i> ="1" (initial value) when not using FR-E500 operation panel (PA02).	243
	Bias and gain <i>(calibration parameter C2 to C7)</i> settings are improper.	Check the bias and gain <i>(calibration parameter C2 to C7)</i> settings.	154
	Pr. 13 Starting frequency setting is greater than the running frequency.	Set running frequency higher than <i>Pr. 13</i> . The inverter does not start if the frequency setting signal is less than the value set in <i>Pr. 13</i> .	99
	Frequency settings of various running frequency (such as multi-speed operation) are zero. Especially, <i>Pr. 1 Maximum frequency</i> is zero.	Set the frequency command according to the application. Set <i>Pr. 1</i> higher than the actual frequency used.	84
	Pr. 15 Jog frequency setting is lower than Pr. 13 Starting frequency.	Set Pr. 15 Jog frequency higher than Pr. 13 Starting frequency.	92
Parameter Setting	Operation mode and a writing device do not match.	Check <i>Pr. 79, Pr. 338, Pr. 339, Pr. 551,</i> and select an operation mode suitable for the purpose.	166, 177
	Start signal operation selection is set by the <i>Pr. 250 Stop selection</i>	Check <i>Pr. 250</i> setting and connection of STF and STR signals.	118
	Inverter decelerated to a stop when power failure deceleration stop function is selected.	When power is restored, ensure the safety, and turn OFF the start signal once, then turn ON again to restart. Inverter restarts when <i>Pr. 261</i> ="2".	143
	Performing auto tuning.	When offline auto tuning ends, press (STOP) of the operation panel for the PU operation. For the External operation, turn OFF the start signal (STF or STR). This operation resets the offline auto tuning, and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)	106
	Automatic restart after instantaneous power failure function or power failure stop function is activated. (Performing overload operation with single-phase power input specification model may cause voltage insufficiency, and results in a detection of power failure.)	 Disable the automatic restart after instantaneous power failure function and power failure stop function. Reduce the load. Increase the acceleration time if the automatic restart after instantaneous power failure function or power failure stop function occurred during acceleration. 	137, 143
Load	Load is too heavy.	Reduce the load.	_
Others	Shaft is locked. Operation panel display shows an error (e.g. E.OC1).	Inspect the machine (motor). When any fault occurs, take an appropriate corrective action, then reset the inverter, and resume the operation.	257

5.5.2 Motor or machine is making abnormal acoustic noise

Check points	Possible Cause	Countermeasures	Refer to page
Input signal	Disturbance due to EMI when frequency command is	Take countermeasures against EMI.	40
Parameter Setting	given from analog input (terminal 2, 4).	Increase the <i>Pr. 74 Input filter time constant</i> if steady operation cannot be performed due to EMI.	153
J	No carrier frequency noises (metallic noises) are generated.	In the initial setting, <i>Pr. 240 Soft-PWM operation selection</i> is enabled to change motor noise to an unoffending complex tone. Therefore, no carrier frequency noises (metallic noises) are generated. Set <i>Pr. 240</i> = "0" to disable this function.	149
	Resonance occurs. (output frequency)	Set <i>Pr. 31 to Pr. 36 (Frequency jump)</i> . When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped.	85
Parameter Setting	Resonance occurs. (carrier frequency)	Change <i>Pr. 72 PWM frequency selection</i> setting. Changing the PWM carrier frequency produces an effect on avoiding the resonance frequency of a mechanical system or a motor.	149
	Auto tuning is not performed under General-purpose magnetic flux vector control.	Perform offline auto tuning.	106
	Gain adjustment during PID control is insufficient.	To stabilize the measured value, change the proportional band (<i>Pr. 129</i>) to a larger value, the integral time (<i>Pr. 130</i>) to a slightly longer time, and the differential time (<i>Pr. 134</i>) to a slightly shorter time. Check the calibration of set point and measured value.	213
Others	Mechanical looseness	Adjust machine/equipment so that there is no mechanical looseness.	_
Motor	Operating with output phase loss Contact the motor manufacturer.	Check the motor wiring.	_



5.5.3 Inverter generates abnormal noise

Check points	Possible Cause	Countermeasures	Refer to page
Fan	Fan cover was not correctly installed when a cooling fan was replaced.	Install a fan cover correctly.	282

5.5.4 Motor generates heat abnormally

Check			Refer
points	Possible Cause	Countermeasures	to
points			page
	Motor fan is not working	Clean the motor fan.	
Motor	(Dust is accumulated.)	Improve the environment.	_
	Phase to phase insulation of the motor is insufficient.	Check the insulation of the motor.	_
Main	The inverter output voltage (U, V, W) are unbalanced.	Check the output voltage of the inverter.	277
Circuit	The inverter output voltage (0, v, vv) are unbalanced.	Check the insulation of the motor.	2//
Parameter	The Dr. 71 Applied motor cotting is wrong	Check the Pr. 71 Applied motor setting	104
Setting	The Pr. 71 Applied motor setting is wrong.	Check the Pr. 71 Applied motor setting.	104
_	Motor current is large.	Refer to "5.5.11 Motor current is too large"	273

5.5.5 Motor rotates in the opposite direction

Check points	Possible Cause	Countermeasures	Refer to page
Main Circuit	Phase sequence of output terminals U, V and W is incorrect.	Connect phase sequence of the output cables (terminal U, V, W) to the motor correctly	15
Input	The start signals (forward rotation, reverse rotation) are connected improperly.	Check the wiring. (STF: forward rotation, STR: reverse rotation)	20
signal	Adjustment by the output frequency is improper during the reversible operation with <i>Pr. 73 Analog input selection</i> setting.	Check the setting of Pr. 125, Pr. 126, C2 to C7.	153
Parameter Setting	<i>Pr. 40 RUN key rotation direction selection</i> setting is incorrect.	Check the Pr. 40 setting.	238

5.5.6 Speed greatly differs from the setting

Check			Refer
points	Possible Cause	Countermeasures	to
points			page
Input	Frequency setting signal is incorrectly input.	Measure the input signal level.	_
	The input signal lines are affected by external EMI.	Take countermeasures against EMI such as using	40
signal	The input signal lines are affected by external EMI.	shielded wires for input signal lines.	40
	Pr. 1, Pr. 2, Pr. 18, calibration parameter C2 to C7 settings are improper.	Check the settings of Pr. 1 Maximum frequency, Pr. 2	84
Parameter		Minimum frequency, Pr. 18 High speed maximum frequency.	04
Setting		Check the calibration parameter C2 to C7 settings.	154
	Pr. 31 to Pr. 36 (frequency jump) settings are improper.	Narrow down the range of frequency jump.	85
Load		Reduce the load weight.	_
Parameter	Stall provention function is activated due to a heavy	Set Pr. 22 Stall prevention operation level higher according	
	otali provention famolien le delivated ade te a neary	to the load. (Setting Pr. 22 too large may result in	80
Setting	load.	frequent overcurrent trip (E.OC□).)	
Motor		Check the capacities of the inverter and the motor.	_

5.5.7 Acceleration/deceleration is not smooth

Check points	Possible Cause	Countermeasures	Refer to page
	Acceleration/deceleration time is too short.	Increase acceleration/deceleration time.	97
	Torque boost (<i>Pr. 0, Pr. 46</i>) setting is improper under V/F control, so the stall prevention function is activated.	Increase/decrease <i>Pr. 0 Torque boost</i> setting value by 0.5% increments to the setting.	75
	The base frequency does not match the motor	For V/F control, set Pr. 3 Base frequency and Pr. 47 Second V/F (base frequency).	86
Parameter	characteristics.	For General-purpose magnetic flux vector control, set <i>Pr.</i> 84 Rated motor frequency.	106
		Reduce the load weight.	_
Setting	Stall prevention function is activated due to a heavy load.	Set $Pr. 22$ Stall prevention operation level higher according to the load. (Setting $Pr. 22$ too large may result in frequent overcurrent trip (E.OC \square).)	80
		Check the capacities of the inverter and the motor.	_
	Regeneration avoidance operation is performed	If the frequency becomes unstable during regeneration avoidance operation, decrease the setting of <i>Pr. 886</i> Regeneration avoidance voltage gain.	227

5.5.8 Speed varies during operation

When the slip compensation is selected, the output frequency varies between 0 and 2Hz as with load fluctuates. This is a normal operation and not a fault.

Check points	Possible Cause	Countermeasures	Refer to page
Input signal	Multi-speed command signal is chattering.	Take countermeasures to suppress chattering.	_
Load	Load varies during an operation.	Select General-purpose magnetic flux vector control.	76
	Frequency setting signal is varying.	Check the frequency setting signal.	_
	The frequency cetting signal is effected by FMI	Set filter to the analog input terminal using <i>Pr. 74 Input filter time constant</i> .	153
Input signal	The frequency setting signal is affected by EMI.	Take countermeasures against EMI, such as using shielded wires for input signal lines.	40
	Malfunction is occurring due to the undesirable current generated when the transistor output unit is connected.	Use terminal PC (terminal SD when source logic) as a common terminal to prevent a malfunction caused by undesirable current.	23
	Pr. 80 Motor capacity setting is improper for the capacities of the inverter and the motor for General-purpose magnetic flux vector control.	Check the Pr. 80 Motor capacity setting.	76
	Fluctuation of power supply voltage is too large.	Change the <i>Pr. 19 Base frequency voltage</i> setting (about 3%) under V/F control.	86
Parameter Setting	Hunting occurs by the generated vibration, for example, when structural rigidity at load side is insufficient.	Disable automatic control functions, such as energy saving operation, fast-response current limit function, regeneration avoidance function, General-purpose magnetic flux vector control, and stall prevention. Adjust so that the control gain decreases and the level of safety increases. Change <i>Pr. 72 PWM frequency selection</i> setting.	149
	Wiring length exceeds 30m when General-purpose magnetic flux vector control is performed.	Perform offline auto tuning.	106
Others	Wiring length is too long for V/F control, and a voltage	Adjust <i>Pr. 0 Torque boost</i> by increasing with 0.5% increments for low-speed operation.	75
	drop occurs.	Change to General-purpose magnetic flux vector control.	76



5.5.9 Operation mode is not changed properly

Check	Parathia Cara		Refer
points	Possible Cause	Countermeasures	to page
Input signal	Start signal (STF or STR) is ON.	Check that the STF and STR signals are OFF. When either is ON, the operation mode cannot be changed.	166
Parameter Setting	Pr. 79 setting is improper.	When <i>Pr. 79 Operation mode selection</i> setting is "0" (initial value), the inverter is placed in the External operation mode at input power ON. To switch to the PU operation mode, press (PU) on the operation panel (press PU) when the parameter unit (FR-PU04/FR-PU07) is used). At other settings (1 to 4, 6, 7), the operation mode is limited accordingly.	166
	Operation mode and a writing device do not correspond.	Check <i>Pr. 79, Pr. 338, Pr. 339, Pr. 551,</i> and select an operation mode suitable for the purpose.	166, 177

5.5.10 Operation panel display is not operating

Check points	Possible Cause	Countermeasures	Refer to
-			page
Main		Check for the wiring and the installation.	
Circuit	Wiring or installation is improper.	Make sure that the connector is fitted securely across	14
Circuit		terminal P/+ to P1.	
Main			
Circuit			
Control	Power is not input.	Input the power.	14
Circuit			
	Command sources at the PU operation mode is not at	Check the setting of Pr. 551 PU mode operation command	
	'	source selection.	
Parameter	the operation panel.	(If parameter unit (FR-PU04/FR-PU07) is connected	177
Setting	(None of the operation mode displays (PU_EXI NET)	while $Pr. 551$ = "9999" (initial setting), all the operation	
	is lit.)	mode displays (PU_EXT_NET) turn OFF.)	

5.5.11 Motor current is too large

Check points	Possible Cause	Countermeasures	Refer to page			
	Torque boost (<i>Pr. 0, Pr. 46</i>) setting is improper under V/F control, so the stall prevention function is activated.	Increase/decrease <i>Pr. 0 Torque boost</i> setting value by 0.5% increments to the setting.	75			
	V/F pattern is improper when V/F control is performed. (Pr. 3, Pr. 14, Pr. 19)	i l (e.g. rated motor voltage).				
Parameter		Change <i>Pr. 14 Load pattern selection</i> according to the load characteristic.				
Setting		Reduce the load weight.				
	Stall prevention function is activated due to a heavy load.	Set Pr. 22 Stall prevention operation level higher according to the load. (Setting Pr. 22 too large may result in frequent overcurrent trip (E.OC□).)	80			
		Check the capacities of the inverter and the motor.	_			
	Auto tuning is not performed under General-purpose magnetic flux vector control.	Perform offline auto tuning.	106			

5.5.12 Speed does not accelerate

Check points	Possible Cause	Countermeasures	Refer to page	
	Start command and frequency command are chattering. Check if the start command and the frequency command are correct.			
Input signal	The wiring length used for analog frequency command is too long, and it is causing a voltage (current) drop.	Perform analog input bias/gain calibration.		
	Input signal lines are affected by external EMI.	Take countermeasures against EMI, such as using shielded wires for input signal lines.	40	
	Pr. 1, Pr. 2, Pr. 18, calibration parameter C2 to C7 settings are improper.	Check the settings of <i>Pr. 1 Maximum frequency and Pr. 2 Minimum frequency</i> . If you want to run the motor at 120Hz or higher, set <i>Pr. 18 High speed maximum frequency</i> . Check the <i>calibration parameter C2 to C7</i> settings.	84 154	
	Torque boost (<i>Pr.</i> 0, <i>Pr.</i> 46) setting is improper under V/F control, so the stall prevention function is activated.	Increase/decrease <i>Pr. 0 Torque boost</i> setting value by 0.5% increments so that stall prevention does not occur.		
Parameter	V/F pattern is improper when V/F control is performed.	Set rated frequency of the motor to <i>Pr. 3 Base frequency</i> . Use <i>Pr. 19 Base frequency voltage</i> to set the base voltage (e.g. rated motor voltage).	86	
Setting	(Pr. 3, Pr. 14, Pr. 19)	Change <i>Pr. 14 Load pattern selection</i> according to the load characteristic.	88	
		Reduce the load weight.	_	
	Stall prevention function is activated due to a heavy load.	Set <i>Pr. 22 Stall prevention operation level</i> higher according to the load. (Setting <i>Pr. 22</i> too large may result in frequent overcurrent trip (E.OC□).)	80	
		Check the capacities of the inverter and the motor.	_	
	Auto tuning is not performed under General-purpose magnetic flux vector control.	Perform offline auto tuning.	106	
	During PID control, output frequency is automatically cor	strolled to make measured value = set point.	213	
Main Circuit	Brake resistor is connected between terminal P/+ and P1 by mistake. Connect an optional brake transistor (MRS type, MY type, FR-ABR) between terminal P/+ and PR.			

5.5.13 Unable to write parameter setting

Check			Refer	
points	Possible Cause	Countermeasures	to	
points			page	
Input	Operation is being performed (signal STF or STR is	Stop the operation.		
•	ON).	When $Pr. 77 = "0"$ (initial value), write is enabled only	162	
signal	ON).	during a stop.		
	You are attempting to set the parameter in the External	Choose the PU operation mode.		
	operation mode.	Or, set Pr. 77 = "2" to enable parameter write regardless	162	
	operation mode.	of the operation mode.		
Parameter	Parameter is disabled by the Pr. 77 Parameter write	Check Pr. 77 Parameter write selection setting.		
Setting	selection setting.	Check Fr. // Furumeter write selection Setting.		
Setting	Key lock is activated by the Pr. 161 Frequency setting/key	Check Pr. 161 Frequency setting/key lock operation selection	239	
	lock operation selection setting.	setting.	239	
	Operation mode and a writing device do not	Check Pr. 79, Pr. 338, Pr. 339, Pr. 551, and select an		
	correspond.	operation mode suitable for the purpose.	177	

PRECAUTIONS FOR MAINTENANCE AND INSPECTION

This chapter provides the "PRECAUTIONS FOR MAINTENANCE AND INSPECTION" of this product.

Always read the instructions before using the equipment.

3.1	Inspection items	276
3 2	Measurement of main circuit voltages, currents and nowers	284

2

3

ļ

5

6

7

Inspection items

The inverter is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

Precautions for maintenance and inspection

For some short time after the power is switched OFF, a high voltage remains in the smoothing capacitor. When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched OFF, and then make sure that the voltage across the main circuit terminals P/+ and N/- of the inverter is not more than 30VDC using a tester, etc.

6.1 Inspection items

6.1.1 Daily inspection

Basically, check for the following faults during operation.

- (1) Motor operation fault
- (2) Improper installation environment
- (3) Cooling system fault
- (4) Abnormal vibration, abnormal noise
- (5) Abnormal overheat, discoloration

6.1.2 Periodic inspection

Check the areas inaccessible during operation and requiring periodic inspection.

Consult us for periodic inspection.

- (1) Check for cooling system fault......Clean the air filter, etc.
- (2) Tightening check and retightening......The screws and bolts may become loose due to vibration, temperature changes, etc. Check and tighten them.

Tighten them according to the specified tightening torque (Refer to page 17).

- (3) Check the conductors and insulating materials for corrosion and damage.
- (4) Measure insulation resistance.
- (5) Check and change the cooling fan and relay.

When using the safety stop function, periodic inspection is required to confirm that safety function of the safety system operates correctly.

(For more details, refer to the Safety stop function instruction manual (BCN-A211508-000).)

6.1.3 Daily and periodic inspection

Araa af	Inspection Item			Inte	erval	Corrective Action of	0								
Area of Inspection			Description	Daily	Periodic *2	Corrective Action at Alarm Occurrence	Customer's Check								
	Surrounding environment		Check the surrounding air temperature, humidity, dirt, corrosive gas, oil mist, etc.	0		Improve environment									
General	Ove	rall unit	Check for unusual vibration and noise.	0		Check alarm location and retighten									
	Pow	er supply voltage	Check that the main circuit voltages are normal.*1	0		Inspect the power supply									
			(1) Check with megger (across main circuit terminals and earth (ground) terminal).		0	Contact the manufacturer									
	Gen	eral	(2) Check for loose screws and bolts.		0	Retighten									
			(3) Check for overheat traces on the parts.		0	Contact the manufacturer									
			(4) Check for stain		0	Clean									
			(1) Check conductors for distortion.		0	Contact the manufacturer									
	Con	ductors, cables	(2) Check cable sheaths for breakage and deterioration (crack, discoloration, etc.)		0	Contact the manufacturer									
Main circuit	Tern	ninal block	Check for damage.		0	Stop the device and contact the manufacturer.									
			(1) Check for liquid leakage.		0	Contact the manufacturer									
	Smc	oothing aluminum	(2) Check for safety valve projection and bulge.		0	Contact the manufacturer									
	electrolytic capacitor		(3) Visual check and judge by the life check of the main circuit capacitor (<i>Refer to page 278</i>)		0										
	Relay		Check that the operation is normal and no chatter is heard.		0	Contact the manufacturer									
	Operation check		(1) Check that the output voltages across phases with the inverter operated alone is balanced		0	Contact the manufacturer									
Control			(2) Check that no fault is found in protective and display circuits in a sequence protective operation test.		0	Contact the manufacturer									
circuit, Protective circuit	1 45	arts check		Overall	(1) Check for unusual odor and discoloration.		0	Stop the device and contact the manufacturer.							
Circuit											(2) Check for serious rust development		0	Contact the manufacturer	
											Aluminum electrolytic	(1) Check for liquid leakage in a capacitor and deformation trace		0	Contact the manufacturer
	Д.	capacitor	(2) Visual check and judge by the life check of the main circuit capacitor (<i>Refer to page 278</i>)		0										
			(1) Check for unusual vibration and noise.	0		Replace the fan									
Cooling	Cool	ling fan	(2) Check for loose screws and bolts		0	Retighten									
Cooling system			(3) Check for stain		0	Clean									
0,010111	Heat	tsink	(1) Check for clogging (2) Check for stain		0	Clean Clean									
			(1) Check that display is normal.	0		Contact the manufacturer									
Dieplay	Indic	cation	(2) Check for stain	_	0	Clean									
Display	Mete	er	Check that reading is normal	0		Stop the device and contact the manufacturer.									
Load motor	Ope	ration check	Check for vibration and abnormal increase in operation noise	0		Stop the device and contact the manufacturer.									

^{*1} It is recommended to install a device to monitor voltage for checking the power supply voltage to the inverter.

^{*2} One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. Consult us for periodic inspection.

6.1.4 Display of the life of the inverter parts

The self-diagnostic alarm is output when the life span of the control circuit capacitor, cooling fan and each parts of the inrush current limit circuit is near its end. It gives an indication of replacement time.

The life alarm output can be used as a guideline for life judgement.

Parts	Judgement Level
Main circuit capacitor	85% of the initial capacity
Control circuit capacitor	Estimated remaining life 10%
Inrush current limit circuit	Estimated remaining life 10%
Initiasii current iiriit circuit	(Power ON: 100,000 times left)
Cooling fan	Less than 50% of the predetermined speed



POINT

Refer to page 230 to perform the life check of the inverter parts.

6.1.5 Checking the inverter and converter modules

<Preparation>

- (1) Disconnect the external power supply cables (R/L1, S/L2, T/L3) and motor cables (U, V, W).
- (2) Prepare a tester. (Use 100Ω range.)

<Checking method>

Change the polarity of the tester alternately at the inverter terminals R/L1, S/L2, T/L3, U, V, W, + and -, and check for continuity.




NOTE

- 1. Before measurement, check that the smoothing capacitor is discharged.
- 2. At the time of discontinuity, the measured value is almost ∞. When there is an instantaneous continuity, due to the smoothing capacitor, the tester may not indicate ∞. At the time of continuity, the measured value is several to several tens-of ohms depending on the module type, circuit tester type, etc. If all measured values are almost the same, the modules are without fault.

<Module device numbers and terminals to be checked>

●Three-phase 200V class, Three-phase 400V class, single-phase 200V class


		Tester	Polarity	Measured		Tester Polarity		Measured
			0	Value		\oplus	()	Value
	D1	R/L1	P/+	Discontinuity	D4	R/L1	N/-	Continuity
<u></u>	וט	P/+	R/L1	Continuity	D4	N/-	R/L1	Discontinuity
erte	D2	S/L2	P/+	Discontinuity	D5	S/L2	N/-	Continuity
Converter module	DZ	P/+	S/L2	Continuity	DS	N/-	S/L2	Discontinuity
0 -	D3*	T/L3*	P/+	Discontinuity	D6*	T/L3*	N/-	Continuity
		P/+	T/L3*	Continuity		N/-	T/L3*	Discontinuity
	TR1	U	P/+	Discontinuity	TR4	U	N/-	Continuity
		P/+	U	Continuity		N/-	U	Discontinuity
Inverter module	TR3	V	P/+	Discontinuity	TR6	V	N/-	Continuity
lve lod	1173	P/+	V	Continuity	110	N/-	V	Discontinuity
= =		W	P/+	Discontinuity		W	N/-	Continuity
	TR5	P/+	W	Continuity	TR2	N/-	W	Discontinuity



(Assumes the use of an analog meter.)

●Single-phase 100V class

			Tester Polarity		Measured		Polarity	Measured
			Θ	Value		(+)	\bigcirc	Value
	D1	S/L2	P/+	Discontinuity		R/L1	P/+	Discontinuity
Converter module	וט	P/+	S/L2	Continuity		P/+	R/L1	Discontinuity
Conv	D2	S/L2	N/-	Continuity	_	R/L1	N/-	Discontinuity
		N/-	S/L2	Discontinuity		N/-	R/L1	Discontinuity
	TR1	U	P/+	Discontinuity	TR4	U	N/-	Continuity
		P/+	U	Continuity		N/-	U	Discontinuity
Inverter module	TR3	V	P/+	Discontinuity	TR6	V	N/-	Continuity
moc	113	P/+	V	Continuity	TNO	N/-	V	Discontinuity
	TR5	W	P/+	Discontinuity	TDC	W	N/-	Continuity
	IKS	P/+	W	Continuity	TR2	N/-	W	Discontinuity



(Assumes the use of an analog meter.)

^{*} T/L3, D3 and D6 are only for the three-phase power input specification models.

6.1.6 Cleaning

Always run the inverter in a clean status.

When cleaning the inverter, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.



NOTE

Do not use solvent, such as acetone, benzene, toluene and alcohol, as these will cause the inverter surface paint to peel off. The display, etc. of the operation panel and parameter unit (FR-PU04/FR-PU07) are vulnerable to detergent and alcohol. Therefore, avoid using them for cleaning.

6.1.7 Replacement of parts

The inverter consists of many electronic parts such as semiconductor devices.

The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the inverter. For preventive maintenance, the parts must be replaced periodically.

Use the life check function as a guidance of parts replacement.

Part Name	Standard Replacement Interval *1	Description
Cooling fan	10 years	Replace (as required)
Main circuit smoothing capacitor	10 years *2	Replace (as required)
On-board smoothing capacitor	10 years	Replace the board (as required)
Relays	_	as required

^{*1} Replacement years for when the yearly average surrounding air temperature is 40°C (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)

^{*2} Output current: 80% of the inverter rated current




NOTE

For parts replacement, contact the nearest Mitsubishi FA Center.




(1) Cooling fan

The replacement interval of the cooling fan used for cooling the parts generating heat such as the main circuit semiconductor is greatly affected by the surrounding air temperature. When unusual noise and/or vibration is noticed during inspection, the cooling fan must be replaced immediately.




Reinstallation

 After confirming the orientation of the fan, reinstall the fan so that the arrow on the left of "AIR FLOW" faces up.




- 2) Reconnect the fan connectors.
- 3) When wiring, avoid the cables being caught by the fan.

3.7K or less




4) Reinstall the fan cover.

3.7K or less




Example for FR-D740-1.5K

5.5K or more



5.5K or more



Example for FR-D740-7.5K



NOTE

- · Installing the fan in the opposite of air flow direction can cause the inverter life to be shorter.
- · Prevent the cable from being caught when installing a fan.
- Switch the power OFF before replacing fans. Since the inverter circuits are charged with voltage even after power OFF, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.



(2) Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing in the main circuit DC section, and an aluminum electrolytic capacitor is used for stabilizing the control power in the control circuit. Their characteristics are deteriorated by the adverse effects of ripple currents, etc. The replacement intervals greatly vary with the surrounding air temperature and operating conditions. When the inverter is operated in air-conditioned and normal environment conditions, replace the capacitors about every 10 years.

When a certain period of time has elapsed, the capacitors will deteriorate more rapidly. Check the capacitors at least every year (less than six months if the life will be expired soon).

The appearance criteria for inspection are as follows:

- 1) Case: Check the side and bottom faces for expansion
- 2) Sealing plate: Check for remarkable warp and extreme crack.
- 3) Check for external crack, discoloration, liquid leakage, etc. Judge that the capacitor has reached its life when the measured capacitance of the capacitor reduced below 80% of the rating.



POINT

Refer to page 230 to perform the life check of the main circuit capacitor.

(3) Relays

To prevent a contact fault, etc., relays must be replaced according to the cumulative number of switching times (switching life).

6.2 Measurement of main circuit voltages, currents and powers


Since the voltages and currents on the inverter power supply and output sides include harmonics, measurement data depends on the instruments used and circuits measured.

When instruments for commercial frequency are used for measurement, measure the following circuits with the instruments given on the next page.

• When installing meters etc. on the inverter output side

When the inverter-to-motor wiring length is large, especially in the 400V class, small-capacity models, the meters and CTs may generate heat due to line-to-line leakage current. Therefore, choose the equipment which has enough allowance for the current rating.

To measure and display the output voltage and output current of the inverter, it is recommended to use the terminal FM output function of the inverter.



* At, As, Vt, Vs, W12, W13 are only for the three-phase power input specification models.

Examples of Measuring Points and Instruments

1

Measuring Points and Instruments

Item	Measuring Point	Measuring Instrument	Remarks (Reference Measure	d Value)
Power supply voltage	R/L1 and S/L2	Moving-iron type AC	Commercial power supply	
V1	S/L2 and T/L3	voltmeter *5	Within permissible AC voltage fluctuat	ion (Refer to
	T/L3 and R/L1 *4	Volumeter **5	page 290)	
Power supply side	R/L1, S/L2, T/L3 line	Moving-iron type AC		
current	current *4	ammeter *5		
<u> </u>				
Power supply side	R/L1, S/L2, T/L3 and	Digital power meter		
power	R/L1 and S/L2,	(designed for inverter) or	P1=W11+W12+W13 (3-wattmeter met	hod)
P1	S/L2 and T/L3,	electrodynamic type single-	(, , , , , , , , , , , , , , , , , , ,	,
	T/L3 and R/L1 *4	phase wattmeter		
	Calculate after measuring p			
Power supply side	supply side current and pow		[Cingle phase newspaper]	
power factor	[Three-phase power supply]		[Single-phase power supply]	
Pf1	$Pf_1 = \frac{P_1}{\sqrt{3}V_1 \times I_1} \times 100$	%	$Pf_1 = \frac{P_1}{V_1 \times I_1} \times 100 \%$	
	,			
Output side voltage	Across U and V, V and W,	Rectifier type AC voltage meter *1 *5	Difference between the phases is with	in 1% of the
V2	and W and U	(moving-iron type cannot	Difference between the phases is with maximum output voltage.	111 1 /0 OI UIE
٧Z	and W and O	measure)	maximum output voltage.	
Output side current		Moving-iron type AC	Difference between the phases is 10%	or lower of
12	U, V and W line currents	ammeter *2 *5	the rated inverter current.	
·-		Digital power meter		
Output side power	U, V, W and	(designed for inverter) or	P2 = W21 + W22	
P2 .	U and V, V and W	electrodynamic type single-	2-wattmeter method (or 3-wattmeter m	nethod)
		phase wattmeter	·	
	Calculate in similar manner	to power supply side power fact	or.	
Output side power factor Pf2	$Pf_2 = \frac{P_2}{\sqrt{3}V_2 \times I_2} \times 100$	%		
Converter output	Across P/+ and N/-	Moving-coil type (such as tester)	Inverter LED display is lit. 1.35 × V1	
Frequency setting	Across 2(+) and 5		0.45.40\/DC.4.45.2055ADC	
signal	Across 4(+) and 5	1	0 to 10VDC, 4 to 20mADC	"5" is
Frequency setting power supply	Across 10(+) and 5		5.2VDC	common
			Approximately 5VDC at maximum	
			frequency	
			(without frequency meter)	
			T1	
		Moving-coil type	1.1	
		J ,,		
Frequency meter	Acres FM(1) and CD	Moving-coil type (tester and such may be used)	₹8VDC	
•	Across FM(+) and SD	(tester and such may be	★	"SD" ie
•	Across FM(+) and SD	(tester and such may be used)	★	"SD" is
•	Across FM(+) and SD	(tester and such may be used) (internal resistance $50 k\Omega$ or	\$\displaystyle{\text{\rightarrow}}\$	"SD" is common.
Frequency meter signal	Across FM(+) and SD	(tester and such may be used) (internal resistance $50 k\Omega$ or	₹8VDC T2	
• •	Across FM(+) and SD	(tester and such may be used) (internal resistance $50 k\Omega$ or	$\begin{array}{c c} & & & \\ \hline \downarrow 8 \text{VDC} & & \\ \hline \\ \hline$	
• •	Across FM(+) and SD	(tester and such may be used) (internal resistance $50 k\Omega$ or	Pulse width T1: Adjust with C0 (Pr. 900)	
signal		(tester and such may be used) (internal resistance $50 k\Omega$ or	Pulse width T1: Adjust with C0 (Pr. 900) Pulse cycle T2: Set with Pr. 55	
signal Start signal	Across SD and STF, STR,	(tester and such may be used) (internal resistance $50 k\Omega$ or	Pulse width T1: Adjust with C0 (Pr. 900) Pulse cycle T2: Set with Pr. 55 (frequency monitor only)	
signal Start signal		(tester and such may be used) (internal resistance $50 k\Omega$ or	Pulse width T1: Adjust with C0 (Pr. 900) Pulse cycle T2: Set with Pr. 55 (frequency monitor only) When open	
signal Start signal	Across SD and STF, STR, RH, RM, or RL(+)	(tester and such may be used) (internal resistance 50kΩ or more)	Pulse width T1: Adjust with C0 (Pr. 900) Pulse cycle T2: Set with Pr. 55 (frequency monitor only) When open 20 to 30VDC	
signal Start signal Select signal	Across SD and STF, STR, RH, RM, or RL(+) Across A and C	(tester and such may be used) (internal resistance 50kΩ or more)	Pulse width T1: Adjust with C0 (Pr. 900) Pulse cycle T2: Set with Pr. 55 (frequency monitor only) When open 20 to 30VDC ON voltage: 1V or less Continuity check *3 <normal></normal>	common.
signal Start signal	Across SD and STF, STR, RH, RM, or RL(+)	(tester and such may be used) (internal resistance 50kΩ or more)	Pulse width T1: Adjust with C0 (Pr. 900) Pulse cycle T2: Set with Pr. 55 (frequency monitor only) When open 20 to 30VDC ON voltage: 1V or less Continuity check *3 <normal> Across A and C Discontinuity (C)</normal>	common.

- *1 Use an FFT to measure the output voltage accurately. An FA tester or general measuring instrument cannot measure accurately.
- When the carrier frequency exceeds 5kHz, do not use this instrument since using it may increase eddy-current losses produced in metal parts inside the instrument, leading to burnout. In this case, use an approximate-effective value type.
- *3 When the setting of Pr. 192 A,B,C terminal function selection is positive logic
- *4 T/L3 is only for the three-phase power input specification models.
- *5 A digital power meter (designed for inverter) can also be used to measure.

6.2.1 Measurement of powers

Use digital power meters (for inverter) for the both of inverter input and output side. Alternatively, measure using electrodynamic type single-phase wattmeters for the both of inverter input and output side in two-wattmeter or three-wattmeter method. As the current is liable to be imbalanced especially in the input side, it is recommended to use the three-wattmeter method.

Examples of process value differences produced by different measuring meters are shown below.

An error will be produced by difference between measuring instruments, e.g. power calculation type and two- or three-wattmeter type three-phase wattmeter. When a CT is used in the current measuring side or when the meter contains a PT on the voltage measurement side, an error will also be produced due to the frequency characteristics of the CT and PT.

[Measurement conditions]


Constant-torque (100%) load, note that 60Hz or more should be constantly output 3.7kW, 4-pole motor, value indicated in 3-wattmeter method is 100%.

120100 30 3-wattmeter method (Electro-dynamometer type) 2-wattmeter method (Electro-dynamometer type) Clip AC power meter (For balanced three-phase load) Clamp-on wattmeter (Hall device power arithmetic type)

Example of Measuring Inverter Input Power

[Measurement conditions]

Constant-torque (100%) load, note that 60Hz or more should be constantly output 3.7kW, 4-pole motor, value indicated in 3-wattmeter method is 100%.



Example of Measuring Inverter Output Power

6.2.2 Measurement of voltages and use of PT

(1) Inverter input side

As the input side voltage has a sine wave and it is extremely small in distortion, accurate measurement can be made with an ordinary AC meter.

(2) Inverter output side

Since the output side voltage has a PWM-controlled rectangular wave, always use a rectifier type voltmeter. A needle type tester can not be used to measure the output side voltage as it indicates a value much greater than the actual value. A moving-iron type meter indicates an effective value which includes harmonics and therefore the value is larger than that of the fundamental wave. The value monitored on the operation panel is the inverter-controlled voltage itself. Hence, that value is accurate and it is recommended to monitor values using the operation panel.

(3) PT

No PT can be used in the output side of the inverter. Use a direct-reading meter. (A PT can be used in the input side of the inverter.)

6.2.3 Measurement of currents

Use moving-iron type meters on both the input and output sides of the inverter. However, If the carrier frequency exceeds 5kHz, do not use that meter since an overcurrent losses produced in the internal metal parts of the meter will increase and the meter may burn out. In this case, use an approximate-effective value type.

Since current on the inverter input side tends to be unbalanced, measurement of three phases is recommended. Correct value can not be obtained by measuring only one or two phases. On the other hand, the unbalanced ratio of each phase of the output side current should be within 10%.


When a clamp ammeter is used, always use an effective value detection type. A mean value detection type produces a large error and may indicate an extremely smaller value than the actual value. The value monitored on the operation panel is accurate if the output frequency varies, and it is recommended to monitor values (provide analog output) using the operation panel.


[Measurement conditions]

Examples of process value differences produced by different measuring meters are shown below.

[Measurement conditions]

Value indicated by moving-iron type ammeter is 100%. Value indicated by moving-iron type ammeter is 100%.





Example of measuring inverter input current

Example of measuring inverter output current


6.2.4 Use of CT and transducer

A CT may be used in both the input and output sides of the inverter, but the one used should have the largest possible VA ability because an error will increase if the frequency gets lower.

When using a transducer, use the effective value calculation type which is immune to harmonics.

6.2.5 Measurement of inverter input power factor

Calculate using effective power and apparent power. A power-factor meter can not indicate an exact value.



6.2.6 Measurement of converter output voltage (across terminals P and N)

The output voltage of the converter is developed across terminals P and N and can be measured with a moving-coil type meter (tester). Although the voltage varies according to the power supply voltage, approximately 270VDC to 300VDC (540VDC to 600VDC for the 400V class) is output when no load is connected and voltage decreases during driving load operation.

When energy is regenerated from the motor during deceleration, for example, the converter output voltage rises to nearly 400VDC to 450VDC (800VDC to 900VDC for the 400V class) maximum.


6.2.7 Measurement of inverter output frequency

A pulse train proportional to the output frequency is output across the frequency meter signal output terminal FM-SD of the inverter. This pulse train output can be counted by a frequency counter, or a meter (moving-coil type voltmeter) can be used to read the mean value of the pulse train output voltage. When a meter is used to measure the output frequency, approximately 5VDC is indicated at the maximum frequency.

For detailed specifications of the frequency meter signal output terminal FM, refer to page 135.

6.2.8 Insulation resistance test using megger

• For the inverter, conduct the insulation resistance test on the main circuit only as shown below and do not perform the test on the control circuit. (Use a 500VDC megger.)



- Before performing the insulation resistance test on the external circuit, disconnect the cables from all terminals of the inverter so that the test voltage is not applied to the inverter.

 For the continuity test of the control circuit, use a tester (high resistance range) and do not use the megger or buzzer.

6.2.9 Pressure test

Do not conduct a pressure test. Deterioration may occur.

7 SPECIFICATIONS

This chapter provides the "SPECIFICATIONS" of this product. Always read the instructions before using the equipment.

7.1	Rating	290
7.2	Common specifications	292
7.3	Outline dimension drawings	293

L

7.1 Rating

• Three-phase 200V power supply

	Model FR-D720-□K(-C)∗7	0.1	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
Apı	olicable motor capacity (kW)*1	0.1	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
	Rated capacity (kVA)*2	0.3	0.6	1.0	1.7	2.8	4.0	6.6	9.5	12.7	17.1	22.1
Ħ	Rated current (A)	0.8	1.4	2.5	4.2	7.0	10.0	16.5	23.8	31.8	45.0	58.0
Output	Overload current rating*3		150% 60s, 200% 0.5s (inverse-time characteristics)									
0	Voltage*4	Three-phase 200 to 240V										
	Regenerative braking torque*5	150	150% 100%			50%	20%					
<u>></u>	Rated input AC voltage/frequency	Three-phase 200 to 240V 50Hz/60Hz										
supply	Permissible AC voltage	170 to 264V 50Hz/60Hz										
	fluctuation					170 10 2	2047 301	12/001 12				
ower	Permissible frequency fluctuation	±5%										
ď	Power supply capacity (kVA)*6	0.4	0.4 0.7 1.2 2.1		4.0	5.5	9.0	12.0	17.0	20.0	27.0	
Pro	tective structure (JEM1030)	e (JEM1030) Enclosed type (IP20). IP40 for totally enclosed structure series.										
Co	oling system		Self-c	ooling				Ford	ed air co	oling		
Apı	proximate mass (kg)	0.5	0.5	8.0	1.0	1.4	1.4	1.8	3.6	3.6	6.5	6.5

• Three-phase 400V power supply

	Model FR-D740-□K(-C)∗7	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
App	olicable motor capacity (kW)*1	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
	Rated capacity (kVA)*2	0.9	1.7	2.7	3.8	6.1	9.1	12.2	17.5	22.5
Ħ	Rated current (A)	1.2	2.2	3.6	5.0	8.0	12.0	16.0	23.0	29.5
Output	Overload current rating*3		150% 60s, 200% 0.5s (inverse-time character				aracterist	cs)		
0	Voltage*4	Three-phase 380 to 480V								
	Regenerative braking torque*5	10	0%	50%			20)%		
Ş	Rated input AC voltage/frequency	Three-phase 380 to 480V 50Hz/60Hz								
supply	Permissible AC voltage fluctuation	325 to 528V 50Hz/60Hz								
Permissible frequency fluctuation						±5%				
Power	Power supply capacity (kVA)*6	1.5	2.5	4.5	5.5	9.5	12.0	17.0	20.0	28.0
Pro	tective structure (JEM1030)		Enclosed	l type (IP	20). IP40	for totally	, enclose	d structu	re series.	
Cod	oling system	Self-c	ooling			Ford	ed air co	oling		
App	proximate mass (kg)	1.3	1.3	1.4	1.5	1.5	3.3	3.3	6.0	6.0

- *1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- *2 The rated output capacity indicated assumes that the output voltage is 230V for three-phase 200V class and 440V for three-phase 400V class.
- *3 The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
- The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about $\sqrt{2}$ that of the power supply.
- *5 The braking torque indicated is a short-duration average torque (which varies with motor loss) when the motor alone is decelerated from 60Hz in the shortest time and is not a continuous regenerative torque. When the motor is decelerated from the frequency higher than the base frequency, the average deceleration torque will reduce. Since the inverter does not contain a brake resistor, use the optional brake resistor when regenerative energy is large. A brake unit (FR-BU2) may also be used.
- *6 The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).
- *7 Totally enclosed structure series ends with -C.

Single-phase 200V power supply

	Model FR-D720S-□K	0.1	0.2	0.4	0.75	1.5	2.2
App	licable motor capacity (kW)*1	0.1	0.2	0.4	0.75	1.5	2.2
	Rated capacity (kVA)*2	0.3	0.6	1.0	1.7	2.8	4.0
Ħ	Rated current (A)	0.8	1.4	2.5	4.2	7.0	10.0
Output	Overload current rating*3	150% 60s, 200% 0.5s (inverse-time characteristics)					
Ō	Voltage*4	Three-phase 200 to 240V					
	Regenerative braking torque*5	150% 100%		50%	20%		
Ş	Rated input AC voltage/frequency	Single-phase 200 to 240V 50Hz/60Hz					
supply	Permissible AC voltage fluctuation	170 to 264V 50Hz/60Hz					
er s	Permissible frequency fluctuation	±5%					
Power	Power supply capacity (kVA)*6	0.5	0.9	1.5	2.3	4.0	5.2
Pro	Protective structure (JEM1030) Enclosed type (IP20).						
Coc	oling system		Self-c	ooling		Forced a	ir cooling
App	roximate mass (kg)	0.5	0.5	0.9	1.1	1.5	2.0

Single-phase 100V power supply

	Model FR-D710W-□K	0.1	0.2	0.4	0.75
App	licable motor capacity (kW)*1	0.1	0.2	0.4	0.75
	Rated capacity (kVA)*2	0.3	0.6	1.0	1.7
	Rated current (A)	0.8	1.4	2.5	4.2
put	Overload current rating*3		150% 60s,	200% 0.5s	;
Ont	Overload current rating*3		erse-time o	characterist	ics)
	Voltage	Thre	ee-phase 2	00 to 230V	*7, *8
	Regenerative braking torque*5	150% 100%			0%
Ş	Rated input AC voltage/frequency	Single-phase 100 to 115V 50Hz/60Hz			
ddn	Permissible AC voltage fluctuation	90 to 132V 50Hz/60Hz			
s Je	Permissible frequency fluctuation		±5	5%	
Power supply	Power supply capacity (kVA)*6	0.5	0.9	1.5	2.5
Pro	tective structure (JEM1030)		Enclosed t	ype (IP20).	
Cod	oling system		Self-c	ooling	
App	proximate mass (kg)	0.6	0.7	0.9	1.4

- *1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- *2 The rated output capacity indicated assumes that the output voltage is 230V.
- The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load. If the automatic restart after instantaneous power failure function (Pr. 57) or power failure stop function (Pr. 261) is set and power supply voltage is low while load becomes bigger, the bus voltage decreases to power failure detection level and load of 100% or more may not be available.
- *4 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about $\sqrt{2}$ that of the power supply.
- The braking torque indicated is a short-duration average torque (which varies with motor loss) when the motor alone is decelerated from 60Hz in the shortest time and is not a continuous regenerative torque. When the motor is decelerated from the frequency higher than the base frequency, the average deceleration torque will reduce. Since the inverter does not contain a brake resistor, use the optional brake resistor when regenerative energy is large. A brake unit (FR-BU2) may also be used.
- *6 The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).
- For single-phase 100V power input model, the maximum output voltage is twice the amount of the power supply voltage and cannot be exceeded.
- In a single-phase 100V power input model, the output voltage may fall down when the load is heavy, and larger output current may flow compared to a threephase input model. Use the motor with less load so that the output current is within the rated motor current range.

Common specifications

	Cor	ntrol method		Soft-PWM control/high carrier frequency PWM control (V/F control, General-purpose magnetic flux vector control, and Optimum excitation control are available)
	Out	put frequency ra	ange	0.2 to 400Hz
	-	put frequency fe	90	0.06Hz/60Hz (terminal2, 4: 0 to 10V/10bit)
2	Fre	quency setting	Analog input	0.12Hz/60Hz (terminal2, 4: 0 to 5V/9bit)
₫		olution		0.06Hz/60Hz (terminal4: 0 to 20mA/10bit)
specifications			Digital input	0.01Hz
É	Fre	quency	Analog input	Within ±1% of the max. output frequency (25°C ±10°C)
ĕ			Digital input	Within 0.01% of the set output frequency
	Vol	tage/frequency c		Base frequency can be set from 0 to 400Hz. Constant-torque/variable torque pattern can be selected
5		rting torque		150% or more (at 1Hz)when General-purpose magnetic flux vector control and slip compensation is set
Control	_	que boost		Manual torque boost
Ö		•		0.1 to 3600s (acceleration and deceleration can be set individually),
	Acc	eleration/deceler	ation time setting	Linear and S-pattern acceleration/deceleration modes are available.
	DC	injection brake		Operation frequency (0 to 120Hz), operation time (0 to 10s), and operation voltage (0 to 30%) can be changed
	_	Il prevention ope	eration level	Operation current level (0 to 200%), and whether to use the function or not can be selected
				Two terminals
	Fre sigi	quency setting	Analog input	Terminal 2: 0 to 10V and 0 to 5V are available Terminal 4: 0 to 10V, 0 to 5V, and 4 to 20mA are available
	Jigi		Digital input	The signal is entered from the operation panel or parameter unit. Frequency setting increment can be set.
	Sta	rt signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.
ations	Inp	ut signal (five tei	rminals)	The following signals can be assigned to <i>Pr. 178 to Pr.182 (input terminal function selection)</i> : multi-speed selection, remote setting, second function selection, terminal 4 input selection, JOG operation selection, PID control valid terminal, external thermal input, PU-External operation switchover, V/F switchover, output stop, start self-holding selection, forward rotation, reverse rotation command, inverter reset, PU-NET operation switchover, External-NET operation switchover, command source switchover, inverter operation enable signal, and PU operation external interlock.
ion specifications			ns	Maximum/minimum frequency setting, frequency jump operation, external thermal relay input selection, automatic restart after instantaneous power failure operation, forward/reverse rotation prevention, remote setting, second function, multi-speed operation, regeneration avoidance, slip compensation, operation mode selection, offline auto tuning function, PID control, computer link operation (RS-485), Optimum excitation control, power failure stop, speed smoothing control, Modbus-RTU
Operation			terminal)	The following signals can be assigned to Pr.190, Pr.192 and Pr.197 (output terminal function selection): inverter operation, up-to-frequency, overload alarm, output frequency detection, regenerative brake prealarm, electronic thermal relay function prealarm, inverter operation ready, output current detection, zero current detection, PID lower limit, PID upper limit, PID forward/reverse rotation output, fan alarm*1, heatsink overheat pre-alarm, deceleration at an instantaneous power failure, PID control activated, PID output interruption, safety monitor output, safety monitor output 2, during retry, life alarm, current average value monitor, remote output, alarm
		For meter Pulse train outp (MAX 2.4kHz: o		output, fault output, fault output 3, and maintenance timer alarm. The following signals can be assigned to <i>Pr.54 FM terminal function selection</i> : output frequency, output current (steady), output voltage, frequency setting, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, reference voltage output, motor load factor, PID set point, PID measured value, output power, PID deviation, motor thermal load factor, and inverter thermal load factor. Pulse train output (1440 pulses/s/full scale)
ication		eration panel	Operating status	The following operating status can be displayed: output frequency, output current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peal value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, and PTC thermistor resistance.
Indic	Par (FR	ameter unit -PU07)	Fault definition	Fault definition is displayed when a fault occurs. Past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored.
			Interactive guidance	Function (help) for operation guide *2
	Protective function incition			Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during acceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase loss *3 *4, output side earth (ground) fault overcurrent at start*3, output phase loss, external thermal relay operation *3, PTC thermistor operation*3, parameter error, PU disconnection, retry count excess *3, CPU fault, brake transistor alarm, inrush resistance overheat, analog input error, stall prevention operation, output current detection value exceeded *3, safety circuit fau
			Warning function	Fan alarm*1, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error, regenerative brake prealarm *3, electronic thermal relay function prealarm, maintenance output *3, undervoltage operation panel lock, password locked, inverter reset, safety stop
'n	Sur	rounding air tem	perature	-10°C to +50°C maximum (non-freezing) (-10°C to +40°C for totally-enclosed structure feature) *5
лe	Am	bient humidity		90%RH or less (non-condensing)
ū		rage temperatur	e *6	-20°C to +65°C
Environment	_	nosphere		Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)
ū		tude/vibration		Maximum 1000m above sea level, 5.9m/s ² or less at 10 to 55Hz (directions of X, Y, Z axes)
_				a cooling for this clarm does not function

- As the 0.75K or less are not provided with the cooling fan, this alarm does not function.

- *2 *3 *4 *5 *6
- This operation guide is only available with option parameter unit (FR-PU07).

 This protective function does not function in the initial status.


 This protective function is available with the three-phase power input specification model only.

 When using the inverters at the surrounding air temperature of 40°C or less, the inverters can be installed closely attached (0cm clearance). Temperatures applicable for a short time, e.g. in transit.




Outline dimension drawings


- ●FR-D720-0.1K to 0.75K
- ●FR-D720S-0.1K to 0.75K
- ●FR-D710W-0.1K to 0.4K




- ●FR-D720-1.5K to 3.7K
- ●FR-D740-0.4K to 3.7K
- ●FR-D720S-1.5K
- ●FR-D710W-0.75K




●FR-D720S-2.2K




- ●FR-D720-5.5K, 7.5K
- ●FR-D740-5.5K, 7.5K




- ●FR-D720-11K, 15K
- ●FR-D740-11K, 15K



●Parameter unit (option) (FR-PU07)



●Enclosure surface operation panel (option) (FR-PA07)



MEMO

APPENDIX

This chapter provides the "APPENDIX" of this product. Always read the instructions before using the equipment.

APPENDIX

Appendix1 For customers replacing the conventional model with this inverter

Appendix 1-1 Replacement of the FR-S500 series

(1) Instructions for installation

- 1) Removal procedure of the front cover and wiring cover was changed. (Refer to page 5)
- 2) FR-SW0-SETUP, FR-SW1-SETUP, FR-SW2-SETUP (setup softwares) can not be used.

(2) Instructions for continuous use of the FR-PU04 (parameter unit)

- 1) For the FR-D700 series, many functions (parameters) have been added. When setting these parameters, the parameter name and setting range are not displayed. User initial value list and user clear of the HELP function can not be used.
- 2) For the FR-D700 series, many protective functions have been added. These functions activate, but all faults are displayed as "Fault 14". When the faults history has been checked, "E.14" appears. Added faults display will not appear on the parameter unit.
- 3) User initial value setting can not be used.
- 4) User registration/clear can not be used.
- 5) Parameter copy/verification function can not be used.

(3) Parameter resetting

It is easy if you use FR Configurator SW3 (setup software).

(4) Main differences and compatibilities with the FR-S500 series

Item	FR-S500	FR-D700
Item	FR-3000	V/F control
Control method	V/F control	General-purpose magnetic flux vector control
Control method	Automatic torque boost	Optimum excitation control
Output frequency		'
range	0.5 to 120Hz	0.2 to 400Hz
	Pr. 0 Torque boost	
	FR-S520E-1.5K to 3.7K: 6%	FR-D720-1.5K to 3.7K: 4%
	FR-S540E-1.5K, 2.2K: 5%	FR-D740-1.5K, 2.2K: 4%
Changed initial value	FR-S520SE-1.5K: 6%	FR-D720S-1.5K: 4%
Changed initial value	Pr.1 Maximum frequency	
	60Hz	120Hz
	Pr. 12 DC injection brake operation voltage	
	0.4K to 3.7K: 6%	0.4K to 3.7K: 4%
	Pr. 37 Speed display	
Changed setting	0.1	0.001
increments	H2(Pr. 504) Maintenance timer alarm output set time	Pr.504 Maintenance timer alarm output set time
morements	Time per increments: 1000h	Time per increments: 100h
	Initial value: 36 (36000h)	Initial value: 9999 (not function)
	Pr. 52 Control panel display data selection	Pr.52 DU/PU main display data selection
	1: Output current	0/100: Output current (select with (SET))
	Pr.54 FM terminal function selection	
	0: Output frequency (initial value),	1: Output frequency (initial value),
	1: Output current	2: Output current
	Pr. 60 to Pr. 63 Input terminal function selection	Pr. 178 to Pr. 182 Input terminal function selection
	5: STOP signal (start self-holding selection)	5: JOG signal (Jog operation selection)
Changed setting value	6: MRS signal (output stop)	6: None
	9: JOG signal (Jog operation selection)	24: MRS signal (output stop)
	10: RES signal (reset)	25: STOP signal (start self-holding selection)
	: STR signal (reverse rotation command)	61: STR signal (reverse rotation command)
		62: RES signal (reset)
	Second applied motor	D 450 G 1 1: 1
	Pr. 71 = 100, 101	Pr. 450 Second applied motor
	Pr. 73 Terminal 2 0 to 5V, 0 to 10V selection	Pr. 73 Analog input selection
	0: 0 to 5V (initial value), 1: 0 to 10V	0: 0 to 10V, 1: 0 to 5V (initial value)
	1.00100	1. 0 to 5v (irilliai value)

Item		FR-S500	FR-D700			
			Replacement function (General-purpose magnetic flux			
Pr. 98 Automatic torque boost selection			vector contro	,		
Deleted functions		•	(Pr. 80 Motor capacity)			
20.0.54 14.100010	<i>Pr. 99</i> Motor p	orimary resistance	(Pr. 90 Motor constant (R1))			
	Long wiring n	node (setting value 10, 11 of Pr. 70)	Setting unnecessary (setting value 10, 11 of <i>Pr. 240</i> i			
	, ,	1	deleted)	I		
	Parameter Number	Name	Parameter	Name		
	Pr. 17	DLIN key retation direction collection	Number Pr. 40	DLIN key retation direction coloction		
	Pr. 21	RUN key rotation direction selection Stall prevention function selection	Pr. 156	RUN key rotation direction selection Stall prevention operation selection		
		Stall prevention operation reduction		Stall prevention operation reduction		
	Pr. 28	starting frequency	Pr. 66	starting frequency		
	Pr. 30	Extended function display selection	Pr. 160	Extended function display selection		
	Pr. 38	Frequency setting voltage gain frequency	Pr. 125	Terminal 2 frequency setting gain frequency		
	Pr. 39	Frequency setting current gain frequency	Pr. 126	Terminal 4 frequency setting gain frequency		
	Pr. 40	Start-time ground fault detection selection	Pr. 249	Earth (ground) fault detection at start		
	Pr. 48	Output current detection level	Pr. 150	Output current detection level		
	Pr. 49	Output current detection signal delay time	Pr. 151	Output current detection signal delay time		
	Pr. 50	Zero current detection level	Pr. 152	Zero current detection level		
	Pr. 51	Zero current detection time	Pr. 153	Zero current detection time		
	Pr. 53	Frequency setting operation selection	Pr. 161	Frequency setting/key lock operation selection		
	Pr. 60	RL terminal function selection	Pr. 180	RL terminal function selection		
	Pr. 61	RM terminal function selection	Pr. 181	RM terminal function selection		
	Pr. 62	RH terminal function selection	Pr. 182	RH terminal function selection		
	Pr. 63	STR terminal function selection	Pr. 179	STR terminal function selection		
	Pr. 64	RUN terminal function selection	Pr. 190	RUN terminal function selection		
	Pr. 65	A, B, C terminal function selection	Pr. 192	A,B,C terminal function selection		
	Pr. 66 Pr. 70	Retry selection Soft-PWM setting	Pr. 65 Pr. 240	Retry selection Soft-PWM operation selection		
	Pr. 76	Cooling fan operation selection	Pr. 244	Cooling fan operation selection		
	Pr. 80	Multi-speed setting (speed 8)	Pr. 232	Multi-speed setting (speed 8)		
	Pr. 81	Multi-speed setting (speed 9)	Pr. 233	Multi-speed setting (speed 9)		
Changed parameter	Pr. 82	Multi-speed setting (speed 10)	Pr. 234	Multi-speed setting (speed 10)		
number and name	Pr. 83	Multi-speed setting (speed 11)	Pr. 235	Multi-speed setting (speed 11)		
	Pr. 84	Multi-speed setting (speed 12)	Pr. 236	Multi-speed setting (speed 12)		
	Pr. 85	Multi-speed setting (speed 13)	Pr. 237	Multi-speed setting (speed 13)		
	Pr. 86	Multi-speed setting (speed 14)	Pr. 238	Multi-speed setting (speed 14)		
	Pr. 87	Multi-speed setting (speed 15)	Pr. 239	Multi-speed setting (speed 15)		
	Pr. 88	PID action selection	Pr. 128	PID action selection		
	Pr. 89 Pr. 90	PID proportional band PID integral time	Pr. 129 Pr. 130	PID proportional band PID integral time		
	Pr. 91	PID upper limit	Pr. 131	PID upper limit		
	Pr. 92	PID lower limit	Pr. 132	PID lower limit		
	Pr. 93	PID action set point for PU operation	Pr. 133	PID action set point		
	Pr. 94	PID differential time	Pr. 134	PID differential time		
	Pr. 95	Rated motor slip	Pr. 245	Rated slip		
	Pr. 96	Slip compensation time constant	Pr. 246	Slip compensation time constant		
	Pr. 97	Constant power range slip compensation	Pr. 247	Constant-power range slip compensation		
		selection		selection		
	H7(Pr. 559) b1(Pr. 560)	Second electronic thermal O/L relay Regenerative function selection	Pr. 51 Pr. 30	Second electronic thermal O/L relay Regenerative function selection		
	b2(Pr. 561)	Special regenerative brake duty	Pr. 70	Special regenerative brake duty		
	n1(Pr. 331)	Communication station number	Pr. 117	PU communication station number		
	n2(Pr. 332)	Communication speed	Pr. 118	PU communication speed		
	n3(Pr. 333)	Stop bit length	Pr. 119	PU communication stop bit length		
	n4(Pr. 334)	Parity check presence/absence	Pr. 120	PU communication parity check		
	n5(Pr. 335)	Number of communication retries	Pr. 121	Number of PU communication retries		
	n6(Pr. 336)	Communication check time interval	Pr. 122	PU communication check time interval		
	n7(Pr. 337)	Waiting time setting	Pr. 123	PU communication waiting time setting		
		CR/LF setting	Pr. 124	PU communication CR/LF selection		
	n16(Pr. 992)	PU main display screen data selection	Pr.52	DU/PU main display data selection		
	` ′	Disconnected PU detection/PU setting lock	Pr. 75	Reset selection/disconnected PU detection/PU stop selection		
	Screw type to			terminal block		
		h a flathead screw	Fix a wire wit	h a pressure of inside spring		
Control terminal block	,	M2(M3 for terminal A, B, C))				
	Length of rec	ommended blade terminal: 6mm		ommended blade terminal: 10mm		
	Length of recommended blade terminal: omm			al of FR-S500 is unavailable)		
	FR-PU04					
PU	FR-PU04			me functions, such as parameter copy, are		
PU		K to 3.7K, FR-D740-0.4K to 3.7K, FR-D720S	FR-PU04 (so unavailable.)			

Appendix2 **Specification change**

Appendix 2-1 SERIAL number check

Check the SERIAL number indicated on the inverter rating plate or package. (Refer to page 2)

Rating plate example

0 000000 Symbol Year Month Control number SERIAL (Serial No.)

The SERIAL consists of 1 version symbol, 2 numeric characters or 1 numeric character and 1 alphabet letter indicating year and month, and 6 numeric characters indicating control number.

Last digit of the production year is indicated as the Year, and the Month is indicated by 1 to 9, X (October), Y (November), and Z (December).

Appendix 2-2 Changed function

(1) Addition of output signal for the safety function

The change applies to the February 2009 production or later.

- 1) Output terminal function selection
 - ●Output of safety monitor output signal 2 (SAFE2) is enabled by setting "81 or 181" to any of Pr.190, Pr.192, Pr.197 (Output terminal function selection).
 - The function of terminal SO is set by *Pr.197 SO terminal function selection*.

Parameter Number	Name		Initial Value	Initial Signal	Setting Range	
190	RUN terminal function selection	Open collector output terminal	0	RUN (inverter run- ning)	0, 1, 3, 4, 7, 8, 11 to 16, 25, 26, 46, 47, 64, 70,	
192	A,B,C terminal function selection	Relay output terminal	99	ALM (fault output)	80, 81 , 90, 91, 93*1, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 125, 126, 146, 147, 164, 170, 180, 181 .	
197	197 SO terminal function selection		80	SAFE (safety monitor output)	190, 191, 193*1, 195, 196, 198, 199, 9999*2	

The above parameters can be set when *Pr. 160 Extended function display selection* = "0". (*Refer to page 163.*) *1 "93" and "193" cannot be set to *Pr. 192*.

Refer to the following table and set the parameters:

Set	ting			
Positive logic	Negative logic	Signal	Function	Operation
81	181	SAFE2	ISatety monitor output 2	Output while safety circuit fault (E.SAF) is not activated. (Refer to page 27)

2) Remote output selection

Terminal SO can be turned ON/OFF by setting Pr.496 Remote output data 1.

<Remote output data>

Pr.496 b11 b0 SO

^{*2 &}quot;9999" cannot be set to Pr.197.

^{*} Any

Appendix3 Index

15-speed selection (combination with three speeds RL, RM,	(SU, FU signal, Pr. 41 to Pr. 43)
	Display of the life of the inverter parts
RH)(REX signal)	(Pr. 255 to Pr. 259)230, 278
,	During PID control activated (PID signal)120, 213, 221
A	During retry (Y64 signal)
Acceleration time, deceleration time setting (Pr. 7, Pr. 8, Pr.	E
20, Pr. 21, Pr. 44, Pr. 45)	_
Acceleration/deceleration pattern (Pr. 29)	Earth (ground) fault detection at start (Pr. 249)
Actual operation time	Easy operation mode setting (easy setting mode)
Alarm output (LF signal)	Electronic thermal O/L relay pre-alarm (THP signal)101, 120 Electronic Thermal Relay Function Load Factor129
Analog input fault (E.AIE)	Electronic Thermal Relay Function Doad Factor
Analog input selection (Pr. 73, Pr. 267)	EMC measures40
Applied motor (Pr. 71, Pr. 450)	Exhibiting the best performance for the motor (offline auto
Automatic restart after instantaneous power failure/flying start	tuning) (Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90, Pr. 96)106
(Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	Extended parameter display (Pr. 160)
Avoid mechanical resonance points (frequency jumps) (Pr. 31	External thermal relay input (OH signal)101, 114
to Pr. 36)	External thermal relay operation (E.OHT)101, 265
(a) 11. (b)	External/NET operation switchover (turning ON X66 selects
В	NET operation) (X66 signal)114, 174
Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)	
Basic operation (factory setting)	F
Bias and gain of frequency setting voltage (current) (Pr. 125,	Fan alarm (FN)229, 261
Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	Fan fault output (FAN signal)120, 229
Bias and gain of the built-in frequency setting potentiometer	Fault or alarm indication
(C22 (Pr. 922) to C25 (Pr. 923))	Fault output (ALM signal)120, 123
Brake transistor alarm detection (E.BE)	Fault output 3 (power-OFF signal) (Y91 signal) 120, 123
Built-in potentiometer switching (Pr. 146)243	Faults history (E)
Buzzer control (Pr. 990)	Fin overheat (E.FIN)
,	Forward rotation command (assigned to STF terminal (Pr.
C	178) only) (STF signal)114, 118
Cables and wiring length	Free parameter (Pr. 888, Pr. 889)237
Changing the control logic	Frequency setting value
Changing the parameter setting value	Front cover5
Checking the inverter and converter modules	
Cleaning	G
Command source switchover (turning ON X67 makes Pr. 338	General-purpose magnetic flux vector control
and Pr. 339 commands valid) (X67 signal) 114, 177	(Pr. 71, Pr. 80)76
Communication EEPROM write selection (Pr. 342) 188	
Condition selection of function validity by second function	Н
selection signal (RT signal)117	Harmonic suppression guideline in Japan43
Connection of a DC reactor (FR-HEL)35	Heatsink overheat pre-alarm (FIN signal)120, 263
Connection of a dedicated external brake resistor (MRS type,	High speed operation command (RH signal)90, 114
MYS type, FR-ABR)	
Connection of the brake unit (FR-BU2)	I
Connection of the high power factor converter (FR-HC) 34	Initial settings and specifications of RS-485 communication
Connection of the power regeneration common converter	(Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)
(FR-CV)	Input phase loss (E.ILF)
Connection to the PU connector	Input terminal function selection (Pr. 178 to Pr. 182)114
Converter Output Voltage	Input Terminal Status
Converter Output Voltage	Input/output phase loss protection selection
Cooling fan operation selection (Pr. 244)	(Pr. 251, Pr. 872)
Cooling system types for inverter panel	Inrush current limit circuit fault (E.IOH)
CPU fault (E.5, E.CPU)	Insulation resistance test using megger
Cumulative energization time	Inverter I/O Terminal Monitor
	Inverter installation environment
	Inverter operation ready (RY signal)120, 122 Inverter output shutoff signal (MRS signal, Pr. 17)116
Cumulative power	
Current average value monitor signal (Pr. 555 to Pr. 557) 235	
Cumulative power	Inverter overload trip (electronic thermal relay function)
Current average value monitor signal (Pr. 555 to Pr. 557) 235	Inverter overload trip (electronic thermal relay function) (E.THT)
Current average value monitor signal (Y93 signal) 120, 235 Current average value monitor signal (Y93 signal) 120, 235	Inverter overload trip (electronic thermal relay function) (E.THT)
Cumulative power	Inverter overload trip (electronic thermal relay function) (E.THT)
Cumulative power	Inverter overload trip (electronic thermal relay function) (E.THT)
Cumulative power	Inverter overload trip (electronic thermal relay function) (E.THT)

Inverter thermal load factor	Output Terminal Status
1	Output voltage
J	Overcurrent trip during acceleration (E.OC1)
Jog operation (Pr. 15, Pr. 16)	Overcurrent trip during constant speed (E.OC2)
JOG operation selection (JOG signal)92, 114	Overload alarm (OL signal)80, 120
L	5 7 5 11 5 4 4 4 4 4 1 1 1 1 1 1 1 1 1 1 1
	Р
Leakage currents and countermeasures	Parameter list
Life alarm (Y90 signal)	Parameter storage device fault
Low-speed operation command (RL signal)90, 114	(control circuit board) (E.PE)
Low-speed operation command (IXL signal)90, 114	Parameter write disable selection (Pr. 77)
M	Parameter write error (Er1 to Er4)258
Magnitude of frequency change setting (Pr. 295)241	Password function
Maintenance signal output (MT)234, 260	Password locked (LOCd)258
Maintenance timer alarm (Pr. 503, Pr. 504)	Periodic inspection
Maintenance timer signal (Y95 signal)120, 234	Peripheral devices
Manual torque boost (Pr. 0, Pr. 46)	PID control (Pr. 127 to Pr. 134, Pr. 575, Pr. 577)
Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)84	PID control valid terminal (X14 signal)
Measurement of converter output voltage287	PID Deviation
Measurement of currents	(RL signal)
Measurement of inverter input power factor287	PID lower limit (FDN signal)
Measurement of inverter output frequency287	PID Measured Value
Measurement of powers	PID Set Point
Measurement of voltages and use of PT286	PID upper limit (FUP signal)
Middle-speed operation command (RM signal)90, 114	Power failure deceleration signal (Y46 signal) 120, 143
Mitsubishi inverter protocol	Power supply harmonics42
(computer link communication)	Power-failure deceleration stop function (Pr. 261)
Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	Pressure test
Monitor display selection of DU/PU and terminal FM (Pr. 52,	PTC thermistor operation (E.PTC)
Pr. 54, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564)	PTC thermistor resistance
Motor Load Factor	PU contrast adjustment (Pr. 991)
Motor overheat protection (Electronic thermal O/L relay, PTC	PU disconnection (E.PUE)
thermistor protection) (Pr. 9, Pr. 51, Pr. 561)101	PU display language selection (Pr. 145)
Motor overload trip (electronic thermal relay function)	PU stop (PS)
(E.THM)	PU/NET operation switchover (turning ON X65 selects PU
Motor thermal load factor	operation) (X65 signal)
Motor Torque129	PU-External operation switchover (turning ON X16 selects
A1	External operation) (X16)114, 173
N	PWM carrier frequency and Soft-PWM control (Pr. 72, Pr.
Names and functions of the operation panel54	240)
0	ъ
	R
Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)90	Reference of the terminal FM (pulse train output)
Operation mode at power-ON (Pr. 79, Pr. 340)	(Pr. 55, Pr. 56)
Operation mode selection (Pr. 79)	Reference voltage output
Operation panel frequency setting/key lock operation	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)
selection (Pr. 161)	Regenerative brake duty
Operation panel lock (HOLD)239, 258	Regenerative brake prealarm (RB)
Operation selection at communication error occurrence (Pr.	Regenerative brake prealarm (RBP signal)
121, Pr. 122, Pr. 502)	Regenerative overvoltage trip during acceleration
Optimum excitation control (Pr. 60)148	(E.OV1)
Output current	Regenerative overvoltage trip during constant speed
Output current detection (Y12 signal)120, 125	(E.OV2)227, 262
Output current detection function (Y12 signal, Y13 signal, Pr.	Regenerative overvoltage trip during deceleration or stop
150 to Pr. 153)	(E.OV3)
Output current detection value exceeded (E.CDO)266	Remote output (REM signal)120, 127
Output Current Peak Value	Remote output selection
Output frequency	(REM signal, Pr. 495, Pr. 496)
Output phase loss (E.LF)	Remote setting (RH, RM, RL signal)
Output priase ioss (E.E.)	Remote setting function (Pr. 59)
Output side earth (ground) fault overcurrent at start	Replacement of parts
(E.GF)	Reset selection/disconnected PU detection/PU stop selection (Pr. 75)
Output stop (MRS signal)114, 116	Response level of analog input and noise elimination
Output terminal function selection	(Pr. 74)
(Pr. 190, Pr. 192, Pr. 197)	(· · · · ·)

Retry count excess (E.RET)		
Retry function (Pr. 65, Pr. 67 to Pr. 69)		
Reverse rotation command (assigned to STR termin		
179) only) (STR signal)		
Reverse rotation prevention selection (Pr. 78)		
RUN key rotation direction selection (Pr. 40)		238
5		
Safety circuit fault (E.SAF)		
Safety monitor output (SAFE signal)		
Safety monitor output 2 (SAFE2 signal)		
Safety stop (SA)		
Safety stop function		
Second function selection (RT signal)	. 114,	11/
Selection of a regenerative brake (Pr. 30, Pr. 70)	•••••	111
Setting dial pushSlip compensation (Pr. 245 to Pr. 247)		. 37
Specification of main circuit terminal		
Speed display and speed setting (Pr. 37)		
Speed smoothing control (Pr. 653)		
Stall prevention (E.OLT)		
Stall prevention (e.o.c.r)		
Stall prevention (overcoltage) (oL)		
Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr.		
156, Pr. 157)		
Start command source and frequency command sou		. 00
during communication operation	JI 00	
(Pr. 338, Pr. 339, Pr. 551)		177
Start self-holding selection (STOP signal)		
Start signal operation selection (STF, STR, STOP si		
250)		
Starting frequency and start-time hold function (Pr. 1		
571)		
Stop selection (Pr. 250)		
Γ		
Terminal 4 input selection (AU signal)	. 114,	151
Terminal arrangement of the main circuit terminal, p		
supply and the motor wiring		. 15
Terminal connection diagram		. 14
Terminal FM calibration		
(calibration parameter C0 (Pr. 900))		135
J		
Undervoltage (UV)		260
Up-to-frequency signal (SU signal)		
Use of CT and transducer		
1		
V/F switchover (V/F control is exercised when X18 is	s ON)	
(X18 signal)		
N		
Wiring and configuration of PU connector		181
Wiring cover		
Wiring of control circuit		
<u>Z</u>		
7	100	

unction selection)

1 For Maximum Safety

- Mitsubishi inverters are not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi sales representative.
- Although this product was manufactured under conditions of strict quality control, you are strongly advised to
 install safety devices to prevent serious accidents when it is used in facilities where breakdowns of the product
 are likely to cause a serious accident.
- Please do not use this product for loads other than three-phase induction motors.