



FR-D740-012 to 160 - EC FR-D720S-008 to 100 - EC

OUTLINE 1

WIRING 2

PRECAUTIONS FOR USE
OF THE INVERTER

3

PARAMETERS

4

TROUBLESHOOTING

5

PRECAUTIONS FOR MAINTENANCE AND INSPECTION

6

SPECIFICATIONS

7

Thank you for choosing this Mitsubishi Inverter.

This Instruction Manual provides instructions for advanced use of the FR-D700 series inverters.

Incorrect handling might cause an unexpected fault. Before using the inverter, always read this instruction manual and the Installation Guideline [IB-0600352ENG] packed with the product carefully to use the equipment to its optimum performance.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect the inverter until you have read through the Instruction Manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION".

≜WARNING

Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

ACAUTION

Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the ACAUTION level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety.

1. Electric Shock Prevention

MWARNING

- While power is on or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.
- Do not run the inverter with the front cover or wiring cover removed. Otherwise, you may access the exposed highvoltage terminals or the charging part of the circuitry and get an electric shock.
- Even if power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, switch off power, check to make sure that the operation panel indicator is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- This inverter must be earthed (grounded). Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical code. (NEC section 250, IEC 536 class 1 and other applicable standards)

Use an neutral-point earthed (grounded) power supply for 400V class inverter in compliance with EN standard.

- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the inverter before wiring. Otherwise, you may get an electric shock or be injured.
- Perform setting dial and key operations with dry hands to prevent an electric shock. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise, you may get an electric shock.
- Do not change the cooling fan while power is on. It is dangerous to change the cooling fan while power is on.
- Do not touch the printed circuit board with wet hands.
 Otherwise, you may get an electric shock.
- When measuring the main circuit capacitor capacity, the DC voltage is applied to the motor for 1s at powering off.
 Never touch the motor terminal, etc. right after powering off to prevent an electric shock.

2. Fire Prevention

ACAUTION

- Install the inverter on a nonflammable wall without holes (so that nobody can touch the inverter heatsink on the rear side, etc.). Mounting it to or near combustible material can cause a fire.
- If the inverter has become faulty, switch off the inverter power. A continuous flow of large current could cause a fire.
- When using a brake resistor, make up a sequence that will turn off power when an alarm signal is output. Otherwise, the brake resistor may excessively overheat due to damage of the brake transistor and such, causing a fire.
- Do not connect a resistor directly to the DC terminals + and -. This could cause a fire.

ACAUTION

- Apply only the voltage specified in the instruction manual to each terminal. Otherwise, burst, damage, etc. may occur
- Ensure that the cables are connected to the correct terminals. Otherwise, burst, damage, etc. may occur.
- Always make sure that polarity is correct to prevent damage, etc. Otherwise, burst, damage, etc. may occur.
- While power is on or for some time after power-off, do not touch the inverter as they will be extremely hot. Doing so can cause burns

4. Additional Instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.

(1) Transportation and mounting

ACAUTION

- Transport the product using the correct method that corresponds to the weight. Failure to observe this could lead to injuries.
- Do not stack the inverter boxes higher than the number recommended.
- Ensure that installation position and material can withstand the weight of the inverter. Install according to the information in the instruction manual.
- Do not install or operate the inverter if it is damaged or has parts missing.
- When carrying the inverter, do not hold it by the front cover or setting dial; it may fall off or fail.
- Do not stand or rest heavy objects on the product.
- Check the inverter mounting orientation is correct.
- Prevent other conductive bodies such as screws and metal fragments or other flammable substance such as oil from entering the inverter.
- As the inverter is a precision instrument, do not drop or subject it to impact.
- Use the inverter under the following environmental conditions: Otherwise, the inverter may be damaged.

•	conditions. Other wise, the inverter may be dumaged.					
	Surrounding air temperature	-10°C to +50°C (non-freezing)				
'n	Ambient humidity	90%RH maximum (non-condensing)				
nvironment	Storage temperature	-20°C to +65°C *1				
Envir	Atmosphere	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)				
	Altitude/ vibration	Maximum 1000m above sea level for standard operation. After that derate by 3% for every extra 500m up to 2500m (91%). 5.9m/s ² or less				

*1 Temperature applicable for a short time, e.g. in transit.

(2) Wiring

ACAUTION

- Do not install a power factor correction capacitor or surge suppressor/capacitor type filter on the inverter output side. These devices on the inverter output side may be overheated or burn out.
- The connection orientation of the output cables U, V, W to the motor will affect the direction of rotation of the motor.

(3) Trial run

ACAUTION

 Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.

(4) Usage

AWARNING

- When you have chosen the retry function, stay away from the equipment as it will restart suddenly after trip.
- Since pressing (STOP) key may not stop output depending on the function setting status (Refer to page 153), provide a circuit and switch separately to make an emergency stop (power off, mechanical brake operation for emergency stop, etc).
- Make sure that the start signal is off before resetting the inverter alarm. A failure to do so may restart the motor suddenly.
- The load used should be a three-phase induction motor only.
 Connection of any other electrical equipment to the inverter output may damage the equipment.
- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the product.

↑CAUTION

- The electronic thermal relay function does not guarantee protection of the motor from overheating. It is recommended to install both an external thermal and PTC thermistor for overheat protection.
- Do not use a magnetic contactor on the inverter input for frequent starting/stopping of the inverter. Otherwise, the life of the inverter decreases.
- Use a noise filter to reduce the effect of electromagnetic interference. Otherwise nearby electronic equipment may be affected.
- Take measures to suppress harmonics. Otherwise power supply harmonics from the inverter may heat/damage the power factor correction capacitor and generator.
- When a 400V class motor is inverter-driven, please use an insulation-enhanced motor or measures taken to suppress surge voltages. Surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.
- When parameter clear or all parameter clear is performed, reset the required parameters before starting operations.
 Each parameter returns to the initial value.
- The inverter can be easily set for high-speed operation.
 Before changing its setting, fully examine the performances of the motor and machine.
- In addition to the inverter's holding function, install a holding device to ensure safety.
- Before running an inverter which had been stored for a long period, always perform inspection and test operation.
- For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

(5) Emergency stop

ACAUTION

- Provide a safety backup such as an emergency brake which will prevent the machine and equipment from hazardous conditions if the inverter fails.
- When the breaker on the inverter input side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.
- When any protective function is activated, take the appropriate corrective action, then reset the inverter, and resume operation.

(6) Maintenance, inspection and parts replacement

MCAUTION

 Do not carry out a megger (insulation resistance) test on the control circuit of the inverter. It will cause a failure.

(7) Disposal

ACAUTION

• Treat as industrial waste.

General instruction

Many of the diagrams and drawings in this Instruction Manual show the inverter without a cover, or partially open. Never operate the inverter in this manner. Always replace the cover and follow this Instruction Manual when operating the inverter.

1	OUTLINE	1
	1.1 Product checking and parts identification	

1.	 .2	nverter and peripheral devices	3
	1.2.1		
1.	.3	Removal and reinstallation of the cover	5
	1.3.1	Front cover	5
	1.3.2		
1.	.4	nstallation of the inverter and enclosure design	7
	1.4.1	Inverter installation environment	7
	1.4.2		
	1.4.3		
2	WII	RING	13
	4		
2.	.1	Wiring	
	2.1.1	Terminal connection diagram	14
2.	.2	Main circuit terminal specifications	15
	2.2.1	Specification of main circuit terminal	15
	2.2.2	Terminal arrangement of the main circuit terminal, power supply and the motor wiring	15
	2.2.3	Cables and wiring length	16
2.	.3	Control circuit specifications	19
	2.3.1	Control circuit terminal	19
	2.3.2	Changing the control logic	21
	2.3.3	Wiring of control circuit	23
	2.3.4	Wiring instructions	25
	2.3.5	Connection to the PU connector	26
2.	.4	Connection of stand-alone option unit	28
	2.4.1	Connection of a dedicated external brake resistor (MRS type, FR-ABR) (FR-D740-012 or more, FR-D720S-025 or more)	28
	2.4.2	Connection of the brake unit (FR-BU2)	30
	2.4.3	Connection of the high power factor converter (FR-HC)	31
	2.4.4	Connection of the power regeneration common converter (FR-CV)	32
	2.4.5	Connection of a DC reactor (FR-HEL)	32
3	PRE	CAUTIONS FOR USE OF THE INVERTER	33
3.	.1	EMC and leakage currents	34

3.1.1	Leakage currents and countermeasures	
3.1.2		
3.1.3	Power supply harmonics	38
3.2 I	nstallation of power factor improving reactor	. 39
3.3 I	Power-off and magnetic contactor (MC)	. 40
3.4 I	nverter-driven 400V class motor	. 41
3.5 I	Precautions for use of the inverter	. 42
	Failsafe of the system which uses the inverter	
0.0		
4 PAR	RAMETERS	47
4.1	Operation panel	. 48
4.1.1	Names and functions of the operation panel	48
4.1.2	Basic operation (factory setting)	49
4.1.3	Easy operation mode setting (easy setting mode)	50
4.1.4	Change the parameter setting value	51
4.1.5	Setting dial push	51
4.2 I	Parameter list	. 52
4.2.1	Parameter list	52
4.3	Adjust the output torque (current) of the motor	69
4.3.1	Manual torque boost (Pr. 0, Pr. 46)	69
4.3.2	General-purpose magnetic flux vector control (Pr. 71, Pr. 80)	70
4.3.3	Slip compensation (Pr. 245 to Pr. 247)	73
4.3.4	Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157)	74
4.4 I	Limit the output frequency	78
4.4.1	Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	78
4.4.2		
4.5	Set V/F pattern	80
4.5.1	Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)	80
4.5.2		
4.6 I	Frequency setting by external terminals	84
4.6.1	Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)	84
4.6.2		
4.6.3	Remote setting function (Pr. 59)	
4.7	Setting of acceleration/deceleration time and acceleration/	
	deceleration pattern	91

4.7.1	Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 44, Pr. 45)	91
4.7.2	Starting frequency and start-time hold function (Pr. 13, Pr. 571)	93
4.7.3	Acceleration/deceleration pattern (Pr. 29)	94
4.8 S	election and protection of a motor	95
4.8.1	Motor overheat protection (Electronic thermal O/L relay, PTC thermistor protection) (Pr. 561)	
4.8.2	Applied motor (Pr. 71, Pr. 450)	98
4.8.3	To exhibit the best performance of the motor performance (offline auto tuning) (Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90, Pr. 96)	100
4.9 M	otor brake and stop operation	104
4.9.1	DC injection brake (Pr. 10 to Pr. 12)	104
4.9.2	Selection of a regenerative brake (Pr. 30, Pr. 70)	105
4.9.3	Stop selection (Pr. 250)	107
4.10 F	unction assignment of external terminal and control	108
4.10.1	Input terminal function selection (Pr. 178 to Pr. 182)	108
4.10.2	Inverter output shutoff signal (MRS signal, Pr. 17)	
4.10.3	Condition selection of function validity by second function selection signal (RT)	111
4.10.4	Start signal operation selection (STF, STR, STOP signal, Pr. 250)	112
4.10.5	Output terminal function selection (Pr. 190, Pr. 192)	114
4.10.6	Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)	118
4.10.7	Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153, Pr. 166, Pr. 167)	119
4.10.8	Remote output selection (REM signal, Pr. 495, Pr. 496)	121
4.11 M	onitor display and monitor output signal	122
4.11.1	Speed display and speed setting (Pr. 37)	122
	Monitor display selection of operation panel/PU and terminal AM	
	(Pr. 52, Pr. 158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891)	123
	Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)	
4.11.4	Terminal AM calibration (calibration parameter C1 (Pr.901))	129
	peration selection at power failure and instantaneous pow	
Ta	ilure	131
4.12.1	Automatic restart after instantaneous power failure/flying start (Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	131
4.12.2	Power-failure deceleration stop function (Pr. 261)	137
4.13 0	peration setting at fault occurrence	139
4.13.1	Retry function (Pr. 65, Pr. 67 to Pr. 69)	139
4.13.2	Input/output phase loss protection selection (Pr. 251, Pr. 872)	
4.13.3	Earth (ground) fault detection at start (Pr. 249)	
4.14 E	nergy saving operation	142

4.14.1	Optimum excitation control (Pr. 60)	142
4.15 M	otor noise, EMI measures, mechanical resonance	143
4.15.1	PWM carrier frequency and soft-PWM control (Pr. 72, Pr. 240, Pr. 260)	143
4.15.2	Speed smoothing control (Pr. 653)	144
4.16 F	requency setting by analog input (terminal 2, 4)	145
4.16.1	Analog input selection (Pr. 73, Pr. 267)	145
4.16.2	Response level of analog input and noise elimination (Pr. 74)	147
4.16.3	Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	148
4.17 M	isoperation prevention and parameter setting restriction	153
4.17.1	Reset selection/disconnected PU detection/PU stop selection (Pr. 75)	153
4.17.2	Parameter write disable selection (Pr. 77)	156
4.17.3	Reverse rotation prevention selection (Pr. 78)	157
4.17.4	Extended parameter display (Pr. 160)	157
4.17.5	Password function (Pr. 296, Pr. 297)	158
4.18 S	election of operation mode and operation location	160
4.18.1	Operation mode selection (Pr. 79)	160
4.18.2	Operation mode at power-on (Pr. 79, Pr. 340)	170
4.18.3	Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 551)	171
4.19 C	ommunication operation and setting	175
4.19.1	Wiring and configuration of PU connector	175
4.19.2	Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)	178
4.19.3	Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)	179
4.19.4	Communication EEPROM write selection (Pr. 342)	182
4.19.5	Mitsubishi inverter protocol (computer link communication)	183
4.19.6	Modbus RTU communication specifications (Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	195
4.20 S	pecial operation and frequency control	207
4.20.1	PID control (Pr. 127 to Pr. 134, Pr. 575 to Pr. 577)	207
4.20.2	Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)	215
4.20.3	Traverse function (Pr. 592 to Pr. 597)	221
4.20.4	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)	223
4.21 U	seful functions	225
4.21.1	Cooling fan operation selection (Pr. 244)	225
4.21.2	Display of the life of the inverter parts (Pr. 255 to Pr. 259)	226
4.21.3	Maintenance timer alarm (Pr. 503, Pr. 504)	230
4.21.4	Current average value monitor signal (Pr. 555 to Pr. 557)	231

	4.21.5	Free parameter (Pr. 888, Pr. 889)	233
	4.22 S	etting from the parameter unit and operation panel	234
	4.22.1	RUN key rotation direction selection (Pr. 40)	234
	4.22.2	PU display language selection(Pr.145)	234
	4.22.3	Operation panel frequency setting/key lock operation selection (Pr. 161)	235
	4.22.4	Magnitude of frequency change setting (Pr. 295)	237
	4.22.5	Buzzer control (Pr. 990)	238
	4.22.6	PU contrast adjustment (Pr. 991)	238
	4.23 P	arameter clear/ All parameter clear	239
	4.24 Ir	nitial value change list	240
	4.25 C	heck and clear of the faults history	241
5	TRO	UBLESHOOTING	243
	5.1 R	eset method of protective function	244
		· ist of fault or alarm indications	
		auses and corrective actions	
		orrespondences between digital and actual characters	
		heck first when you have some troubles	
	5.5.1	Motor will not start	
	5.5.1	Motor generates abnormal noise	
	5.5.3	Motor generates heat abnormally	
	5.5.4	Motor rotates in opposite direction.	
	5.5.5	Speed greatly differs from the setting	
	5.5.6	Acceleration/deceleration is not smooth	
	5.5.7	Motor current is large	
	5.5.8	Speed does not increase	256
	5.5.9	Speed varies during operation	257
	5.5.10	Operation mode is not changed properly	257
	5.5.11	Operation panel display is not operating	257
	5.5.12	Parameter write cannot be performed	257
6	PF	RECAUTIONS FOR MAINTENANCE AND INSPECTION	259
	6.1 Ir	spection items	260
	6.1.1	Daily inspection	260
	6.1.2	Periodic inspection	260
	6.1.3	Daily and periodic inspection	261

Annen	dix1 Index	280
APPEN	IDIX	279
7.3	Outline dimension drawings	276
7.2	common specifications	275
7.1.1	Inverter rating	
	Rating	
7 SPE	CIFICATIONS	273
6.2.8	Pressure test	
6.2.7	Insulation resistance test using megger	
6.2.6	Measurement of converter output voltage (across terminals + and -)	
6.2.5	Measurement of inverter input power factor	270
6.2.4	Use of CT and transducer	270
6.2.3	Measurement of currents	270
6.2.2	Measurement of voltages and use of PT	269
6.2.1	Measurement of powers	269
6.2 N	Measurement of main circuit voltages, currents and powers	267
6.1.7	Replacement of parts	
6.1.6	Cleaning	
6.1.5	Checking the inverter and converter modules	262
6.1.4	Display of the life of the inverter parts	262

MEMO

1 / OUTLINE

This chapter explains the "OUTLINE" for use of this product. Always read the instructions before using the equipment

1.1	Product checking and parts identification	. 2
	Inverter and peripheral devices	
	Removal and reinstallation of the cover	
1.4	Installation of the inverter and enclosure design	. 7


<abbreviations></abbreviations>	
PU	Operation panel and parameter unit (FR-PU04/FR-PU07)
Inverter	Mitsubishi inverter FR-D700 series
FR-D700	Mitsubishi inverter FR-D700 series
Pr	Parameter number
PU operation	Operation using the PU (operation panel/FR-PU04/FR-PU07)
External operation	Operation using the control circuit signals
Combined operation	Operation using both the PU (operation panel/FR-PU04/FR-
	PU07) and external operation
Operation panel for E500, PA02	FR-E500 series operation panel (FR-PA02-02)
Mitsubishi standard motor	SF-JR
Mitsubishi constant-torque motor	SF-HRCA

<Trademarks>

- Microsoft and Visual C++ are registered trademarks of Microsoft Corporation in the United States and/or other countries.
- Company and product names herein are the trademarks and registered trademarks of their respective owners.

<Mark>

• REMARKS : Additional helpful contents and relations with other functions are stated



POINT :Useful contents and points are stated.

Parameters referred to: related parameters are stated.

2

3

4

5


6

7

1.1 Product checking and parts identification

Unpack the inverter and check the capacity plate on the front cover and the rating plate on the inverter side face to ensure that the product agrees with your order and the inverter is intact.

Inverter type



Accessory


· Fan cover fixing screws (M3 × 35mm)

These screws are necessary for compliance with the European Directive (Refer to Installation Guideline)

Туре	Number
FR-D740-036 to 080	1
FR-D740-120, 160	2
FR-D720S-070, 100	1



1.2 Inverter and peripheral devices





- Do not install a power factor correction capacitor, surge suppressor or capacitor type filter on the inverter output side. This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them.
- Electromagnetic wave interference
 The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, install the FR-BIF optional capacitor type filter (for use in the input side only) or FR-BSF01 or FR-BLF common mode filter to minimize interference. (Refer to page 36).
- · Refer to the instruction manual of each option and peripheral devices for details of peripheral devices.


1.2.1 Peripheral devices

Check the inverter type of the inverter you purchased. Appropriate peripheral devices must be selected according to the capacity.

Refer to the following list and prepare appropriate peripheral devices:

	Invertor Type	Motor	Moulded Case Circuit Breaker (MCCB) *1 or Earth Leakage Circuit Breaker (ELB) *2		Magnetic Contactor (MC) *3	
	Inverter Type	Output	Reactor connection		Reactor connection	
		(kW)	without	with	without	with
	FR-D740-012	0.4	30AF 5A	30AF 5A	S-N10	S-N10
400V	FR-D740-022	0.75	30AF 5A	30AF 5A	S-N10	S-N10
	FR-D740-036	1.5	30AF 10A	30AF 10A	S-N10	S-N10
Three-Phase	FR-D740-050	2.2	30AF 15A	30AF 10A	S-N10	S-N10
e-P	FR-D740-080	3.7	30AF 20A	30AF 15A	S-N10	S-N10
Thre	FR-D740-120	5.5	30AF 30A	30AF 20A	S-N20	S-N11, S-N12
ľ	FR-D740-160	7.5	30AF 30A	30AF 30A	S-N20	S-N20
>	FR-D720S-008	0.1	30AF 5A	30AF 5A	S-N10	S-N10
200V	FR-D720S-014	0.2	30AF 5A	30AF 5A	S-N10	S-N10
ase	FR-D720S-025	0.4	30AF 10A	30AF 5A	S-N10	S-N10
Ή	FR-D720S-042	0.75	30AF 15A	30AF 10A	S-N10	S-N10
Single-	FR-D720S-070	1.5	30AF 30A	30AF 15A	S-N10	S-N10
Sir	FR-D720S-100	2.2	30AF 40A	30AF 30A	S-N20, S-N21	S-N10

^{*1 •}Select an MCCB according to the power supply capacity.



^{*2} For installations in the United States or Canada, use the class T type fuse certified by the UL and cUL.

When using the MC for emergency stop during motor driving or using on the motor side during commercial-power supply operation, select the MC with class AC-3 rated current for the motor rated current.



- When the inverter capacity is larger than the motor capacity, select an MCCB and a magnetic contactor according to the inverter type
 and cable and reactor according to the motor output.
- When the breaker on the inverter primary side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.

[•]Install one MCCB per inverter.

^{*3} Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stop during motor driving, the electrical durability is 25 times.



1.3 Removal and reinstallation of the cover


1.3.1 Front cover


FR-D740-080 or less

FR-D720S-008 to 100

●Removal (Example of FR-D740-036)


- 1) Loosen the installation screws of the front cover. (The screws cannot be removed.)
- 2) Remove the front cover by pulling it like the direction of arrow.






●Reinstallation (Example of FR-D740-036)

- 1) Place the front cover in front of the inverter, and install it straight.
- 2) Tighten the installation screws on the front cover.








FR-D740-120, 160

●Removal (Example of FR-D740-160)

- 1) Loosen the installation screws of the front cover. (The screws cannot be removed.)
- 2) Remove the front cover by pulling it like the direction of arrow with holding an installation hook on the front cover.









NOTE

- Fully make sure that the front cover has been reinstalled securely.
- The same serial number is printed on the capacity plate of the front cover and the rating plate of the inverter. Since these plates have the same serial numbers, always reinstall the removed cover onto the original inverter.

1.3.2 Wiring cover

Removal and reinstallation

FR-D740-012 to 080	FR-D740-120, 160
FR-D720S-008 to 100	118-57-40-120, 100
The cover can be removed easily by pulling it downward. To reinstall, fit the cover to the inverter along the guides.	The cover can be removed easily by pulling it toward you. To reinstall, fit the cover to the inverter along the guides.
Guide Wiring cover	Guide Wiring cover
Example of FR-D740-036	Example of FR-D740-160



1.4 Installation of the inverter and enclosure design

When an inverter panel is to be designed and manufactured, heat generated by contained equipment, etc., the environment of an operating place, and others must be fully considered to determine the panel structure, size and equipment layout. The inverter unit uses many semiconductor devices. To ensure higher reliability and long period of operation, operate the inverter in the ambient environment that completely satisfies the equipment specifications.

1.4.1 Inverter installation environment

As the inverter installation environment should satisfy the standard specifications indicated in the following table, operation in any place that does not meet these conditions not only deteriorates the performance and life of the inverter, but also causes a failure. Refer to the following points and take adequate measures.

Environmental standard specifications of inverter

Item	Description
Surrounding air	-10 to +50°C (non-freezing)
temperature	-10 to +30 C (non-neezing)
Ambient humidity	90%RH maximum (non-condensing)
Atmosphere	Free from corrosive and explosive gases, free from dust and dirt
Maximum altitude	1,000m or less
Vibration	5.9m/s ² or less

(1) Temperature

The permissible surrounding air temperature of the inverter is between -10 and \pm 50°C. Always operate the inverter within this temperature range. Operation outside this range will considerably shorten the service lives of the semiconductors, parts, capacitors and others. Take the following measures so that the surrounding air temperature of the inverter falls within the specified range.

- 1) Measures against high temperature
 - Use a forced ventilation system or similar cooling system. (Refer to page 9)
 - Install the panel in an air-conditioned electrical chamber.
 - · Block direct sunlight.
 - Provide a shield or similar plate to avoid direct exposure to the radiated heat and wind of a heat source.
 - · Ventilate the area around the panel well.
- 2) Measures against low temperature
 - · Provide a space heater in the enclosure.
 - Do not power off the inverter. (Keep the start signal of the inverter off.)
- 3) Sudden temperature changes
 - Select an installation place where temperature does not change suddenly.
 - · Avoid installing the inverter near the air outlet of an air conditioner.
 - If temperature changes are caused by opening/closing of a door, install the inverter away from the door.

(2) Humidity

Normally operate the inverter within the 45 to 90% range of the ambient humidity. Too high humidity will pose problems of reduced insulation and metal corrosion. On the other hand, too low humidity may produce a spatial electrical breakdown. The insulation distance specified in JEM1103 "Control Equipment Insulator" is defined as humidity 45 to 85%.

- 1) Measures against high humidity
 - Make the panel enclosed, and provide it with a hygroscopic agent.
 - Take dry air into the enclosure from outside.
 - Provide a space heater in the enclosure.
- 2) Measures against low humidity

What is important in fitting or inspection of the unit in this status is to discharge your body (static electricity) beforehand and keep your body from contact with the parts and patterns, besides blowing air of proper humidity into the panel from outside.

3) Measures against condensation

Condensation may occur if frequent operation stops change the in-panel temperature suddenly or if the outside-air temperature changes suddenly.

Condensation causes such faults as reduced insulation and corrosion.

- · Take the measures against high humidity in 1).
- Do not power off the inverter. (Keep the start signal of the inverter off.)

Installation of the inverter and enclosure design

(3) Dust, dirt, oil mist

Dust and dirt will cause such faults as poor contact of contact points, reduced insulation or reduced cooling effect due to moisture absorption of accumulated dust and dirt, and in-panel temperature rise due to clogged filter. In the atmosphere where conductive powder floats, dust and dirt will cause such faults as malfunction, deteriorated insulation and short circuit in a short time.

Since oil mist will cause similar conditions, it is necessary to take adequate measures.

Countermeasures

- Place in a totally enclosed enclosure.

 Take measures if the in-enclosure temperature rises. (Refer to page 9)
- Purge air.

Pump clean air from outside to make the in-panel pressure higher than the outside-air pressure.

(4) Corrosive gas, salt damage

If the inverter is exposed to corrosive gas or to salt near a beach, the printed board patterns and parts will corrode or the relays and switches will result in poor contact.

In such places, take the measures given in Section 3.

(5) Explosive, flammable gases

As the inverter is non-explosion proof, it must be contained in an explosion proof enclosure. In places where explosion may be caused by explosive gas, dust or dirt, an enclosure cannot be used unless it structurally complies with the guidelines and has passed the specified tests. This makes the enclosure itself expensive (including the test charges). The best way is to avoid installation in such places and install the inverter in a non-hazardous place.

(6) Highland

Use the inverter at the altitude of within 1000m. If it is used at a higher place, it is likely that thin air will reduce the cooling effect and low air pressure will deteriorate dielectric strength.

Maximum 1000m above sea level for standard operation. After that derate by 3% for every extra 500m up to 2500m (91%).

(7) Vibration, impact

The vibration resistance of the inverter is up to 5.9m/s² at 10 to 55Hz frequency and 1mm amplitude. Vibration or impact, if less than the specified value, applied for a long time may make the mechanism loose or cause poor contact to the connectors. Especially when impact is imposed repeatedly, caution must be taken as the part pins are likely to break.

Countermeasures

- · Provide the panel with rubber vibration isolators.
- Strengthen the structure to prevent the panel from resonance.
- · Install the panel away from sources of vibration.



1.4.2 Cooling system types for inverter panel

From the panel that contains the inverter, the heat of the inverter and other equipment (transformers, lamps, resistors, etc.) and the incoming heat such as direct sunlight must be dissipated to keep the in-panel temperature lower than the permissible temperatures of the in-panel equipment including the inverter.

The cooling systems are classified as follows in terms of the cooling calculation method.


- 1) Cooling by natural heat dissipation from the enclosure surface (totally enclosed type)
- 2) Cooling by heat sink (aluminum fin, etc.)
- 3) Cooling by ventilation (forced ventilation type, pipe ventilation type)
- 4) Cooling by heat exchanger or cooler (heat pipe, cooler, etc.)

Cooling System		Panel Structure	Comment	
Natural cooling	Natural ventilation (enclosed, open type)	INV	Low in cost and generally used, but the panel size increases as the inverter capacity increases. For relatively small capacities.	
	Natural ventilation (totally enclosed type)		Being a totally enclosed type, the most appropriate for hostile environment having dust, dirt, oil mist, etc. The panel size increases depending on the inverter capacity.	
	Fin cooling	Heatsink NV	Having restrictions on the heatsink mounting position and area, and designed for relative small capacities.	
Forced cooling	Forced ventilation		For general indoor installation. Appropriate for panel downsizing and cost reduction, and often used.	
	Heat pipe	Heat pipe	Totally enclosed type for panel downsizing.	


1.4.3 Inverter placement

(1) Installation of the inverter Enclosure surface mounting

• FR-D740-012 or more




• FR-D720S-008 to 042





NOTE


- When encasing multiple brake units, install them in parallel as a cooling measure.
- Install the inverter vertically.




(2) Clearances around inverter

To ensure ease of heat dissipation and maintenance, leave at least the shown clearances around the inverter. At least the following clearances are required under the inverter as a wiring space, and above the inverter as a heat dissipation space.

Surrounding air temperature and humidity



Leave enough clearances and take cooling measures.



air temperature of 40°C or less, the inverters can be installed without any clearance between them (0cm clearance).

When surrounding air temperature exceeds 40°C, clearances between the inverters should be 1cm or more (5cm or more for the

FR-D740-120 or more).

Clearances (side)

* 5cm or more for the FR-D740-120 or more

(3) Inverter mounting orientation

Mount the inverter on a wall as specified. Do not mount it horizontally or any other way.

(4) Above inverter

Heat is blown up from inside the inverter by the small fan built in the unit. Any equipment placed above the inverter should be heat resistant.



(5) Arrangement of multiple inverters

When multiple inverters are placed in the same enclosure, generally arrange them horizontally as shown in the right figure (a). When it is inevitable to arrange them vertically to minimize space, take such measures as to provide guides since heat from the bottom inverters can increase the temperatures in the top inverters, causing inverter failures.


When mounting multiple inverters, fully take caution not to make the surrounding air temperature of the inverter higher than the permissible value by providing ventilation and increasing the panel size.

Inverter Inverter Inverter Guide Guide Guide Inverter Inv

Arrangement of multiple inverters

(6) Arrangement of ventilation fan and inverter

Heat generated in the inverter is blown up from the bottom of the unit as warm air by the cooling fan. When installing a ventilation fan for that heat, determine the place of ventilation fan installation after fully considering an air flow. (Air passes through areas of low resistance. Make an airway and airflow plates to expose the inverter to cool air.)



MEMO

2 WIRING

This chapter describes the basic "WIRING" for use of this product.

Always read the instructions before using the equipment

2.1	Wiring	14
	Main circuit terminal specifications	
	Control circuit specifications	
	•	28

ı

2

3

Ļ


.

6

7

2.1 Wiring

2.1.1 Terminal connection diagram



- To prevent a malfunction caused by noise, separate the signal cables more than 10cm from the power cables.
- After wiring, wire offcuts must not be left in the inverter.

 Wire offcuts can cause an alarm, failure or malfunction, Always ke
 - Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean. When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- To ensure safety, for single-phase power input specification model, connect the power input to the inverter via a
 magnetic contactor and earth leakage circuit breaker or moulded case circuit breaker, and use the magnetic
 contactor to switch power on-off.
- The output of the single-phase power input specification is three-phase 200V.



2.2 Main circuit terminal specifications


2.2.1 Specification of main circuit terminal

Terminal Symbol	Terminal Name	Description				
R/L1,		Connect to the commercial power supply.				
S/L2,	AC power input	Keep these terminals open when using the high power factor converter (FR-HC) or				
T/L3 *		power regeneration common converter (FR-CV).				
U, V, W	Inverter output	Connect a three-phase squirrel-cage motor.				
. DD	Duelle register composition	Connect a brake transistor (FR-ABR, MRS) across terminals + and PR.				
+, PR	Brake resistor connection	(The brake resistor can not be connected to the FR-D720S-008 and 014.)				
	Brake unit connection	Connect the brake unit (FR-BU2), power regeneration common converter (FR-CV)				
+, -	Brake unit connection	or high power factor converter (FR-HC).				
+, P1	DC reactor connection	Remove the jumper across terminals + and P1 and connect a DC reactor.				
	Earth (Ground)	For earthing (grounding) the inverter chassis. Must be earthed (grounded).				


 $^{^{\}star}$ $\,$ When using single-phase power input, terminals are L1 and N. $\,$

2.2.2 Terminal arrangement of the main circuit terminal, power supply and the motor wiring

●Three-phase 400V class



●Single-phase 200V class





- Make sure the power cables are connected to the R/L1, S/L2, T/L3. (Phase need not be matched.) Never connect the power cable to the U, V, W of the inverter. Doing so will damage the inverter.
- Connect the motor to U, V, W. Turning on the forward rotation switch (signal) at this time rotates the motor counterclockwise when viewed from the load shaft.

2.2.3 Cables and wiring length

(1) Applied wire size

Select the recommended cable size to ensure that a voltage drop will be 2% max.

If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.

The following table indicates a selection example for the wiring length of 20m.

Three-phase 400V class (when input power supply is 440V)

	Terminal Tightening		Crimping Terminal		Cable Size							
Applicable Inverter					HIV Cables, etc. (mm²) *1		AWG *2		PVC Cables, etc. (mm ²) *3			
Model	Size *4	N·m	R/L1 S/L2 T/L3	U, V, W	R/L1 S/L2 T/L3	U, V, W	Earth (ground) cable	R/L1 S/L2 T/L3	U, V, W	R/L1 S/L2 T/L3	U, V, W	Earth (ground) cable
FR-D740-012 to 080	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5
FR-D740-120	M4	1.5	5.5-4	2-4	3.5	2	3.5	12	14	4	2.5	4
FR-D740-160	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	12	12	4	4	4

Single-phase 200V class (when input power supply is 220V)

			Crimping		Cable Size							
Applicable Inverter	Terminal Screw			HIV Cables, etc. (mm²) *1		AWG *2		PVC Cables, etc. (mm ²) *3				
Model	Size *4	N·m	L1 N	U, V, W	L1 N	U, V, W	Earth (ground) cable	L1 N	U, V, W	L1 N	U, V, W	Earth (ground) cable
FR-D720S-008 to 042	M3.5	1.2	2-3.5	2-3.5	2	2	2	14	14	2.5	2.5	2.5
FR-D720S-070	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5
FR-D720S-100	M4	1.5	5.5-4	2-4	3.5	2	3.5	12	14	4	2.5	4

- *1 The cable size is that of the cable (HIV cable (600V class 2 vinyl-insulated cable) etc.) with continuous maximum permissible temperature of 75°C. Assumes that the surrounding air temperature is 50°C or less and the wiring distance is 20m or less.
- *2 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 75°C. Assumes that the surrounding air temperature is 40°C or less and the wiring distance is 20m or less.
 - (Selection example for use mainly in the United States.)
- *3 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 70°C. Assumes that the surrounding air temperature is 40°C or less and the wiring distance is 20m or less.

 (Selection example for use mainly in Europe.)
- *4 The terminal screw size indicates the terminal size for R/L1, S/L2, T/L3, U, V, W, and a screw for earthing (grounding). For single-phase power input, the terminal screw size indicates the size of terminal screw for L1, N, U, V, W, and a screw for earthing (grounding).



NOTE

- Tighten the terminal screw to the specified torque. A screw that has been tighten too loosely can cause a short circuit
 or malfunction. A screw that has been tighten too tightly can cause a short circuit or malfunction due to the unit
 breakage.
- Use crimping terminals with insulation sleeve to wire the power supply and motor.

The line voltage drop can be calculated by the following formula:

line voltage drop [V]= $\frac{\sqrt{3} \times \text{wire resistance}[\text{m}\Omega/\text{m}] \times \text{wiring distance}[\text{m}] \times \text{current}[\text{A}]}{1000}$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.



(2) Earthing (Grounding) precautions

- Always earth (ground) the motor and inverter.
 - 1) Purpose of earthing (grounding)

Generally, an electrical apparatus has an earth (ground) terminal, which must be connected to the ground before use. An electrical circuit is usually insulated by an insulating material and encased. However, it is impossible to manufacture an insulating material that can shut off a leakage current completely, and actually, a slight current flow into the case. The purpose of earthing (grounding) the case of an electrical apparatus is to prevent operator from getting an electric shock from this leakage current when touching it.

To avoid the influence of external noises, this earthing (grounding) is important to audio equipment, sensors, computers and other apparatuses that handle low-level signals or operate very fast.

2) Earthing (grounding) methods and earthing (grounding) work


As described previously, earthing (grounding) is roughly classified into an electrical shock prevention type and a noise-affected malfunction prevention type. Therefore, these two types should be discriminated clearly, and the following work must be done to prevent the leakage current having the inverter's high frequency components from entering the malfunction prevention type earthing (grounding):


(a)Where possible, use independent earthing (grounding) for the inverter. If independent earthing (grounding) (I) is impossible, use joint earthing (grounding) (II) where the inverter is connected with the other equipment at an earthing (grounding) point. Joint earthing (grounding) as in (III) must be avoided as the inverter is connected with the other equipment by a common earth (ground) cable.


Also a leakage current including many high frequency components flows in the earth (ground) cables of the inverter and inverter-driven motor. Therefore, they must use the independent earthing (grounding) method and be separated from the earthing (grounding) of equipment sensitive to the aforementioned noises.

In a tall building, it will be a good policy to use the noise malfunction prevention type earthing (grounding) with steel frames and carry out electric shock prevention type earthing (grounding) in the independent earthing (grounding) method.

- (b)This inverter must be earthed (grounded). Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards).
 - Use an neutral-point earthed (grounded) power supply for 400V class inverter in compliance with EN standard.
- (c)Use the thickest possible earth (ground) cable. The earth (ground) cable should be of not less than the size indicated in the table on the previous *page 16*.
- (d)The grounding point should be as near as possible to the inverter, and the ground wire length should be as short as possible.
- (e)Run the earth (ground) cable as far away as possible from the I/O wiring of equipment sensitive to noises and run them in parallel in the minimum distance.









POINT

To be compliant with the European Directive (Low Voltage Directive), Prefer to the Installation Guideline.



(3) Total wiring length


The overall wiring length for connection of a single motor or multiple motors should be within the value in the table below.

200V class

Pr. 72 PWM frequency selection Setting (carrier frequency)	008	014	025	042	070 or More
1 (1kHz) or less	200m	200m	300m	500m	500m
2 to15 (2kHz to 14.5kHz)	30m	100m	200m	300m	500m

400V class

Pr. 72 PWM frequency selection Setting (carrier frequency)	012	022	036	050	080 or More
1 (1kHz) or less	200m	200m	300m	500m	500m
2 to15 (2kHz to 14.5kHz)	30m	100m	200m	300m	500m



When driving a 400V class motor by the inverter, surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor. (Refer to page 78)



- Especially for long-distance wiring, the inverter may be affected by a charging current caused by the stray capacitances of the wiring, leading to a malfunction of the overcurrent protective function, fast response current limit function, or stall prevention function or a malfunction or fault of the equipment connected on the inverter output side. If fast-response current limit malfunctions, disable this function. When the stall prevention function misoperates, increase the stall level. (Refer to page 74 for Pr. 22 Stall prevention operation level and Pr. 156 Stall prevention operation selection)
- Refer to page 143 for details of Pr. 72 PWM frequency selection. Refer to the manual of the option for details of surge voltage suppression filter (FR-ASF-H/FR-BMF-H).
- When using the automatic restart after instantaneous power failure function with wiring length exceeding below, select without frequency search (*Pr. 162* = "1, 11"). (*Refer to page 131*)

Motor capacity	0.1K	0.2K	0.4K or more		
Wiring length	20m	50m	100m		



2.3 Control circuit specifications

2.3.1 Control circuit terminal

indicates that terminal functions can be selected using *Pr. 178 to Pr. 182*, *Pr. 190*, *Pr. 192 (I/O terminal function selection)*. (*Refer to page 108*).

(1) Input signal

Туре	Terminal Symbol	Terminal Name	Description		Rated Specifications	Refer to Page
	STF STR	Forward rotation start Reverse rotation start	turn it off to stop. Turn on the STR signal to	when the STF and STR signal to stop. When the STF and STR signals are turned on simultaneously, the stop command is given. When the STF and STR Voltage when copen command is given.		112
	RH, RM, RL	Multi-speed selection	Multi-speed can be selected accombination of RH, RM and RI		When contacts are short- circuited 4 to 6mADC	84
Contact input	SD	Contact input common (sink) External transistor common (source) (initial setting) 24VDC power supply common	Common terminal for contact in logic). When connecting the transisto output), such as a programmal source logic is selected, connesupply common for transistor oprevent a malfunction caused in Common output terminal for 24 supply (PC terminal).	r output (open collector ble controller, when ect the external power output to this terminal to by undesirable currents. 4VDC 0.1A power	_	_
	PC	External transistor common (sink) Contact input common (source) (initial setting)	When connecting the transisto output), such as a programmat logic is selected, connect the ecommon for transistor output to a malfunction caused by undes Common terminal for contact in logic).	or output (open collector ble controller, when sink external power supply this terminal to prevent sirable currents. Input terminal (source	Power supply voltage range 22 to 26.5VDC permissible load current 100mA	22
	10	24VDC power supply Frequency setting power supply	Can be used as 24VDC 0.1A pulsed as power supply when confor frequency setting (speed setthe inverter. (Refer to Pr. 73 Ana)	onnecting potentiometer etting) from outside of	5.0V ± 0.2VDC permissible load current 10mA	145
	2	Frequency setting (voltage)	Inputting 0 to 5VDC (or 0 to 10V output frequency at 5V (10V) and proportional. Use <i>Pr. 73</i> to switch 5VDC input (initial setting) and 0	d makes input and output n between input 0 to	Input resistance10k Ω ± 1k Ω Permissible maximum voltage 20VDC	145
Frequency setting	4	Frequency setting (current)	Inputting 4 to 20mADC (or 0 to the maximum output frequency input and output proportional. only when the AU signal is on invalid). Use <i>Pr. 267</i> to switch fr 20mA (initial setting), 0 to 5VD the voltage/current input switch select voltage input (0 to 5V/0 to 10 to	y at 20mA and makes This input signal is valid (terminal 2 input is rom among input 4 to C and 0 to 10VDC. Set in in the "V" position to	Current input: Input resistance $233\Omega \pm 5\Omega$ Maximum permissible current 30mA Voltage input: Input resistance $10k\Omega \pm 1k\Omega$ Permissible maximum voltage 20VDC Current input (initial status) Voltage input	145
	5	Frequency setting common	Common terminal for frequenc (terminal 2 or 4) and analog ou not earth (ground).		7	_
PTC thermistor	10 2	PTC thermistor input	For connecting PTC thermistor When PTC thermistor protectic "9999"), terminal 2 is not availa setting.	on is valid (<i>Pr. 561</i> ≠	Adaptive PTC thermistor resistance: 100Ω to 30kΩ	95





NOTE

Set *Pr. 267* and a voltage/current input switch correctly, then input analog signals in accordance with the settings. Applying a voltage with voltage/current input switch in "I" position (current input is selected) or a current with switch in "V" position (voltage input is selected) could cause component damage of the inverter or analog circuit of output devices. *Refer to page 145 for details.*

(2) Output signal

Туре	Terminal Symbol	Terminal Name	Descrip	tion	Rated Specifications	Reference Page
Relay	A, B, C	Relay output (fault output)	1 changeover contact output inc protective function has activated Fault: discontinuity across B-C (Normal: continuity across B-C (Contact capacity:230VAC 0.3A (power factor =0.4) 30VDC 0.3A	114	
Open collector	RUN	Inverter running	Switched low when the inverter of higher than the starting freques witched high during stop or DC (Low indicates that the open coll (conducts). High indicates that the transisto	Permissible load 24VDC (maximum 27VDC) 0.1A (a voltage drop is 3.4V maximum when the signal is on)	114	
	SE	Open collector output common	Common terminal of terminal RI	_	_	
Analog	АМ	Analog signal output	Select one e.g. output frequency from monitor items. Not output during inverter reset. The output signal is proportional to the magnitude of the corresponding monitoring item.	Output item: Output frequency (initial setting)	Output signal 0 to 10VDC Permissible load current 1mA (load impedance 10kΩ or more) Resolution 8 bit	123


(3) Communication

Туре	Terminal Symbol	Terminal Name	Description	Reference Page	
RS-485	-	PU connector	With the PU connector, communication can be made through RS-485.		
			Conforming standard: EIA-485 (RS-485)		
			Transmission format: Multidrop link	175	
			Communication speed: 4800 to 38400bps		
			Overall length: 500m		

(4) Terminal for inverter manufacturer setting

Terminal Symbol	Description			
S1				
S2	Keep these open. Otherwise, the inverter may be damaged.			
SO	Do not remove wires for shorting across terminal S1 and SC, across terminal S2 and SC. If one of these wires is removed, the inverter cannot be operated.			
SC				

2.3.2 Changing the control logic



The input signals are set to source logic (SOURCE) when shipped from the factory.

To change the control logic, the jumper connector above the control terminal must be moved to the other position.

●To change to sink logic, change the jumper connector in the source logic (SOURCE) position to sink logic (SINK) position using tweezers, a pair of long-nose pliers etc. Change the jumper connector position before switching power on.




- Fully make sure that the front cover has been reinstalled securely.
- The capacity plate is placed on the front cover and the rating plate is on the inverter. Since these plates have the same serial numbers, always reinstall the removed cover onto the original inverter.
- The sink-source logic change-over jumper connector must be fitted in only one of those positions. If it is fitted in both positions at the same time, the inverter may be damaged.

- (1) Sink logic type and source logic type
 - In sink logic, a signal switches on when a current flows from the corresponding signal input terminal.

 Terminal SD is common to the contact input signals. Terminal SE is common to the open collector output signals.
 - In source logic, a signal switches on when a current flows into the corresponding signal input terminal.


 Terminal PC is common to the contact input signals. Terminal SE is common to the open collector output signals.
- Current flow concerning the input/output signal when sink logic is selected
- Current flow concerning the input/output signal when source logic is selected



•When using an external power supply for transistor output


Sink logic type

Use terminal PC as a common terminal, and perform wiring as shown below. (Do not connect terminal SD of the inverter with terminal 0V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



· Source logic type

Use terminal SD as a common terminal, and perform wiring as shown below. (Do not connect terminal PC of the inverter with terminal +24V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)






2.3.3 Wiring of control circuit

(1) Standard control circuit terminal layout

Recommend cable size: 0.3mm² to 0.75mm²




(2) Wiring method

Wiring

Use a bar terminal and a cable with a sheath stripped off for the control circuit wiring. For a single wire, strip off the sheath of the cable and apply directly.

Insert the bar terminal or the single wire into a socket of the terminal.


1) Strip off the sheath about the size below. If the length of the sheath peeled is too long, a short circuit may occur among neighboring wires. If the length is too short, wires might come off.




Wire the stripped cable after twisting it to prevent it from becoming loose. In addition, do not solder it.

2) Crimp the bar terminal.

Insert wires to a bar terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve.



Check the condition of the bar terminal after crimping. Do not use a bar terminal of which the crimping is inappropriate, or the face is damaged.




Introduced products on bar terminals :(as of Mar., 2008)


Wire Size (mm ²)	Bar Term	Maker		
wire Size (mm ⁻)	With Insulation Sleeve Without Insulation Sleeve		Water	
0.3, 0.5	AI 0,5-10WH	_		
0.75	AI 0,75-10GY	A 0,75-10	Phoenix Contact Co.,Ltd.	
1	AI 1-10RD	A1-10		
1.25, 1.5	AI 1,5-10BK	A1,5-10]	
0.75 (for two cables) Al-TWIN 2 x 0,75-10GY		_		

Bar terminal crimping tool: CRIMPFOX ZA3 (Phoenix Contact Co., Ltd.)

3) Insert the wire into a socket.



When using a stranded wire without a bar terminal, push a open/close button all the way down with a flathead screw driver, and insert the wire.






Note

- When using a stranded wire without a bar terminal, twist enough to avoid short circuit with a nearby terminals or wires.
- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause to damage of inverter or injury.

Wire removal

Pull the wire with pushing the open/close button all the way down firmly with a flathead screwdriver.





Note

- Use a small flathead screwdriver (Tip thickness: 0.4mm/tip width: 2.5mm).
 - If a flathead screwdriver with a narrow tip is used, terminal block may be damaged.
- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause to damage of inverter or injury.

(3) Control circuit common terminals (PC, 5, SE)

Terminals PC, SE and 5 are common terminals for I/O signals.(All common terminals are isolated from each other.) Do not earth them. Avoid connecting the terminal PC and 5 and the terminal SE and 5.


Terminal PC is a common terminal for the contact input terminals (STF, STR, RH, RM, RL). The open collector circuit is isolated from the internal control circuit by photocoupler

Terminal 5 is a common terminal for the frequency setting signals (terminals 2 or 4) and analog signal output (AM). It should be protected from external noise using a shielded or twisted cable.

Terminal SE is a common terminal for the open collector output terminal (RUN). The contact input circuit is isolated from the internal control circuit by photocoupler

(4) Signal inputs by contactless switches

The contacted input terminals of the inverter (STF, STR, RH, RM, RL) can be controlled using a transistor instead of a contacted switch as shown on the right.



External signal input using transistor

2.3.4 Wiring instructions

- 1) Use shielded or twisted cables for connection to the control circuit terminals and run them away from the main and power circuits (including the 200V relay sequence circuit).
- 2) Use two or more parallel micro-signal contacts or twin contacts to prevent contact faults when using contact inputs since the control circuit input signals are micro-currents.






- 3) Do not apply a voltage to the contact input terminals (e.g. STF) of the control Micro signal contacts circuit.
- Twin contacts

- 4) Always apply a voltage to the fault output terminals (A, B, C) via a relay coil, lamp, etc.
- 5) It is recommended to use the cables of 0.3mm² to 0.75mm² gauge for connection to the control circuit terminals. If the cable gauge is 1.25mm² or more, the front cover may be lifted when there are many cables running or the cables are run improperly, resulting in a fall off of the front cover.
- 6) The maximum wiring length should be 30m.
- 7) Do not short terminal PC and SD. Inverter may be damaged.

2.3.5 Connection to the PU connector

Using the PU connector, you can perform communication operation from the FR-PU07, enclosure surface operation panel or a personal computer etc.

Remove the inverter front cover when connecting.




•When connecting the parameter unit, enclosure surface operation panel using a connection cable

Use the optional FR-CB2□□ or connector and cable available on the market.

Insert the cable plugs securely into the PU connector of the inverter and the connection connector of the FR-PU07, FR-PA07 along the guide until the tabs snap into place.

Install the inverter front cover after connecting.



> REMARKS

- Overall wiring length when the parameter unit is connected: max 20m
- Refer to the following when fabricating the cable on the user side.

Examples of product available on the market (as of February, 2008)

	Product	Туре	Maker
1)	10BASE-T cable	SGLPEV-T 0.5mm × 4P	Mitsubishi Cable Industries, Ltd.




●RS-485 communication

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

The protocol can be selected from Mitsubishi inverter and Modbus RTU.

· PU connector pin-outs



Pin Number	Name	Description
1)	SG	Earth (ground)
1)	30	(connected to terminal 5)
2)	_	Parameter unit power supply
3)	RDA	Inverter receive+
4)	SDB	Inverter send-
5)	SDA	Inverter send+
6)	RDB	Inverter receive-
7)	SG	Earth (ground)
7)	36	(connected to terminal 5)
8)	_	Parameter unit power supply



NOTE

- Pins No. 2 and 8 provide power to the parameter unit. Do not use these pins for RS-485 communication.
- When making RS-485 communication between the FR-D700 series, FR-E500 series and FR-S500 series, incorrect
 connection of pins No.2 and 8 (parameter unit power supply) of the above PU connector may result in the inverter
 malfunction or failure.
- Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector. The product could be damaged due to differences in electrical specifications.

For further details, refer to page 175.

•Conforming standard: EIA-485 (RS-485)

•Transmission form: Multidrop link

•Communication speed: Maximum 38400 bps

•Overall extension: 500m

Connection of stand-alone option unit 2.4

The inverter accepts a variety of stand-alone option units as required.

Incorrect connection will cause inverter damage or accident. Connect and operate the option unit carefully in accordance with the corresponding option unit manual.

2.4.1 Connection of a dedicated external brake resistor (MRS type, FR-ABR) (FR-D740-012 or more, FR-D720S-025 or more)

Install a dedicated brake resistor (MRS type, FR-ABR) outside when the motor is made to run by the load, quick deceleration is required, etc. Connect a dedicated brake resistor (MRS type, FR-ABR) to terminal + and PR.


(For the locations of terminal + and PR, refer to the terminal block layout (page 15).)

Set parameters below.

Connected Brake	Pr. 30 Regenerative function selection		aganavativa hvaka dutu Sotting	
Resistor	Setting	Pr. 70 Special regenerative brake duty Sett		
MRS type	0 (initial value)	_		
FR-ABR	1	10% Refer to page 103		



The brake resistor connected should only be the dedicated brake resistor.




Do not remove a jumper across terminal + and P1 except when connecting a DC reactor.



(1) When using the brake resistor (MRS) and high-duty brake resistor (FR-ABR)


• It is recommended to configure a sequence, which shuts off power in the input side of the inverter by the external thermal relay as shown below, to prevent overheat and burnout of the brake resistor (MRS) and high duty brake resistor (FR-ABR) in case the regenerative brake transistor is damaged. (The brake resistor can not be connected to the FR-D720S-008 or 014.)



- *1 Refer to the table below for the type number of each capacity of thermal relay and the diagram below for the connection.
- *2 When the power supply is 400V class, install a step-down transformer.

Power Supply Voltage	Brake Resistor	Thermal Relay Type (Mitsubishi product)	Contact Rating
	MRS120W200	TH-N20CXHZ-0.7A	110VAC 5A,
200V	MRS120W100	TH-N20CXHZ-1.3A	220VAC 2A(AC11 class)
2007	MRS120W60	TH-N20CXHZ-2.1A	110VDC 0.5A,
	MRS120W40	TH-N20CXHZ-3.6A	220VDC 0.25A(DC11class)

Power Supply Voltage	High-duty Brake Resistor	Thermal Relay Type (Mitsubishi product)	Contact Rating
	FR-ABR-0.4K	TH-N20CXHZ-0.7A	
200V	FR-ABR-0.75K	TH-N20CXHZ-1.3A	
	FR-ABR-2.2K	TH-N20CXHZ-2.1A	
	FR-ABR-H0.4K	TH-N20CXHZ-0.24A	110VAC 5A,
	FR-ABR-H0.75K	TH-N20CXHZ-0.35A	220VAC 2A(AC11 class)
	FR-ABR-H1.5K	TH-N20CXHZ-0.9A	110VDC 0.5A,
400V	FR-ABR-H2.2K	TH-N20CXHZ-1.3A	220VDC 0.25A(DC11 class)
	FR-ABR-H3.7K	TH-N20CXHZ-2.1A	
	FR-ABR-H5.5K	TH-N20CXHZ-2.5A]
	FR-ABR-H7.5K	TH-N20CXHZ-3.6A	






NOTE

- Brake resistor can not be used with the brake unit, high power factor converter, power supply regeneration converter, etc.
- Do not use the brake resistor with a lead wire extended.
- · Do not connect a resistor directly to the DC terminals + and -. This could cause a fire.

2.4.2 Connection of the brake unit (FR-BU2)

Connect the brake unit (FR-BU2(-H)) as shown below to improve the braking capability at deceleration. If the transistors in the brake unit should become faulty, the resistor can be unusually hot. To prevent unusual overheat and fire, install a magnetic contactor on the inverter's input side to configure a circuit so that a current is shut off in case of fault.

(1) Connection example with the GRZG type discharging resistor



- *1 Connect the inverter terminals (+ and -) and brake unit (FR-BU2) terminals so that their terminal names match with each other.
 - (Incorrect connection will damage the inverter and brake unit.)
- *2 When the power supply is 400V class, install a step-down transformer.
- *3 The wiring distance between the inverter, brake unit (FR-BU2) and discharging resistor should be within 5m. Even when the wiring is twisted, the cable length must not exceed 10m.
- *4 It is recommended to install an external thermal relay to prevent overheat of brake resistors.

<Recommended external thermal relay>


Brake Unit	Discharging Resistor	Recommended External Thermal Relay
FR-BU2-1.5K	GZG 300W-50Ω	TH-N20CXHZ 1.3A
FR-BU2-H7.5K	GRZG 200-10Ω	TH-N20CXHZ 3.6A
FR-BU2-H15K	GRZG 300-5Ω	TH-N20CXHZ 6.6A



NOTE

- Set "1" in Pr. 0 Brake mode selection of the FR-BU2 to use GRZG type discharging resistor.
- Do not remove a jumper across terminal + and P1 except when connecting a DC reactor.

(2) Connection example with the FR-BR(-H) type resistor



- Connect the inverter terminals (+ and -) and brake unit (FR-BU2) terminals so that their terminal names match with
 - (Incorrect connection will damage the inverter and brake unit.)
- When the power supply is 400V class, install a step-down transformer.
- The wiring distance between the inverter, brake unit (FR-BU2) and resistor unit (FR-BR) should be within 5m. Even when the wiring is twisted, the cable length must not exceed 10m.
- Normal: across TH1-TH2...close, Alarm: across TH1-TH2...open
- A jumper is connected across BUE and SD in the initial status.




NOTE

Do not remove a jumper across terminal + and P1 except when connecting a DC reactor.

2.4.3 Connection of the high power factor converter (FR-HC)

When connecting the high power factor converter (FR-HC) to suppress power harmonics, perform wiring securely as shown below. Incorrect connection will damage the high power factor converter and inverter.




- Always keep the power input terminals R/L1, S/L2, T/L3 open. Incorrect connection will damage the inverter.
- Do not insert an MCCB between the terminals + and (between P and +, between N and -). Opposite polarity of terminals and + will damage the
- Use Pr. 178 to Pr. 182 (input terminal function selection) to assign the terminals used for the MRS, RES signal. (Refer to page 108)



- The voltage phases of terminals R/L1, S/L2, T/L3 and terminals R4, S4, T4 must be matched.
- Use sink logic when the FR-HC is connected. The FR-HC cannot be connected when source logic (factory setting) is selected.
- Do not remove a jumper across terminal + and P1.

2.4.4 Connection of the power regeneration common converter (FR-CV)

When connecting the power regeneration common converter (FR-CV), connect the inverter terminals (+ and -) and power regeneration common converter (FR-CV) terminals as shown below so that their symbols match with each other.



- *1 Always keep the power input terminals R/L1, S/L2, T/L3 open. Incorrect connection will damage the inverter.
- *2 Do not insert an MCCB between the terminals + and (between P/L+ and +, between N/L- and -). Opposite polarity of terminals and + will damage the inverter.
- *3 Always connect the power supply and terminals R/L11, S/L21, T/MC1.

 Operating the inverter without connecting them will damage the power regeneration common converter.
- *4 Use Pr. 178 to Pr. 182 (input terminal function selection) to assign the terminals used for the MRS, RES signal. (Refer to page 108)




NOTE

- The voltage phases of terminals R/L11, S/L21, T/MC1 and terminals R2/L1, S2/L2, T2/L3 must be matched.
- Use sink logic when the FR-CV is connected. The FR-CV cannot be connected when source logic (factory setting) is selected.
- Do not remove a jumper across terminal + and P1.

2.4.5 Connection of a DC reactor (FR-HEL)

When using the DC reactor (FR-HEL), connect it across terminals + and P1.

In this case, the jumper connected across terminals + and P1 must be removed. Otherwise, the reactor will not exhibit its performance.





NOTE

- · The wiring distance should be within 5m.
- The size of the cables used should be equal to or larger than that of the power supply cables (R/L1, S/L2, T/L3). (Refer to page 16)

3 PRECAUTIONS FOR USE OF THE INVERTER

This chapter explains the "PRECAUTIONS FOR USE OF THE INVERTER" for use of this product.

Always read the instructions before using the equipment

3.1	EMC and leakage currents	34
3.2	Installation of power factor improving reactor	39
3.3	Power-off and magnetic contactor (MC)	40
3.4	Inverter-driven 400V class motor	41
3.5	Precautions for use of the inverter	42
3.6	Failsafe of the system which uses the inverter	44

3.1 EMC and leakage currents

3.1.1 Leakage currents and countermeasures

Capacitances exist between the inverter I/O cables, other cables and earth and in the motor, through which a leakage current flows. Since its value depends on the static capacitances, carrier frequency, etc., low acoustic noise operation at the increased carrier frequency of the inverter will increase the leakage current. Therefore, take the following measures. Select the earth leakage current breaker according to its rated sensitivity current, independently of the carrier frequency setting.

(1) To-earth (ground) leakage currents

Leakage currents may flow not only into the inverter's own line but also into the other lines through the earth (ground) cable, etc. These leakage currents may operate earth (ground) leakage circuit breakers and earth leakage relays unnecessarily.

Suppression technique

- If the carrier frequency setting is high, decrease the *Pr. 72 PWM frequency selection* setting.

 Note that motor noise increases. Selecting *Pr. 240 Soft-PWM operation selection* makes the sound inoffensive.
- By using earth leakage circuit breakers designed for harmonic and surge suppression in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).
- •To-earth (ground) leakage currents
 - Take caution as long wiring will increase the leakage current. Decreasing the carrier frequency of the inverter reduces the leakage current.
 - Increasing the motor capacity increases the leakage current. The leakage current of the 400V class is larger than that of the 200V class.

(2) Line-to-line leakage currents

Harmonics of leakage currents flowing in static capacitances between the inverter output cables may operate the external thermal relay unnecessarily. When the wiring length is long (50m or more) for the 400V class small-capacity model (FR-D740-160 or less), the external thermal relay is likely to operate unnecessarily because the ratio of the leakage current to the rated motor current increases.

●Line-to-line leakage current data example

Motor Capacity	Rated Motor	Leakage Current (mA) *		
(kW)	Current (A)	Wiring length 50m	Wiring length 100m	
0.4	1.1	620	1000	
0.75	1.9	680	1060	
1.5	3.5	740	1120	
2.2	4.1	800	1180	
3.7	6.4	880	1260	
5.5	9.7	980	1360	
7.5	12.8	1070	1450	


•Motor: SF-JR 4P

Carrier frequency: 14.5kHz

•Used wire: 2mm², 4 cores

Cabtyre cable

*The leakage currents of the 200V class are about a half.



Line-to-line leakage currents path

Measures

- Use Pr. 9 Electronic thermal O/L relay.
- If the carrier frequency setting is high, decrease the Pr. 72 PWM frequency selection setting.
 Note that motor noise increases. Selecting Pr. 240 Soft-PWM operation selection makes the sound inoffensive.
 To ensure that the motor is protected against line-to-line leakage currents, it is recommended to use a temperature sensor to directly detect motor temperature.

Installation and selection of moulded case circuit breaker

Install a moulded case circuit breaker (MCCB) on the power receiving side to protect the wiring of the inverter input side. Select the MCCB according to the inverter input side power factor (which depends on the power supply voltage, output frequency and load). Especially for a completely electromagnetic MCCB, one of a slightly large capacity must be selected since its operation characteristic varies with harmonic currents. (Check it in the data of the corresponding breaker.) As an earth leakage current breaker, use the Mitsubishi earth leakage current breaker designed for harmonics and surge suppression.

Leakage currents in wire path during commercial



(3) Selection of rated sensitivity current of earth (ground) leakage current breaker

When using the earth leakage current breaker with the inverter circuit, select its rated sensitivity current as follows, independently of the PWM carrier frequency.

lg1, lg2:


operation

 Breaker designed for harmonic and surge suppression
 Rated sensitivity current:
 I∆n≥10×(Ig1+Ign+Igi+Ig2+Igm)

Standard breaker
 Rated sensitivity current:
 I∆n≥10×{Ig1+Ign+Igi+3×(Ig2+Igm)}

+Igm)}

Example of leakage current of three-phase induction motor during the commercial power supply operation



Example of leakage current per 1km during the commercial power supply operation when the CV cable is routed in metal conduit (Three-phase three-wire delta


connection 400V60Hz)

Igi:Leakage current of inverter unit


power supply operation

Ign:Leakage current of inverter input side noise filter


Igm:Leakage current of motor during commercial power supply



Example of leakage current of three phase induction motor during the commercial power supply operation (Totally-enclosed fan-cooled type motor 400V60Hz)



For " \downarrow " connection, the amount of leakage current is appox.1/3 of the above value.




Cable size (mm²)

Example of leakage current of

when the CV cable is routed in

cable path per 1km during the commercial power supply operation

<Example>



	Breaker Designed for Harmonic and Surge Suppression	Standard Breaker
Leakage current lg1 (mA)	$\frac{1}{3} \times 66 \times \frac{5m}{1000m} = 0.11$	
Leakage current Ign (mA)	e current Ign (mA) 0 (without noise filter)	
Leakage current Igi (mA)	1	
Leakage current lg2 (mA)	$\frac{1}{3} \times 66 \times \frac{60}{100}$)m = 1.32
Leakage current ig2 (IIIA)	3 ^ 00 ^ 100	00m
Motor leakage current Igm (mA)	0.36	
Total leakage current (mA)	2.79	6.15
Rated sensitivity current (mA) (≥ Ig × 10)	30	100
·		



NOTE


- Install the earth leakage breaker (ELB) on the input side of the inverter.
- An the connection earthed-neutral system, the sensitivity current is blunt against an earth (ground) fault in the
 inverter output side. Earthing (Grounding) must conform to the requirements of national and local safety regulations
 and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)
- When the breaker is installed on the output side of the inverter, it may be unnecessarily operated by harmonics even if the effective value is less than the rating.
- In this case, do not install the breaker since the eddy current and hysteresis loss will increase, leading to temperature rise.
- General products indicate the following models. BV-C1, BC-V, NVB, NV-L, NV-G2N, NV-G3NA, NV-2F earth leakage relay (except NV-ZHA), NV with AA neutral wire open-phase protection
 - The other models are designed for harmonic and surge suppressionNV-C/NV-S/MN series, NV30-FA, NV50-FA, BV-C2, earth leakage alarm breaker (NF-Z), NV-ZHA, NV-H


3.1.2 EMC measures

Some electromagnetic noises enter the inverter to malfunction it and others are radiated by the inverter to malfunction peripheral devices. Though the inverter is designed to have high immunity performance, it handles low-level signals, so it requires the following basic techniques. Also, since the inverter chops outputs at high carrier frequency, that could generate electromagnetic noises. If these electromagnetic noises cause peripheral devices to malfunction, EMI measures should be taken to suppress noises. These techniques differ slightly depending on EMI paths.

- (1) Basic techniques
 - Do not run the power cables (I/O cables) and signal cables of the inverter in parallel with each other and do not bundle them.
 - Use twisted shield cables for the detector connecting and control signal cables and connect the sheathes of the shield cables to terminal SD.
 - Earth (Ground) the inverter, motor, etc. at one point.
- (2) Techniques to reduce electromagnetic noises that enter and malfunction the inverter (Immunity measures) When devices that generate many electromagnetic noises (which use magnetic contactors, magnetic brakes, many relays, for example) are installed near the inverter and the inverter may be malfunctioned by electromagnetic noises, the following measures must be taken:
 - Provide surge suppressors for devices that generate many electromagnetic noises to suppress electromagnetic noises.
 - Fit data line filters (page 37) to signal cables.
 - · Earth (Ground) the shields of the detector connection and control signal cables with cable clamp metal.
- (3) Techniques to reduce electromagnetic noises that are radiated by the inverter to malfunction peripheral devices (EMI measures)

Inverter-generated electromagnetic noises are largely classified into those radiated by the cables connected to the inverter and inverter main circuits (I/O), those electromagnetically and electrostatically induced to the signal cables of the peripheral devices close to the main circuit power supply, and those transmitted through the power supply cables.








Propagation Path	Measures
	When devices that handle low-level signals and are liable to malfunction due to electromagnetic noises, e.g.
	instruments, receivers and sensors, are contained in the enclosure that contains the inverter or when their signal
	cables are run near the inverter, the devices may be malfunctioned by air-propagated electromagnetic noises. The
	following measures must be taken:
(1)(2)(3)	Install easily affected devices as far away as possible from the inverter.
	Run easily affected signal cables as far away as possible from the inverter and its I/O cables.
	Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
	Insert common mode filters into I/O and capacitors between the input lines to suppress cable-radiated noises.
	Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
	When the signal cables are run in parallel with or bundled with the power cables, magnetic and static induction noises
	may be propagated to the signal cables to malfunction the devices and the following measures must be taken:
(A)(E)(G)	Install easily affected devices as far away as possible from the inverter.
(4)(5)(6)	Run easily affected signal cables as far away as possible from the I/O cables of the inverter.
	Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
	Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
	When the power supplies of the peripheral devices are connected to the power supply of the inverter in the same line,
(7)	inverter-generated noises may flow back through the power supply cables to malfunction the devices and the
(1)	following measures must be taken:
	Install the common mode filter (FR-BLF, FR-BSF01) to the power cables (output cable) of the inverter.
	When a closed loop circuit is formed by connecting the peripheral device wiring to the inverter, leakage currents may
(8)	flow through the earth (ground) cable of the inverter to malfunction the device. In such a case, disconnection of the
	earth (ground) cable of the device may cause the device to operate properly.

Data line filter

As immunity measures it may effective, provide a data line filter for the detector cable etc.

EMC measures





For compliance with the EU EMC directive, please refer the Installation Guideline.

3.1.3 Power supply harmonics

The inverter may generate power supply harmonics from its converter circuit to affect the power generator, power capacitor etc. Power supply harmonics are different from noise and leakage currents in source, frequency band and transmission path. Take the following countermeasure suppression techniques.


•The differences between harmonics and RF noises are indicated below:

Item	Harmonics	Noise	
Frequency	Normally 40th to 50th degrees or less	High frequency (several 10kHz to 1GHz order)	
rrequency	(up to 3kHz or less)	riigh hequency (several Tokhiz to Tohiz order)	
Environment To-electric channel, power impedance		To-space, distance, wiring path	
Quantitative understanding	Theoretical calculation possible	Random occurrence, quantitative grasping difficult	
Generated amount	Nearly proportional to load capacity	Change with current variation ratio (larger as switching	
Generated amount	Nearly proportional to load capacity	speed increases)	
Affected equipment immunity	Specified in standard per equipment	Different depending on maker's equipment specifications	
Suppression example	Provide reactor.	Increase distance.	

Suppression technique

The harmonic current generated from the inverter to the input side differs according to various conditions such as the wiring impedance, whether a reactor is used or not, and output frequency and output current on the load side.

For the output frequency and output current, we understand that they should be calculated in the conditions under the rated load at the maximum operating frequency.





NOTE


The power factor improving capacitor and surge suppressor on the inverter output side may be overheated or damaged by the harmonic components of the inverter output. Also, since an excessive current flows in the inverter to activate overcurrent protection, do not provide a capacitor and surge suppressor on the inverter output side when the motor is driven by the inverter. For power factor improvement, install a reactor on the inverter input side or in the DC circuit.




3.2 Installation of power factor improving reactor


When the inverter is connected near a large-capacity power transformer (500kVA or more) or when a power capacitor is to be switched over, an excessive peak current may flow in the power input circuit, damaging the converter circuit. To prevent this, always install an optional reactor (FR-HAL, FR-HEL).

Three-phase power input





Single-phase power input



When connecting the FR-HEL, remove the jumper across terminals + and P1.
The wiring length between the FR-HEL and inverter should be 5m maximum and minimized.

• REMARKS

Use the same wire size as that of the power supply wire (R/L1, S/L2, T/L3). (Refer to page 16)

3.3 Power-off and magnetic contactor (MC)


(1) Inverter input side magnetic contactor (MC)

On the inverter input side, it is recommended to provide an MC for the following purposes. (Refer to $page\ 4$ for selection.)

- 1) To release the inverter from the power supply when the fault occurs or when the drive is not functioning (e.g. emergency stop operation). When cycle operation or heavy-duty operation is performed with an optional brake resistor connected, overheat and burnout of the discharging resistor can be prevented if a regenerative brake transistor is damaged due to insufficient heat capacity of the discharging resistor and excess regenerative brake duty.
- 2) To prevent any accident due to an automatic restart at restoration of power after an inverter stop made by a power failure
- 3) The control power supply for inverter is always running and consumes a little power. When stopping the inverter for an extended period of time, powering off the inverter will save power slightly.
- 4) To separate the inverter from the power supply to ensure safe maintenance and inspection work. The inverter's input side MC is used for the above purpose, select class JEM1038-AC3 MC for the inverter input side current when making an emergency stop during normal operation.

• REMARKS

Since repeated inrush currents at power on will shorten the life of the converter circuit (switching life is about 1,000,000 times.), frequent starts and stops of the MC must be avoided. Turn on/off the inverter start controlling terminals (STF, STR) to run/stop the inverter.



Inverter start/stop circuit example

As shown on the right, always use the start signal (ON or OFF across terminals STF or STR-PC) to make a start or stop.

*When the power supply is 400V class, install a step-down transformer.

(2) Handling of inverter output side magnetic contactor

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned on while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided for switching to the commercial power supply, for example, switch it on/off after the inverter and motor have stopped.



Inverter-driven 400V class motor 3.4

In the PWM type inverter, a surge voltage attributable to wiring constants is generated at the motor terminals. Especially for a 400V class motor, the surge voltage may deteriorate the insulation. When the 400V class motor is driven by the inverter, consider the following measures:

Measures

It is recommended to take either of the following measures:

Rectifying the motor insulation and limiting the PWM carrier frequency according to the wiring length

For the 400V class motor, use an insulation-enhanced motor.

Specifically,

- 1) Specify the "400V class inverter-driven insulation-enhanced motor".
- 2) For the dedicated motor such as the constant-torque motor and low-vibration motor, use the "inverter-driven, dedicated
- 3) Set Pr. 72 PWM frequency selection as indicated below according to the wiring length

	Wiring Length 50m or less 50m to 100m exceeding 100m		
Pr. 72 PWM frequency selection	15 (14.5kHz) or less	8 (8kHz) or less	2 (2kHz) or less

(2) Suppressing the surge voltage on the inverter side

Connect the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) on the inverter output side.



NOTE

- For details of *Pr. 72 PWM frequency selection*, *refer to page 143*.

 For explanation of surge voltage suppression filter (FR-ASF-H/FR-BMF-H), refer to the manual of each option

3.5 Precautions for use of the inverter

The FR-D700 series is a highly reliable product, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the product.

Before starting operation, always recheck the following items.

- (1) Use crimping terminals with insulation sleeve to wire the power supply and motor.
- (2) Application of power to the output terminals (U, V, W) of the inverter will damage the inverter. Never perform such wiring.
- (3) After wiring, wire offcuts must not be left in the inverter.
 - Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean.
 - When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- (4) Use cables of the size to make a voltage drop 2% maximum.
 - If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.
 - Refer to page 16 for the recommended wire sizes.
- (5) The overall wiring length should be 500m maximum.
 - Especially for long distance wiring, the fast-response current limit function may decrease or the equipment connected to the secondary side may malfunction or become faulty under the influence of a charging current due to the stray capacity of the wiring. Therefore, note the overall wiring length. (*Refer to page 18*)
- (6) Electromagnetic wave interference
 - The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, install the FR-BIF optional capacitor type filter (for use in the input side only) or FR-BSF01 or FR-BLF common mode filter to minimize interference.
- (7) Do not install a power factor correction capacitor, surge suppressor or capacitor type filter on the inverter output side.


 This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them. When using capacitor type filter (FR-BIF) for single-phase power supply specification, make sure of secure insulation of T/L3-phase, and connect to the input side of the inverter.
- (8) Before starting wiring or other work after the inverter is operated, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- (9) A short circuit or earth (ground) fault on the inverter output side may damage the inverter modules.
 - Fully check the insulation resistance of the circuit prior to inverter operation since repeated short circuits caused by
 peripheral circuit inadequacy or an earth (ground) fault caused by wiring inadequacy or reduced motor insulation
 resistance may damage the inverter modules.
 - Fully check the to-earth (ground) insulation and phase to phase insulation of the inverter output side before power-on. Especially for an old motor or use in hostile atmosphere, securely check the motor insulation resistance etc.
- (10) Do not use the inverter input side magnetic contactor to start/stop the inverter.

 Always use the start signal (turn on/off terminals STF, STR-PC) to start/stop the inverter. (*Refer to page 40*)
- (11) Across + and PR terminals, connect only an external regenerative brake discharging resistor. The brake resistor can not be connected to the FR-D720S-008 and 014. Do not connect a mechanical brake.
 - The brake resistor can not be connected to the FR-D720S-008 and 014. Leave terminals + and PR open. Also, never short between + and PR.



- (12) Do not apply a voltage higher than the permissible voltage to the inverter I/O signal circuits.

 Application of a voltage higher than the permissible voltage to the inverter I/O signal circuits or opposite polarity may damage the I/O devices. Especially check the wiring to prevent the speed setting potentiometer from being connected incorrectly to short terminals 10-5.
- (13) Provide electrical and mechanical interlocks for MC1 and MC2 which are used for bypass operation. When the wiring is incorrect and if there is a bypass operation circuit as shown right, the inverter will be damaged when the power supply is connected to the inverter U, V, W terminals, due to arcs generated at the time of switch-over or chattering caused by a sequence error.



- (14) If the machine must not be restarted when power is restored after a power failure, provide a magnetic contactor in the inverter's input side and also make up a sequence which will not switch on the start signal.
 If the start signal (start switch) remains on after a power failure, the inverter will automatically restart as soon as the power is restored.
- (15) Instructions for overload operation

When performing operation of frequent start/stop of the inverter, rise/fall in the temperature of the transistor element of the inverter will repeat due to a repeated flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing current at locked condition, starting current, etc. Decreasing current may increase the life. However, decreasing current will result in insufficient torque and the inverter may not start. Therefore, choose the inverter which has enough allowance for current (up to 2 rank larger in capacity).

- (16) Make sure that the specifications and rating match the system requirements.
- (17) When the motor speed is unstable, due to change in the frequency setting signal caused by electromagnetic noises from the inverter, take the following measures when applying the motor speed by the analog signal.
 - Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
 - Run signal cables as far away as possible from power cables (inverter I/O cables).
 - Use shield cables as signal cables.
 - Install a ferrite core on the signal cable (Example: ZCAT3035-1330 TDK).

3.6 Failsafe of the system which uses the inverter

When a fault occurs, the inverter trips to output a fault signal. However, a fault output signal may not be output at an inverter fault occurrence when the detection circuit or output circuit fails, etc. Although Mitsubishi assures best quality products, provide an interlock which uses inverter status output signals to prevent accidents such as damage to machine when the inverter fails for some reason and at the same time consider the system configuration where failsafe from outside the inverter, without using the inverter, is enabled even if the inverter fails.

(1) Interlock method which uses the inverter status output signals By combining the inverter status output signals to provide an interlock as shown below, an inverter alarm can be

No	Interlock Method	Check Method	Used Signals	Refer to Page
1)	Inverter protective function operation	Operation check of an alarm contact Circuit error detection by negative logic	Fault output signal (ALM signal)	117
2)	Inverter running status	Operation ready signal check	Operation ready signal (RY signal)	116
3)	Inverter running status	Logic check of the start signal and running signal	Start signal (STF signal, STR signal) Running signal (RUN signal)	112, 116
4)	Inverter running status	Logic check of the start signal and output current	Start signal (STF signal, STR signal) Output current detection signal (Y12 signal)	112, 119

1) Check by the output of the inverter fault signal

When the fault occurs and trips the inverter, the fault output signal (ALM signal) is output (ALM signal is assigned to terminal ABC in the initial setting).

Check that the inverter functions properly.

In addition, negative logic can be set (on when the inverter is normal, off when the fault occurs).

Output frequency Time ALM ON OFF (when output at NC contact) ON OFF Reset processing **RFS** (about 1s) Reset ON

Inverter fault occurrence

2) Checking the inverter operating status by the inverter operation ready completion signal Operation ready signal (RY signal) is output when the


inverter power is on and the inverter becomes operative.

Check if the RY signal is output after powering on the inverter.

3) Checking the inverter operating status by the start signal input to the inverter and inverter running signal.

The inverter running signal (RUN signal) is output when the inverter is running (RUN signal is assigned to terminal RUN in the initial setting).

Check if RUN signal is output when inputting the start signal to the inverter (forward signal is STF signal and reverse signal is STR signal). For logic check, note that RUN signal is output for the period from the inverter decelerates until output to the motor is stopped, configure a sequence considering the inverter deceleration time





4) Checking the motor operating status by the start signal input to the inverter and inverter output current detection signal. The output current detection signal (Y12 signal) is output when the inverter operates and currents flows in the motor. Check if Y12 signal is output when inputting the start signal to the inverter (forward signal is STF signal and reverse signal is STR signal). Note that the current level at which Y12 signal is output is set to 150% of the inverter rated current in the initial setting, it is necessary to adjust the level to around 20% using no load current of the motor as reference with *Pr.150 Output current detection level*.

For logic check, as same as the inverter running signal (RUN signal), the inverter outputs for the period from the inverter decelerates until output to the motor is stopped, configure a sequence considering the inverter deceleration time.

Output	Pr. 190, Pr. 192 Setting					
signal	Positive logic	Negative logic				
ALM	99	199				
RY	11	111				
RUN	0	100				
Y12	12	112				

 When using various signals, assign functions to Pr.190, Pr.192 (output terminal function selection) referring to the table on the left.



NOTE

Changing the terminal assignment using *Pr. 190, Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

(2) Backup method outside the inverter

Even if the interlock is provided by the inverter status signal, enough failsafe is not ensured depending on the failure status of the inverter itself. For example, even if the interlock is provided using the inverter fault output signal, start signal and RUN signal output, there is a case where a fault output signal is not output and RUN signal is kept output even if an inverter fault occurs.


Provide a speed detector to detect the motor speed and current detector to detect the motor current and consider the backup system such as checking up as below according to the level of importance of the system.

1) Start signal and actual operation check

Check the motor running and motor current while the start signal is input to the inverter by comparing the start signal to the inverter and detected speed of the speed detector or detected current of the current detector. Note that the motor current runs as the motor is running for the period until the motor stops since the inverter starts decelerating even if the start signal turns off. For the logic check, configure a sequence considering the inverter deceleration time. In addition, it is recommended to check the three-phase current when using the current detector.

2) Command speed and actual operation check

Check if there is no gap between the actual speed and commanded speed by comparing the inverter speed command and detected speed of the speed detector.



MEMO

4 PARAMETERS

This chapter explains the "PARAMETERS" for use of this product.

Always read the instructions before using the equipment

The abbreviations in the explanations below are as follows:

WFV/F control,

(Parameters without any indication are valid for both control)

1

2

3

1

5

6

7

4.1 Operation panel

4.1.1 Names and functions of the operation panel

The operation panel cannot be removed from the inverter.

Operation mode indication

PU: Lit to indicate PU operation mode. EXT: Lit to indicate external operation mode.

NET: Lit to indicate network operation mode.

PU, EXT: Lit to indicate external/PU combined operation mode 1, 2.

Unit indication

Hz: Lit to indicate frequency.
A: Lit to indicate current.
(Off to indicate voltage and flicker to indicate set frequency monitor.)

Monitor (4-digit LED)

Shows the frequency, parameter number, etc.

Setting dial

(Setting dial: Mitsubishi inverter dial)
Used to change the frequency setting
and parameter values.

Press to display the following.

- Displays the set frequency in the monitor mode
- Currently set value is displayed during calibration
- Displays the order in the faults history mode

Mode switchover

Used to change each setting mode.


Pressing (PU simultaneously changes


the operation mode. (Refer to page 54) Pressing for a while (2s) can lock operation.

(Refer to page 261)

Determination of each setting

If pressed during operation, monitor changes as below;





Operating status display

Lit or flicker during inverter operation.

On: Indicates that forward rotation operation is being performed.

Slow flickering (1.4s cycle):

Reverse rotation operation

Fast flickering (0.2s cycle):

When (RUN) was pressed or the start command was given, but the operation can not be made.

- When the frequency command is less than the starting frequency.
- When the MRS signal is input.

Parameter setting mode

Lit to indicate parameter setting mode.

Monitor indication

Lit to indicate monitoring mode.

Stop operation

Used to stop Run command.

Fault can be reset when protective function is activated (fault).

Operation mode switchover

Used to switch between the PU and external operation mode.

When using the external operation mode (operation using a separately connected frequency setting potentiometer and start signal), press this key to light up the EXT indication.

(Press (MODE) simultanesouly (0.5s) (Refer


to page 54), or change Pr. 79 setting to change to combined mode .)
PU: PU operation mode

EXT: External operation mode Cancels PU stop also.

Start command

The rotation direction can be selected by setting Pr. 40.

4.1.2 Basic operation (factory setting)



Easy operation mode setting (easy setting mode)

Setting of Pr. 79 Operation mode selection according to combination of the start command and speed command can be easily made.

Operation example

Start command: external (STF/STR), frequency command: operate with



Display -

 Operation 1. Screen at powering on

The monitor display appears.

2. Press $\left(\frac{PU}{FXT}\right)$ and $\left(MODE\right)$ for 0.5s.

Flickering

3. Turn until 79 - 3 appears. (refer to the table below for other settings)



Operation Panel Indication	Operatio	n Method
Operation i allei mulcation	Start command	Frequency command
Flickering Flickering	RUN	
Flickering	External (STF, STR)	Analog voltage input
Flickering	External (STF, STR)	
Flickering	RUN	Analog voltage input

4. Press(SET) to set.

SET

Flicker ··· Parameter setting complete!! $_{
m I\!\!I}$ The monitor display appears after 3s.



Er! is displayed ... Why?

Parameter write is disabled with "1" set in Pr. 77.

E r ∂ is displayed ... Why?

- Press (MODE) before pressing (SET) to return to the monitor display without setting. In this case, the mode changes to external operation mode when performed in the PU operation mode (PU JOG operation mode) and PU operation mode when performed in the external operation mode.
- Reset can be made with



Display -


(The parameter number read previously




Changing example


Change the Pr. 1 Maximum frequency setting.


Operation 1. Screen at powering on The monitor display appears. 2. Press PU to choose the PU operation mode.





MODE









PU indication is lit


appears.)



Flicker...Parameter setting complete!!

- Turn to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.
- Press (MODE) twice to return the monitor to frequency monitor.

REMARKS



The number of digits displayed on the operation panel is four. Only the upper four digits of values can be displayed and set. If the
values to be displayed have five digits or more including decimal places, the fifth or later numerals can not be displayed nor set.
(Example) For Pr. 1

When 50Hz is set, 50.00 is displayed.

When 120Hz is set, 120.0 is displayed and second decimal place is not displayed nor set.

4.1.5 Setting dial push

Push the setting dial (



) to display the set frequency* currently set.

^{*} Appears when PU operation mode or external/PU combined operation mode 1 is selected (Pr. 79 = "3").

4.2 Parameter list

4.2.1 Parameter list

For simple variable-speed operation of the inverter, the initial setting of the parameters may be used as they are. Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check can be made from the operation panel. For details of parameters, refer to the instruction manual.

• REMARKS

- @ indicates simple mode parameters.
- The parameters surrounded by a black border in the table allow its setting to be changed during operation even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
	© 0	Torque boost	0 to 30%	0.1%	6/4/3% *1	69	
	© 1	Maximum frequency	0 to 120Hz	0.01Hz	120Hz	78	
	© 2	Minimum frequency	0 to 120Hz	0.01Hz	0Hz	78	
2	© 3	Base frequency	0 to 400Hz	0.01Hz	50Hz	80	
Basic functions	© 4	Multi-speed setting (high speed)	0 to 400Hz	0.01Hz	50Hz	84	
oun	© 5	Multi-speed setting (middle speed)	0 to 400Hz	0.01Hz	30Hz	84	
ic fe	© 6	Multi-speed setting (low speed)	0 to 400Hz	0.01Hz	10Hz	84	
sasi	© 7	Acceleration time	0 to 3600s	0.1s	5/10s *2	91	
ш	® 8	Deceleration time	0 to 3600s	0.1s	5/10s *2	91	
	© 9	Electronic thermal O/L relay	0 to 500A	0.01A	Rated inverter current	95	
tion	10	DC injection brake operation frequency	0 to 120Hz	0.01Hz	3Hz	104	
DC injection brake	11	DC injection brake operation time	0 to 10s	0.1s	0.5s	104	
OG	12	DC injection brake operation voltage	0 to 30%	0.1%	6/4% *3	104	
_	13	Starting frequency	0 to 60Hz	0.01Hz	0.5Hz		
_	14	Load pattern selection	0 to 3	1	0	82	
JOG	15	Jog frequency	0 to 400Hz	0.01Hz	5Hz	86	
JC	16	Jog acceleration/deceleration time	0 to 3600s	0.1s	0.5s	Page 69 78 78 80 84 84 91 91 95 104 104 104 93 82	
_	17	MRS input selection	0, 2, 4	1	0	110	
_	18	High speed maximum frequency	120 to 400Hz	0.01Hz	120Hz	78	
_	19	Base frequency voltage	0 to 1000V, 8888, 9999	0.1V	8888	80	
Acceleration/ deceleration time	20	Acceleration/deceleration reference frequency	1 to 400Hz	0.01Hz	50Hz	91	
Stall	22	Stall prevention operation level	0 to 200%	0.1%	150%	74	
Stall prevent	23	Stall prevention operation level compensation factor at double speed	0 to 200%, 9999	0.1%	9999	74	
70	24	Multi-speed setting (speed 4)	0 to 400Hz, 9999	0.01Hz	9999	84	
g G	25	Multi-speed setting (speed 5)	0 to 400Hz, 9999	0.01Hz	9999	84	
ulti-spee setting	26	Multi-speed setting (speed 6)	0 to 400Hz, 9999	0.01Hz	9999	84	
Multi-speed setting	27	Multi-speed setting (speed 7)	0 to 400Hz, 9999	0.01Hz	9999	84	
_	29	Acceleration/deceleration pattern selection	0, 1, 2	1	0	94	

- These instruction codes are used for parameter read and write by using Mitsubishi inverter protocol with the RS-485 communication. (Refer to page 204 for RS-485 communication)
- "O" indicates valid and "x" indicates invalid of "control mode-based correspondence table", "parameter copy", "parameter clear", and "all parameter clear".

Parameter	Remarks	Inst	truction C	ode		ode-based dence Table		Paramete	r
		Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
© 0		00	80	0	0	×	0	0	0
© 1		01	81	0	0	0	0	0	0
© 2		02	82	0	0	0	0	0	0
⊚ 3		03	83	0	0	×	0	0	0
© 4		04	84	0	0	0	0	0	0
© 5		05	85	0	0	0	0	0	0
© 6		06	86	0	0	0	0	0	0
© 7 © 8		07 08	87 88	0	0	0	0	0	0
© 9		09	89	0	0	0	0	0	0
10		0A	8A	0	0	0	0	0	0
11		0B	8B	0	0	0	0	0	0
12		ОС	8C	0	0	0	0	0	0
13		0D	8D	0	0	0	0	0	0
14		0E	8E	0	0	×	0	0	0
15		0F	8F	0	0	0	0	0	0
16		10	90	0	0	0	0	0	0
17		11	91	0	0	0	0	0	0
18		12	92	0	0	0	0	0	0
19		13	93	0	0	×	0	0	0
20		14	94	0	0	0	0	0	0
22		16	96	0	0	0	0	0	0
23		17	97	0	0	0	0	0	0
24		18	98	0	0	0	0	0	0
25		19	99	0	0	0	0	0	0
26		1A	9 <i>A</i>	0	0	0	0	0	0
27		1B	9B	0	0	0	0	0	0
29		1D	9D	0	0	0	0	0	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
_	30	Regenerative function selection	0, 1, 2	1	0	105, 131	
۵	31	Frequency jump 1A	0 to 400Hz, 9999	0.01Hz	9999	79	
Frequency jump	32	Frequency jump 1B	0 to 400Hz, 9999	0.01Hz	9999	79	
Ş.	33	Frequency jump 2A	0 to 400Hz, 9999	0.01Hz	9999	79	
en	34	Frequency jump 2B	0 to 400Hz, 9999	0.01Hz	9999	79	
edr	35	Frequency jump 3A	0 to 400Hz, 9999	0.01Hz	9999	79	
Ē	36	Frequency jump 3B	0 to 400Hz, 9999	0.01Hz	9999	79	
_	37	Speed display	0, 0.01 to 9998	0.001	0	122	
_	40	RUN key rotation direction selection	0, 1	1	0	234	
<u>></u> −	41	Up-to-frequency sensitivity	0 to 100%	0.1%	10%	118	
enc	42	Output frequency detection	0 to 400Hz	0.01Hz	6Hz	118	
Frequency detection	43	Output frequency detection for reverse rotation	0 to 400Hz, 9999	0.01Hz	9999	118	
	44	Second acceleration/deceleration time	0 to 3600s	0.1s	5/10s *2	91, 215	
Suc	45	Second deceleration time	0 to 3600s, 9999	0.1s	9999	91, 215	
octic	46	Second torque boost	0 to 30%, 9999	0.1%	9999	69	
fū	47	Second V/F (base frequency)	0 to 400Hz, 9999	0.01Hz	9999	80	
Second functions	48	Second stall prevention operation current	0 to 200%, 9999	0.1%	9999	74	
ő	51	Second electronic thermal O/L relay	0 to 500A, 9999	0.01A	9999	95	
suc	52	DU/PU main display data selection	0, 5, 8 to 12, 14, 20, 23 to 25, 52 to 55, 61, 62, 64, 100	1	0	123	
ğ	55	Frequency monitoring reference	0 to 400Hz	0.01Hz	50Hz	128	
Monitor functions	56	Current monitoring reference	0 to 500A	0.01A	Rated inverter current	128	
Automatic restart functions	57	Restart coasting time	0, 0.1 to 5s, 9999	0.1s	9999	131	
Auto res funo	58	Restart cushion time	0 to 60s	0.1s	1s	131	
_	59	Remote function selection	0, 1, 2, 3	1	0	88	
_	60	Energy saving control selection	0, 9	1	0	142	
_	65	Retry selection	0 to 5	1	0	139	
_	66	Stall prevention operation reduction starting frequency	0 to 400Hz	0.01Hz	50Hz	74	
>	67	Number of retries at fault occurrence	0 to 10, 101 to 110	1	0	139	
Retry	68	Retry waiting time	0.1 to 600s	0.1s	1s	139	
Œ	69	Retry count display erase	0	1	0	139	
	70	Special regenerative brake duty	0 to 30%	0.1%	0%	105	
_	71	Applied motor	0, 1, 3, 13, 23, 40, 43, 50, 53	1	0	70, 98, 100,	
_	72	PWM frequency selection	0 to 15	1	1	143	
_	73	Analog input selection	0, 1, 10, 11	1	1	145	
_	74	Input filter time constant	0 to 8	1	1	147	
_	75	Reset selection/disconnected PU detection/PU stop selection	0 to 3, 14 to 17	1	14	153	
_	77	Parameter write selection	0, 1, 2	1	0	156	
_	78	Reverse rotation prevention selection	0, 1, 2	1	0	157	
_	© 79	Operation mode selection	0, 1, 2, 3, 4, 6, 7	1	0	160, 170	

Parameter	Remarks	Inst	ruction C	ode	Control Me Correspond	ode-based dence Table		Paramete	r
r urumotor	romano	Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
30		1E	9E	0	0	0	0	0	0
31		1F	9F	0	0	0	0	0	0
32		20	A0	0	0	0	0	0	0
33		21	A1	0	0	0	0	0	0
34		22	A2	0	0	0	0	0	0
35		23	А3	0	0	0	0	0	0
36		24	A4	0	0	0	0	0	0
37		25	A5	0	0	0	0	0	0
40 41		28 29	A8 A9	0	0	0	0	0	0
42		29 2A	AA	0	0	0	0	0	0
42		ZA	АА	0	0	O			
43		2B	AB	0	0	0	0	0	0
44		2C	AC	0	0	0	0	0	0
45		2D	AD	0	0	0	0	0	0
46		2E	AE	0	0	×	0	0	0
47		2F	AF	0	0	×	0	0	0
48		30	B0	0	0	0	0	0	0
51		33	В3	0	0	0	0	0	0
52		34	В4	0	0	0	0	0	0
55		37	B7	0	0	0	0	0	0
56		38	В8	0	0	0	0	0	0
57		39	В9	0	0	0	0	0	0
58		3A	BA	0	0	0	0	0	0
59		3B	BB	0	0	0	0	0	0
60		3C	BC	0	0	×	0	0	0
65		41	C1	0	0	0	0	0	0
66		42	C2	0	0	0	0	0	0
67		43	C3	0	0	0	0	0	0
68		44	C4	0	0	0	0	0	0
69		45	C5	0	0	0	0	0	0
70		46	C6	0	0	0	0	0	0
71		47	C7	0	0	0	0	0	0
72		48	C8	0	0	0	0	0	0
73		49	C9	0	0	0	0	×	0
74 75		4A 4B	CA CB	0	0	0 0	0	O ×	O ×
77		4D 4E	CD *4	0	0	0	0	0	0
78 © 79		4E 4F	CF *4	0	0	0	0	0	0
								<u> </u>	

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
	80	Motor capacity	0.1 to 7.5kW, 9999	0.01kW	9999	70, 100	
nts	82	Motor excitation current	0 to 500A, 9999	0.01A	9999	100	
sta	83	Motor rated voltage	0 to 1000V	0.1V	200V/400V *6	100	
Motor constants	84	Rated motor frequency	10 to 120Hz	0.01Hz	50Hz	100	
otor	90	Motor constant (R1)	0 to 50Ω , 9999	0.001Ω	9999	100	
M	96	Auto tuning setting/status	0, 11, 21	1	0	100, 131	
L	117	PU communication station number	0 to 31 (0 to 247)	1	0	to Page 70, 100 100 100 100 100, 131 178, 195 178, 195 178 179, 195 179, 195 178 148 148 207 207, 215	
ınicatic	118	PU communication speed	48, 96, 192, 384	1	192		
E L	119	PU communication stop bit length	0, 1, 10, 11	1	1	178	
or con	120	PU communication parity check	0, 1, 2	1	2		
ect	121	Number of PU communication retries	0 to 10, 9999	1	1	179	
J conn	122	PU communication check time interval	0, 0.1 to 999.8s, 9999	0.1s	0		
٦	123	PU communication waiting time setting	0 to 150ms, 9999	1	9999	178	
	124		0, 1, 2	1	1	178	
_	© 125	frequency	0 to 400Hz	0.01Hz	50Hz	148	
_	⊚ 126	frequency	0 to 400Hz	0.01Hz	50Hz	148	
	127	frequency	0 to 400Hz, 9999	0.01Hz	9999		
	128	PID action selection	0, 20, 21, 40 to 43	1	0	215	
ر	129	PID proportional band	0.1 to 1000%, 9999	0.1%	100%	215	
eration	130	PID integral time	0.1 to 3600s, 9999	0.1s	1s	215	
do Olc	131	PID upper limit	0 to 100%, 9999	0.1%	9999		
	132	PID lower limit	0 to 100%, 9999	0.1%	9999		
	133	PID action set point	0 to 100%, 9999	0.01%	9999	215	
	118						
P		1 7 0 0		1	1	234	
_	-	_		0.40/	1500/	110	
on		•					
Current		time					
C. det							
_				· ·			
_			1 to 3, 5, 8 to 12, 14, 21,				
	@ 160	Extended function display selection		1	0000	157	
_		Frequency setting/key lock operation	·				
c restart ons	162	Automatic restart after instantaneous	0, 1, 10, 11	1	1	131	
Automatic restart functions	165	Stall prevention operation level for restart	0 to 200%	0.1%	150%	131	



Parameter	Remarks	Inst	truction C	ode		ode-based dence Table		Parametei	
1 drameter	Kemarks	Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
80		50	D0	0	×	0	0	0	0
82		52	D2	0	×	0	0	×	0
83		53	D3	0	×	0	0	0	0
90		54 5A	D4 DA	0	×	0	0	O ×	0
96		60	E0	0	0	0	0	×	0
117		11	91	1	0	0	0	O *7	O *7
118		12	92	1	0	0	0	O *7	O *7
119		13	93	1	0	0	0	O *7	O *7
120		14	94	1	0	0	0	O *7	O *7
121		15	95	1	0	0	0	O *7	O *7
122		16	96	1	0	0	0	O *7	O *7
123		17	97	1	0	0	0	O *7	O *7
124		18	98	1	0	0	0	O *7	O *7
⊚ 125		19	99	1	0	0	0	×	0
© 126		1A	9 <i>A</i>	1	0	0	0	×	0
127		1B	9B	1	0	0	0	0	0
128		1C	9C	1	0	0	0	0	0
129		1D	9D	1	0	0	0	0	0
130		1E	9E	1	0	0	0	0	0
131		1F	9F	1	0	0	0	0	0
132		20	A0	1	0	0	0	0	0
133		21	A1	1	0	0	0	0	0
134		22	A2	1	0	0	0	0	0
145		2D	AD	1	0	0	0	×	×
146	Parameter for manufac								
150		32	B2	1	0	0	0	0	0
151		33	В3	1	0	0	0	0	0
152		34	B4	1	0	0	0	0	0
153 156		35 38	B5 B8	1	0	0	0	0	0
156 157		38	B8 B9	1	0	0	0	0	0
158		3A	BA	1	0	0	0	0	0
© 160		00	80	2	0	0	0	0	0
161		01	81	2	0	0	0	×	0
162		02	82	2	0	0	0	0	0
165		05	85	2	0	0	0	0	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting			
letection	166	Output current detection signal retention time	0 to 10s, 9999	0.1s	0.1s	119				
Current detection	167	Output current detection operation selection	0, 1	1	0	119				
_	168 169	Parameter for manufacturer setting. Do	acturer setting. Do not set.							
lative r clear	170	Watt-hour meter clear	0, 10, 9999	1	9999	123				
Cumulative monitor clear	171	Operation hour meter clear	0, 9999	1	9999	123				
nction t	178	STF terminal function selection	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 37, 60, 62, 65 to 67, 9999	1	60					
Input terminal function assignment	179	STR terminal function selection	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 37, 61, 62, 65 to 67, 9999	1	61	108				
t ter as:	180	RL terminal function selection	0 to 5, 7, 8, 10, 12,	1	0	108				
indu	181	RM terminal function selection	14, 16, 18, 24, 25, 37,	1	1	108				
<u> =</u>	182	RH terminal function selection	62, 65 to 67, 9999	1	2	108				
unction assignment	190	RUN terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 25, 26, 46, 47, 64, 70, 90, 91, 93, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 125, 126, 146, 147, 164, 170, 190, 191, 193, 195, 196, 198, 199, 9999	1	0	114				
Output terminal function assignment	192	A,B,C terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 25, 26, 46, 47, 64, 70, 90, 91, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 125, 126, 146, 147, 164, 170, 190, 191, 195, 196, 198, 199, 9999	1	99	114				
	232	Multi-speed setting (speed 8)	0 to 400Hz, 9999	0.01Hz	9999	84				
ing	233	Multi-speed setting (speed 9)	0 to 400Hz, 9999	0.01Hz	9999	84				
setti	234	Multi-speed setting (speed 10)	0 to 400Hz, 9999	0.01Hz	9999	84				
pe :	235	Multi-speed setting (speed 11)	0 to 400Hz, 9999	0.01Hz	9999	84				
spe	236	Multi-speed setting (speed 12)	0 to 400Hz, 9999	0.01Hz	9999	84				
Multi-speed setting	237	Multi-speed setting (speed 13)	0 to 400Hz, 9999	0.01Hz	9999	84				
ML	238	Multi-speed setting (speed 14)	0 to 400Hz, 9999	0.01Hz	9999	84				
	239	Multi-speed setting (speed 15)	0 to 400Hz, 9999	0.01Hz	9999	84				
	240	Soft-PWM operation selection	0, 1	1	1	143				
	241	Analog input display unit switchover	0, 1	1	0	148				
	244	Cooling fan operation selection	0, 1	1	1	225				
o sation	245	Rated slip	0 to 50%, 9999	0.01%	9999	73				
Slip compensation	246	Slip compensation time constant Constant-power range slip	0.01 to 10s	0.01s	0.5s	73				
ပိ	247	compensation selection	0, 9999	1	9999	73				
_	249	Earth (ground) fault detection at start	0, 1	1	1	141				
_	250	Stop selection	0 to 100s, 1000 to 1100s, 8888, 9999	0.1s	9999	107, 112				
	251	Output phase loss protection selection	0, 1	1	1	141				



Parameter	Remarks	Inst	truction C	ode		ode-based dence Table	Parameter		
T didiliotoi	Romano	Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
166		06	86	2	0	0	0	0	0
167		07	87	2	0	0	0	0	0
168 169	Parameter for manufac	cturer settin	g. Do not s	et.				•	•
170		0A	8A	2	0	0	0	×	0
171		0B	8B	2	0	0	×	×	×
178		12	92	2	0	0	0	×	0
179		13	93	2	0	0	0	×	0
180 181		14 15	94 95	2 2	0	0	0 0	×	0
182		16	96	2	0	0	0	×	0
190		1E	9E	2	0	0	0	×	0
192		20	AO	2	0	0	0	×	0
232		28	A8	2	0	0	0	0	0
233 234		29 2A	A9 AA	2	0	0	0	0	0
235		2A 2B	AB	2	0	0	0	0	0
236		2C	AC	2	0	0	0	0	0
237		2D	AD	2	0	0	0	0	0
238		2E	AE	2	0	0	0	0	0
239 240		2F 30	AF B0	2	0	0	0	0	0
241		31	B1	2	0	0	0	0	0
244		34	B4	2	0	0	0	0	0
245		35	B5	2	0	0	0	0	0
246		36	В6	2	0	0	0	0	0
247		37	В7	2	0	0	0	0	0
249		39	B9	2	0	0	0	0	0
250		3A	BA	2	0	0	0	0	0
251		3B	BB	2	0	0	0	0	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
sis	255	Life alarm status display	(0 to 15)	1	0	226	
Life diagnosis	256	Inrush current limit circuit life display	(0 to 100%)	1%	100%	226	
liag	257	Control circuit capacitor life display	(0 to 100%)	1%	100%	226	
e d	258	Main circuit capacitor life display	(0 to 100%)	1%	100%	226	
	259	Main circuit capacitor life measuring	0, 1 (2, 3, 8, 9)	1	0	226	
_	260	PWM frequency automatic switchover	0, 1	1	0	143	
Power failure stop	261	Power failure stop selection	0, 1, 2	1	0	137	
_	267	Terminal 4 input selection	0, 1, 2	1	0	145	
_	268	Monitor decimal digits selection	0, 1, 9999	1	9999	123	
_	269	Parameter for manufacturer setting. Do					•
_	295	Magnitude of frequency change setting	0, 0.01, 0.10, 1.00, 10.00	0.01	0	237	
word	296	Password lock level	1 to 6, 101 to 106, 9999	1	9999	158	
Password function	297	Password lock/unlock	1000 to 9999 (0 to 5, 9999)	1	9999	158	
_	298	Frequency search gain	0 to 32767, 9999	1	9999	131	
_	299	Rotation direction detection selection at restarting	0, 1, 9999	1	0	131	
ation	338	Communication operation command source	0, 1	1	0	171	
RS-485 communication	339	Communication speed command source	0, 1, 2	1	0	171	
Juc	340	Communication startup mode selection	0, 1, 10	1	0	170	
485 cc	342	Communication EEPROM write selection	0, 1	1	0	182	
RS-	343	Communication error count	_	1	0	195	
Second motor constant	450	Second applied motor	0, 1, 9999	1	9999	98	
Remote Output	495	Remote output selection	0, 1, 10, 11	1	0	121	
Rer	496	Remote output data 1	0 to 4095	1	0	121	
_	502	Stop mode selection at communication error	0, 1, 2	1	0	179, 195	
Maintenance	503	Maintenance timer	0 (1 to 9998)	1	0	230	
Mainte	504	Maintenance timer alarm output set time	0 to 9998, 9999	1	9999	230	
ation	549	Protocol selection	0, 1	1	0	195	
Communication	551	PU mode operation command source selection	2, 4, 9999	1	9999	171	
age or	555	Current average time	0.1 to 1s	0.1s	1s	231	
Current average time monitor	556	Data output mask time	0 to 20s	0.1s	0s	231	
Curre	557	Current average value monitor signal output reference current	0 to 500A	0.01A	Rated inverter current	231	
_	561	PTC thermistor protection level	0.5 to 30 k Ω , 9999	0.01Ω	9999	95	
_	563	Energization time carrying-over times	(0 to 65535)	1	0	123	



Parameter	Remarks	Inst	truction C	ode		ode-based dence Table	Parameter		•
i arameter	Kemarks	Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
255		3F	BF	2	0	0	×	×	×
256		40	C0	2	0	0	×	×	×
257 258		41 42	C1 C2	2	0 0	0 0	×	×	×
259		43	C3	2	0	0	0	0	0
260		44	C4	2	0	0	0	0	0
261		45	C5	2	0	0	0	0	0
267		4B	CB	2	0	0	0	×	0
268		4C	CC	2	0	0	0	0	0
269	Parameter for manufac	turer settin	g. Do not s	et.				I	I
295		67	E7	2	0	0	0	0	0
296		68	E8	2	0	0	0	×	0
297		69	E9	2	0	0	0	×	0
298		6A	EA	2	0	0	0	×	0
299		6B	EB	2	0	0	0	0	0
338		26	A6	3	0	0	0	O *7	O *7
339 340		27 28	A7	3	0	0	0	O *7	O *7
			A8						
342		2A	AA	3	0	0	0	0	0
343		2B	AB	3	0	0	×	×	×
450		32	В2	4	0	0	0	0	0
495		5F	DF	4	0	0	0	0	0
496		60	E0	4	0	0	×	×	×
502		02	82	5	0	0	0	0	0
503		03	83	5	0	0	×	×	×
504		04	84	5	0	0	0	×	0
549		31	B1	5	0	0	0	O *7	O *7
551		33	В3	5	0	0	0	O *7	O *7
555		37	В7	5	0	0	0	0	0
556		38	B8	5	0	0	0	0	0
557		39	В9	5	0	0	0	0	0
561		3D	BD	5	0	0	0	×	0
563		3F	BF	5	0	0	×	×	×

Func- tion	Parameter	Name	Name Setting Range		Initial Value	Refer to Page	Customer Setting
	564	Operating time carrying-over times	(0 to 65535)	1	0	123	
_	571	Holding time at a start	0 to 10s, 9999	0.1s	9999	93	
PID	575	Output interruption detection time	0 to 3600s, 9999	0.1s	1s	207	
	576	Output interruption detection level	0 to 400Hz	0.01Hz	0Hz	207	
	577	Output interruption cancel level	900 to 1100%	0.1%	1000%	207	
	592	Traverse function selection	0, 1, 2	1	0	221	
	593	Maximum amplitude amount	0 to 25%	0.1%	10%	221	
Traverse	594	Amplitude compensation amount during deceleration	0 to 50%	0.1%	10%	221	
Trav	595	Amplitude compensation amount during acceleration	0 to 50%	0.1%	10%	221	
	596	Amplitude acceleration time	0.1 to 3600s	0.1s	5s	221	
	597	Amplitude deceleration time	0.1 to 3600s	0.1s	5s	221	
_	611	Acceleration time at a restart	0 to 3600s, 9999	0.1s	9999	131	
_	653	Speed smoothing control Regeneration avoidance frequency	0 to 200%	0.1%	0	144	
_	665	gain gain	0 to 200%	0.1%	100	223	
Protective functions	872 *8	Input phase loss protection selection	0, 1	1	1	141	
ance	882	Regeneration avoidance operation selection	0, 1, 2	1	0	223	
Regeneration avoidance function	883	Regeneration avoidance operation level	300 to 800V	0.1V	400VDC/ 780VDC *6	223	
	885	Regeneration avoidance compensation frequency limit value	0 to 10Hz, 9999	0.01Hz	6Hz	223	
	886	Regeneration avoidance voltage gain	0 to 200%	0.1%	100%	223	
Free rameter	888	Free parameter 1	0 to 9999	1	9999	233	
Free parameter	889	Free parameter 2	0 to 9999	1	9999	233	
_	891	Cumulative power monitor digit shifted times	0 to 4, 9999	1	9999	123	
	C1 (901) *5	AM terminal calibration	_	_	_	129	
	C2 (902) *5	Terminal 2 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	148	
S	C3 (902) *5	Terminal 2 frequency setting bias	0 to 300%	0.1%	0%	148	
ramete	125 (903) *5	Terminal 2 frequency setting gain frequency	0 to 400Hz	0.01Hz	50Hz	148	
tion pa	C4 (903) *5	Terminal 2 frequency setting gain	0 to 300%	0.1%	100%	148	
Calibration parameters	C5 (904) *5	Terminal 4 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	148	
	C6 (904) *5	Terminal 4 frequency setting bias	0 to 300%	0.1%	20%	148	
	126 (905) *5	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	50Hz	148	
	C7 (905) *5	Terminal 4 frequency setting gain	0 to 300%	0.1%	100%	148	
_	C22 to C25 (922 to 923)	Parameter for manufacturer setting. Do	not set.				
_	990	PU buzzer control	0, 1	1	1	238	
PU	991	PU contrast adjustment	0 to 63	1	58	238	

Parameter	Remarks	Inst	truction C	ode	Control M Correspond	ode-based dence Table	Parameter		r
T didilictor	Remarks	Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
564		40	C0	5	0	0	×	×	×
571		47	C7	5	0	0	0	0	0
575		4B	СВ	5	0	0	0	0	0
576		4C	CC	5	0	0	0	0	0
577		4D	CD	5	0	0	0	0	0
592 593		5C 5D	DC DD	5 5	0	0	0 0	0	0
594		5E	DE	5	0	0	0	0	0
595		5F	DF	5	0	0	0	0	0
596		60	E0	5	0	0	0	0	0
597		61 0B	E1	5	0	0	0 0	0	0
611 653		0B 35	8B B5	6	0	0	0 0	0	0
665		41	C1	6	0	0	0	0	0
872		48	C8	8	0	0	0	0	0
882		52	D2	8	0	0	0	0	0
883		53	D3	8	0	0	0	0	0
885		55	D5	8	0	0	0	0	0
886		56	D6	8	0	0	0	0	0
888		58	D8	8	0	0	0	×	×
889		59	D9	8	0	0	0	×	×
891		5B	D8	8	0	0	0	0	0
C1 (901)		5D	DD	1	0	0	0	×	0
C2 (902)		5E	DE	1	0	0	0	×	0
C3 (902)		5E	DE	1	0	0	0	×	0
125 (903)		5F	DF	1	0	0	0	×	0
C4 (903)		5F	DF	1	0	0	0	×	0
C5 (904)		60	E0	1	0	0	0	×	0
C6 (904)		60	E0	1	0	0	0	×	0
126 (905)		61	E1	1	0	0	0	×	0
C7 (905)		61	E1	1	0	0	0	×	0
C22 to C25 (922 to 923)	Parameter for manufac	cturer settin	g. Do not s	et.					
990		5A	DA	9	0	0	0	0	0
991		5B	DB	9	0	0	0	×	0

PARAMETERS

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
rs e list	Pr.CL	Parameter clear	0, 1	1	0	239	
parameters ue change	ALLC	All parameter clear	0, 1	1	0	239	
	Er.CL	Faults history clear	0, 1	1	0	241	
Clear Initial val	Pr.CH	Initial value change list	_	_	_	240	

6%: FR-D740-022 or less, FR-D720S-042 or less

4%: FR-D740-036 to 080, FR-D720S-070 and 100

3%: FR-D740-120 and 160

*2 Differ according to capacities.

5s: FR-D740-080 or less, FR-D720S-008 to 100

10s: FR-D740-120 and 160

*3 Differ according to capacities.

6%: , FR-D720S-008 and 014

4%: , FR-D740-012 or more, FR-D720S-025 or more *4 Write is disabled in the communication mode (network operation mode) from the PU connector.

- *5 The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).
- *6 The initial value differs according to the voltage class. (200V class, 400V class)
- *7 These parameters are communication parameters that are not cleared when parameter clear (all clear) is executed from RS-485 communication. (Refer to page 175 for RS-485 communication)
- *8 Available only for the three-phase power input specification model.

Parameter	Remarks	Instruction Code		Control Mode-based Correspondence Table		Parameter			
i didiliotoi		Read	Write	Extended	V/F	GP MFVC	Сору	Clear	All clear
Pr.CL		_	_	_	_	_	_	_	_
ALLC		_	_	_	_	_	_	_	_
Er.CL		_	_	_	_	_	_	_	_
Pr.CH		_	_	_	_	_	_	_	_

Parameters according to purposes

4.3	Adjust the output torque (current) of the motor	69
4.3.1	Manual torque boost (Pr. 0, Pr. 46)	69
4.3.2	General-purpose magnetic flux vector control (Pr. 71, Pr. 80)	70
4.3.3	Slip compensation (Pr. 245 to Pr. 247)	
4.3.4	Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157)	74
4.4 I	Limit the output frequency	78
4.4.1	Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	78
4.4.2	Avoid mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)	79
4.5	Set V/F pattern	80
4.5.1	Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)	80
4.5.2	Load pattern selection (Pr. 14)	82
4.6 I	Frequency setting by external terminals	84
4.6.1	Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)	84
4.6.2	Jog operation (Pr. 15, Pr. 16)	
4.6.3	Remote setting function (Pr. 59)	
4.7	Setting of acceleration/deceleration time and acceleration/	
	deceleration pattern	91
4.7.1	Setting of the acceleration and deceleration time	
	(Pr. 7, Pr. 8, Pr. 20, Pr. 44, Pr. 45)	91
4.7.2	Starting frequency and start-time hold function (Pr. 13, Pr. 571)	93
4.7.3	Acceleration/deceleration pattern (Pr. 29)	94
4.8	Selection and protection of a motor	95
4.8.1	Motor overheat protection (Electronic thermal O/L relay, PTC thermistor protection) (Pr. 9	9, Pr. 51,
	Pr. 561)	
4.8.2	Applied motor (Pr. 71, Pr. 450)	98
4.8.3	To exhibit the best performance of the motor performance (offline auto tuning) (Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90, Pr. 96)	100
4.9 I	Motor brake and stop operation	104
4.9.1	DC injection brake (Pr. 10 to Pr. 12)	104
4.9.2	Selection of a regenerative brake (Pr. 30, Pr. 70)	
4.9.3	Stop selection (Pr. 250)	
	Function assignment of external terminal and control	108
4.10.1	Input terminal function selection (Pr. 178 to Pr. 182)	108
4.10.2		
4.10.3		
4.10.4		
4.10.5		
4.10.6		
4.10.7		
4.10.8		

4.11 N	Nonitor display and monitor output signal	122
4.11.1	Speed display and speed setting (Pr. 37)	122
4.11.2	Monitor display selection of operation panel/PU and terminal AM	
4.44.0	(Pr. 52, Pr.158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891)	
4.11.3 4.11.4	Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)	
	Terminal AM calibration (calibration parameter C1 (Pr.901))	
	peration selection at power failure and instantaneous power ailure	131
4.12.1	Automatic restart after instantaneous power failure/flying start	
4.12.1	(Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	131
4.12.2	Power-failure deceleration stop function (Pr. 261)	137
4.13 C	peration setting at fault occurrence	139
4.13.1	Retry function (Pr. 65, Pr. 67 to Pr. 69)	139
4.13.2	Input/output phase loss protection selection (Pr. 251, Pr. 872)	141
4.13.3	Earth (ground) fault detection at start (Pr. 249)	141
4.14 E	inergy saving operation	142
4.14.1	Optimum excitation control (Pr. 60)	142
4.15 N	Notor noise, EMI measures, mechanical resonance	143
4.15.1	PWM carrier frequency and soft-PWM control (Pr. 72, Pr. 240, Pr. 260)	143
4.15.2	Speed smoothing control (Pr. 653)	
4.16 F	requency setting by analog input (terminal 2, 4)	145
4.16.1	Analog input selection (Pr. 73, Pr. 267)	145
4.16.2	Response level of analog input and noise elimination (Pr. 74)	
4.16.3	Bias and gain of frequency setting voltage (current)	
	(Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	
4.17 N	lisoperation prevention and parameter setting restriction	153
4.17.1	Reset selection/disconnected PU detection/PU stop selection (Pr. 75)	153
4.17.2	Parameter write disable selection (Pr. 77)	
4.17.3	Reverse rotation prevention selection (Pr. 78)	
4.17.4	Extended parameter display (Pr. 160)	
4.17.5	Password function (Pr. 296, Pr. 297)	
4.18 \$	Selection of operation mode and operation location	160
4.18.1	Operation mode selection (Pr. 79)	
4.18.2	Operation mode at power-on (Pr. 79, Pr. 340)	170
4.18.3	Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 551)	171
4.19 C	Communication operation and setting	175
4.19.1	Wiring and configuration of PU connector	175
4.19.2	Initial settings and specifications of RS-485 communication	
	(Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)	
4.19.3	Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)	179

4.19.4	Communication EEPROM write selection (Pr. 342)	182
4.19.5	Mitsubishi inverter protocol (computer link communication)	183
4.19.6	Modbus RTU communication specifications	
	(Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	195
4.20 S	pecial operation and frequency control	207
4.20.1	PID control (Pr. 127 to Pr. 134, Pr. 575 to Pr. 577)	207
4.20.2	Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)	215
4.20.3	Traverse function (Pr. 592 to Pr. 597)	221
4.20.4	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)	223
4.21 U	seful functions	225
4.21.1	Cooling fan operation selection (Pr. 244)	225
4.21.2	Display of the life of the inverter parts (Pr. 255 to Pr. 259)	226
4.21.3	Maintenance timer alarm (Pr. 503, Pr. 504)	230
4.21.4	Current average value monitor signal (Pr. 555 to Pr. 557)	231
4.21.5	Free parameter (Pr. 888, Pr. 889)	233
4.22 S	etting from the parameter unit and operation panel	234
4.22.1	RUN key rotation direction selection (Pr. 40)	234
4.22.2	PU display language selection(Pr.145)	234
4.22.3	Operation panel frequency setting/key lock operation selection (Pr. 161)	235
4.22.4	Magnitude of frequency change setting (Pr. 295)	237
4.22.5	Buzzer control (Pr. 990)	238
4.22.6	PU contrast adjustment (Pr. 991)	238
4.23 P	arameter clear/ All parameter clear	239
4.24 lı	nitial value change list	240
4.05.0	heck and clear of the faults history	241



4.3 Adjust the output torque (current) of the motor

Purpose	Parameter that	Refer to Page	
Set starting torque manually	Manual torque boost	Pr. 0, Pr. 46	69
Automatically control output current according to load	General-purpose magnetic flux vector control	Pr. 71, Pr. 80	70
Compensate for motor slip to secure low-speed torque	Slip compensation	Pr. 245 to Pr. 247	73
Limit output current to prevent inverter trip	Stall prevention operation	Pr. 22, Pr. 23, Pr. 66, Pr. 156, Pr. 157	74

4.3.1 Manual torque boost (Pr. 0, Pr. 46)

You can compensate for a voltage drop in the low-frequency range to improve motor torque reduction in the low-speed range.


- Motor torque in the low-frequency range can be adjusted to the load to increase the starting motor torque.
- •Two kinds of start torque boosts can be changed by switching between terminals.

Parameter Number	Name	Initial Value		Setting Range	Description
		FR-D740-022 or less	6%		
	0 Torque boost	FR-D720S-008 to 042	0%	0 to 30%	Set the output voltage at 0Hz as %.
0		FR-D740-036 to 080	4%		
		FR-D720S-070 and 100	4 70		
		FR-D740-120 and 160	3%		
46 *	Second torque	0000		0 to 30%	Set the torque boost when the RT signal is on.
40 *	boost	9999		9999	Without second torque boost

^{*} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Starting torque adjustment

- •On the assumption that *Pr. 19 Base frequency voltage* is 100%, set the output voltage at 0Hz in % to *Pr. 0 (Pr. 46)*.
- •Adjust the parameter little by little (about 0.5%), and check the motor status each time. If the setting is too large, the motor will overheat. The guideline is about 10% at the greatest.



(2) Set two kinds of torque boosts (RT signal, Pr. 46)

- •When you want to change torque boost according to applications, switch multiple motors with one inverter, etc., use *Second torque boost*.
- Pr. 46 Second torque boost is valid when the RT signal is on.
- •For the terminal used for RT signal input, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.

REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 111)



NOTE

- The amount of current flows in the motor may become large according to the conditions such as the motor characteristics, load, acceleration/deceleration time, wiring length, etc., resulting in an overcurrent trip (OL (overcurrent alarm) then E.OC1 (overcurrent trip during acceleration), overload trip (E.THM (motor overload trip), or E.THT (inverter overload trip).
- (When a fault occurs, release the start command, and decrease the $Pr. \theta$ setting 1% by 1% to reset.) (Refer to page 244.) The $Pr. \theta$, $Pr. \theta$ settings are valid only when V/F control is selected.
- When using the inverter dedicated motor (constant torque motor) with the FR-D740-120 and 160, set torque boost value to 2%. When $Pr. \theta = "3\%"$ (initial value), if Pr. 71 value is changed to the setting for use with a constant-torque motor, the $Pr. \theta$ setting changes to 2%.
- Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 3 Base frequency, Pr. 19 Base frequency voltage Refer to page 80 Pr. 71 Applied motor Refer to page 98

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108

4.3.2 General-purpose magnetic flux vector control (Pr. 71, Pr. 80) GPMIVO

General-purpose magnetic flux vector control is available.

Large starting torque and low speed torque are available with general-purpose magnetic flux vector control.

• What is general-purpose magnetic flux vector control?

The low speed torque can be improved by providing voltage compensation so that the motor current which meets the load torque to flow. With setting slip compensation (*Pr. 245 to Pr. 247*), output frequency compensation (slip compensation) is made so that the actual motor speed goes closer to a speed command value. Effective when load fluctuates drastically, etc.

General-purpose magnetic flux vector control is the same function as the FR-E500 series.

Parameter	Parameter Name		Setting Range	Description
Number			Setting Range	Description
			0,1, 3,	By selecting a standard motor or constant torque motor,
71	Applied motor	0	13, 23, 40, 43	thermal characteristic and motor constants of each motor
			50, 53	are set.
			0.1 to 7.5kW	Applied motor capacity. (general-purpose magnetic flux
80 Motor capacity		9999	0.1 to 7.5kvv	vector control)
			9999	V/F control

The above parameters can be set when Pr. 160 Extended function display selection = "0".(Refer to page 157)



POINT

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.

- The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity should be 0.1kW or more)
- Motor to be used is any of Mitsubishi standard motor, high efficiency motor (SF-JR, SF-HR 0.2kW or more) or Mitsubishi constant torque motor (SF-JRCA four-pole, SF-HRCA 0.4kW to 7.5kW). When using a motor other than the above (other manufacturer's motor), perform offline auto tuning without fail.
- Single-motor operation (one motor run by one inverter) should be performed.
- The wiring length from inverter to motor should be within 30m. (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m.)

Permissible wiring length between inverter and motor differs according to the inverter capacity and setting value of *Pr. 72 PWM frequency selection* (carrier frequency). *Refer to page 18* for the permissible wiring length.

(1) Control mode

- V/F control (initial setting) and general-purpose magnetic flux vector control are available with this inverter.
- V/F control is for controlling frequency and voltage so that the ratio of frequency (F) to voltage (V) is constant when changing frequency.
- General-purpose magnetic flux vector control divides the inverter output current into an excitation current and a torque current by vector calculation, and makes voltage compensation to flow a motor current which meets the load torque. (General-purpose magnetic flux vector control is the same function as the FR-E500 series.)



(2) Selection method of general-purpose magnetic flux vector control

Perform secure wiring. (Refer to page 14)

1

Display the extended function parameters.

(Pr. 160) (Refer to page 157)



Set "0" in Pr. 160 to display the extended function parameters.

Set the motor. (Pr. 71)

	Motor	Pr. 71 Setting *1	Remarks	
Mitsubishi standard	SF-JR	0 (initial value)		
motor	SF-HR	40		
Mitsubishi high efficiency motor	Others	3	Offline auto tuning is necessary. *2	
Mitsubishi constant-	SF-JRCA 4P	1		
torque motor	SF-HRCA	50		
torque motor	Others (SF-JRC, etc.)	13	Offline auto tuning is necessary. *2	
Other standard motor	_	3	Offline auto tuning is necessary. *2	
Other constant-		13	Offline auto tuning is necessary. *2	
torque motor	_	13	Offiline auto turning is necessary. *2	

- *1 Refer to page 98, for other settings of Pr. 71.
- *2 Refer to page 100 for offline auto tuning.



Set the motor capacity.

(Pr. 80) (Refer to page 74)



Set motor capacity (kW) in Pr. 80 Motor capacity.

(V/F control is performed when the setting is "9999" (initial value).

Set the operation command. (Refer to page 160)

Select the start command and speed command.

(1)Start command

- 1)Operation panel: Setting by pressing (RUN) of the operation panel
- 2)External command: Setting by forward rotation or reverse rotation command (terminal STF or STR)
- (2)Speed command
 - 1)Operation panel: Setting by pressing of the operation panel
 - 2)External analog command (terminal 2 or 4):
 - Give a speed command using the analog signal input to terminal 2 (or terminal 4).
 - 3)Multi-speed command:

The external signals (RH, RM, RL) may also be used to give speed

Test run

As required

- Perform offline auto tuning. (Pr. 96) (Refer to page 100)
- Set slip compensation. (Pr. 245, Pr. 246, Pr. 247) (Refer to page 73)



NOTE

- Uneven rotation slightly increases as compared to the V/F control. (It is not suitable for machines such as grinding machine and wrapping machine which requires less uneven rotation at low speed.
- When a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) is connected between the inverter and motor, output torque may decrease.)

(3) Control method switching by external terminals (X18 signal)

- •Use the V/F switchover signal (X18) to change the control method (V/F control and general-purpose magnetic flux vector control) with external terminal.
- •Turn the X18 signal on to change the currently selected control method (general-purpose magnetic flux vector control) to

For the terminal used for X18 signal input, set "18" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.



REMARKS

When V/F control is selected by V/F switchover (X18 signal), second function is also selected at the same time. Control between V/F and general-purpose magnetic flux can not be switched while the inverter is running. In case control is switched between V/F and general-purpose magnetic flux, only second function is selected.



• Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr.3 Base frequency, Pr.19 Base frequency voltage Refer to page 80 Pr.71 Applied motor Refer to page 98 Pr.77 Parameter write selection Refer to page 156 Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108



4.3.3 Slip compensation (Pr. 245 to Pr. 247)

Inverter output current may be used to assume motor slip to keep the motor speed constant.

Parameter Number	Name	Initial Value	Setting Range	Description
245	Rated slip	9999	0.01 to 50%	Rated motor slip.
245	Rated Slip	9999	0, 9999	No slip compensation
246	Slip compensation time constant	0.5s	0.01 to 10s	Slip compensation response time. When the value is made smaller, response will be faster. However, as load inertia is greater, a regenerative overvoltage fault (E.OV□) is more liable to occur.
247	Constant-power range slip compensation selection	9999	0 9999	Slip compensation is not made in the constant power range (frequency range above the frequency set in <i>Pr. 3</i>) Slip compensation is made in the constant power range.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

• Slip compensation is validated when the motor rated slip calculated by the following formula is set in Pr. 245. Slip compensation is not made when Pr. 245 = "0" or "9999".



• When performing slip compensation, the output frequency may become greater than the set frequency. Set the *Pr. 1 Maximum frequency* value a little higher than the set frequency.



Parameters referred to

Pr. 1 Maximum frequency Refer to page 78
Pr. 3 Base frequency Refer to page 80

4.3.4 Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157)

This function monitors the output current and automatically changes the output frequency to prevent the inverter from coming to trip due to overcurrent, overvoltage, etc. In addition, simple torque limit which limits the output torque to the predetermined value can be selected.

It can also limit stall prevention and fast-response current limit operation during acceleration/deceleration, driving or regeneration.

Stall prevention

If the output current exceeds the stall prevention operation level, the output frequency of the inverter is automatically varied to reduce the output current.


•Fast-response current limit

If the current exceeds the limit value, the output of the inverter is shut off to prevent an overcurrent.

Parameter Number	Name	Initial Value	Setting Range	Description
	Stall prevention operation		0	Stall prevention operation invalid
22	level	150%	0.1 to 200%	Set the current value to start the stall
			0.1 to 20070	prevention operation.
	Stall prevention			The stall operation level can be reduced
	operation level		0 to 200%	when operating at a high speed above the
23	compensation factor	9999		rated frequency.
	at double speed		9999	Constant according to Pr. 22.
	Second stall prevention		0	Stall prevention operation invalid
48	<u>-</u>	9999	0.1 to 200%	Second stall prevention operation level
	operation current		9999	Same level as Pr. 22.
	Stall prevention			Set the frequency at which the stall
66	operation reduction	50Hz	0 to 400Hz	' '
	starting frequency			operation level is started to reduce.
	Stall prevention operation			Select whether stall prevention operation
156	selection	0	0 to 31, 100, 101	and fast-response current limit operation
	Selection			will be performed or not.
			0 to 25s	Output start time of the OL signal output
157	OL signal output timer	0s	0 10 258	when stall prevention is activated.
			9999	Without the OL signal output


The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Block diagram



Adjust the output torque (current) of the motor

(2) Setting of stall prevention operation level (Pr. 22)



- •Set in Pr. 22 the percentage of the output current to the rated inverter current at which stall prevention operation will be performed. Normally set this parameter to 150% (initial value).
- •Stall prevention operation stops acceleration (makes deceleration) during acceleration, makes deceleration during constant speed, and stops deceleration (makes acceleration) during deceleration.
- •When stall prevention operation is performed, the OL signal is




NOTE

• If an overload status lasts long, an inverter trip (e.g. electronic thermal O/L relay (E.THM)) may occur.

(3) Stall prevention operation signal output and output timing adjustment (OL signal, Pr. 157)

- •When the output current exceeds the stall prevention operation level and stall prevention is activated, the stall prevention operation signal (OL signal) turns on for longer than 100ms. When the output current falls to or below the stall prevention operation level, the output signal turns off.
- •Use Pr. 157 OL signal output timer to set whether the OL signal is output immediately or after a preset period of time.
- •This operation is also performed when the regeneration avoidance function or $\Box L$ (overvoltage stall) is executed.
- •For the Y13 signal, set "3 (positive logic) or 103 (negative logic)" in Pr. 190 or Pr. 192 (output terminal function selection) and assign functions to the output terminal.


Pr. 157 Setting	Description			
0	Output immediately.			
(initial value)	Output infinediately.			
0.1 to 25	Output after the set time (s) has elapsed.			
9999	Not output.			






- If the frequency has fallen to 1Hz by stall prevention operation and remains for 3s, a fault (E.OLT) appears to trip the
- Changing the terminal assignment using Pr. 190, Pr. 192 (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

(4) Setting of stall prevention operation in high frequency range (Pr. 22, Pr. 23, Pr. 66)





- •During high-speed operation above the rated motor frequency, acceleration may not be made because the motor current does not increase. If operation is performed in a high frequency range, the current at motor lockup becomes smaller than the rated output current of the inverter, and the protective function (OL) is not executed even if the motor is at a stop. To improve the operating characteristics of the motor in this case, the stall prevention level can be reduced in the high frequency range. This function is effective for performing operation up to the high-speed range on a centrifugal separator etc. Normally, set 50Hz in *Pr.* 66 and 100% in *Pr.* 23.
- •Formula for stall prevention operation level

Stall prevention operation level in high frequency range (%) = A + B
$$\times \left[\frac{Pr. 22 - A}{Pr. 22 - B} \right] \times \left[\frac{Pr. 23 - 100}{100} \right]$$

However, A =
$$\frac{Pr. 66 \text{ (Hz)} \times Pr. 22 \text{ (\%)}}{\text{Output frequency (Hz)}}$$
, B = $\frac{Pr. 66 \text{ (Hz)} \times Pr. 22 \text{ (\%)}}{400 \text{Hz}}$

•By setting "9999" (initial value) in *Pr. 23 Stall prevention operation level compensation factor at double speed*, the stall prevention operation level is constant at the *Pr. 22* setting up to 400Hz.

(5) Set two types stall prevention operation levels (Pr. 48)

- •Turning RT signal on makes Pr. 48 Second stall prevention operation current valid.
- •For the terminal used for RT signal input, set "3" in any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the function.



NOTE

- Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.
- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 111)



(6) Limit the stall prevention operation and fast-response current limit operation according to the operating status (Pr. 156)

•Refer to the following table and select whether fast-response current limit operation will be performed or not and the operation to be performed at OL signal output.

Pr. 1	156	Fast-Response Current Limit	Opera	reventio tion Sele tivated activate	ection	OL Signal Output O:Operation	Pr. 156	Fast-Response Current Limit	Opera	revention tion Sel tivated activate	ection	OL Signal Output O:Operation
Sett		O: Activated ●: Not activated	Acceleration	Constant	Deceleration	continued •: Operation not continued *1	Setting	O: Activated •: Not activated	Acceleration	Constant	Deceleration	continued •: Operation not continued *1
0 (init valu	ial	0	0	0	0	0	16	0	0	0	0	•
1	,	•	0	0	0	0	17	•	0	0	0	•
2		0	•	0	0	0	18	0	•	0	0	•
3		•	•	0	0	0	19	•	•	0	0	•
4		0	0	•	0	0	20	0	0	•	0	•
5		•	0	•	0	0	21	•	0	•	0	•
6		0	•	•	0	0	22	0	•	•	0	•
7		•	•	•	0	0	23	•	•	•	0	•
8		0	0	0	•	0	24	0	0	0	•	•
9		•	0	0	•	0	25	•	0	0	•	•
10		0	•	0	•	0	26	0	•	0	•	•
11		•	•	0	•	0	27	•	•	0	•	•
12		0	0	•	•	0	28	0	0	•	•	•
13		•	0	•	•	0	29	•	0	•	•	•
14		0	•	•	•	— *2	30	0	•	•	•	— *2
15)	•	•	•	•	— *2	31	•	•	•	•	— *2
100	Power driving	0	0	0	0	0	101 Power driving	•	0	0	0	0
*3	Regeneration	•	•	•	•	— *2	*3 Regeneration	onned by stall prevention	•	•	•	- *2

- *1 When "Operation not continued for OL signal output" is selected, the III fault (stopped by stall prevention) is displayed and operation stopped.
- Since stall prevention is not activated, OL signal and E.OLT are not output.

 The settings "100" and "101" allow operations to be performed in the driving and regeneration modes, respectively. The setting "101" disables the fastresponse current limit in the driving mode.




NOTE

- When the load is heavy or the acceleration/deceleration time is short, stall prevention is activated and acceleration/ deceleration may not be made according to the preset acceleration/deceleration time. Set Pr. 156 and stall prevention operation level to the optimum values.
- In vertical lift applications, make setting so that the fast-response current limit is not activated. Torque may not be produced, causing a load drop due to gravity.



No not set a small value as the stall prevention operation current. Otherwise, torque generated will reduce.



Stall prevention operation during acceleration may increase the acceleration time.

Stall prevention operation performed during constant speed may cause sudden speed changes.

Stall prevention operation during deceleration may increase the deceleration time, increasing the deceleration distance.



Parameters referred to

- Pr. 3 Base frequency Refer to page 80
 Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108
- Pr. 190, Pr. 192 (output terminal function selection) Refer to page 114

4.4 Limit the output frequency

Purpose	Parameter	Refer to Page	
Set upper limit and lower limit of output frequency	Maximum/minimum frequency	Pr. 1, Pr. 2, Pr. 18	78
Perform operation by avoiding mechanical resonance points	Frequency jump	Pr. 31 to Pr. 36	79


4.4.1 Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)

Motor speed can be limited.

Clamp the upper and lower limits of the output frequency.

Parameter Number	Name	Initial Value	Setting Range	Description
1	Maximum frequency	120Hz	0 to 120Hz	Upper limit of the output frequency.
2	Minimum frequency	0Hz	0 to 120Hz	Lower limit of the output frequency.
18 *	High speed maximum	120Hz	120 to 400Hz	Set when performing the operation at 120Hz
18 *	frequency	12002	120 (0 40002	or more.

^{*} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



(1) Set maximum frequency

- Use Pr. 1 Maximum frequency to set the maximum frequency. If the frequency of the frequency command entered is higher than the setting, the output frequency is clamped at the maximum frequency.
- When you want to perform operation above 120Hz, set the upper limit of the output frequency to Pr. 18 High speed maximum frequency. (When Pr. 18 is set, Pr. 1 automatically switches to the frequency of Pr. 18. Also, when Pr. 1 is set, Pr. 18 is automatically changed to the frequency set in Pr. 1.

REMARKS

• When performing operation above 50Hz using the frequency setting analog signal, change *Pr. 125 (Pr. 126) (frequency setting gain).*

(2) Set minimum frequency

- Use Pr. 2 Minimum frequency to set the minimum frequency.
- If the set frequency is less than Pr. 2, the output frequency is clamped at Pr. 2 (will not fall below Pr. 2).

REMARKS

- When Pr. 15 Jog frequency is equal to or less than Pr. 2, the Pr. 15 setting has precedence over the Pr. 2 setting.
- When stall prevention is activated to decrease the output frequency, the output frequency may drop to Pr. 2 or below.



Note that when *Pr. 2* is set to any value equal to or more than *Pr. 13 Starting frequency*, simply turning on the start signal will run the motor at the preset frequency according to the set acceleration time even if the command frequency is not input.



Parameters referred to

Pr. 13 Starting frequency Refer to page 93 Pr. 15 Jog frequency Refer to page 86

Pr. 125 Terminal 2 frequency setting gain frequency, Pr. 126 Terminal 4 frequency setting gain frequency \$\mathbb{Q}\mathbb{T}\$ Refer to page 148




4.4.2 Avoid mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)

When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped.

Parameter Number	Name	Initial Value	Setting Range	Description
31	Frequency jump 1A	9999	0 to 400Hz, 9999	
32	Frequency jump 1B	9999	0 to 400Hz, 9999	444 45 044 05 044 05: 6
33	Frequency jump 2A	9999	0 to 400Hz, 9999	1A to 1B, 2A to 2B, 3A to 3B is frequency
34	Frequency jump 2B	9999	0 to 400Hz, 9999	jumps 9999: Function invalid
35	Frequency jump 3A	9999	0 to 400Hz, 9999	a cood. I difederi ilivalid
36	Frequency jump 3B	9999	0 to 400Hz, 9999	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



- Up to three areas may be set, with the jump frequencies set to either the top or bottom point of each area.
- The value set to 1A, 2A or 3A is a jump point and operation in the jump zone is performed at these frequencies.



Example 1

To fix the frequency to 30Hz in the range 30Hz to 35Hz, set 35Hz in Pr. 34 and 30Hz in Pr. 33.

To jump the frequency to 35Hz in the range 30Hz to 35Hz, set 35Hz in Pr. 33 and 30Hz in Pr. 34.



NOTE

During acceleration/deceleration, the running frequency within the set area is valid.

4.5 Set V/F pattern


Purpose	Parameter	Refer to Page	
Set motor ratings	Base frequency, Base frequency voltage Pr. 3, Pr. 19, Pr. 47		80
Select a V/F pattern according to applications.	Load pattern selection	Pr. 14	82

4.5.1 Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)

Used to adjust the inverter outputs (voltage, frequency) to the motor rating.

Parameter Number	Name	Initial Value	Setting Range	Description
3	Base frequency	50Hz	0 to 400Hz	Rated motor frequency. (50Hz/60Hz)
			0 to 1000V	Base voltage.
19 *	Base frequency voltage	8888	8888	95% of power supply voltage
			9999	Same as power supply voltage
47	Second V/F (base	0000	0 to 400Hz	Base frequency when the RT signal is on.
47 *	frequency)	9999	9999	Second V/F invalid

^{*} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



(1) Base frequency setting (Pr. 3)

- When operating a standard motor, generally set the rated frequency of the motor to *Pr. 3 Base frequency*. When running the motor using commercial power supply-inverter switch-over operation, set *Pr. 3* to the same value as the power supply frequency.
- If the frequency given on the motor rating plate is "60Hz" only, always set to "60Hz". It may result in an inverter trip due to overload.

Special care must be taken when "1" (variable torque load) is set in $Pr.\ 14\ Load\ pattern\ selection$.

 \bullet When using the Mitsubishi constant-torque motor, set Pr.~3 to 60Hz.

(2) Set two kinds of base frequencies (Pr. 47)

- When you want to change the base frequency when switching two types of motors with one inverter, use the *Pr. 47 Second V/ F (base frequency)*.
- *Pr. 47 Second V/F (base frequency)* is valid when the RT signal is on. Set "3" in any of *Pr. 178 to Pr. 182 (input terminal function selection)* and assign the RT signal.

• REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 111)



(3) Base frequency voltage setting (Pr. 19)

- •Use Pr. 19 Base frequency voltage to set the base voltage (e.g. rated motor voltage).
- •If the setting is less than the power supply voltage, the maximum output voltage of the inverter is as set in Pr. 19.
- Pr. 19 can be utilized in the following cases.
 - (a) When regeneration is high (e.g. continuous regeneration) During regeneration, the output voltage becomes higher than the reference and may cause an overcurrent trip (E.OC□) due to an increased motor current.
 - (b) When power supply voltage variation is large

When the power supply voltage exceeds the rated voltage of the motor, speed variation or motor overheat may be caused by excessive torque or increased motor current.



• When general-purpose magnetic flux vector control is selected, Pr. 3, Pr. 47 and Pr. 19 are invalid and Pr. 83 and Pr. 84

Note that Pr. 3 or Pr. 47 value is made valid as inflection points of S-pattern when Pr. 29 Acceleration/deceleration pattern selection = "1" (S-pattern acceleration/deceleration A).

· Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 14 Load pattern selection Refer to page 82

Pr. 29 Acceleration/deceleration pattern selection Refer to page 94

Pr. 83 Motor rated voltage, Pr. 84 Rated motor frequency Refer to page 100

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108


General-purpose magnetic flux vector control Refer to page 70

4.5.2 Load pattern selection (Pr. 14)

You can select the optimum output characteristic (V/F characteristic) for the application and load characteristics.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	For constant torque load
	4.4 Lood nottown colootion	0	1	For variable torque load
14			2	For constant torque elevators
14	Load pattern selection			(at reverse rotation boost of 0%)
			3	For constant torque elevators
				(at forward rotation boost of 0%)

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)




(1) Constant-torque load application (setting "0", initial value)

- At or less than the base frequency, the output voltage varies linearly with the output frequency.
- Set this value when driving the load whose load torque is constant even if the speed varies, e.g. conveyor, cart or roll drive.

POINT


If the load is a fan or pump, select for constant-torque load (setting "0") in any of the following cases.


- When a blower of large inertia moment (J) is accelerated in a short time
- · For constant-torque load such as rotary pump or gear pump
- · When load torque increases at low speed, e.g. screw pump



(2) Variable-torque load application (setting "1")

- At or less than the base frequency, the output voltage varies with the output frequency in a square curve.
- Set this value when driving the load whose load torque varies in proportion to the square of the speed, e.g. fan or pump.





(3) Constant-torque load application (setting "2, 3")

- Set "2" when a vertical lift load is fixed as power driving load at forward rotation and regenerative load at reverse rotation.
- Pr. 0 Torque boost is valid during forward rotation and torque boost is automatically changed to "0%" during reverse rotation. Pr. 46 Second torque boost is made valid when the RT signal turns on.
- Set "3" for an elevated load that is in the driving mode during reverse rotation and in the regenerative load mode during forward rotation according to the load weight, e.g. counterweight system.
- For the RT signal, set "3" in any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the function.



REMARKS

- When torque is continuously regenerated as vertical lift load, it is effective to set the rated voltage in *Pr. 19 Base frequency voltage* to prevent trip due to current at regeneration.
- In addition, when the RT signal is on, the other second functions are also valid.



NOTE

- · Load pattern selection does not function under general-purpose magnetic flux vector control.
- Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 0, Pr. 46 (Torque boost) Refer to page 69
Pr. 3 Base frequency Refer to page 80
Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108
General-purpose magnetic flux vector control Refer to page 70

4.6 Frequency setting by external terminals

Purpose	Parameter	Refer to Page	
Make frequency setting by	Multi anad aparation	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27,	9.1
combination of terminals	Multi-speed operation	Pr. 232 to Pr. 239	84
Perform jog operation	Jog operation	Pr. 15, Pr. 16	86
Infinitely variable speed setting by terminals	Remote setting function	Pr. 59	88

4.6.1 Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)


Can be used to change the preset speed in the parameter with the contact signals.

Any speed can be selected by merely turning on-off the contact signals (RH, RM, RL, REX signals).

Parameter	Name	Initial Value	Setting Range	Description
Number	Name	illitiai value	Setting Range	Description
4	Multi-speed setting (high	50Hz	0 to 400Hz	Frequency when RH turns on
-	speed)	30112	0 10 400112	requericy when rain turns on
5	Multi-speed setting (middle	30Hz	0 to 400Hz	Frequency when RM turns on.
	speed)	00112	0 10 400112	Trequency when two tame on.
6	Multi-speed setting (low	10Hz	0 to 400Hz	Frequency when RL turns on.
	speed)	10112	0 10 400112	Trequency when the turns on.
24 *	Multi-speed setting (speed 4)	9999	0 to 400Hz, 9999	
25 *	Multi-speed setting (speed 5)	9999	0 to 400Hz, 9999	
26 *	Multi-speed setting (speed 6)	9999	0 to 400Hz, 9999	
27 *	Multi-speed setting (speed 7)	9999	0 to 400Hz, 9999	Fraguency from 4 and data 15 and dan
232 *	Multi-speed setting (speed 8)	9999	0 to 400Hz, 9999	Frequency from 4 speed to 15 speed can
233 *	Multi-speed setting (speed 9)	9999	0 to 400Hz, 9999	be set according to the combination of
234 *	Multi-speed setting (speed 10)	9999	0 to 400Hz, 9999	the RH, RM, RL and REX signals.
235 *	Multi-speed setting (speed 11)	9999	0 to 400Hz, 9999	9999: not selected
236 *	Multi-speed setting (speed 12)	9999	0 to 400Hz, 9999	
237 *	Multi-speed setting (speed 13)	9999	0 to 400Hz, 9999	
238 *	Multi-speed setting (speed 14)	9999	0 to 400Hz, 9999	
239 *	Multi-speed setting (speed 15)	9999	0 to 400Hz, 9999	

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

^{*} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



(1) 3-speed setting (Pr. 4 to Pr. 6)

•The inverter operates at frequencies set in Pr. 4 when RH signal is on, Pr. 5 when RM signal is on and Pr. 6 when RL signal is on.


• REMARKS


- For multi-speed setting, if two or three speeds are simultaneously selected, priority is given to the set frequency of the lower signal.
 - For example, when the RH and RM signals turn on, the RM signal (Pr. 5) has a higher priority.
- The RH, RM, RL signals are assigned to the terminal RH, RM, RL in the initial setting. By setting "0 (RL)", "1 (RM)", "2 (RH)" in any of *Pr. 178 to Pr. 182 (input terminal function selection)*, you can assign the signals to other terminals.



(2) Multi-speed setting for 4 or more speeds (Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)

- •Frequency from 4 speed to 15 speed can be set according to the combination of the RH, RM, RL and REX signals. Set the running frequencies in *Pr. 24 to Pr. 27, Pr. 232 to Pr. 239* (In the initial value setting, speed 4 to speed 15 are unavailable).
- •For the terminal used for REX signal input, set "8" in any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the function.





Multi-speed operation connection example

*1 When "9999" is set in Pr. 232 Multi-speed setting (speed 8), operation is performed at frequency set in Pr. 6 when RH, RM and RL are turned off and REX is turned on.



REMARKS

• The priorities of the frequency commands by the external signals are "jog operation > multi-speed operation > terminal 4 analog input > terminal 2 analog input".

(Refer to page 148 for the frequency command by analog input)

- Valid in the external operation mode or PU/external combined operation mode (Pr. 79 = "3" or "4").
- Multi-speed parameters can also be set in the PU or external operation mode.
- Pr. 24 to Pr. 27 and Pr. 232 to Pr. 239 settings have no priority between them.
- When Pr. 59 Remote function selection ≠ "0", multi-speed setting is invalid as RH, RM and RL signals are remote setting signals.



NOTE

• Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 15 Jog frequency Refer to page 86
Pr. 59 Remote function selection Refer to page 88

Pr. 79 Operation mode selection Refer to page 160

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108

4.6.2 Jog operation (Pr. 15, Pr. 16)

You can set the frequency and acceleration/deceleration time for jog operation. Jog operation can be performed in either of the external and the PU operation mode.


This operation can be used for conveyor positioning, test operation, etc.


Parameter Number	Name	Initial Value	Setting Range	Description
15	Jog frequency	5Hz	0 to 400Hz	Frequency for jog operation.
16	Jog acceleration/ deceleration time	0.5s	0 to 3600s	Acceleration/deceleration time for jog operation. As the acceleration/deceleration time, set the time taken to reach the frequency (initial value is 50Hz) set in <i>Pr. 20 Acceleration/deceleration reference frequency</i> . Acceleration/deceleration time can not be set separately.

These parameters are displayed as simple mode parameter only when the parameter unit (FR-PU04/FR-PU07) is connected. When the parameter unit is not connected, the above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

Jog operation from outside

- •When the JOG signal is on, a start and stop can be made by the start signal (STF, STR).
- •For the terminal used for Jog operation selection, set "5" in any of Pr.178 to Pr.182 (input terminal function selection) to assign the function.





Connection diagram for external jog operation

Display -




1. Screen at powering on

- Confirm that the external operation mode is selected. ([EXT] lit)
 - If not displayed, press $\frac{PU}{FXT}$ to change to the external (EXT) operation mode. If the operation mode still does not change, set Pr. 79 to change to the external operation mode.
- 2. Turn on the JOG switch.



- - The motor runs while the start switch (STF or STR) is on.
 - The motor runs at 5Hz. (initial value of Pr. 15)
- 4. Turn the start switch (STF or STR) off.




> REMARKS

- When you want to change the running frequency, change Pr. 15 Jog frequency. (initial value "5Hz")
- When you want to change the acceleration/deceleration time, change Pr. 16 Jog acceleration/deceleration time. (initial value "0.5s") The acceleration time and deceleration time cannot be set separately for jog operation.



(2) Jog operation from PU

•Selects Jog operation mode from the operation panel and PU (FR-PU04/FR-PU07). Operation is performed only while the start button is pressed.



Operation

Display

- Confirmation of the RUN indication and operation mode indication
 - The monitor mode should have been selected.
 - The inverter should be at a stop.
- 2. Press $\frac{PU}{EXT}$ to choose the PU Jog operation mode.
- 3. Press (RUN)
 - While (RUN) is pressed, the motor rotates.
 - The motor runs at 5Hz. (Pr. 15 initial value)
- 4. Release RUN





- RUN
- Hold down.









[When changing the frequency of PU Jog operation]


5. Press (MODE) to choose the parameter setting mode.



PRM indication is lit.




(The parameter number read previously appears.)



- 7. Press (SET) to show the currently set value. (5Hz)
- 8. Turn to set the value to " !!!!!".

 (10Hz)
- 9. Press (SET) to set.









Flicker...Parameter setting complete!!



NOTE

- When *Pr. 29 Acceleration/deceleration pattern selection* = "1" (S-pattern acceleration/deceleration A), the acceleration/deceleration time is the period of time required to reach *Pr. 3 Base frequency*.
- The Pr. 15 setting should be equal to or higher than the Pr. 13 Starting frequency.
- The JOG signal can be assigned to the input terminal using any of *Pr. 178 to Pr. 182 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.
- During jog operation, the second acceleration/deceleration via the RT signal cannot be selected. (The other second functions are valid. (Refer to page 227))
- When *Pr. 79 Operation mode selection* = "4", pressing RUN of the operation panel and FWD / REV of the parameter unit (FR-PU04/FR-PU07) starts the inverter and pressing STOP stops the inverter.
- This function is invalid when Pr. 79 = "3".



Parameters referred to


- Pr. 13 Starting frequency Refer to page 93
- Pr. 29 Acceleration/deceleration pattern selection Refer to page 94
- Pr. 20 Acceleration/deceleration reference frequency, Pr. 21 Acceleration/deceleration time increments 👺 Refer to page 91
- Pr. 79 Operation mode selection Refer to page 160
- Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108

4.6.3 Remote setting function (Pr. 59)

•Even if the operation panel is located away from the enclosure, you can use contact signals to perform continuous variable-speed operation, without using analog signals.

Parameter	ameter		Setting	Description		
Number	Name	Initial Value	Range	RH, RM, RL signal function	Frequency setting storage function	
		0	0	Multi-speed setting	-	
			1	Remote setting	With	
			2	Remote setting	Not used	
59	Remote function selection				Not used	
			3	Remote setting	(Turning STF/STR off	
			3		clears remotely-set	
					frequency.)	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 156)



^{*} External running frequency (other than multi-speed) or PU running frequency



(1) Remote setting function

•Use *Pr. 59* to select whether the remote setting function is used or not and whether the frequency setting storage function in the remote setting mode is used or not.

When *Pr.* 59 is set to any of "1 to 3" (remote setting function valid), the functions of the RH, RM and RL signals are changed to acceleration (RH), deceleration (RM) and clear (RL).

•When using the remote setting function, following frequencies can be compensated to the frequency set by RH and RM operation according to the operation mode.

During external operation (including Pr. 79 = "4") external frequency command other than multi-speed settings

(2) Frequency setting storage

•The frequency setting storage function stores the remotely-set frequency (frequency set by RH/RM operation) into the memory (EEPROM). When power is switched off once, then on, operation is resumed with that output frequency value. (Pr. 59 = 1)


<Frequency setting storage conditions>

- · Frequency at the point when the start signal (STF or STR) turns off
- The remotely-set frequency is stored every one minute after one minute has elapsed since turn off (on) of both the RH (acceleration) and RM (deceleration) signals. (The frequency is written if the present frequency setting compared with the past frequency setting every one minute is different. The state of the RL signal does not affect writing.)



NOTE

The range of frequency changeable by RH (acceleration) and RM (deceleration) is 0 to maximum frequency (Pr. 1 or Pr. 18 setting).
 Note that the maximum value of set frequency is (main speed + maximum frequency).



• When the acceleration or deceleration signal switches on, acceleration/deceleration time is as set in *Pr. 44 Second acceleration/deceleration time* and *Pr. 45 Second deceleration time*. Note that when long time has been set in *Pr. 7* or *Pr. 8*, the acceleration/deceleration time is as set in *Pr. 7* or *Pr. 8*. (when RT signal is off)

When the RT signal is on, acceleration/deceleration is made in the time set in Pr.~44 and Pr.~45, regardless of the Pr.~7 or Pr.~8 setting.

- Even if the start signal (STF or STR) is off, turning on the acceleration (RH) or deceleration (RM) signal varies the preset frequency. (When Pr. 59 = "1" or "2")
- When switching the start signal from ON to OFF, or changing frequency by the RH or RM signal frequently, set the frequency setting value storage function (write to EEPROM) invalid (Pr. 59 = "2, 3"). If set valid (Pr. 59 = "1"), frequency is written to EEPROM frequently, this will shorten the life of the EEPROM.
- The RH, RM, RL signals can be assigned to the input terminal using any *Pr. 178 to Pr. 182 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.
- · Also available for the network operation mode.






> REMARKS

During jog operation or PID control operation, the remote setting function is invalid.

Setting frequency is "0"

- Even when the remotely-set frequency is cleared by turning on the RL (clear) signal after turn off (on) of both the RH and RM signals, the inverter operates at the remotely-set frequency stored in the last operation if power is reapplied before one minute has elapsed since turn off (on) of both the RH and RM signals
- When the remotely-set frequency is cleared by turning on the RL (clear) signal after turn off (on) of both the RH and RM signals, the inverter operates at the frequency in the remotely-set frequency cleared state if power is reapplied after one minute has elapsed since turn off (on) of both the RH and RM signals.
- Output frequency (Hz) Remotely-set frequency stored last time Within 1 minute Remotely-set frequency stored last time **→**Time JON Acceleration (RH) Deceleration (RM) OFF Clear (RL) Forward rotation (STF) ON ONON Power supply — ON





 $\hat{\mathbb{N}}$ When selecting this function, re-set the maximum frequency according to the machine.



Parameters referred to

Pr. 1 Maximum frequency, Pr. 18 High speed maximum frequency Refer to page 78

Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 44 Second acceleration/deceleration time, Pr. 45 Second deceleration time 👺 Refer to page 91

Pr. 178 to Pr. 182 (input terminal function selection) TF Refer to page 108



4.7 Setting of acceleration/deceleration time and acceleration/deceleration pattern

Purpose	Parameter t	Parameter that should be Set		
Motor acceleration/deceleration time setting	Acceleration/deceleration times	Pr. 7, Pr. 8, Pr. 20, Pr. 44, Pr. 45	91	
Starting frequency	Starting frequency and start-time hold	Pr. 13, Pr. 571	93	
Set acceleration/deceleration pattern suitable for application	Acceleration/deceleration pattern	Pr. 29	94	

4.7.1 Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 44, Pr. 45)

Used to set motor acceleration/deceleration time.

Set a larger value for a slower speed increase/decrease or a smaller value for a faster speed increase/decrease. For the acceleration time at automatic restart after instantaneous power failure, refer to *Pr. 611 Acceleration time at a restart (page 131)*.

Parameter Number	Name	Initial Value		Setting Range	Description
7	Acceleration time	FR-D740-080 or less FR-D720S-008 to 100 FR-D740-120 and 160	5s 10s	0 to 3600s	Motor acceleration time.
8	Deceleration time	FR-D740-080 or less FR-D720S-008 to 100 FR-D740-120 and 160	5s 10s	0 to 3600s	Motor deceleration time.
20 *1	Acceleration/ deceleration reference frequency	50Hz		1 to 400Hz	Frequency that will be the basis of acceleration/deceleration time. As acceleration/deceleration time, set the frequency change time from stop to <i>Pr. 20</i> .
44 *1	Second acceleration/ deceleration time	FR-D740-080 or less FR-D720S-008 to 100 FR-D740-120 and 160	5s 10s	0 to 3600s	Acceleration/deceleration time when the RT signal is on.
45 *1	Second deceleration time	9999		0 to 3600s 9999	Deceleration time when the RT signal is on. Acceleration time = deceleration time

^{*1} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

Pr. 20 (50Hz) Running frequency Time Acceleration time Pr. 7, Pr. 44 Pr. 8, Pr. 45

(1) Acceleration time setting (Pr. 7, Pr. 20)

- •Use *Pr. 7 Acceleration time* to set the acceleration time required to reach *Pr. 20 Acceleration/deceleration reference frequency* from 0Hz.
- •Set the acceleration time according to the following formula.

Acceleration time setting
$$= \frac{Pr. 20}{\text{Maximum operating}} \times \frac{\text{Acceleration time from stop to maximum operating frequency}}{\text{operating frequency}}$$

Example)When Pr. 20 = 50Hz (initial value), Pr. 13 = 0.5Hz, and acceleration can be made up to the maximum operating frequency of 40Hz in 10s

$$Pr. 7 = \frac{50\text{Hz}}{40\text{Hz} - 0.5\text{Hz}} \times 10\text{s} = 12.7\text{s}$$

Setting of acceleration/deceleration time and acceleration/ deceleration pattern

Deceleration time setting (Pr. 8, Pr. 20)

- •Use Pr. 8 Deceleration time to set the deceleration time required to reach 0Hz from Pr. 20 Acceleration/deceleration reference frequency.
- •Set the deceleration time according to the following expression.

Deceleration Deceleration time from maximum operating frequency to stop time setting Maximum operating frequency - Pr. 10

Example)When the frequency can be decelerated down to the maximum operating frequency of 40Hz in 10s with 120Hz set in Pr. 20 and 3Hz set in Pr. 10

$$Pr. 8 = \frac{120 \text{Hz}}{40 \text{Hz} - 3 \text{Hz}} \times 10 \text{s} = 32.4 \text{s}$$

(3) Set two kinds of acceleration/deceleration times (RT signal, Pr. 44, Pr. 45)

- Pr. 44 and Pr. 45 are valid when the RT signal is on.
- •When "9999" is set to Pr. 45, the deceleration time becomes equal to the acceleration time (Pr. 44).
- •For the RT signal, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.



- When the acceleration/deceleration pattern is S-pattern acceleration/deceleration A (refer to page 94), the acceleration/ deceleration time is the time required to reach Pr. 3 Base frequency.
- · Acceleration/deceleration time formula when the set frequency is the base frequency or higher

$$t = \frac{4}{9} \times \frac{T}{(Pr. 3)^2} \times f^2 + \frac{5}{9} T$$

T: Acceleration/deceleration time setting (s)

f: Set frequency (Hz)

· Guideline for acceleration/deceleration time at the Pr. 3 Base frequency of 50Hz (0Hz to set frequency)

Frequency setting (Hz) Acceleration/ deceleration time (s)	50	120	200	400
5	5	16	38	145
15	15	47	115	429

· Changing terminal assignment may affect the other functions. Make setting after confirming the function of each terminal.



REMARKS

- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 111)
- If the Pr. 20 setting is changed, the Pr. 125 and Pr. 126 (frequency setting signal gain frequency) settings do not change. Set Pr. 125 and Pr. 126 to adjust the gains.
- When the Pr. 7, Pr. 8, Pr. 44 and Pr. 45 settings are 0.03s or less, the acceleration/deceleration time is 0.04s. At that time, set Pr. 20 to "120Hz" or less.
- · Any value can be set to the acceleration/deceleration time but the actual motor acceleration/deceleration time cannot be made shorter than the shortest acceleration/deceleration time determined by the mecanical system J (moment of inertia) and motor torque.



Parameters referred to

Pr. 3 Base frequency Refer to page 80

Pr. 10 DC injection brake operation frequency Refer to page 104

Pr. 29 Acceleration/deceleration pattern selection Refer to page 94
Pr. 125, Pr. 126 (frequency setting gain frequency) Refer to page 148

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108




4.7.2 Starting frequency and start-time hold function (Pr. 13, Pr. 571)

You can set the starting frequency and hold the set starting frequency for a certain period of time. Set these functions when you need the starting torque or want to smooth motor drive at a start.

Parameter Number	Name	Initial Value	Setting Range	Description
13	Starting frequency	0.5Hz	0 to 60Hz	Frequency at start can be set in the range 0 to 60Hz. Starting frequency at which the start signal is turned on.
571	Restart coasting time	9999	0.0 to 10.0s 9999	Holding time of <i>Pr. 13 Starting frequency</i> . Holding function at a start is invalid

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)




(1) Starting frequency setting (Pr. 13)

- •Frequency at start can be set in the range 0 to 60Hz.
- You can set the starting frequency at which the start signal is turned on.



NOTE

The inverter will not start if the frequency setting signal is less than the value set in Pr. 13. For example, when 5Hz is set in Pr. 13, the motor will not start running until the frequency setting signal reaches 5Hz.



(2) Start-time hold function (Pr. 571)

- •This function holds during the period set in *Pr. 571* and the output frequency set in *Pr. 13 Starting frequency*.
- •This fnction performs initial excitation to smooth the motor drive at a start.



When Pr. 13 = "0Hz", the starting frequency is held at 0.01Hz.



NOTE

- When the start signal was turned off during start-time hold, deceleration is started at that point.
 - At switching between forward rotation and reverse rotation, the starting frequency is valid but the start-time hold function is invalid.



Note that when *Pr. 13* is set to any value equal to or lower than *Pr. 2 Minimum frequency*, simply turning on the start signal will run the motor at the preset frequency even if the command frequency is not input.



Parameters referred to


Pr. 2 Minimum frequency Refer to page 78

4.7.3 Acceleration/deceleration pattern (Pr. 29)

You can set the acceleration/deceleration pattern suitable for application.


Parameter Number	Name	Initial Value	Setting Range	Description
	Acceleration/deceleration		0	Linear acceleration/ deceleration
29		0	1	S-pattern acceleration/deceleration A
1	pattern selection		2	S-pattern acceleration/deceleration B

The above parameters can be set when Pr. 160 Extended function display selection ="0". (Refer to page 157)



(1) Linear acceleration/deceleration (Pr. 29 setting "0", initial value)

•For the inverter operation, the output frequency is made to change linearly (linear acceleration/deceleration) to prevent the motor and inverter from excessive stress to reach the set frequency during acceleration, deceleration, etc. when frequency changes. Linear acceleration/deceleration has a uniform frequency/time slope.



(2) S-pattern acceleration/deceleration A (Pr. 29 = "1")

•For machine tool spindle applications, etc.


Used when acceleration/deceleration must be made in a short time to a highspeed range of not lower than the base frequency.

In this acceleration/deceleration pattern, *Pr. 3 Base frequency* (fb) is the inflection point of the S pattern and you can set the acceleration/deceleration time appropriate for motor torque reduction in a constant-power operation range of base frequency (fb) or higher.



NOTE

As the acceleration/deceleration time of S-pattern acceleration/deceleration A, set the time taken until *Pr. 3 Base frequency* is reached, not *Pr. 20 Acceleration/deceleration reference frequency*.



(3) S-pattern acceleration/deceleration B (Pr. 29 = "2")

•For prevention of load shifting in conveyor and other applications.

Since acceleration/deceleration is always made in an S shape from current frequency (f2) to target frequency (f1), this function eases shock produced at acceleration/deceleration and is effective for load collapse prevention, etc.



Parameters referred to

Pr. 3 Base frequency Refer to page 80

Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 20 Acceleration/deceleration reference frequency Refer to page 91



4.8 Selection and protection of a motor

Purpose	Parameter that	should be Set	Refer to Page
Motor protection from overheat	Electronic thermal O/L relay Pr. 9, Pr. 51, Pr. 56		95
,	PTC thermistor protection	· · · · · · · · · · · · · · · · · · ·	
Use the constant torque motor	Applied motor	Pr. 71	98
The motor performance can be maximized for operation in magnetic flux vector control method.	Offline auto tuning	Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90, Pr. 96	100


4.8.1 Motor overheat protection (Electronic thermal O/L relay, PTC thermistor protection) (Pr. 9, Pr. 51, Pr. 561)

Set the current of the electronic thermal relay function to protect the motor from overheat. This feature provides the optimum protective characteristics, including reduced motor cooling capability, at low speed.

Parameter Number	Name	Initial Value	Setting Range	Description
9	Electronic thermal O/L relay	Inverter rated current	0 to 500A	Set the rated motor current.
51 *1	Second electronic thermal O/L relay *2	9999	0 to 500A 9999	Valid when the RT signal is on. Set the rated motor current. Second electronic thermal O/L relay invalid
561 *1	PTC thermistor protection level	9999	0.50 to 30kΩ 9999	Set the level (resistance value) when PTC thermistor protection activates. PTC thermistor protection is inactive.

- *1 The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)
- *2 When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.

(1) Electronic thermal O/L relay (Pr. 9) Electronic thermal O/L relay operation characteristic



This function detects the overload (overheat) of the motor and trips. (The operation characteristic is shown on the left)

- Set the rated current (A) of the motor in *Pr. 9*. (If the motor has both 50Hz and 60Hz rating and the *Pr. 3 Base frequency* is set to 60Hz, set the 1.1 times of the 60Hz rated motor current.)
- Set "0" in Pr. 9 when you do not want to operate the electronic thermal O/L relay, e.g. when using an external thermal relay with the motor. (Note that the output transistor protection of the inverter functions (E.THT).)
- When using a Mitsubishi constant-torque motor
 - 1) Set "1" or "13", "50", "53" in any of *Pr. 71*. (This provides a 100% continuous torque characteristic in the low-speed range.
 - 2) Set the rated current of the motor in Pr. 9.
- When a value 50% of the inverter rated output current (current value) is set to Pr. 9
- *2 The % value denotes the percentage to the inverter rated output current. It is not the percentage to the motor rated current.
- *3 When you set the electronic thermal O/L relay dedicated to the Mitsubishi constant-torque motor, this characteristic curve applies to operation at 6Hz or higher.




NOTE

- Fault by electronic thermal relay function is reset by inverter power reset and reset signal input. Avoid unnecessary reset and power-off.
- When multiple motors are operated by a single inverter, protection cannot be provided by the electronic thermal function. Install an external thermal relay to each motor.
- When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In this case, use an external thermal relay.
- A special motor cannot be protected by the electronic thermal relay function.
- The operation time of the transistor protection thermal shortens when the Pr. 72 PWM frequency selection setting increases.

(2) Set two different electronic thermal O/L relays (Pr. 51)

Use this function when running two motors of different rated currents individually by a single inverter. (When running two motors together, use external thermal relays.)

- •Set the rated current of the second motor to Pr. 51.
- •When the RT signal is on, thermal protection is provided based on the Pr. 51 setting.
- •For the terminal used for RT signal input, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.



Pr. 450	Pr. 9	Pr.51	RT =	OFF	RT :	= ON
Second applied motor	Electronic thermal O/L relay	Second electronic thermal O/L relay	First motor	Second motor	First motor	Second motor
		9999	×	×	×	×
9999	0	0	×	×	×	×
		0.01 to 500	×	Δ	×	0
		9999	0	×	0	×
9999	Other than 0	0	0	×	Δ	×
		0.01 to 500	0	Δ	Δ	0
		9999	×	×	×	×
Other than 9999	0	0	×	×	×	×
		0.01 to 500	×	Δ	×	0
		9999	0	Δ	Δ	0
Other than 9999	Other than 0	0	0	×	Δ	×
		0.01 to 500	0	Δ	Δ	0


- O... Output current value is used to perform integration processing.
- Δ... Output current is assumed as 0A to perform integration processing. (cooling processing)
- x... Electronic thermal relay function is not activated.

• REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 111)

(3) Electronic thermal relay function prealarm (TH) and alarm signal (THP signal)

100%: Electronic thermal O/L relay alarm operation value




- The alarm signal (THP) is output and electronic thermal relay function prealarm (TH) is displayed when the electronic thermal O/L relay cumulative value reaches 85% of the level set in Pr. 9 or Pr. 51. If it reaches 100% of the Pr. 9 Electronic thermal O/L relay setting, a motor overload trip (E.THM/E.THT) occurs.
- The inverter does not trip even when the alarm signal (THP) is output.
- For the terminal used for the THP signal output, assign the function by setting "8 (positive logic) or 108 (negative logic)" in *Pr. 190 or Pr. 192 (output terminal function selection)* .

(1)

NOTE

• Changing the terminal assignment using *Pr.190*, *Pr.192* (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

(4) External thermal relay input (OH signal)



connection example


- To protect the motor against overheat, use the OH signal when using an external thermal relay or the built-in thermal protector of the motor.
- When the thermal relay operates, the inverter trips and outputs the fault signal (E.OHT).
- For the terminal used for OH signal input, assign the function by setting "7" to any of *Pr. 178 to Pr.182 (input terminal function selection)*.



NOTE

• Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

(5) PTC thermistor protection (Pr. 561)



TN: Rated operational temperature

- Terminal 2 and terminal 10 are available for inputting of motor built-in PTC thermistor output. When the PTC thermistor input reaches to the resistance value set in *Pr. 561 PTC thermistor* protection level, inverter outputs PTC thermistor operation error signal (E.PTC) and trips.
- Check the characteristics of the using PTC thermistor, and set the resistance value within a protection providing temperature TN, just around the center or R1 and R2 in a left figure. If the *Pr*: 561 setting is closer to R1 or R2, the working temperature of protection goes higher (protection works later), or lower (protection works earlier).
- PTC thermistor resistance can be displayed in operation panel, parameter unit (FR-PU07) (Refer to page 123), or RS-485 communication (Refer to page 175) when PTC thermistor protection is active (Pr. 561 ≠ "9999").

REMARKS

• When using terminal 2 as PTC thermistor input (*Pr.* 561 ≠ "9999"), terminal 2 is not available for analog frequency command. Also unavailable when using terminal 2 for PID control and Dancer control. When PID control and Dancer control is not active (*Pr.* 128 PID action selection = "0"), terminal 4 functions as follows.

• For the power supply terminal of PTC thermistor input, do not use power supply other than terminal 10 (external power supply, etc). PTC thermistor does not work properly.

Parameters referred to

Pr. 71 Applied motor Refer to page 98

Pr. 72 PWM frequency selection Refer to page 143

Pr. 79 Operation mode selection Refer to page 160 Pr. 128 PID action selection Refer to page 207

Pr. 128 PID action selection Refer to page 20/

Pr. 178 to Pr. 182 (input terminal function selection) 🐨 Refer to page 108 Pr. 190, Pr. 192 (output terminal function selection) 🐨 Refer to page 114

4.8.2 Applied motor (Pr. 71, Pr. 450)

Setting of the used motor selects the thermal characteristic appropriate for the motor.

Setting is required to use a constant-torque motor. Thermal characteristic of the electronic thermal relay function suitable for the motor is set.

When general-purpose magnetic flux vector is selected, the motor constants (SF-JR, SF-HR, SF-JRCA, SF-HRCA, etc.) necessary for control are selected as well.

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0, 1, 3, 13, 23, 40, 43, 50, 53	Selecting the standard motor or constant-torque motor sets the corresponding motor thermal characteristic.
			0, 1	Set when using the second motor.
450	Second applied motor	9999	9999	Second motor is invalid (thermal characteristic of the first motor (<i>Pr. 71</i>))

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Set the motor to be used

Refer to the following list and set this parameter according to the motor used.

Pr. 71 (Pr. 450) Setting		The second of the first of the	Motor (O: Used motor)		
Pr. 71	Pr. 450	Thermal Characteristic of the Electron	Characteristic of the Electronic Thermal Relay Function		
(<i>Pr. 71</i> init	(Pr. 71 initial value) Thermal characteristics of a standard motor			0	
1 Thermal characteristics of the Mits		Thermal characteristics of the Mitsubishi const	ant-torque motor		0
40	_	Thermal characteristic of Mitsubishi high efficie	nal characteristic of Mitsubishi high efficiency motor (SF-HR)		
50	_	Thermal characteristic of Mitsubishi constant to	characteristic of Mitsubishi constant torque motor (SF-HRCA)		O *2
3	_	Standard motor		0	
13	_	Constant-torque motor	1		0
23	_	Mitsubishi standard motor (SF-JR 4P 1.5kW or less)	Select "Offline auto tuning setting"	0	
43	_	Mitsubishi high efficiency motor (SF-HR)	1	0 *1	
53	_	Mitsubishi constant-torque motor (SF-HRCA)	1		O *2
_	9999 (initial value)	Without second applied motor			

^{*1} Motor constants of Mitsubishi high efficiency motor SF-HR.

REMARKS

- When performing offline auto tuning, set any of "3, 13, 23, 43, 53" in *Pr. 71*. (Refer to *page 100* for offline auto tuning.)
- For the FR-D740-120 and 160, the *Pr. 0 Torque boost* and *Pr. 12 DC injection brake operation voltage* settings are automatically changed according to the *Pr. 71* setting as follows.

Automatic Change	Standard Motor	Constant-torque Motor	
Parameter	Setting *1	Setting *2	
Pr. 0	3%	2%	
Pr. 12	4%	2%	

^{*1} Pr. 71 setting: 0, 3, 23, 40, 43

^{*2} Motor constants of Mitsubishi constant-torque motor SF-HRCA.

^{*2} Pr. 71 setting: 1, 13, 50, 53



(2) Use two motors (Pr. 450)

- Set Pr. 450 Second applied motor to use two different motors with one inverter.
- When "9999" (initial value) is set, no function is selected.
- When a value other than 9999 is set in Pr. 450, the second motor is valid when the RT signal turns on.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.



(I) REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 111)



• Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect other functions. Make setting after confirming the function of each terminal.



Net this parameter correctly according to the motor used.

Incorrect setting may cause the motor to overheat and burn.

Set the electronic thermal relay function to the thermal characteristic for the constant-torque motor when using a geared motor (GM-G, GM-D, GM-SY, GM-HY2 series) to perform general-purpose magnetic-flux vector control.



Parameters referred to

Pr. 0 Torque boost Refer to page 69 Pr. 12 DC injection brake operation voltage Te Refer to page 104 Pr. 80 Motor capacity Refer to page 100

4.8.3 To exhibit the best performance of the motor performance (offline auto tuning) (Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90, Pr. 96)

The motor performance can be maximized with offline auto tuning.

•What is offline auto tuning?

When performing general-purpose magnetic flux vector control, the motor can be run with the optimum operating characteristics by automatically measuring the motor constants (offline auto tuning) even when each motor constants differs, other manufacturer's motor is used, or the wiring length is long.

Parameter Number	Name	Initial Value		Setting Range	Description		
71	Applied motor	0		0		0, 1, 3, 13, 23, 40, 43, 50, 53	By selecting a standard motor or constant- torque motor, thermal characteristic and motor constants of each motor are set.
80	Motor capacity	9999		0.1 to 7.5kW	Applied motor capacity.		
00	Motor capacity	9999		9999	V/F control		
82	Motor excitation current	9999		9999		0 to 500A	Tuning data (The value measured by offline auto tuning is automatically set.)
				9999	Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants.		
83	Motor rated voltage	200V class 200V 400V class 400V		0 to 1000V	Rated motor voltage (V).		
84	Rated motor frequency	50Hz		10 to 120Hz	Rated motor frequency (Hz).		
90	Motor constant (R1)	9999		0 to 50Ω, 9999	Tuning data (The value measured by offline auto tuning is automatically set.) 9999: Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants.		
				0	Offline auto tuning is not performed		
96	Auto tuning setting/ status	0		0		11	For general-purpose magnetic flux vector control Offline auto tuning is performed without motor running. (motor constant (R1) only) Offline auto tuning for V/F control (automatic
				21	restart after instantaneous power failure (with frequency search)) (Refer to page 134)		

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Before performing offline auto tuning



POINT

- This function is made valid only when a value other than "9999" is set in *Pr.* 80 and general-purpose magnetic flux vector control is selected.
- · You can copy the offline auto tuning data (motor constants) to another inverter with the PU (FR-PU07).
- Even when motors (other manufacturer's motor, SF-JRC, etc.) other than Mitsubishi standard motor, high
 efficiency motor (SF-JR, SF-HR 0.2kW or more), and Mitsubishi constant-torque motor (SF-JRCA SF-HRCA
 four-pole 0.4kW to 7.5kW) are used or the wiring length is long, using the offline auto tuning function runs the
 motor with the optimum operating characteristics.
- Tuning is enabled even when a load is connected to the motor.
 As the motor may run slightly, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs (caution is required especially in elevator). Note that tuning performance is unaffected even if the motor runs slightly.
- Reading/writing/copy of motor constants (*Pr. 90*) and motor excitation current tuned by offline auto tuning are enabled.
- The offline auto tuning status can be monitored with the operation panel and PU (FR-PU04/FR-PU07).
- Do not connect a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) between the inverter and motor.

Check the following before performing offline auto tuning.

- Make sure general-purpose magnetic flux vector control (*Pr.* 80) is selected. (Tuning can be performed even under V/F control selected by turning on X18.)
- · A motor should be connected. Note that the motor should be at a stop at a tuning start.
- The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity should be 0.1kW or more)
- The maximum frequency is 120Hz.
- A high-slip motor, high-speed motor and special motor cannot be tuned.
- As the motor may run slightly, fix the motor securely with a mechanical brake or make sure that there will be no problem
 in safety if the motor runs (caution is required especially in elevator). Note that tuning performance is unaffected even if
 the motor runs slightly.
- Offline auto tuning will not be performed properly if it is performed with a surge voltage suppression filter (FR-ASFH/FR-BMF-H) connected between the inverter and motor. Remove it before starting tuning.

(2) Setting

- 1) Select general-purpose magnetic flux vector control (*Refer to page 70*).
- 2) Set "11" in Pr. 96 Auto tuning setting/status.
 - Tuning motor constants (R1) only without running the motor. (It takes approximately 9s until tuning is completed.)
- 3) Set the rated motor current (initial value is rated inverter current) in Pr. 9 Electronic thermal O/L relay. (Refer to page 95)
- 4) Set the rated voltage of motor (initial value is 200V/400V) in *Pr. 83 Motor rated voltage* and rated motor frequency (initial value is 50Hz) in *Pr. 84 Rated motor frequency*.
 - (For a Japanese standard motor, etc. which has both 50Hz and 60Hz rated values, use it with an initial value(200V/60Hz or 400V/60Hz).
- 5) Set Pr. 71 Applied motor according to the motor used.

Motor	Motor				
	SF-JR	3			
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	23			
Mitsubishi high efficiency motor	SF-HR	43			
	Others	3			
	SF-JRCA 4P	13			
Mitsubishi constant-torque motor	SF-HRCA	53			
	Others (SF-JRC, etc.)	13			
Other standard motor	_	3			
Other constant-torque motor	_	13			

$\overline{\gamma}$

(3) Execution of tuning



POINT

Before performing tuning, check the monitor display of the operation panel or parameter unit (FR-PU04/FR-PU07) if the inverter is in the status for tuning. (Refer to 2) below) When the start command is turned on under V/F control, the motor starts.

1) When performing tuning or PU operation, press (RUN) of the operation panel or FWD or REV of the parameter unit (FR-PU04/FR-PU07).

For external operation, turn on the run command (STF signal or STR signal). Tuning starts.



NOTE

- To force tuning to end, use the MRS or RES signal or press (STOP) of the operation panel. (Turning the start signal (STF signal or STR signal) off also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid: (initial value)
- Input terminal <valid signal> STF, STR
- Output terminal RUN, AM, A, B, C

Note that the progress status of offline auto tuning is output in five steps from AM when speed and output frequency are selected.

- Since the RUN signal turns on when tuning is started, caution is required especially when a sequerence which
 releases a mechanical brake by the RUN signal has been designed.
- When executing offline auto tuning, input the run command after switching on the main circuit power (R/L1, S/L2, T/L3) of the inverter.
- Do not perform ON/OFF switching of the second function selection signal (RT) during execution of offline auto tuning. Auto tuning is not excecuted properly.
- 2) Monitor is displayed on the operation panel and parameter unit (FR-PU04/FR-PU07) during tuning as below.

	Parameter Unit (FR-PU04/FR-PU07) Display	Operation Panel Indication
Pr. 96 setting	11	11
(1) Setting	READ:List 11 STOP PU	, i mon ext
(2)Tuning in progress	TUNE 12 STF FWD PU	12 EXT
(3)Normal end		Flickering
(4)Error end (when inverter protective function operation is activated)	IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	3 <u>ex</u>

REMARKS

- It takes approximately 9s until tuning is completed.
- The set frequency monitor displayed during the offline auto tuning is 0Hz.



- 3) When offline auto tuning ends, press (STOP) of the operation panel during PU operation. For external operation, turn off the start signal (STF signal or STR signal) once. This operation resets the offline auto tuning and the PU's monitor display returns to the normal indication.
- 4) If offline auto tuning ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

(Without this operation, next operation cannot be started.)

Error Display	Error Cause	Remedy
8	Forced end	Set "11" in Pr. 96 and perform tuning again.
9	Inverter protective function operation	Make setting again.
91	Current limit (stall prevention) function was activated.	Set "1" in Pr. 156.
92	Converter output voltage reached 75% of rated value.	Check for fluctuation of power supply voltage.
93	Calculation error	Check the motor wiring and make setting again.
93	A motor is not connected.	Set the rated current of the motor in Pr. 9.

5) When tuning is ended forcibly by pressing (STOP) or turning off the start signal (STF or STR) during tuning, offline auto tuning does not end normally. (The motor constants have not been set.) Perform an inverter reset and restart tuning.



- . The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again.
- An instantaneous power failure occurring during tuning will result in a tuning error. After power is restored, the inverter goes into the normal operation mode. Therefore, when STF (STR) signal is on, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the ordinary mode. Note that if a fault retry has been set, retry is

!CAUTION

As the motor may run slightly during offline auto tuning, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs. Note that if the motor runs slightly, tuning performance is unaffected.



Parameters referred to

Pr. 9 Electronic thermal O/L relay Refer to page 110 Pr. 71 Applied motor Refer to page 95

Pr. 80 Motor capacity Refer to page 70
Pr. 156 Stall prevention operation selection Refer to page 74

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108

Pr. 190, Pr. 192 (output terminal function selection) Refer to page 114

4.9 Motor brake and stop operation


Purpose	Parameter th	Refer to Page	
Motor braking torque adjustment	DC Injection brake Pr. 10 to Pr. 12		104
Improve the motor braking torque with	Selection of a	Pr. 30, Pr. 70	105
an option	regenerative brake	nerative brake	
Coast the motor to a stop	Selection of motor	Pr. 250	107
Coast the motor to a stop	stopping method	F1. 230	107

4.9.1 DC injection brake (Pr. 10 to Pr. 12)

The DC injection brake can be operated at a motor stop to adjust the stop timing and braking torque. In DC injection brake operation, DC voltage is directly applied to the motor to prevent the motor shaft from rotating. The motor will not return to the original position if the motor shaft rotates due to external force.

Parameter Number	Name	Initial Value		Setting Range	Description
10	DC injection brake operation frequency	3Hz		0 to 120Hz	Operation frequency of the DC injection brake.
11	DC injection brake	0.5-		0	DC injection brake disabled
- ''	operation time	0.5s		0.1 to 10s	Operation time of the DC injection brake.
	DC injection brake	FR-D720S-008 and 014	6%		DC injection brake voltage (torque). When "0" is
12	operation voltage	FR-D740-012 to 160 FR-D720S-025 or more	4%	0 to 30%	set, DC injection brake is disabled.

The above parameters can be set when Pr. 160 Extended function display selection ="0". (Refer to page 157)



(1) Operation frequency setting (Pr. 10)

• After the frequency at which the DC injection brake will be operated is set to *Pr. 10*, the DC voltage is applied to the motor when this frequency is reached during deceleration.

Operation frequency (2) Operation time setting (*Pr. 11*)

- •In Pr. 11, set the time of the DC injection brake.
- •When the motor does not stop due to large load moment (J), increasing the setting produces an effect.
- •When *Pr. 11* = "0s", the DC injection brake is disabled. (At a stop, the motor coasts.)

(3) Operation voltage (torque) setting (Pr. 12)

- Use Pr. 12 to set the percentage to the power supply voltage.
- When Pr. 12 = "0%", the DC injection brake is disabled. (At a stop, the motor coasts.)
- •When using the constant-torque motor (SF-JRCA) and energy saving motor (SF-HR, SF-HRCA), change the *Pr. 12* setting as follows:

SF-JRCA:

FR-D740-080 or less, FR-D720S-100 or less...4%

FR-D740-120 or more...2%

SF-HR, SF-HRCA:

FR-D740-080 or less, FR-D720S-100 or less...4%

FR-D740-120 or more...3%





REMARKS

- For the FR-D740-120 and 160, when the Pr. 12 setting is the following, changing the Pr. 71 Applied motor setting automatically changes the Pr. 12 setting. Therefore, it is not necessary to change the Pr. 12 setting.
 - (a) When 4% (initial value) is set in Pr. 12
 - The Pr. 12 setting is automatically changed to 2% if the Pr. 71 value is changed from the value selecting the standard motor (0, 3, 23, 40, 43) to the value selecting the constant torque motor (1, 13, 50, 53).
 - (b) When 2% is set in Pr. 12
 - The Pr. 12 setting is automatically changed to 4% (initial value) if the Pr. 71 value is changed from the value selecting the constant torque motor (1, 13, 50, 53) to the value selecting the standard motor (0, 3, 23, 40, 43).
- Even if the Pr. 12 setting is increased, braking torque is limited so that the output current is within the rated inverter current.



CAUTION

As stop holding torque is not produced, install a mechanical brake.



Parameters referred to

Pr. 13 Starting frequency Refer to page 93 Pr. 71 Applied motor Refer to page 98

4.9.2 Selection of a regenerative brake (Pr. 30, Pr. 70)

- When making frequent starts/stops, use the optional brake resistor (MRS type), high-duty brake resistor (FR-ABR) and brake unit (FR-BU2) to increase the regenerative brake duty.
- Use a power regeneration common converter (FR-CV) for continuous operation in regeneration status. Use the high power factor converter (FR-HC) to reduce harmonics, improve the power factor, or continuously use the regenerative status.

Parameter	Name	Initial	Setting	Description
Number	Name	Value	Range	Description
				Without regenerative function,
				Brake resistor (MRS type),
			0	Brake unit (FR-BU2)
30	Regenerative function selection	0		Power regeneration common converter (FR-CV)
30				High power factor converter (FR-HC)
			1	High-duty brake resistor (FR-ABR)
			2	High power factor converter (FR-HC) when automatic
				restart after instantaneous power failure is selected
70	Special regenerative		0 to 30%	Brake duty when using the high-duty brake resistor
70	brake duty	0%	0 10 30%	(FR-ABR)

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) When using the brake resistor (MRS type), brake unit (FR-BU2), power regeneration common converter (FR-CV), and high power factor converter (FR-HC).

•Set Pr. 30 to "0" (initial value). The Pr. 70 setting is made invalid.

At this time, the regenerative brake duty is as follows.

- Assign the inverter operation enable signal (X10) to the contact input terminal. To make protective coordination with the FR-HC and FR-CV, use the inverter operation enable signal to shut off the inverter output. Input the RDY signal of the FR-HC (RDYB signal of the FR-CV).
- •For the terminal used for X10 signal input, assign its function by setting "10" (X10) to any of Pr. 178 to Pr. 182.

(2) When using the high-duty brake resistor (FR-ABR) (FR-D720S-025 or more, FR-D740-012 or more)


- •Set "1" in Pr. 30.
- •Set "10%" in Pr. 70.

When a high power factor converter (FR-HC) is used and automatic restart after instantaneous power failure function is made valid.

- •When automatic restart after instantaneous power failure function of both the FR-HC and inverter is made valid (when a value other than "9999" is set in Pr. 57 Restart coasting time), set "2" in Pr. 30.
- •Set Pr. 70 to "0%" (initial value).
- •When the FR-HC detects power failure during inverter operation, the RDY signal turns on, resulting in the motor coasting. Turning the RDY signal off after power restoration, the inverter detects the motor speed (depends on the Pr.162 Automatic restart after instantaneous power failure selection) and restarts automatically after instantaneous power failure.

(4) Regenerative brake duty alarm output and alarm signal (RBP signal)

100%: regenerative overvoltage protection operation value



- •[RB] appears on the operation panel and an alarm signal (RBP) is output when 85% of the regenerative brake duty set in Pr. 70 is reached. If the regenerative brake duty reaches 100% of the Pr. 70 setting, a regenerative overvoltage (E.OV1 to E.OV3) occurs. Note that [RB] is not displayed when Pr. 30 = "0".
- •The inverter does not trip even when the alarm (RBP) signal is output.
- •For the terminal used for the RBP signal output, assign the function by setting "7 (positive logic) or 107 (negative logic)" in Pr. 190 or Pr. 192 (output terminal function selection).



> REMARKS

- The MRS signal can also be used instead of the X10 signal. (Refer to page 110)
- Refer to page 28 to 32 for connecting the brake resistor (MRS type), high-duty brake resistor (FR-ABR), brake unit (FR-BU2), high power factor converter (FR-HC), and power regeneration common converter (FR-CV).



When terminal assignment is changed using Pr. 178 to Pr. 182 (input terminal function selection) and Pr. 190, Pr. 192 (output terminal function selection), the other functions may be affected. Make setting after confirming the function of each terminal. (Refer to page 108)





The value set in Pr. 70 must not exceed the setting of the brake resistor used. Otherwise, the resistor can overheat.



Parameters referred to

Pr. 57 Restart coasting time Refer to page 131 Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108 Pr. 190, Pr. 192 (output terminal function selection) Refer to page 114



4.9.3 Stop selection (Pr. 250)


Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns off.


Used to stop the motor with a mechanical brake, etc. together with switching off of the start signal.

You can also select the operations of the start signals (STF/STR). (Refer to *page 112* for start signal selection)

		Initial Value		De	scription
Parameter	Name		0.40	Start signal (STF/	
Number	Name	iiiiliai vaiue	Setting Range	STR)	Stop operation
				(Refer to page 112)	
				STF signal:	The motor is coasted to a stop
			0 to 100s	Forward rotation start	when the preset time elapses
			0 10 1005	STR signal:	after the start signal is turned
				Reverse rotation start	off.
			1000s to 1100s	STF signal: Start signal	The motor is coasted to a stop
				STR signal:	(Pr. 250 - 1000)s after the start
250	Stop selection	9999		Forward/reverse signal	signal is turned off.
250	Stop Selection	9999		STF signal:	
			9999	Forward rotation start	
			9999	STR signal:	When the start signal is turned
				Reverse rotation start	off, the motor decelerates to
				STF signal: Start signal	stop.
			8888	STR signal:	
				Forward/reverse signal	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)





(1) Decelerate the motor to a stop

- •Set Pr. 250 to "9999" (initial value) or "8888".
- •The motor decelerates to a stop when the start signal (STF/STR) turns off.

(2) Coast the motor to a stop

- •Use *Pr. 250* to set the time from when the start signal turns off until the output is shut off. When any of "1000 to 1100" is set, the output is shut off in (*Pr. 250* 1000)s.
- •The output is shut off when the time set in *Pr. 250* has elapsed after the start signal had turned off. The motor coasts to a stop.
- •The RUN signal turns off when the output stops.

REMARKS

Stop selection is invalid when the following functions are activated.

- Power failure stop function (Pr. 261)
- PU stop (Pr. 75)
- Deceleration stop because of communication error (Pr. 502)
- Jog operation mode



NOTE

•When the start signal is turned on again during motor coasting, the motor starts at Pr. 13 Starting frequency.



Parameters referred to

Pr. 7 Acceleration time, Pr. 8 Deceleration time Refer to page 91 Pr. 13 Starting frequency Refer to page 93

4.10 Function assignment of external terminal and control

Purpose	Parameter	that should be Set	Refer to Page
Assign function to input terminal	Input terminal function selection	Pr. 178 to Pr. 182	108
Set MRS signal (output shutoff) to NC contact specification	MRS input selection	Pr. 17	110
Assign start signal and forward/ reverse command to other signals	Start signal (STF/STR) operation selection	Pr. 250	112
Assign function to output terminal	Output terminal function assignment	Pr. 190, Pr. 192	114
Detect output frequency	Up-to-frequency sensitivity Output frequency detection	Pr. 41 to Pr. 43	118
Detect output current	Output current detection Zero current detection	Pr. 150 to Pr. 153, Pr. 166, Pr. 167	119
Remote output function	Remote output	Pr. 495, Pr. 496	121

4.10.1 Input terminal function selection (Pr. 178 to Pr. 182)

Use these parameters to select/change the input terminal functions.

Parameter Number	Name	Initial Value	Initial Signal	Setting Range	
178	STF terminal function selection	60	STF (forward rotation command)	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 37, 60, 62, 65 to 67, 9999	
179	STR terminal function selection	61	STR (reverse rotation command)	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 37, 61, 62, 65 to 67, 9999	
180	RL terminal function selection	0	RL (low-speed operation command)		
181	RM terminal function selection	1	RM (middle speed operation command)	0 to 5, 7, 8, 10, 12, 14, 16, 18, 24, 25, 37, 62, 65 to 67, 9999	
182	RH terminal function selection	2	RH (high-speed operation command)		

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



(1) Input terminal function assignment

- •Using Pr. 178 to Pr. 182, set the functions of the input terminals.
- •Refer to the following table and set the parameters:

Setting	Signal		Function	Related Parameters	Refer to Page
0	RL	<i>Pr.</i> 59 = 0 (initial value)	Low-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27 Pr.232 to Pr.239	84
		Pr. 59 ≠ 0 *1	Remote setting (setting clear)	Pr. 59	88
1	RM	Pr. 59 = 0 (initial value)	Middle-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	84
		Pr. 59 ≠ 0 *1	Remote setting (deceleration)	Pr. 59	88
2	RH	Pr. 59 = 0 (initial value)	High-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	84
		Pr. 59 ≠ 0 *1	Remote setting (acceleration)	Pr. 59	88
3	RT	Second function selection	n	Pr. 44 to Pr. 51	111
4	AU	Terminal 4 input selectio	n	Pr. 267	145
5	JOG	Jog operation selection		Pr. 15, Pr. 16	86
7	ОН	External thermal relay in	put *2	Pr. 9	95
8	REX	15-speed selection (combination with three speeds RL, RM, RH)		Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	84
10	X10	Inverter run enable signal (FR-HC, FR-CV connection)		Pr. 30, Pr. 70	105
12	X12	PU operation external interlock		Pr. 79	160
14	X14	PID control valid terminal		Pr. 127 to Pr. 134	207
16	X16	PU-external operation sweeternal operation)	witchover (turning on X16 selects	Pr. 79, Pr. 340	167
18	X18	V/F switchover (V/F cont	trol is exercised when X18 is on)	Pr. 80	70, 100
24	MRS	Output stop		Pr. 17	110
25	STOP	Start self-holding selection	on	_	112
37	X37	Traverse function selecti	on	Pr. 592 to Pr. 597	221
60	STF	Forward rotation (assign	ed to STF terminal (Pr. 178) only)	_	112
61	STR	Reverse rotation comma only)	nd (assigned to STR terminal (Pr. 179)	_	112
62	RES	Inverter reset		_	_
65	X65	PU/NET operation switchover (turning on X65 selects PU operation)		Pr. 79, Pr. 340	168
66	X66	External/NET operation : NET operation)	switchover (turning on X66 selects	Pr. 79, Pr. 340	168
67	X67	Command source switch and Pr. 339 commands va	nover (turning on X67 makes <i>Pr. 338</i> alid)	Pr. 338, Pr. 339	171
9999	_	No function		_	_

^{*1} When Pr. 59 Remote function selection ≠ "0", the functions of the RL, RM and RH signals are changed as given in the table.

^{*2} The OH signal turns on when the relay contact "opens".



NOTE

- Changing the terminal assignment using Pr.178 to Pr.182 (input terminal function selection) may affect the other functions.

 Make setting after confirming the function of each terminal.
- · One function can be assigned to two or more terminals. In this case, the terminal inputs are ORed.
- The priorities of the speed commands are in order of jog > multi-speed setting (RH, RM, RL, REX) > PID (X14).
- When the X10 signal (FR-HC, FR-CV connection-inverter operation enable signal) is not set or when the PU operation external interlock (X12) signal is not assigned with *Pr.79 Operation mode selection* set to "7", the MRS signal shares this function.
- Use common terminals to assign multi-speeds (7 speeds) and remote setting. They cannot be set individually.
 (Common terminals are used since these functions are designed for speed setting and need not be set at the same time.)
- When V/F control is selected by V/F switchover (X18 signal), second function is also selected at the same time.
 Control between V/F and general-purpose magnetic flux can not be switched during operation. In case control is switched between V/F and general-purpose magnetic flux, only second function is selected.
- Turning the AU signal on makes terminal 2 (voltage input) invalid.

(2) Response time of each signal


The response time of the X10 signal and MRS signal is within 2ms.
 The response time of other signals is within 20ms.


4.10.2 Inverter output shutoff signal (MRS signal, Pr. 17)

The inverter output can be shut off by the MRS signal. Also, logic for the MRS signal can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Normally open input
	17 MRS input selection	0	2	Normally closed input
17			2	(NC contact input specifications)
17	MICS IIIput selection	U		External terminal: Normally closed input
			4	(NC contact input specifications)
				Communication: Normally open input

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)





(1) Output shutoff signal (MRS signal)

• Turning on the output shutoff signal (MRS) during inverter running shuts off the output immediately.

Set "24" in any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign a function to the MRS signal.

- •MRS signal may be used as described below.
- (a) When mechanical brake (e.g. electromagnetic brake) is used to stop motor

The inverter output is shut off when the mechanical brake operates.

- (b) To provide interlock to disable operation by the inverter With the MRS signal on, the inverter cannot be operated if the start signal is entered into the inverter.
- (c) Coast the motor to a stop.

 When the start signal is turned off, the inverter decelerates the motor

to a stop in the preset deceleration time, but when the MRS signal is turned on, the motor coasts to a stop.

(2) MRS signal logic inversion (Pr. 17)

• When *Pr. 17* is set to "2", the MRS signal (output stop) can be changed to the normally closed (NC contact) input specification. When the MRS signal turns on (opens), the inverter shuts off the output.

(3) Assign a different action for each MRS signal input from communication and external terminal (Pr. 17 = "4")

•When *Pr.* 17 is set to "4", the MRS signal from external terminal (output stop) can be changed to the normally closed (NC contact) input, and the MRS signal from communication can be changed to the normally open (NO contact) input. This function is useful to perform operation by communication with MRS signal from external terminal remained on.

External MRS	Communication MRS	Pr. 17 Setting				
LAGINAL WING	Communication with	0	2	4		
OFF	OFF	Operation enabled	Output shutoff	Output shutoff		
OFF	ON	Output shutoff	Output shutoff	Output shutoff		
ON	OFF	Output shutoff	Output shutoff	Operation enabled		
ON	ON	Output shutoff	Operation enabled	Output shutoff		



> REMARKS

• The MRS signal can shut off the output, independently of the PU, external or network operation mode.



NOTE

• Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 178 to Pr. 182 (input terminal function selection) 👺 Refer to page 108




4.10.3 Condition selection of function validity by second function selection signal (RT)

- You can select the second function using the RT signal.
- When the RT signal turns on, the second function becomes valid.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the function.
- The second function has the following applications.
- (a) Switching between normal use and emergency use
- (b) Switching between heavy load and light load
- (c) Changing of acceleration/deceleration time by broken line acceleration/deceleration
- (d) Switching of characteristic between the main motor and sub motor

Second function connection diagram

Start Second function selection High speed Middle speed RM

Second acceleration/deceleration time



Function	First Function	Second Function	Refer to
	Parameter Number	Parameter Number	Page
Torque boost	Pr. 0	Pr. 46	69
Base frequency	Pr. 3	Pr. 47	80
Acceleration time	Pr. 7	Pr. 44	91
Deceleration time	Pr. 8	Pr. 44, Pr. 45	91
Electronic thermal O/L relay	Pr. 9	Pr. 51	95
Stall prevention	Pr. 22	Pr. 48	74
Applied motor	Pr. 71	Pr. 450	98



NOTE

- When the RT signal is on, the above second function is selected at the same time.
- Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108

4.10.4 Start signal operation selection (STF, STR, STOP signal, Pr. 250)

You can select the operation of the start signal (STF/STR).


Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns off. Used to stop the motor with a mechanical brake, etc. together with switching off of the start signal. (Refer to page 107 for stop selection)

Parameter	Parameter Name Initial			Description		
			Setting Range	Start signal	Stop operation	
Number		value		(STF/STR)	Refer to page 107	
				STF signal: Forward rotation start	The motor is coasted to a stop	
			0 to 100s	STR signal: Reverse rotation start	when the preset time elapses	
		9999		311 Signal. Neverse rotation start	after the start signal is turned off.	
			1000s to 1100s	STF signal: Start signal	When the setting is any of 1000s to	
250	Stop			STR signal: Forward/reverse signal	1100s, the inverter coasts to a stop	
250	selection	9999			in (Pr. 250 - 1000)s.	
			9999	STF signal: Forward rotation start	When the start signal is turned	
			3333	STR signal: Reverse rotation start	off, the motor decelerates to	
			8888	STF signal: Start signal	stop.	
			0000	STR signal: Forward/reverse signal	διυμ.	


The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Two-wire type connection (STF, STR signal)

- •The two-wire connection is shown below.
- In the default setting, the forward/reverse rotation signals (STF/STR) are used as start and stop signals. Turn on either of the forward and reverse rotation signals to start the motor in the corresponding direction. Switch on both or switch off (or both on) the start signal during operation to decelerate the inverter to a stop.
- •The speed setting signal may either be given by entering 0 to 10VDC across the speed setting input terminal 2-5, by setting the required values in *Pr. 4 to Pr. 6 Multi-speed setting (high, middle, low speeds)*, etc. (For multi-speed operation, refer to *page 84*.)
- •When Pr. 250 is set to any of "1000 to 1100, 8888", the STF signal becomes a start command and the STR signal a forward/reverse command.



2-wire connection example ($Pr. 25\theta$ = "9999")



2-wire connection example (Pr. 250 = "8888")


• REMARKS

- When Pr. 250 is set to any of "0 to 100, 1000 to 1100", turning off the start command coasts the inverter to a stop. (Refer to page 107)
- The STF and STR signals are assigned to the STF and STR terminals in the default setting. The STF signal can be assigned to *Pr. 178 STF terminal function selection*, and the STR signal to *Pr. 179 STR terminal function selection* only.



(2) Three-wire type (STF, STR, STOP signal)

- •The three-wire connection is shown below.
- •Turning the STOP signal on makes start self-holding function valid. In this case, the forward/reverse rotation signal functions only as a start signal.
- If the start signal (STF or STR) is turned on and then off, the start signal is held and makes a start. When changing the direction of rotation, turn STR (STF) on once and then off.
- •To stop the inverter, turning off the STOP signal once decelerates it to a stop.
- When using the STOP signal, set "25" in any of Pr.178 to Pr.182 to assign function.



REMARKS

- When the JOG signal is turned on to enable jog operation, the STOP signal becomes invalid.
- If the MRS signal is turned on to stop the output, the self-holding function is not canceled.

(3) Start signal selection

STF	STR	Pr. 250 Setting	Inverter Status	
317	SIK	0 to 100s, 9999	1000s to 1100s 8888	
OFF	OFF	Stop	Stop	
OFF	ON	Reverse rotation	σιορ	
ON	OFF	Forward rotation	Forward rotation	
ON	ON	Stop	Reverse rotation	



Parameters referred to

Pr. 4 to Pr. 6 (multi-speed setting) Refer to page 84
Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108

4.10.5 Output terminal function selection (Pr. 190, Pr. 192)

You can change the functions of the open collector output terminal and relay output terminal.

Parameter Number	Name		Initial Value	Initial Signal	Setting Range
190	RUN terminal function selection	Open collector output terminal	0	RUN (inverter running)	0, 1, 3, 4, 7, 8, 11 to 16, 25, 26, 46, 47, 64, 70, 90, 91, 93*, 95, 96, 98, 99, 100, 101, 103, 104,
192	A,B,C terminal function selection	Relay output terminal	99	ALM (fault output)	107, 108, 111 to 116, 125, 126, 146, 147, 164, 170, 190, 191, 193*, 195, 196, 198, 199, 9999

^{* &}quot;93" and "193" can not be set in Pr. 192.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Output signal list

- •You can set the functions of the output terminals.
- •Refer to the following table and set the parameters: (0 to 99: positive logic, 100 to 199: negative logic)

Setting					Related	Refer
Positive logic	Negative logic	Signal	Function	Operation	Parameter	to Page
0	100	RUN	Inverter running	Output during operation when the inverter output frequency rises to or above <i>Pr. 13 Starting frequency</i> .	_	116
1	101	SU	Up to frequency *1	Output when the output frequency is reached to the set frequency.	Pr. 41	118
3	103	OL	Overload alarm	Output while stall prevention function is activated.	Pr. 22, Pr. 23, Pr. 66	74
4	104	FU	Output frequency detection	Output when the output frequency reaches the frequency set in <i>Pr. 42</i> (<i>Pr. 43</i> for reverse rotation).	Pr. 42, Pr. 43	118
7	107	RBP	Regenerative brake pre-alarm	Output when 85% of the regenerative brake duty set in Pr : 70 is reached.	Pr. 70	105
8	108	THP	Electronic thermal O/L relay pre-alarm	Output when the electronic thermal value reaches 85% of the trip level. (Electronic thermal relay function protection (E.THT/E.THM) activates, when the value reached 100%.	Pr. 9, Pr. 51	95
11	111	RY	Inverter operation ready	Output when reset process is completed (when the inverter can be started by switching the start signal on or while it is running) after powering on inverter.	_	116
12	112	Y12	Output current detection	Output when the output current is higher than the $Pr. 150$ setting for longer than the time set in $Pr. 151$.	Pr. 150, Pr. 151	119
13	113	Y13	Zero current detection	Output when the output power is lower than the $Pr. 152$ setting for longer than the time set in $Pr. 153$.	Pr. 152, Pr. 153	119
14	114	FDN	PID lower limit	Output when the feedback value falls below the lower limit of PID control.	Pr. 127 to	
15	115	FUP	PID upper limit	Output when the feedback value rises above the upper limit of PID control	Pr. 134 Pr. 575 to Pr.	207
16	116	RL	PID forward/reverse rotation output	Output when forward rotation is performed in PID control.	577	
25	125	FAN	Fan fault output	Output at the time of a fan fault.	Pr. 244	225
26	126	FIN	Heatsink overheat pre-alarm	Output when the heatsink temperature reaches about 85% of the heatsink overheat protection providing temperature.	_	251
46	146	Y46	During deceleration at occurrence of power failure	Output when the power failure-time deceleration function is executed. (retained until release)	Pr. 261	137
47	147	PID	During PID control activated	Output during PID control.	Pr. 127 to Pr. 134 Pr. 575 to Pr. 577	207
64	164	Y64	During retry	Output during retry processing.	Pr. 65 to Pr. 69	139
70	170	SLEEP	PID output interruption	Output when the PID output interruption function is executed.	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577	207

Output to the terminal when a value is set to the parameter.

Output when an alarm (fan failure or communication error

The signal output is stopped when the fault is reset.

121

178,

225

117

496

Pr. 121,

Pr. 244

Setting				Related	Refer	
Positive logic	Negative logic	Signal	Function	Operation	Parameter	to Page
90	190	Y90	Life alarm	Output when any of the control circuit capacitor, main circuit capacitor and inrush current limit circuit or the cooling fan approaches the end of its service life.	Pr. 255 to Pr. 259	226
91	191	Y91	Fault output 3 (power-off signal)	Output when a fault occurs due to the internal circuit failure of the inverter wiring mistake.	_	117
93	193	Y93	Current average value monitor signal	Average current value and maintenance timer value are output as pulses. The signal can not be set in <i>Pr. 192 A,B,C terminal function selection</i> .	Pr. 555 to Pr. 557	231
95	195	Y95	Maintenance timer signal	Output when Pr. 503 rises to or above the Pr. 504 setting.	Pr. 503, Pr. 504	230
06	106	DEM	Domoto outnut	Output to the terminal when a value is get to the peremeter	Pr. 495, Pr.	121

Note that when the frequency setting is varied using an analog signal or of the operation panel, the output of the SU (up to frequency) signal may alternate on and off depending on that varying speed and the timing of the varying speed due to acceleration/deceleration time setting. (The output will not alternate on and off when the acceleration/deceleration time setting is "0s".)

Output when the fault occurs.

warning) occurs.



96

98

99

196

198

199

9999

REM

LF

ALM

(I) REMARKS

The same function may be set to more than one terminal.

Remote output

Alarm output

Fault output


No function

When the function is executed, the terminal conducts at the setting of any of "0 to 99", and does not conduct at the setting of any of "100 to 199".



- Changing the terminal assignment using Pr.190, Pr.192 (output terminal function selection) may affect the other functions.
 Make setting after confirming the function of each terminal.
 Do not assign signals which repeat frequent ON/OFF to A, B, and C. Otherwise, the life of the relay contact decreases.

(2) Inverter operation ready signal (RY signal) and inverter running signal (RUN signal)



- When the inverter is ready to operate, the output of the operation ready signal (RY) is on. (It is also on during inverter running.)
- When the output frequency of the inverter rises to or above *Pr. 13 Starting frequency*, the output of the inverter running signal (RUN) is turned on. During an inverter stop or DC injection brake operation, the output is off.
- When using the RY and RUN signals, assign functions to *Pr.190 or Pr.192 (output terminal selection function)* referring to the table below.

Output	Pr. 190 to 1	Pr. 190 to Pr. 192 Setting				
Signal	Positive logic	Negative logic				
RY	11	111				
RUN	0	100				


Inverter Status	Start Signal	Start			At Alarm	Automatic Restart after Instantaneous Power Failure			
Output signal	OFF (during stop)	Signal ON (during stop)	Signal ON (during operation)	Under DC Injection Brake	Occurrence or MRS Signal ON (output shutoff)	Coas Start signal ON	Start Start signal OFF	Restarting	
RY	ON	ON	ON	ON	OFF	ON	l *1	ON	
RUN	OFF	OFF	ON	OFF	OFF	OFF		ON	

^{*1} This signal turns OFF during power failure or undervoltage.

• REMARKS

• The RUN signal (positive logic) is assigned to the terminal RUN in the initial setting.

(3) Fault output signal (ALM signal)



• If the inverter comes to trip, the ALM signal is output.

(I) REMARKS

- The ALM signal is assigned to the ABC contact in the default setting. By setting "99 (positive logic) or 199 (negative logic) in *Pr.190 or Pr.192 (output terminal function selection)*, the ALM signal can be assigned to the other signal.
- Refer to page 246 for the inverter fault description.

(4) Fault output 3 (power-off signal) (Y91 signal)

- The Y91 signal is output at occurrence of a fault attributable to the failure of the inverter circuit or a fault caused by a wiring mistake.
- When using the Y91 signal, set "91 (positive logic)" or "191 (negative logic)" to *Pr.190 or Pr.192 (output terminal function selection)* to assign the function to the output terminal.
- The following table indicates the faults that will output the Y91 signal. (Refer to page 245 for the fault description.)

Operation Indicat		Name			
£. δ ξ E. BE		Brake transistor alarm detection			
E. GF	E.GF	Output side earth (ground) fault overcurrent at start			
E. LF	E.LF	Output phase loss			
E. PE	E.PE	Parameter storage device fault			
E.C PU	E.CPU	CPU fault			
EJ OH	E.IOH	Inrush current limit circuit fault			

• REMARKS

 At occurrence of output side earth (ground) fault overcurrent (E.GF), overcurrent trip during acceleration(E.OC1) may be displayed. At this time, the Y91 signal is output.



Parameters referred to


Pr. 13 Starting frequency Refer to page 93


4.10.6 Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)

The inverter output frequency is detected and output at the output signals.

Parameter Number	Name	Initial Value	Setting Range	Description
41	Up-to-frequency sensitivity	10%	0 to 100%	Level where the SU signal turns on.
42	Output frequency detection	6Hz	0 to 400Hz	Frequency where the FU signal turns on.
43	Output frequency detection for reverse	9999	0 to 400Hz	Frequency where the FU signal turns on in reverse rotation.
	rotation		9999	Same as Pr. 42 setting

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)





(1) Up-to-frequency sensitivity (SU signal, Pr. 41)

- When the output frequency reaches the set frequency, the up-to-frequency signal (SU) is output.
- •The Pr.~41 value can be adjusted within the range 0% to $\pm 100\%$ on the assumption that the set frequency is 100%.
- •This parameter can be used to ensure that the running frequency has been reached to provide the operation start signal etc. for related equipment.
- •When using the SU signal, set "1 (positive logic) or 101 (negative logic)" in *Pr. 190 or Pr. 192 (output terminal function selection)* to assign function to the output terminal.

(2) Output frequency detection (FU signal, *Pr. 42*, *Pr. 43*)

- The output frequency detection signal (FU) is output when the output frequency reaches or exceeds the *Pr. 42* setting.
- •This function can be used for electromagnetic brake operation, open signal, etc.
- •When the detection frequency is set to *Pr. 43*, frequency detection for reverse operation use only can also be set. This function is effective for switching the timing of electromagnetic brake operation between forward rotation (rise) and reverse rotation (fall) during vertical lift operation, etc.
- •When $Pr. 43 \neq$ "9999", the Pr. 42 setting is used for forward rotation and the Pr. 43 setting is used for reverse rotation.
- •When using the FU signal, set "4 (positive logic)" or "104 (negative logic)" to *Pr. 190 or Pr. 192 (output terminal function selection)* to assign the function to the output terminal.

> REMARKS

- All signals are off during DC injection brake.
- The output frequency to be compared with the set frequency is the output frequency before slip compensation is performed.



NOTE

Changing the terminal assignment using Pr.190, Pr.192 (output terminal function selection) may affect the other functions.
 Make setting after confirming the function of each terminal.

Parameters referred to

Pr. 190, Pr. 192 (output terminal function selection) 🕼 (Refer to page 114)




4.10.7 Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153, Pr. 166, Pr. 167)

The output current during inverter running can be detected and output to the output terminal.

Parameter Number	Name	Initial Value	Setting Range	Description
150	Output current detection level	150%	0 to 200%	Output current detection level. 100% is the rated inverter current.
151	Output current detection signal delay time	0s	0 to 10s	Output current detection period. The time from when the output current has risen above the setting until the output current detection signal (Y12) is output.
152	Zero current detection level	5%	0 to 200%	Zero current detection level. The rated inverter current is assumed to be 100%.
153	Zero current detection time	0.5s	0 to 1s	Period from when the output current drops below the <i>Pr. 152</i> value until the zero current detection signal (Y13) is output.
	Output current detection		0 to 10s	Set the retention time when the Y12 signal is on.
166	signal retention time	0.1s	9999	The Y12 signal on status is retained. The signal is turned off at the next start.
	Output current detection		0	Operation continues when the Y12 signal is on
167	operation selection	0	1	The inverter is brought to trip when the Y12 signal is on. (E.CDO)


The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



(1) Output current detection (Y12 signal, *Pr. 150, Pr. 151, Pr. 166, Pr. 167*)

- •The output current detection function can be used for excessive torque detection, etc.
- •If the output current remains higher than the $Pr.\ 150$ setting during inverter operation for longer than the time set in $Pr.\ 151$, the output current detection signal (Y12) is output from the inverter's open collector or relay output terminal.
- •When the Y12 signal turns on, the ON state is held for the time set in *Pr. 166*.
- •When Pr. 166 = "9999", the ON state is held until a next start.
- •At the *Pr.* 167 setting of "1", the inverter trips and the output current detection fault (E.CDO) is displayed when the Y12 signal turns on. When fault occurs, the Y12 signal is on for the time set in *Pr.* 166 at the *Pr.* 166 setting of other than 9999, and remains on until a reset is made at the *Pr.* 166 setting of 9999. E.CDO does not occur even if "1" is set in *Pr.* 167 while Y12 is ON. The *Pr.* 167 setting is made valid after Y12 turns OFF.
- •For the Y12 signal, set "12 (positive logic) or 112 (negative logic)" in *Pr. 190 or Pr. 192 (output terminal function selection)* and assign functions to the output terminal.

7/



* The zero current detection signal (Y13) holds the signal for approximately 0.1s once turned on.

(2) Zero current detection (Y13 signal, Pr. 152, Pr. 153)

- •If the output current remains lower than the *Pr.* 152 setting during inverter operation for longer than the time set in *Pr.* 153, the zero current detection (Y13) signal is output from the inverter's open collector or relay output terminal.
- •When the inverter's output current falls to "0", torque will not be generated. This may cause a drop due to gravity when the inverter is used in vertical lift application.

To prevent this, the Y13 signal can be output from the inverter to close the mechanical brake when the output current has fallen to "zero".

•For the Y13 signal, set "13 (positive logic) or 113 (negative logic)" in *Pr. 190 or Pr. 192 (output terminal function selection)* and assign functions to the output terminal.

> REMARKS

- · This function is also valid during execution of the offline auto tuning.
- The response time of Y12 and Y13 signals is approximately 0.1s. Note that the response time changes according to the load condition.

When Pr. 152 = "0", detection is disabled.



NOTE

• Changing the terminal assignment using *Pr. 190, Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



The zero current detection level setting should not be too high, and the zero current detection time setting not too long. Otherwise, the detection signal may not be output when torque is not generated at a low output current.

To prevent the machine and equipment from resulting in hazardous conditions detection signal, install a safety backup such as an emergency brake even the zero current detection function is set valid.



Parameters referred to

Offline auto tuning Pr. Refer to page 100
Pr. 190, Pr. 192 (output terminal function selection) Pr. Refer to page 114



4.10.8 Remote output selection (REM signal, Pr. 495, Pr. 496)


You can utilize the on/off of the inverter's output signals instead of the remote output terminal of the programmable logic controller.

Parameter	Name	Initial	Setting	Description		
Number	Name	Value	Range	Description		
				Remote output data clear at powering off	Remote output data	
			1	Remote output data retention at	clear at inverter reset	
495	Remote output selection	0	'	powering off	cieai at ilivertei reset	
495		U	10	Remote output data clear at powering off	Remote output data	
			11	Remote output data retention at	retention at inverter	
			11	powering off	reset	
496*	Remote output data 1	0	0 to 4095	95 Refer to the following diagram.		

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

<Remote output data>

Pr. 496




* Any

- The output terminal can be turned on/off depending on the Pr. 496 setting. The remote output selection can be controlled on/off by computer link communication from the PU connector.
- Set "96 (positive logic) or 196 (negative logic)" to Pr. 190 or Pr. 192 (output terminal function selection), and assign the remote output (REM) signal to the terminal used for remote output,
- When you refer to the diagram on the left and set 1 to the terminal bit (terminal where the REM signal has been assigned) of *Pr. 496*, the output terminal turns on (off for negative logic). By setting 0, the output terminal turns off (on for negative logic).

Example: When "96 (positive logic)" is set in *Pr. 190 RUN terminal function selection* and "1" (H01) is set in *Pr. 496*, the terminal RUN turns on.

ON/OFF example for positive logic



- When Pr. 495 = "0 (initial value), 10", performing a power on reset (including a power failure) clears the REM signal output. (The ON/OFF status of the terminals are as set in Pr. 190, Pr. 192.) The Pr. 496 setting is also "0".
 - When *Pr.* 495 = "1, 11", the remote output data before power off is stored into the EEPROM, so the signal output at power recovery is the same as before power off. However, it is not stored when the inverter is reset (terminal reset, reset request through communication). (See the chart on the left)
- When *Pr. 495* = "10, 11", signal before rest is saved even at inverter reset.

REMARKS

- The output terminal where the REM signal is not assigned using *Pr. 190 or Pr. 192* does not turn on/off if 0/1 is set to the terminal bit of *Pr. 496 or Pr. 497*. (It turns on/off with the assigned function.)
- When the inverter is reset (terminal reset, reset request through communication), *Pr. 496* values turn to "0". When *Pr. 495* = "1, 11", however, they are the settings at power off. (The settings are stored at power off.)

 When *Pr. 495* = "10, 11", they are the same as before an inverter reset is made.

Parameters referred to

Pr. 190, Pr. 192 (output terminal function selection) Refer to page 114

^{*} The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

4.11 Monitor display and monitor output signal

Purpose	Parameter that	Refer to Page	
Display motor speed Set speed	Speed display and speed setting	Pr. 37	122
Change PU monitor display data	Monitor display/PU main display data selection Cumulative monitor clear	Pr. 52, Pr. 158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891	123
Change the monitor output from terminal AM	Terminal AM function selection	Pr. 158	123
Set the reference of the monitor output from terminal AM	Terminal AM standard setting	Pr. 55, Pr. 56	128
Adjust terminal AM outputs	Terminal AM calibration	Pr. 901	129

4.11.1 Speed display and speed setting (Pr. 37)

The monitor display and frequency setting of the PU (FR-PU04/FR-PU07) can be changed to the machine speed.

Parameter Number	Name	Initial Value	Setting Range	Description	
37	Speed display	0	0	Frequency display, setting	
31	Speed display		0.01 to 9998*	Machine speed at 60Hz.	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

Maximum setting value of
$$Pr. 37 < \frac{16777.215 \times 60 \text{ (Hz)}}{\text{Setting value of } Pr. 1 \text{ (Hz)}}$$

Note that the maximum setting value of Pr. 37 is 9998 if the result of the above formula exceeds 9998.

• To display the machine speed, set in Pr. 37 the machine speed for 60Hz operation.

For example, when Pr. 37 = "1000", "1000" is displayed on the output frequency and set frequency monitor when the running frequency is 60Hz. When running frequency is 30Hz, "500" is displayed.

Pr. 37 Setting	Output Frequency Monitor	Set Frequency Monitor	Frequency Setting	Parameter Setting
0 (initial value)	Hz	Hz	Hz	Hz
0.01 to 9998	Machine speed *1	Machine speed *1	Machine speed *1	112

- *1 Machine speed conversion formulaPr. 37 × frequency/60Hz
- *2 Hz is displayed in 0.01Hz increments and machine speed is in 0.001.



NOTE

- Under V/F control, the output frequency of the inverter is displayed in terms of synchronous speed, and therefore, displayed value = actual speed + motor slip. The display changes to the actual speed (estimated value calculated based on the motor slip) when slip compensation was made valid.
- Refer to Pr. 52 when you want to change the PU main monitor (PU main display).
- · Since the panel display of the operation panel is 4 digits in length, the monitor value of more than "9999" is displayed "----".
- When the machine speed is displayed on the FR-PU04/FR-PU07, do not change the speed by using an up/down key in the state where the set speed exceeding 65535 is displayed. The set speed may become arbitrary value.
- While the machine speed is displayed on the monitor, values of other parameters related to speed (*Pr. 1*, etc.) are in frequency increments.
- Due to the limitations on the resolution of the set frequency, the indication in the second decimal place may differ from the setting.



⚠ Make sure that the running speed setting is correct.

Otherwise, the motor might run at extremely high speed, damaging the machine.



Parameters referred to

Pr. 1 Maximum frequency Refer to page 78
Pr. 52 DU/PU main display data selection Refer to page 123

^{*} The maximum value of the setting range differs according to the Pr. 1 Maximum frequency and it can be calculated from the following formula.



4.11.2 Monitor display selection of operation panel/PU and terminal AM (Pr. 52, Pr.158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564, Pr. 891)

The monitor to be displayed on the main screen of the operation panel and parameter unit (FR-PU04/FR-PU07) can be selected.

In addition, signal to be output from the terminal AM (analog voltage output) can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
52 *	DU/PU main display data selection	0 (output frequency)	0, 5, 8 to 12, 14, 20, 23 to 25, 52 to 55, 61, 62, 64, 100	Select the monitor to be displayed on the operation panel and parameter unit. Refer to the following table for monitor description.
158 *	AM terminal function selection	1 (output frequency)	1 to 3, 5, 8 to 12, 14, 21, 24, 52, 53, 61, 62	Select the monitor output to terminal AM.
			0	Set "0" to clear the watt-hour meter monitor.
170	Watt-hour meter clear	9999	10	Set the maximum value when monitoring from communication to 0 to 9999kWh.
			9999	Set the maximum value when monitoring from communication to 0 to 65535kWh.
171	Operation hour meter clear	9999	0, 9999	Set "0" in the parameter to clear the operation time monitor. Setting 9999 does not clear.
	Monitor decimal digits		0	Displayed as integral value
268 *	selection	9999	1	Displayed in 0.1 increments.
	Selection		9999	No function
563	Energization time carrying- over times	0	0 to 65535 (reading only)	The numbers of cumulative energization time monitor exceeded 65535h is displayed. (Reading only)
564	Operating time carrying- over times	0	0 to 65535 (reading only)	The numbers of operation time monitor exceeded 65535h is displayed. (Reading only)
	Over unies		(reading only)	Set the number of times to shift the cumulative
891	Cumulative power monitor	9999	0 to 4	power monitor digit. Clamp the monitoring value at maximum.
031	digit shifted times	9999	9999	No shift Clear the monitor value when it exceeds the maximum value.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Monitor description list (Pr. 52)

- •Set the monitor to be displayed on the operation panel and parameter unit (FR-PU04/FR-PU07) in *Pr. 52 DU/PU main display data selection* .
- •Set the monitor to be output to the terminal AM (analog voltage output) in Pr. 158 AM terminal function selection .
- •Refer to the following table and set the monitor to be displayed. (The monitor marked cannot be selected.)

		Pr. 52	Setting					
Types of Monitor	Unit	Operation	PU	Pr.158 (AM)	Terminal	I AM	Description	
Types of Monitor	Onit	panel	main	Setting	Full Scale	Value	Description	
		LED	monitor					
Output frequency	0.01Hz	0/	100	1	Pr. 55		Displays the inverter output frequency.	
Output current	0.01A	0/1	100	2	Pr 56		Displays the inverter output current effective value.	
Output voltage	0.1V	0/	100	00 3		400V	Displays the inverter output voltage.	
Output voltage	0.10	0/	100	3	400V class	800V	Displays the inverter output voltage.	
Fault display	_	0/	100	×	_		Displays 8 past faults individually.	
Frequency setting	0.01Hz	5	*1	5	Pr. 55		Displays the set frequency.	
value	0.01112				17.55		Biopiayo ano oot moquonoy.	
Converter output	0.1V	8	*1	8	200V class	400V	Displays the DC bus voltage value.	
voltage	0.10		-1		400V class 800V		Displays the DO bus voltage value.	

^{*} The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

	Pr. 52 Setting						
Types of Monitor	Unit	Operation panel LED	PU main monitor	Pr.158 (AM) Setting	Terminal Full Scale		Description
Regenerative brake duty	0.1%	9	*1	9	Pr. 70		Brake duty set in Pr. 30, Pr. 70
Electronic thermal relay function load factor	0.1%	10	*1	10	100%		Displays the thermal cumulative value on the assumption that the thermal operation level is 100% (Larger thermal between the motor thermal and transistor thermal).
Output current peak value	0.01A	11	*1	11	Pr. 56		Holds and displays the peak value of the output power monitor. (Cleared at every start)
Converter output voltage peak value	0.1V	12	*1	12	200V class 400V class	400V 800V	Holds and displays the peak value of the DC bus voltage value. (Cleared at every start)
Output power	0.01kW	14	*1	14	Rated invert power × 2	er	Displays the power on the inverter output side
Input terminal status	_		*1	×	_		Displays the input terminal ON/OFF status on the operation panel. (<i>Refer to page 126</i>)
Output terminal status	_		*1	×	_		Displays the output terminal ON/OFF status on the operation panel. (<i>Refer to page 126</i>)
Cumulative energization time *2, *5	1h	2	20	×	_		Adds up and displays the energization time after inverter shipment. You can check the numbers of the monitor value exceeded 65535h with <i>Pr. 563</i> .
Reference voltage output	_	_	_	21	_		Terminal AM: Output 10V
Actual operation time *2, *3, *5	1h	2	:3	×	_		Adds up and displays the inverter operation time. You can check the numbers of the monitor value exceeded 65535h with <i>Pr. 564</i> . Can be cleared by <i>Pr. 171. (Refer to page 127)</i>
Motor load factor	0.1%	2	24	24	200%		Displays the output current value on the assumption that the inverter rated current value is 100%. Monitor value = output power monitor value/rated inverter current 100 [%]
Cumulative power *5	0.01kWh *4		25	×	_		Adds up and displays the power amount based on the output power monitor. Can be cleared by <i>Pr. 170. (Refer to page 126)</i>
PID set point	0.1%		2	52	100%		Displays the set point, measured value and
PID measured value PID deviation	0.1% 0.1%		i3 i4	53 ×	100%		deviation during PID control (<i>Refer to page</i> 212 for details)
Inverter I/O terminal monitor	— —	55	×	×	_		Displays the ON/OFF status of the inverter input terminal and output terminal on the operation panel (<i>Refer to page 126</i> for details)
Motor thermal load factor	0.1%	6	31	61	Thermal relation level (100%)	vel	Motor thermal heat cumulative value is displayed. (Motor overload trip (E.THM) at 100%)
Inverter thermal load factor	0.1%	6	2	62	Thermal relation lever (100%)	•	Transistor thermal heat cumulative value is displayed. (Inverter overload trip (E.THT) at 100%)
PTC thermistor resistance	0.01kΩ	6	64	×	_		Displays the PTC thermistor resistance at terminal 2 when PTC thermistor protection is active. (0.10k Ω to 31.5k Ω) (<i>Refer to page 95</i>)



- 1 Frequency setting to output terminal status on the PU main monitor are selected by "other monitor selection" of the parameter unit (FR-PU04/FR-PU07).
- *2 The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0.

 When the operation panel is used, the time is displayed up to 65.53 (65530h) on the assumption that 1h = 0.001, and thereafter, it is added up from 0.
- *3 Actual operation time is not accumulated when the cumulative operation time is less than 1h until turning off of the power supply.
- *4 When using the parameter unit (FR-PU04/FR-PU07), "kW" is displayed.
- *5 Since the panel display of the operation panel is 4 digits in length, the monitor value of more than "9999" is displayed "----".
- *6 Larger thermal value between the motor thermal and transistor thermal is displayed.


 A value other than 0% is displayed if the surrounding air temperature (heatsink temperature) is high even when the inverter is at a stop.

• REMARKS


- By setting "0" in Pr. 52, the monitoring of output speed to fault display can be selected in sequence by (SET)
- When the operation panel is used, the displayed units are Hz and A only and the others are not displayed.
- The monitor set in *Pr. 52* is displayed in the third monitor position. However, change the output current monitor for the motor load factor.

Initial Value

*The monitor displayed at powering on is the first monitor. Display the monitor you want to display on the first monitor and hold down (SET) for 1s. (To return to the output frequency monitor, hold down (SET) for 1s after displaying the output frequency monitor.)



Example)When *Pr.* 52 is set to "20" (cumulative energization time), the monitor is displayed on the operation panel as described below.



(2) Display set frequency during stop (Pr. 52)

 When "100" is set in Pr. 52, the set frequency and output frequency are displayed during stop and operation respectively. (LED of Hz flickers during stop and is lit during operation.)

	Pr. 52			
	0 1		00	
	During	During ston	During	
	running/stop	During stop	running	
Output	Output	Set	Output	
frequency	frequency	frequency*	frequency	
Output current	Output current			
Output voltage	Output voltage			
Fault display		Fault display		


The set frequency displayed indicates the frequency to be output when the start command is on. Different from the frequency setting displayed when Pr. 52 = "5", the value based on maximum/minimum frequency and frequency jump is displayed.

REMARKS

- During an error, the output frequency at error occurrence appears.
- During MRS signal is on, the values displayed are the same as during a stop.
- During offline auto tuning, the tuning status monitor has priority.

(3) Operation panel I/O terminal monitor (Pr. 52)

- •When Pr. 52 = "55", the I/O terminal status can be monitored on the operation panel.
- •The I/O terminal monitor is displayed on the third monitor.
- •The LED is on when the terminal is on, and the LED is on when the terminal is off. The center line of LED is always on.
- •On the I/O terminal monitor (Pr. 52 = "55"), the upper LEDs denote the input terminal status and the lower the output terminal status.



(4) Cumulative power monitor and clear (Pr. 170, Pr. 891)

- •On the cumulative power monitor (Pr. 52 = "25"), the output power monitor value is added up and is updated in 1h increments.
- The operation panel, parameter unit (FR-PU04/FR-PU07) and communication (RS-485 communication) display increments and display ranges are as indicated below.

Operation Pan	anel *1 Parameter Unit *2		*2	C		
Range Unit Range		Unit	Range		Unit	
Kange	Oilit	Kange	Oilit	<i>Pr. 170</i> = 10	<i>Pr. 170</i> = 9999	Oilit
0 to 99.99kWh	0.01kWh	0 to 999.99kWh	0.01kWh		0 to 65525WMb	1kWh/
100.0 to 999.9kWh	0.1kWh	1000.0 to 9999.9kWh	0.1kWh	0 to 9999kWh	0 to 65535kWh	0.01kWh
1000 to 9999kWh	1kWh	10000 to 99999kWh	1kWh		(initial value)	*3

- *1 Power is measured in the range 0 to 9999.99kWh, and displayed in 4 digits.
 - When the monitor value exceeds "99.99", a carry occurs, e.g. "100.0", so the value is displayed in 0.1kWh increments.
- *2 Power is measured in the range 0 to 99999.99kWh, and displayed in 5 digits.
 - When the monitor value exceeds "999.99", a carry occurs, e.g. "1000.0", so the value is displayed in 0.1kWh increments.
- *3 In monitoring with communication, cumulative power is displayed in 1kWh increments. And cumulative power 2 is displayed in 0.01kWh. (Refer to page 183 for communication)
- •The monitor data digit can be shifted to the right by the number of *Pr. 891* settings.

 For example, if the cumulative power value is 1278.56kWh when *Pr. 891* = "2", the operation panel display or parameter unit (FR-PU04/FR-PU07) display is 12.78 (display in 100kWh increments) and the communication data is 12.
- If the maximum value is exceeded at Pr. 891 = "0 to 4", the power is clamped at the maximum value, indicating that a digit shift is necessary. If the maximum value is exceeded at Pr. 891 = "9999", the power returns to 0 and is recounted. If the maximum value is exceeded at Pr. 891 = "9999", the power returns to 0 and is recounted.
- •Writing "0" in *Pr. 170* clears the cumulative power monitor.

• REMARKS

• If "0" is written to Pr. 170 and Pr. 170 is read again, "9999" or "10" is displayed.



(5) Cumulative energization time and actual operation time monitor (Pr. 171, Pr. 563, Pr. 564)

- •Cumulative energization time monitor (Pr. 52 = "20") accumulates energization time from shipment of the inverter every one hour.
- •On the actual operation time monitor (Pr. 52 = "23"), the inverter running time is added up every hour. (Time is not added up during a stop.)
- •If the monitored value exceeds 65535, it is added up from 0. You can check the numbers of cumulative energization time monitor exceeded 65535h with Pr. 563 and the numbers of actual operation time monitor exceeded 65535h with Pr. 564.
- •Writing "0" to Pr. 171 clears the cumulative energization power monitor. (The cumulative time monitor can not be cleared.)

REMARKS

- · The actual operation time is not added up unless the inverter is operated one or more hours continuously.
- If "0" is written to Pr. 171 and Pr. 171 is read again, "9999" is always displayed. Setting "9999" does not clear the actual operation

(6) You can select the decimal digits of the monitor (Pr. 268)

•As the operation panel display is 4 digits long, the decimal places may vary at analog input, etc. The decimal places can be hidden by selecting the decimal digits.

In such a case, the decimal digits can be selected by Pr. 268.

Pr. 268 Setting	Description
9999 (initial value)	No function
	For the first or second decimal places (0.1 increments or 0.01 increments) of the monitor, numbers in the first
0	decimal place and smaller are rounded to display an integral value (1 increments). The monitor value smaller than
	0.99 is displayed as 0.
1	When 2 decimal places (0.01 increments) are monitored, the 0.01 decimal place is dropped and the monitor
1	displays the first decimal place (0.1 increments). The monitored digits in 1 increments are displayed as they are.



(I) REMARKS

The number of display digits on the cumulative energization time (Pr. 52 = "20") and actual operation time (Pr. 52 = "23") does



Parameters referred to

Pr. 30 Regenerative function selection, Pr. 70 Special regenerative brake duty Refer to page 105 Pr. 37 Speed display Refer to page 122

Pr. 55 Frequency monitoring reference, Pr. 56 Current monitoring reference Refer to page 128


4.11.3 Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)

Analog voltage output from the terminal AM is available. Set the reference of the signal output from terminal AM.

Parameter Number	Name	Initial Value	Setting Range	Description
55*	Frequency monitoring reference	50Hz	0 to 400Hz	Full-scale value to output the output frequency monitor value to terminal AM.
56*	Current monitoring reference	Inverter rated current	0 to 500A	Full-scale value to output the output current monitor value to terminal AM.


The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Frequency monitoring reference (Pr. 55)



- Set the frequency when the optional frequency meter (DC voltmeter 10VDC) shows 50Hz or 120Hz (shows full scale) which is connected to the terminal AM and 5.
- Set the frequency (output frequency/set frequency) when the voltage output at terminal AM is 10VDC.
- The analog voltage output and frequency at terminal AM are proportional. (The maximum output voltage is 10VDC.)

(2) Current monitoring reference (Pr. 56)



- Set the current to be referenced when the current monitor (inverter output current, etc.) is selected for terminal AM display.
- Set the current value when the voltage output at terminal AM is 10VDC.
- The analog voltage output and current value at terminal AM are proportional. (The maximum output voltage is 10VDC.)

^{*} The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.



4.11.4 Terminal AM calibration (calibration parameter C1 (Pr.901))


By using the operation panel or parameter unit, you can calibrate terminal AM to full scale deflection.

Parameter Number	Name	Initial Value	Setting Range	Description
C1(901)	AM terminal calibration	_	_	Calibrates the scale of the meter connected to terminal AM.

- *1 The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)
- *2 The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).
- *3 The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

(1) Terminal AM gain calibration (C1 (Pr. 901))

• Terminal AM is factory-set to provide a 10VDC output in the full-scale status of the corresponding monitor item. Calibration parameter C1 (Pr. 901) allows the output voltage ratios (gains) to be adjusted according to the meter scale. Note that the maximum output voltage is 10VDC.



- · Calibrate the terminal AM gain in the following procedure.
 - 1) Connect a 0-10VDC meter (frequency meter) to across inverter terminals AM-5. (Note the polarity. The terminal AM is positive.)
 - 2) Refer to the monitor description list (page 123) and set Pr. 158.

 When you selected the running frequency, inverter output current, etc. as monitor, preset in Pr. 55 or Pr. 56 the running frequency or current value at which the output signal will be 10V.
 - 3) When outputting the item that cannot achieve a 100% value easily by operation, e.g. output current, set "21" (reference voltage output) in *Pr. 158* and perform the following operation. After that, set "2" (output current, for example) in *Pr. 158*.

(I) REMARKS

• When outputting such an item as the output current, which cannot reach a 100% value easily by operation, set *Pr. 158* to "21" (reference voltage output) and make calibration. 10VDC is output from the terminal AM.

(2) How to calibrate the terminal AM when using the operation panel

Operation -Display (When Pr. 158 = 1) 1. Confirmation of the RUN indication and operation mode indication PRM indication is lit. 2. Press (MODE) to choose the parameter setting mode. (The parameter number read previously appears.) 3. Turn (until [. . . C1 to C7 setting is enabled. 4. Turn (SET) until [- - - appears. 5. Turn (until [Set to C1 AM terminal calibration 6. Press (SET) to enable setting. The monitor set to Pr. 158 AM terminal function selection is displayed. 7. If the inverter is at a stop, press the $\left(\text{RUN}\right)$ key to start the inverter. (Motor needs not be connected.) 8. Turn to adjust the indicator needle to the Analog indicator desired position.

9. Press SET).
Setting is complete.



Flicker...Parameter setting complete!!

- •Turn to read another parameter.
- •Press (SET) to return to the [- indication (step 4).
- •Press (SET) twice to show the next parameter (Pr.[]).

> REMARKS

- Calibration can also be made for external operation. Set the frequency in the external operation mode, and make calibration in the above procedure.
- Calibration can be made even during operation.
- For operation from the parameter unit (FR-PU04/FR-PU07), refer to the instruction manual of the parameter unit.

Parameters referred to

Pr. 55 Frequency monitoring reference Refer to page 128
Pr. 56 Current monitoring reference Refer to page 128
Pr. 158 AM terminal function selection Refer to page 123



4.12 Operation selection at power failure and instantaneous power failure

Purpose	Parameter ti	Refer to Page	
At instantaneous power failure	Automatic restart operation	Pr. 30, Pr. 57, Pr. 58, Pr. 96,	
occurrence, restart inverter without	after instantaneous power	Pr. 162, Pr. 165, Pr. 298, Pr. 299,	131
stopping motor	failure/flying start	Pr. 611	
When undervoltage or a power	Power failure-time		
failure occurs, the inverter can be	deceleration-to-stop	Pr. 261	137
decelerated to a stop.	function		

4.12.1 Automatic restart after instantaneous power failure/flying start (Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)

You can restart the inverter without stopping the motor in the following cases:


- When power comes back on after an instantaneous power failure
- When motor is coasting at start

Parameter Number	Name	Initial Value	Setting Range	Description
30	Regenerative function	0	0, 1	The motor starts at the starting frequency when MRS (X10) turns on then off
30	selection		2	Restart operation is performed when MRS (X10) turns on then off
			0	FR-D740-036 or less, FR-D720S-070 or less . 1s FR-D740-050 or more, FR-D720S-100 2s The above times are coasting time.
57	Restart coasting time	9999	0.1 to 5s	Waiting time for inverter-triggered restart after an instantaneous power failure.
			9999	No restart
58	Restart cushion time	1s	0 to 60s	Voltage starting time at restart.
			0	Offline auto tuning is not performed
0.0	A	0	11	For general-purpose magnetic flux vector control Offline auto tuning is performed without motor running (motor
96	Auto tuning setting/status	0	21	constants (R1) only) (Refer to page 70) Offline auto tuning (tuning performed without motor running) for V/F control and automatic restart after instantaneous power failure (with frequency search)
	Automatic restart after		0	With frequency search
162	instantaneous nower	1	1	Without frequency search (reduced voltage system)
102	•		10	Frequency search at every start
	failure selection		11	Reduced voltage at every start
165	Stall prevention operation level for restart	150%	0 to 200%	Considers the rated inverter current as 100% and sets the stall prevention operation level during restart operation.
298	Frequency search gain	9999	0 to 32767	When offline auto tuning is performed under V/F control, frequency search gain necessary for frequency search for automatic restart after instantaneous power failure is set as well as the motor constants (R1).
			9999	Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants
			0	Without rotation direction detection
	Rotation direction		1	With rotation direction detection
299	detection selection at	0		When <i>Pr.</i> 78 = 0, With rotation direction detection
	restarting		9999	When Pr. 78 = 1, 2
644	Acceleration time at a	0000	0 to 3600s	Without rotation direction detection Acceleration time to reach the acceleration time reference frequency at a restart.
611	restart	9999	9999	Acceleration time for restart is the normal acceleration time (e.g. <i>Pr.</i> 7)

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)


7

When Pr. 162 = 1, 11 (without frequency search)



* The output shut off timing differs according to the load condition.

When Pr. 162 = 0, 10 (with frequency search)



(1) Automatic restart operation selection

(Pr. 30, Pr. 162, Pr. 299)

Without frequency search

When *Pr.* 162 = "1" or "11", automatic restart operation is performed in a reduced voltage system, where the voltage is gradually risen with the output frequency unchanged from prior to an instantaneous power failure independently of the coasting speed of the motor.

> REMARKS

This system stores the output frequency and rotation direction prior to an instantaneous power failure and restart using the stored value. Therefore, if the instantaneous power failure time exceeds 0.2s and the stored value cannot be retained, the inverter starts at *Pr. 13 Starting frequency* (initial value = 0.5Hz) in the starting direction upon power restoration.

With frequency search

When "0 (initial value) or 10" is set in $Pr.\ 162$, the inverter smoothly starts after detecting the motor speed upon power restoration. (The motor capacity should be equal to or one rank lower than the inverter capacity)

When using the frequency search, perform offline auto tuning.

(Refer to page 100 for general-purpose magnetic flux vector control and $page\ 134$ for V/F control.)

- •During reverse rotation, the inverter can be restarted smoothly as the direction of rotation is detected.
- •You can select whether to make rotation direction detection or not with *Pr. 299 Rotation direction detection selection at restarting*.

When capacities of the motor and inverter differ, set "0" (without rotation direction detection) in *Pr. 299*.

Pr. 299 Setting	Pr. 78 Setting			
11. 277 Setting	0	1	2	
9999	0	×	×	
0 (initial value)	×	×	×	
1	0	0	0	

- O: the rotation direction is detected.
- x: the rotation direction is not detected.

> REMARKS

- Speed detection time (frequency search) changes according to the motor speed. (maximum 100ms)
- When the inverter capacity is two rank or more larger than the motor capacity, the inverter may not start due to overcurrent trip (E.OC□).
- If two or more motors are connected to one inverter, the inverter functions abnormally. (The inverter does not start smoothly.)
- When reverse rotation is detected when Pr. 78 = "1" (reverse rotation disabled), the rotation direction is changed to forward rotation after decelerates in reverse rotation when the start command is forward rotation. The inverter will not start when the start command is reverse rotation.





NOTE

- When automatic restart operation after instantaneous power failure is activated while the motor is running at a low speed (less than 10Hz), the motor restarts in the direction prior to instantaneous power failure without detecting the rotation direction (*Pr. 299 Rotation direction detection selection at restarting* = "1").
- If the frequency search result exceeds the set frequency, the output frequency is limited at the set frequency.
- When the wiring length exceeds below, select without frequency search (Pr. 162 = "1, 11").

Motor capacity	0.1K	0.2K	0.4K or more
Wiring length	20m	50m	100m

Restart operation at every start

When Pr. 162 = "10" or "11", automatic restart operation is also performed every start, in addition to the automatic restart after instantaneous power failure. When Pr. 162 = "0", automatic restart operation is performed at the first start after power supply-on, but not performed at the second time or later.

• Automatic restart operation selection of MRS (X10) signal (When Pr. 162 = "0, 1")

Restart operation after turning MRS (X10) signal on then off using Pr.~30 can be selected as in the table below. When automatic restart after instantaneous power failure is selected when using the high power factor converter (FR-HC), noramally set "2" in Pr.~30.

Pr. 30 Setting	Operation after MRS and X10 Signal Turns off, on, then off.
0, 1	Start at the Pr. 13 Starting frequency.
2	Frequency search is made and starts at the coasting speed.

(2) Restart coasting time (Pr. 57)

- •Coasting time is the time from when the motor speed is detected until automatic restart control is started.
- •Set Pr. 57 to "0" to perform automatic restart operation.

The coasting time is automatically set to the value below. Generally this setting will pose no problems.


FR-D740-036 or less, FR-D720S-070 or less 1s

FR-D740-050 or more, FR-D720S-100.....2s

•Operation may not be performed well depending on the magnitude of the moment of inertia (J) of the load or running frequency. Adjust the coasting time between 0.1s and 5s according to the load specifications.

(3) Restart cushion time (Pr. 58)

- •Cushion time is the length of time when the voltage appropriate to the voltage at the detected motor speed (output frequency prior to instantaneous power failure when Pr. 162 = "1, 11") from 0V.
- •Normally the initial value need not be changed for operation, but adjust it according to the magnitude of the moment of inertia (J) of the load or torque.



(4) Automatic restart operation adjustment (Pr. 165, Pr. 611)

- •Using Pr. 165, you can set the stall prevention operation level at a restart.
- •Using *Pr. 611*, you can set the acceleration time to the acceleration time reference frequency when automatic restart operation is performed besides the normal acceleration time.

(5) Frequency search gain (Pr. 298), offline auto tuning (Pr. 96)

- •When automatic restart after instantaneous power failure operation (with frequency search) is valid at V/F control, perform offline auto tuning.
- •Perform offline auto tuning during V/F control in the following order to set *Pr. 298 Frequency search gain* automatically. (Refer to *page 100* during general-purpose magnetic flux vector control.)

Before performing offline auto tuning

Check the following before performing offline auto tuning.

- •The inverter is under V/F control
- •A motor should be connected. Note that the motor should be at a stop at a tuning start.
- •The motor capacity should be equal to or one rank lower than the inverter capacity. (note that the capacity is 0.1kW or more)
- •The maximum frequency is 120Hz.
- •A high-slip motor, high-speed motor and special motor cannot be tuned.
- •The motor may run slightly. Therefore, fix the motor securely with a mechanical brake, or before tuning, make sure that there will be no problem in safety if the motor runs (caution is required especially in vertical lift applications). Note that tuning performance is unaffected even if the motor runs slightly.
- •Offline auto tuning will not be performed properly if it is performed with a surge voltage suppression filter (FR-ASFH, FR-BMF-H) connected between the inverter and motor. Remove it before starting tuning.

Setting

- 1) Set "21" in *Pr. 96 Auto tuning setting/status*. Tuning is performed without motor running.
- 2) Set the rated motor current (initial value is rated inverter current) in Pr. 9 Electronic thermal O/L relay. (Refer to page 95)
- 3) Set Pr. 71 Applied motor according to the motor used.

Motor	Pr.71 Setting *1	
	SF-JR	3
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	23
Mitsubishi high efficiency motor	SF-HR	43
	Others	3
Mitaubiahi canatant taraua	SF-JRCA 4P	13
Mitsubishi constant-torque motor	SF-HRCA	53
motor	Others (SF-JRC, etc.)	13
Other manufacturer's standard motor	_	3
Other manufacturer's constant torque motor	_	13

^{*1} Refer to page 98, for other settings of Pr. 71.

Execution of tuning



POINT

Before performing tuning, check the monitor display of the operation panel or parameter unit (FR-PU04/FR-PU07) if the inverter is in the status for tuning. (Refer to 2) below)

1) When performing PU operation, press (RUN) of the operation panel.

For external operation, turn on the start command (STF signal or STR signal). Tuning starts. (Excitation noise is produced during tuning.)



NOTE

- To force tuning to end, use the MRS or RES signal or press (STOP) of the operation panel. (Turning the start signal (STF signal or STR signal) off also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid: (initial value)
 - •Input terminal <Valid signal> STF, STR
 - •Output terminal RUN, AM, A, B, C

Note that the progress status of offline auto tuning is output in five steps from AM when speed and output frequency are selected.

- Since the RUN signal turns on when tuning is started, caution is required especially when a sequerence which releases a mechanical brake by the RUN signal has been designed.
- When executing offline auto tuning, input the run command after switching on the main circuit power (R/L1, S/L2, T/L3) of the inverter.
- Do not perform ON/OFF switching of the second function selection signal (RT) during execution of offline auto tuning. Auto tuning is not excecuted properly.
- 2) Monitor is displayed on the operation panel and parameter unit (FR-PU04, FR-PU07) during tuning as below.

	Parameter Unit (FR-PU04, FR-PU07)	Operation Panel Indication
Pr. 96 setting	21	21
(1) Setting	READ:List 21 STOP PU	2 1
(2) Tuning in progress	TUNE 22 STF FWD PU	22 RUN MON
(3) Normal end	TUNE 23 COMPLETION STF STOP PU	Flickering
(4) Error end (when inverter protective function operation is activated)	TUNE 9 ERROR STF STOP PU	3 <u>mm</u> <u>mon</u>



It takes approximately 9s until tuning is completed.

3) When offline auto tuning ends, press (STOP) of the operation panel during PU operation. For external operation, turn off the start signal (STF signal or STR signal) once.

This operation resets the offline auto tuning and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)

4) If offline auto tuning ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

Error Display	Error Cause	Remedy
8	Forced end	Set "21" in Pr. 96 and perform tuning again.
9	Inverter protective function operation	Make setting again.
91	Current limit (stall prevention) function was activated.	Set "1" in <i>Pr. 156</i> .
92	Converter output voltage reached 75% of rated value.	Check for fluctuation of power supply voltage.
93	Calculation error	Check the motor wiring and make setting again.
93	A motor is not connected.	Set the rated current of the motor in <i>Pr. 9</i> .

5) When tuning is ended forcibly by pressing (STOP) or turning off the start signal (STF or STR) during tuning, offline auto tuning does not end normally. (The motor constants have not been set.) Perform an inverter reset and restart tuning.



- · The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again.
- An instantaneous power failure occurring during tuning will result in a tuning error. After power is restored, the inverter goes into the normal operation mode. Therefore, when STF (STR) signal is on, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the ordinary mode. Note that if a fault retry has been set, retry is ianored.
- The set frequency monitor displayed during the offline auto tuning is 0Hz.
- Changing the terminal assignment using Pr.178 to Pr.182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.
- · The SU and FU signals are not output during a restart. They are output after the restart cushion time has elapsed.
- · Automatic restart operation will also be performed after a reset or when a retry is made by the retry function.



Mhen automatic restart after instantaneous power failure has been selected, the motor and machine will start suddenly (after the reset time has elapsed) after occurrence of an instantaneous power failure. Stay away from the motor and machine.

When you have selected automatic restart after instantaneous power failure function, apply in easily visible places the CAUTION stickers supplied to the Installation guideline.



/Î\ When the start signal is turned off or (STOP) is pressed during the restart cushion time after instantaneous

power failure, deceleration starts after Pr. 58 Restart cushion time has elapsed.



Parameters referred to

Pr. 7 Acceleration time Refer to page 91

Pr. 13 Starting frequency Refer to page 93

Pr. 65, Pr. 67 to Pr. 69 Retry function Refer to page 139

Pr. 71 Applied motor Refer to page 98

Pr. 78 Reverse rotation prevention selection Refer to page 157

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108





4.12.2 Power-failure deceleration stop function (Pr. 261)

When a power failure or undervoltage occurs, the inverter can be decelerated to a stop or can be decelerated and reaccelerated to the set frequency.

Parameter	Name	Initial	Setting	Description			
Number	Name	Value	Range				
			0	Coasts to stop. When undervoltage or power failure occurs, the inverter output is shut off.			
261	Power failure stop	0	1	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop.			
selection	selection		When under be deceler. If power is	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop. If power is restored during a power failure, the inverter accelerates again.			

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)





(1) Parameter setting


•When Pr. 261 is set to "1" or "2", the inverter decelerates to a stop if an undervoltage or power failure occurs.

Operation outline of deceleration to stop at power

•When undervoltage or power failure has occurred, the output frequency is decreased and controled so that the converter circuit (DC bus) voltage is constant and decreased to 0Hz to stop.

(3) Power failure stop function (Pr. 261 = "1")


•If power is restored during power failure deceleration, deceleration to a stop is continued and the inverter remains stopped. To restart, turn off the start signal once, then turn it on again.



Turn off STF once to make acceleration again

> REMARKS


- When automatic restart after instantaneous power failure is selected (Pr. 57 ≠ "9999"), power failure stop function is made invalid and automatic restart operation after instantaneous power failure is made valid.
 - After a power failure stop, the inverter will not start even if the power is restored with the start signal (STF/STR) input. After switching on the power, turn off the start signal once and then on again to make a start.




7/

(4) Operation continuation at instantaneous power failure function (Pr. 261 = "2")

- •When power is restored during deceleration after a power failure, acceleration is made again up to the set frequency.
- •When this function is used in combination with the automatic restart after instantaneous power failure function($Pr.57 \neq$ "9999"), deceleration can be made at a power failure and acceleration can be made again after power restoration.







NOTE

When operation continuation at instantaneous power failure function is used, keep the starting signal (STF/STR) on
even during instantaneous power failure. If the starting signal turns off during instantaneous power failure, the
inverter decelerates according to the deceleration time setting, causing the motor to coast if enough regenerative
energy is not obtained.

(5) Power failure deceleration signal (Y46 signal)

- •The Y46 signal is on during deceleration at an instantaneous power failure or during a stop after deceleration at an instantaneous power failure.
- •After a power failure stop, the inverter can not start even if power is restored the start command is given. In this case, check the power failure deceleration signal (Y46 signal). (at occurrence of input phase loss (E.ILF), etc.)
- •For the Y46 signal, set "46 (forward operation)" or "146 (reverse operation)" to *Pr. 190 or Pr. 192 (output terminal function selection)* to assign the function.



REMARKS

During a stop or trip, the power failure stop selection is not performed.



NOTE

• Changing the terminal assignment using *Pr. 190, Pr. 192 (output terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.



Even if the power failure stop function is valid, some loads may cause the inverter to trip and the motor to coast.

The motor will coast if enough regenerative energy is not given from the motor to the inverter.



Parameters referred to

Pr. 57 Restart coasting time Refer to page 131
Pr. 190, Pr. 192 (output terminal function selection) Refer to page 114



4.13 Operation setting at fault occurrence


Purpose	Parameter th	Refer to Page	
Recover by retry operation at fault occurrence	Retry operation	Pr. 65, Pr. 67 to Pr. 69	139
Do not output input/output phase failure alarm	Input/output phase failure protection selection	Pr. 251, Pr. 872	141

4.13.1 Retry function (Pr. 65, Pr. 67 to Pr. 69)


If a fault occurs, the inverter resets itself automatically to restart. You can also select the fault for a retry. When you have selected automatic restart after instantaneous power failure ($Pr. 57 Restart coasting time \neq 9999$), restart operation is performed at the retry operation time which is the same of that of a power failure. (Refer to page 131 for the restart function.)

Parameter	Name	Initial	Setting	Description	
Number	Name	Value Range		Description	
65	Retry selection	0	0 to 5	A fault for retry can be selected. (Refer to the next page)	
		0	0	No retry function	
			1 to 10	Set the number of retries at fault occurrence.	
67	Number of retries at fault occurrence			A fault output is not provided during retry operation.	
			101 to 110	Set the number of retries at fault occurrence. (The setting	
				value of minus 100 is the number of retries.)	
				A fault output is provided during retry operation.	
68	Potry waiting time	1s	0.1 to 600s	Set the waiting time from when an inverter fault occurs	
90	Retry waiting time	15	0.1 10 6008	until a retry is made.	
69	Retry count display erase	0	0	Clear the number of restarts succeeded by retry.	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



Retry failure example



- Retry operation automatically resets a fault and restarts the inverter at the starting frequency when the time set in *Pr.* 68 elapses after the inverter is tripped.
- Retry operation is performed by setting Pr.67 to any value other than "0". Set the number of retries at fault occurrence in Pr. 67.
- When retries fail consecutively more than the number of times set in Pr. 67, a retry count excess fault (E.RET) occurs, resulting in inverter trip. (Refer to retry failure example)
- Use Pr. 68 to set the waiting time from when the inverter trips until a retry is made in the range 0 to 600s. (When the setting value is "0s", the actual time is 0.1s.)
- Reading the *Pr. 69* value provides the cumulative number of successful restart times made by retry.
 - The cumulative count in Pr. 69 is increased by 1 when a retry is regarded as successful after normal operation continues without faults occurring for more than five times longer than the time set in Pr. 68 after a retry start. (When retry is successful, cumulative number of retry
 - (When retry is successful, cumulative number of retry failure is cleared.)
- Writing "0" to Pr. 69 clears the cumulative count.
- During a retry, the Y64 signal is on. For the Y64 signal, assign the function by setting "64 (positive operation)" or "164 (negative operation)" to Pr. 190 or Pr. 192 (output terminal faction selection).

- Using Pr. 65, you can select the fault that will cause a retry to be executed. No retry will be made for the fault not indicated. (Refer to page 246 for the fault description.)
 - indicates the faults selected for retry.

Fault for	Pr. 65 Setting					
Retry	0	1	2	3	4	5
E.OC1	•	•		•	•	•
E.OC2	•	•		•	•	
E.OC3	•	•		•	•	•
E.OV1	•		•	•	•	
E.OV2	•		•	•	•	
E.OV3	•		•	•	•	
E.THM	•					
E.THT	•					
E. BE	•				•	
E. GF	•				•	
E.OHT	•					

Fault for	Pr. 65 Setting					
Retry	0	1	2	3	4	5
E.PTC	•					
E.OLT	•				•	
E. PE	•				•	
E.ILF	•				•	
E.CDO	•				•	



NOTE

- When terminal assignment is changed using Pr.190, Pr.192, the other functions may be affected. Make setting after confirming the function of each terminal.
- · The data stored as the error reset for retry is only that of the fault which occurred the first time.
- · When an inverter fault is reset by the retry function at the retry time, the accumulated data of the electronic thermal relay function, regeneration brake duty etc. are not cleared. (Different from the power-on reset.)
- · Retry is not performed if E.PE (Parameter storage device fault) occurred at power on.



Mhen you have selected the retry function, stay away from the motor and machine when the inverter is tripped. They will start suddenly (after the reset time has elapsed) after the inverter trip.

When you have selected the retry function, apply in easily visible places the CAUTION stickers supplied.



Parameters referred to

Pr. 57 Restart coasting time (Refer to page 131)



4.13.2 Input/output phase loss protection selection (Pr. 251, Pr. 872)

You can choose whether to make Input/output phase loss protection valid or invalid.

You can disable the output phase loss protection function that trips the inverter if one phase of the inverter output side (load side) three phases (U, V, W) is lost.

The input phase loss protection function of the inverter input side (R/L1, S/L2, T/L3) can be made invalid.

Parameter Number	Name	Initial Value	Setting Range	Description
254	Output phase loss	4	0	Without output phase loss protection
251	protection selection	1	1	With output phase loss protection
070	Input phase loss protection	4	0	Without input phase loss protection
872 *	selection	1	1	With input phase loss protection

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Output phase loss protection selection (Pr. 251)

• When Pr. 251 is set to "0", output phase loss protection (E.LF) becomes invalid.

(2) Input phase loss protection selection (Pr. 872)

• When *Pr.* 872 is set to "1", input phase loss protection (E.ILF) is provided if a phase loss of one phase among the three phases is detected for 1s continuously.



NOTE

- If an input phase loss continues for a long time, the converter section and capacitor lives of the inverter will be shorter.
- As phase loss is detected according to the bus voltage change, it can not be detected if the load is light. Unbalanced
 phase-to-phase voltage of the three-phase power input may also be detected.
- Phase loss can not be detected during regeneration load operation.
- If parameter copy is performed from single-phase power input specification model to three-phase power input specification model, *Pr. 872* setting may be changed. Check *Pr. 872* setting after parameter copy.

4.13.3 Earth (ground) fault detection at start (Pr. 249)

You can choose whether to make earth (ground) fault detection at start valid or invalid. Earth (Ground) fault detection is executed only right after the start signal is input to the inverter.

Protective function will not activate if an earth (ground) fault occurs during operation.

Parameter Number	Name	Initial Value	Setting Range	Description
0.40	Earth (ground) fault	,	0	Without earth (ground) fault detection
249	detection at start	1	1	With earth (ground) fault detection

The above parameters can be set when Pr.~160 Extended function display selection = "0". (Refer to page 157)



NOTE

- As detection is executed at starting, output is delayed for approx. 20ms every starting.
- If an earth (ground) fault is detected with "1" set in *Pr. 249*, output side earth (ground) fault overcurrent (E.GF) is detected and the inverter trips. (*Refer to page 252*)
- If the motor capacity is smaller than the inverter capacity when using the FR-D740-120 or more, earth (ground) fault detection may not be provided.

^{*} Available only for the three-phase power input specification model.

4.14 Energy saving operation

Purpose	Parameter ti	hat should be Set	Refer to Page
Energy saving operation	Optimum excitation control	Pr. 60	142

4.14.1 Optimum excitation control (Pr. 60)

Without a fine parameter setting, the inverter automatically performs energy saving operation. This inverter is optimum for fan and pump applications

Parameter Number	Name	Initial Value	Setting Range	Description
60	Energy saving control	0	0	Normal operation mode
60	selection *	U	9	Optimum excitation control mode

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Optimum excitation control mode (setting "9")

- •When "9" is set in *Pr.* 60, the inverter operates in the optimum excitation control mode.
- •The optimum excitation control mode is a control system which controls excitation current to improve the motor efficiency to maximum and determines output voltage as an energy saving method.

• REMARKS

• When the motor capacity is too small as compared to the inverter capacity or two or more motors are connected to one inverter, the energy saving effect is not expected.



NOTE

- When the optimum excitation control mode is selected, deceleration time may be longer than the setting value. Since overvoltage alarm tends to occur as compared to the constant torque load characteristics, set a longer deceleration time
- Optimum excitation control functions only under V/F control. Optimum excitation control does not function under general-purpose magnetic flux vector control.
- · Optimum excitation control will not be performed during an automatic restart after instantaneous power failure.
- · Since output voltage is controlled by optimum excitation control, output current may slightly increase.



Parameters referred to

General-purpose magnetic flux vector control 👺 Refer to page 70 Pr. 57 Restart coasting time 👺 Refer to page 131

^{*} When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.



4.15 Motor noise, EMI measures, mechanical resonance

Purpose of Use	Parameter that	should be Set	Refer to Page
Reduction of the motor noise Measures against EMI and leakage currents	Carrier frequency and Soft-PWM selection	Pr. 72, Pr. 240, Pr. 260	143
Reduce mechanical resonance	Speed smoothing control	Pr. 653	144

4.15.1 PWM carrier frequency and soft-PWM control (Pr. 72, Pr. 240, Pr. 260)

You can change the motor sound.

Parameter Number	Name	Initial Value	Setting Range	Description
72 *	PWM frequency selection	1	0 to 15	You can change the PWM carrier frequency. The setting is in [kHz]. Note that 0 indicates 0.7kHz and 15 indicates 14.5kHz.
240 *	Soft-PWM operation	4	0	Soft-PWM is invalid
240 *	selection	1	1	When $Pr. 72 = "0 to 5"$, soft-PWM is valid.
260	PWM frequency automatic switchover	0	0	PWM carrier frequency is constant independently of load. When the carrier frequency is set to 3kHz or more (<i>Pr.</i> 72 ≥ "3"), perform continuous operation at less than 85% of the rated inverter current.
			1	Decreases PWM carrier frequency automatically when load increases.

The above parameters can be set when Pr.160 Extended function display selection = "0". (Refer to page 157)

(1) PWM carrier frequency changing (Pr. 72)

- •You can change the PWM carrier frequency of the inverter.
- •Changing the PWM carrier frequency produces an effect on avoiding the resonance frequency of a mechanical system or motor or on EMI measures or on leakage current reduction caused by the PWM switching.

(2) Soft-PWM control (Pr. 240)

•Soft-PWM control is a control method that changes the motor noise from a metallic tone into an unoffending complex tone.

(3) PWM carrier frequency automatic reduction function (Pr. 260)

- •When continuous operation is performed at 85% or more of the inverter rated current with the carrier frequency of the inverter set to 3kHz or more ($Pr. 72 \ge$ "3"), the carrier frequency is automatically reduced to 2kHz to protect the output transistor of the inverter. (Motor noise increases, but it is not a failure)
- •When *Pr. 260* = "0" (initial value), the carrier frequency becomes constant (*Pr. 72* setting) independently of the load, making the motor sound uniform.

Note that continuous operation should be performed at less than 85% of the inverter rating.



NOTE

- Decreasing the PWM carrier frequency effect on EMI measures and on leakage current reduction, but increases motor noise.
- When PWM carrier frequency is set to 1kHz or less $(Pr.72 \le 1)$, fast response current limit may function prior to stall prevention operation due to increase in ripple currents, resulting in insufficient torque. In such case, set fast-response current limit operation invalid using Pr. 156 Stall prevention operation selection.



Parameters referred to

^{*} The parameters in the table allow its setting to be changed during operation even if "0" (initial value) is set in Pr. 77 Parameter write selection.


4.15.2 Speed smoothing control (Pr. 653)

Vibration due to mechanical resonance influences the inverter control, causing the output current (torque) unstable. In this case, the output current (torque) fluctuation can be reduced to ease vibration by changing the output frequency.

Parameter Number	Name	Initial Value	Setting Range	Description
653	Speed smoothing control	0	0 to 200%	Increase or decrease the value using 100% as reference to check an effect.

The above parameters can be set when Pr.160 Extended function display selection = "0". (Refer to page 157)

(1) Control block diagram



(2) Setting method

If vibration due to mechanical resonance occurs, set 100% in *Pr. 653*, run the inverter at the frequency which generates maximum vibration and check if the vibration will be reduced or not after several seconds.

If effect is not produced, gradually increase the *Pr.* 653 setting and check the effect repeatedly until the most effective value is set in *Pr.* 653.

If vibration becomes large by increasing the Pr. 653 setting, gradually decrease the Pr. 653 setting than 100% to check the effect in a similar manner.



NOTE

Depending on the machine, vibration may not be reduced enough or an effect may not be produced.



4.16 Frequency setting by analog input (terminal 2, 4)

Purpose	Parameter that	t should be Set	Refer to Page
Selection of voltage/current input (terminal 2, 4) Perform forward/reverse rotation by analog input.	Analog input selection	Pr. 73, Pr. 267	145
Adjustment (calibration) of analog input frequency and voltage (current)	Bias and gain of frequency setting voltage (current)	Pr. 125, Pr. 126, Pr. 241, C2 to C7 (Pr. 902 to Pr. 905)	148

4.16.1 Analog input selection (Pr. 73, Pr. 267)

You can select the function that switches between forward rotation and reverse rotation according to the analog input terminal specifications and input signal.

Parameter Number	Name	Initial Value	Setting Range	Description	
			0	Terminal 2 input 0 to 10V	Mith out no continu
73	Analog input selection	1	1	Terminal 2 input 0 to 5V	Without reversible operation
73	Analog input selection	1	10	Terminal 2 input 0 to 10V	With reversible appration
			11	Terminal 2 input 0 to 5V	With reversible operation
				Voltage/current input	Description
				switch	Description
267	Terminal 4 input	0	0	VII	Terminal 4 input 4 to 20mA
			1		Terminal 4 input 0 to 5V
			2	V	Terminal 4 input 0 to 10V

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Selection of analog input specifications

- •For the terminal 2 for analog voltage input, 0 to 5V (initial value) or 0 to 10V can be selected.
- Either voltage input (0 to 5V, 0 to 10V) or current input (4 to 20mA initial value) can be selected for terminal 4 used for analog input.

Change the input specifications to change Pr. 267 and voltage/current input switch.


 Rated specifications of terminal 4 change according to the voltage/current input switch setting.

Voltage input: Input resistance $10k\Omega \pm 1k\Omega$,


Maximum permissible input voltage 20VDC

Current input: Input resistance $233\Omega \pm 5\Omega$,

Maximum permissible input voltage 30mA











NOTE

• Set *Pr. 267* and a voltage/current input switch correctly, then input an analog signal in accordance with the setting. Incorrect setting as in the table below could cause component damage. Incorrect settings other than below can cause abnormal operation.

Setting Causing Component Damage		Operation	
Switch setting	Terminal input	- Operation	
I (current input)	Voltage input	This could cause component damage to the analog signal output circuit of signal output devices. (electrical load in the analog signal output circuit of signal output devices increases)	
V (voltage input)	Current input	This could cause component damage of the inverter signal input circuit. (output power in the analog signal output circuit of signal output devices increases)	

•Refer to the following table and set Pr. 73 and Pr. 267.

indicates main speed setting)

Pr.73	Terminal 2	Termin	al 4 Input	Reversible
Setting	Input	AU signal		Operation
0	0 to 10V			
1 (initial value)	0 to 5V	OFF	_	Not function
10	0 to 10V			Yes
11	0 to 5V			163
0 1 (initial value)		ON	According to the <i>Pr. 267</i> setting 0:4 to 20mA (initial value) 1:0 to 5V	Not function
10 11	_		2:0 to 10V	Yes


- : invalic

•The terminal used for the AU signal input, set "4" in Pr. 178 to Pr. 182 (input terminal function selection) to assign functions.




NOTE

- Turn the AU signal on to make terminal 4 valid.
- Make sure that the parameter and switch settings are the same. Different setting may cause a fault, failure or malfunction.
- Use *Pr. 125 (Pr. 126) (frequency setting gain)* to change the maximum output frequency at input of the maximum output frequency command voltage (current). At this time, the command voltage (current) need not be input. Also, the acceleration/deceleration time, which is a slope up/down to the acceleration/deceleration reference frequency, is not affected by the change in *Pr. 73* setting.
- When Pr. 561 PTC thermistor protection level ≠"9999", terminal 2 is not available for analog frequency command.
- Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Connection diagram using terminal 2 (0 to 5VDC)



Connection diagram using terminal 2 (0 to 10VDC)

(2) Perform operation by analog input selection.


- •The frequency setting signal inputs 0 to 5VDC (or 0 to 10VDC) to across the terminals 2-5. The 5V (10V) input is the maximum output.
- •The power supply 5V can be input by either using the internal power supply or preparing an external power supply. Prepare an external power supply to input the power supply 10V. For the built-in power supply, terminals 10-5 provide 5VDC output.

	Inverter Built-in	Frequency	Pr.73
Terminal	Power Supply	Setting	(terminal 2 input
	Voltage	Resolution	power)

- •When inputting 10VDC to the terminal 2, set "0" or "10" in *Pr. 73*. (The initial value is 0 to 5V)
- •Setting "1 (0 to 5VDC)" or "2 (0 to 10VDC)" in *Pr. 267* and a voltage/current input switch in the OFF position changes the terminal 4 to the voltage input specification. When the AU signal turns on, the terminal 4 input becomes valid.

> REMARKS


The wiring length of the terminal 10, 2, 5 should be 30m maximum.



(3) Perform operation by analog input selection.

- •When the pressure or temperature is controlled constant by a fan, pump, etc., automatic operation can be performed by inputting the output signal 4 to 20mADC of the adjuster to across the terminals 4-5.
- •The AU signal must be turned on to use the terminal 4.

Connection diagram using terminal 4 (4 to 20mADC)



Reversible operation example

(4) Perform forward/reverse rotation by analog input (polarity reversible operation)

•Setting "10" or "11" in *Pr. 73* and adjusting *Pr. 125* (*Pr. 126*) *Terminal 2* frequency setting gain frequency (Terminal 4 frequency setting gain frequency) and *C2* (*Pr. 902*) *Terminal 2 frequency setting bias frequency* to *C7* (*Pr.905*) *Terminal 4 frequency setting gain* makes reverse operation by terminal 2 (terminal 4) valid.

Example)When performing reversible operation by terminal 2 (0 to 5V) input

- 1) Set "11" in *Pr. 73* to make reversible operation valid. Set frequency at maximum analog input in *Pr. 125 (Pr. 903)*
- 2) Set 1/2 of the value set in C4 (Pr. 903) in C3 (Pr. 902).
- 3) Reversible operation is performed when 0 to 2.5VDC is input and forward rotation when 2.5 to 5VDC.



NOTE

- When reversible operation is set, be aware of reverse rotation operation when analog input stops (only the start signal is input).
- When reversible operation is valid, reversible operation (0 to 4mA: reverse operation, 4mA to 20mA: forward operation) is performed by terminal 4 in the initial setting.



Parameters referred to

Pr. 125 Terminal 2 frequency setting gain frequency, Pr. 126 Terminal 4 frequency setting gain frequency ® Refer to page 148 Pr. 561 PTC thermistor protection level ® Refer to page 95

C2 (Pr. 902) Terminal 2 frequency setting bias frequency to C7 (Pr. 905) Terminal 4 frequency setting gain Refer to page 148

4.16.2 Response level of analog input and noise elimination (Pr. 74)

The time constant of the primary delay filter can be set for the external frequency command (analog input (terminal 2, 4) signal).

Parameter Number	Name	Initial Value	Setting Range	Description
74	Input filter time constant	1	0 to 8	Primary delay filter time constant for the analog input. A larger setting results in a larger filter.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

- Valid for eliminating noise of the frequency setting circuit.
- Increase the filter time constant if steady operation cannot be performed due to noise.
 A larger setting results in slower response. (The time constant can be set between approximately 1ms to 1s with the setting of 0 to 8.)

4.16.3 Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))

You can set the magnitude (slope) of the output frequency as desired in relation to the frequency setting signal (0 to 5V, 0 to 10V or 4 to 20mADC).

Set *Pr. 267* and voltage/current input switch to switch between 0 to 5VDC, 0 to 10VDC, 0 to 20mADC using terminal 4. (*Refer to page 145*)


[Frequency setting bias/gain parameter]


Parameter Number	Name	Initial Value	Setting Range		Description
125	Terminal 2 frequency setting gain frequency	50Hz	0 to 400Hz	Frequency of terminal 2 input gain (maximum).	
126	Terminal 4 frequency setting gain frequency	50Hz	0 to 400Hz	Frequency of terminal 4 input gain (maximum).	
24412	Analog input display unit	0	0	Displayed in %	Unit for analog input display
241 *1, *3	switchover	0	1	Displayed in V/mA	Unit for analog input display.
C2 (902)	Terminal 2 frequency setting	0Hz	0 to 400Hz	Frequency on the bias side of terminal 2 input.	
*1, *2	bias frequency	UHZ	0 10 40002		
C3 (902)	Terminal 2 frequency setting	0%	0.4- 2000/	Converted % of the bias side voltage (current) of terminal 2 input.	
*1, *2	bias	0%	0 to 300%		
C4 (903)	Terminal 2 frequency setting	100%	0 to 300%	Converted % of the gain side voltage (current) of	
*1, *2	gain	100%	0 10 300%	terminal 2 input.	
C5 (904)	Terminal 4 frequency setting	0Hz	0 to 400Hz	Fraguency on the h	ice side of terminal 4 input
*1, *2	bias frequency	UHZ	0 10 40002	Frequency on the bias side of terminal 4 input	
C6 (904)	Terminal 4 frequency setting	200/	0 to 300%	Converted % of the bias side current (voltage) of terminal 4 input.	
*1, *2	bias	20%	0 10 300%		
C7 (905)	Terminal 4 frequency setting	4000/	0.4- 2000/	Converted % of the gain side current (voltage) of	
*1, *2	gain	100%	0 to 300%	terminal 4 input.	

^{*1} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

^{*2} The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).

^{*3} The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.





(1) Change the frequency at maximum analog input (Pr. 125, Pr. 126)

•Set *Pr.* 125 (*Pr.* 126) when changing frequency setting (gain) of the maximum analog input voltage (current) only. (*C2* (*Pr.* 902) to *C7* (*Pr.*905) setting need not be changed)

(2) Analog input bias/gain calibration (C2 (Pr. 902) to C7 (Pr. 905))

- •The "bias" and "gain" functions are used to adjust the relationship between the input signal entered from outside the inverter to set the output frequency, e.g. 0 to 5V, 0 to 10V or 4 to 20mADC, and the output frequency.
- •Set the bias frequency of the terminal 2 input using *C2 (Pr. 902)*.

(It is initially-set to the frequency at 0V)

- •Set the output frequency in *Pr. 125* for the frequency command voltage set with *Pr. 73 Analog input selection*
- •Set the bias frequency of the terminal 4 input using *C5* (*Pr.* 904).

(It is initially-set to the frequency at 4mA)

- •Using *Pr. 126*, set the output frequency relative to 20mA of the frequency command current (4 to 20mA).
- •There are three methods to adjust the frequency setting voltage (current) bias/gain.
- a) Method to adjust any point by application of a voltage (current) to across terminals 2-5 (4-5)

 ## page 150
- b) Method to adjust any point without application of a voltage (current) to across terminals 2-5 (4-5)

 ## page 151
- c) Method to adjust frequency only without adjustment of voltage (current) *page 152*



NOTE

When voltage/current input signal for terminal 4 was switched using Pr. 267 and voltage/current input switch, perform
calibration without fail.

(3) Analog input display unit changing (Pr. 241)

- You can change the analog input display unit (%/V/mA) for analog input bias/gain calibration.
- Depending on the terminal input specification set to *Pr. 73*, *Pr. 267*, and voltage/current switch, the display units of *C3 (Pr. 902)*, *C4 (Pr. 903)*, *C6 (Pr. 904)*, *C7 (Pr. 905)* change as shown below.


Analog Command (terminal 2, 4) (depending on <i>Pr. 73, Pr. 267</i> , and voltage/current input switch)	<i>Pr. 241</i> = 0 (initial value)	<i>Pr. 241</i> = 1
0 to 5V input	0 to 5V → 0 to 100% (0.1%) display	0 to 100% → 0 to 5V (0.01V) display
0 to 10V input	0 to 10V → 0 to 100% (0.1%) display	0 to 100% → 0 to 10V (0.01V) display
0 to 20mA input	0 to 20mA \rightarrow 0 to 100%(0.1%) display	0 to 100% → 0 to 20mA (0.01mA) display


(4) Frequency setting signal (current) bias/gain adjustment method

(a) Method to adjust any point by application of a voltage (current) to across terminals 2-5 (4-5). Operation Display -1. Confirmation of the RUN indication and operation mode indication The inverter should be at a stop. • The inverter should be in the PU operation (Using (PU PRM indication is lit. 2. Press (MODE) to choose the parameter setting mode. (The parameter number read previously appears.) 3. Turn (until [. . . 4. Turn (SET) until [- - - appears. C1 to C7 setting is enabled. 5. Turn (until [Set to C4 Terminal 2 frequency setting gain. Terminal 4 input is

- **6.** Press (SET) to display the analog voltage (current) value (%).
- 7. Apply a 5V (20mA) voltage (current). (Turn the external potentiometer connected across terminals 2-5 (across terminals 4-5) to maximum (any position).)







Analog voltage (current) value (%) across terminals 2-5 (across terminals 4-5)



The value is nearly 100 (%) in the maximum position of the potentiometer



NOTE

After performing operation in step 6, do not touch (until completion of calibration.



8. Press (SET) to set.







Terminal 4 input is selected



Flicker...Parameter setting complete!!

The value is nearly 100 (%) in the maximum position of the potentiometer.

- •Turn to read another parameter.
- •Press (SET) to return to the [- indication (step 4).
- •Press (SET) twice to show the next parameter (Pr.[].

> REMARKS

- If the frequency meter (display meter) connected across the terminals AM-5 does not indicate just 50Hz, set the calibration parameter C1 AM terminal calibration. (Refer to page 129)
- If the gain and bias of frequency setting voltage (current) are too close, an error (٤ 3) may be displayed at setting



(b) Method to adjust any point without application of a voltage (current) to across terminals 2-5 (4-5) (To change from 4V (80%) to 5V (100%))

Operation —

- 1. Confirmation of the RUN indication and operation mode indication
 - The inverter should be at a stop.
 - The inverter should be in the PU operation mode.
- 2. Press (MODE) to choose the parameter setting mode.
- 3. Turn until [appears.
- 4. Turn (SET) until [- appears.
- 5. Turn until [4 ([7) appears. Set to C4 Terminal 2 frequency setting gain.
- **6.** Press (SET) to display the analog voltage (current) value (%).
- 7. Turn to set gain voltage (%). "0V(0mA) is 0%, 10V(5V, 20mA) is 100%"

Display -







(The parameter number read previously appears.)










88

Analog voltage (current) value (%) across terminals 2-5 (across terminals 4-5)

The gain frequency is reached when the analog voltage (current) value across terminals 2-5 (across terminals 4-5) is 100%.

REMARKS

The current setting at the instant of turning





8. Press(SET) to set.



BB

Terminal 2 input



Terminal 4 input

Flicker...Parameter setting complete!!

(Adjustment completed)

- to read another parameter.
- •Press (SET) to return to the [- indication (step 4).
- •Press (SET) twice to show the next parameter (Pr. [].).

REMARKS

By pressing after step 6, you can confirm the current frequency setting bias/gain setting. You can not check after performing operation in step 7.

(c) Adjusting only the frequency without adjusting the gain voltage (current).(When changing the gain frequency from 50Hz to 40Hz)

Operation –

1. Turn until P. 125 (Pr. 125) or

P. 126 (Pr. 126) appears

2. Press (SET) to show the currently set value. (50.00Hz)

3. Turn to change the set value to

" \\ [] [] [] ". (40.00Hz)

4. Press (SET) to set.

Display











Terminal 2 input is selected

Terminal 4 input is selected



Flicker...Parameter setting complete!!

5. Mode/monitor check

Press (MODE) twice to choose the monitor/frequency monitor.

Apply a voltage across the inverter terminals 2-5 (across 4-5) and turn on the start command (STF, STR).

Operation starts at 40Hz.







> REMARKS

- Changing C4 (Pr. 903) or C7 (Pr. 905) (gain adjustment) value will not change the Pr. 20 value.
- For operation from the parameter unit (FR-PU04/FR-PU07), refer to the instruction manual of the FR-PU04/FR-PU07.
- When setting the value to 120Hz or more, it is necessary to set *Pr. 18 High speed maximum frequency* to 120Hz or more. (*Refer to page 78*)
- Make the bias frequency setting using the calibration parameter C2 (Pr. 902) or C5 (Pr. 904). (Refer to page 149)

♠ CAUTION

Take care when setting any value other than "0" as the bias frequency at 0V (0mA). Even if a speed command is not given, merely turning on the start signal will start the motor at the preset frequency.



Parameters referred to

Pr. 20 Acceleration/deceleration reference frequency Refer to page 91

Pr. 73 Analog input selection, Pr. 267 Terminal 4 input selection Refer to page 145

Pr. 79 Operation mode selection 👺 Refer to page 160

Bias and gain of built-in frequency setting potentiometer Refer to page 262



4.17 Misoperation prevention and parameter setting restriction

Purpose	Parameter that should	l be Set	Refer to Page
Limits reset function Trips stop when PU is disconnected Stops from PU	Reset selection/disconnected PU detection/PU stop selection	Pr. 75	153
Prevention of parameter rewrite	Parameter write disable selection	Pr. 77	156
Prevention of reverse rotation of the motor	Reverse rotation prevention selection	Pr. 78	157
Displays necessary parameters	Display of applied parameters	Pr. 160	157
Parameter restriction with using password	Password function	Pr. 296, Pr. 297	158
Control of parameter write by communication	EEPROM write selection	Pr. 342	182

4.17.1 Reset selection/disconnected PU detection/PU stop selection (Pr. 75)

You can select the reset input acceptance, disconnected PU (FR-PU04/FR-PU07) connector detection function and PU stop function.

Parameter Number	Name	Initial Value	Setting Range	Description
	Reset selection/			For the initial value, reset always enabled,
75	disconnected PU detection/	14	0 to 3, 14 to 17	without disconnected PU detection, and
	PU stop selection			with PU stop function are set.

^{*}The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

[•]The Pr. 75 value can be set any time. Also, if parameter (all) clear is executed, this setting will not return to the initial value.

Pr. 75 Setting	Reset Selection	Disconnected PU Detection	PU Stop Selection	
0	Reset input normally enabled	If the PU is disconnected, operation		
1	Reset input is enabled only when the fault occurs.	will be continued.	Pressing (STOP) decelerates the motor	
2	Reset input normally enabled	When the PU is disconnected, the	to a stop only in the PU operation	
3	Reset input is enabled only when the fault occurs.	inverter trips.	mode.	
14 (initial value)	Reset input normally enabled	If the PU is disconnected, operation		
15	Reset input is enabled only when the fault occurs.	will be continued.	Pressing (STOP) decelerates the motor	
16	Reset input normally enabled	When the PU is disconnected, the	to a stop in any of the PU, external	
17	Reset input is enabled only when the fault occurs.	inverter trips.	and communication operation modes.	

(1) Reset selection

- •You can select the enable condition of reset function (RES signal, reset command through communication) input.
- •When Pr. 75 is set to any of "1, 3, 15, 17", a reset can be input only when the inverter is tripped.



NOTE

- When the reset signal (RES) is input during operation, the motor coasts since the inverter being reset shuts off the output.
 - When reset is performed, cumulative values of electronic thermal O/L relay, regenerative brake duty are cleared.
- The reset key of the PU is only valid when the inverter is tripped, independently of the Pr. 75 setting.

(2) Disconnected PU detection

- •This function detects that the PU (FR-PU04/FR-PU07) has been disconnected from the inverter for longer than 1s and causes the inverter to provide a fault output (E.PUE) and come to trip.
- •When Pr. 75 is set to any of "0, 1, 14, 15", operation is continued if the PU is disconnected.

• REMARKS

- When the PU has been disconnected since before power-on, it is not judged as a fault.
- To make a restart, confirm that the PU is connected and then reset the inverter.
- The motor decelerates to a stop when the PU is disconnected during PU jog operation with *Pr.* 75 set to any of "0, 1, 14, 15" (which selects operation is continued if the PU is disconnected).
- When RS-485 communication operation is performed through the PU connector, the reset selection/PU stop selection function is valid but the disconnected PU detection function is invalid.

PU stop selection

- •In any of the PU operation, external operation and network operation modes, the motor can be stopped by pressing STOP key of the operation panel or parameter unit (FR-PU04/FR-PU07, operation panel for FR-E500 (PA02)).
- •When the inverter is stopped by the PU stop function, " 🏳 💆 " (PS) is displayed. A fault output is not provided.
- •After the motor is stopped from the PU, it is necessary to perform PU stop (PS) reset to restart. PS reset can be made from the unit from which PU stop is made (operation panel, parameter unit (FR-PU04/PU07, operation panel for FR-E500
- •The motor can be restarted by making PS cancel using a power supply reset or RES signal.
- •When Pr. 75 is set to any of "0 to 3", PU stop (PS display) is invalid, deceleration to a stop by (RESET) is valid only in the PU operation mode.




> REMARKS

During operation in the PU operation mode through RS-485 communication from the PU connector, the motor decelerates to stop (PU stop) when entered from the operation panel (STOP)

(PS) reset method)



(4) How to restart the motor stopped by (STOP) input from the PU in external operation mode (PU stop



a) Operation panel

- 1)After completion of deceleration to a stop, switch off the STF or STR signal.
- 2)Press $\frac{PU}{EXT}$ to display $\frac{PU}{EXT}$ ($\cancel{P5}$ reset)
- 3)Press $\frac{PU}{FXT}$ to return to $\frac{FXT}{FXT}$.
- 4)Switch on the STF or STR signal.

b) Parameter unit (FR-PU04/FR-PU07)

- 1)After completion of deceleration to a stop, switch off the STF or STR signal.
- 2)Press EXT (**P** 5 reset)
- 3)Switch on the STF or STR signal.
- The motor can be restarted by making a reset using a power supply reset or RES signal.



> REMARKS

If Pr. 250 Stop selection is set to other than "9999" to select coasting to a stop, the motor will not be coasted to a stop but decelerated to a stop by the PU stop function during external operation.



(5) Restart (PS reset) method when PU stop (PS display) is made during PU operation

•PU stop (PS display) is made when the motor is stopped from the unit where control command source is not selected (operation panel, parameter unit (FR-PU04/FR-PU07, operation panel for FR-E500 (PA02)) in the PU operation mode. For example, when *Pr. 551 PU mode operation command source selection* = "9999" (initial value), the motor is stopped from

the PU (PS display) if entered from the operation panel (RESET) in PU operation mode with the parameter unit mounted.

When the motor is stopped from the PU when the parameter unit (FR-PU04/FR-PU07) is selected as control command source.

- 1) After the motor has decelerated to a stop, press (STOP) of the parameter unit (FR-PU04/FR-PU07).
- 2) Press $\frac{PU}{EXT}$ to display \boxed{EXT} .($\begin{cases} \begin{cases} \begin{case$
- 3) Press Pulof the parameter unit (FR-PU04/FR-PU07) to select the PU operation mode.
- 4) Press FWD or REV of the parameter unit (FR-PU04/FR-PU07).

• REMARKS

• When Pr. 551 = "9999", the priorities of the PU control source is parameter unit (FR-PU04/FR-PU07) > operation panel.



Otherwise, the motor will start instantly after resetting, leading to potentially hazardous conditions.



Parameters referred to

Pr. 250 Stop selection Refer to page 107
Pr. 551 PU mode operation command source selection Refer to page 171

4.17.2 Parameter write disable selection (Pr. 77)

You can select whether write to various parameters can be performed or not. Use this function to prevent parameter values from being rewritten by misoperation.

Parameter Number	Name	Initial Value	Setting Range	Description
	Parameter write selection	0	0	Write is enabled only during a stop.
77			1	Parameter can not be written.
,,			2	Parameter write is enabled in any operation
				mode regardless of operation status.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Write parameters only during stop (setting "0" initial value)

- •Parameters can be written only during a stop in the PU operation mode.
- •The shaded parameters in the parameter list (page 52) can always be written regardless of the operation mode and operating status. However, Pr. 72 PWM frequency selection and Pr. 240 Soft-PWM operation selection can be written when the inverter is running in the PU operation mode, but cannot be written in the external operation mode.

(2) Inhibit parameter write (setting "1")

- •Parameter write is not enabled. (Read is enabled.)
- Parameter clear and all parameter clear cannot be performed, either.
- •The parameters given on the right can be written if Pr. 77 = "1".

Parameter Number	Name
22	Stall prevention operation level
75	Reset selection/disconnected PU detection/
75	PU stop selection
77	Parameter write selection
79	Operation mode selection
160	Extended function display selection
296	Password lock level
297	Password lock/unlock

(3) Write parameters during operation (setting "2")

- •Parameters can always be written.
- •The following prameters cannot be written when the inverter is running if Pr: 77 = "2". Stop the inverter when changing their parameter settings.

Parameter Number	Name		
Number			
23	Stall prevention operation level compensation		
	factor at double speed		
40	RUN key rotation direction selection		
48	Second stall prevention operation current		
60	Energy saving control selection		
66	Stall prevention operation reduction starting		
00	frequency		
71	Applied motor		
79	Operation mode selection		
80	Motor capacity		
82	Motor excitation current		
83	Motor rated voltage		
84	Rated motor frequency		
90	Motor constant (R1)		

Parameter	Name
Number	Name
96	Auto tuning setting/status
178 to 182	(input terminal function selection)
190, 192	(output terminal function selection)
255	Life alarm status display
256	Inrush current limit circuit life display
257	Control circuit capacitor life display
258	Main circuit capacitor life display
261	Power failure stop selection
298	Frequency search gain
343	Communication error count
450	Second applied motor
561	PTC thermistor protection level
563	Energization time carrying-over times
564	Operating time carrying-over times



Parameters referred to

Pr. 79 Operation mode selection 👺 Refer to page 160

Pr. 77 can be always set independently of the operation mode and operation status.



4.17.3 Reverse rotation prevention selection (Pr. 78)

This function can prevent reverse rotation fault resulting from the incorrect input of the start signal.

Parameter Number	Name	Initial Value	Setting Range	Description
	78 Reverse rotation prevention selection	0	0	Both forward and reverse rotations allowed
78			1	Reverse rotation disabled
			2	Forward rotation disabled

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

- · Set this parameter when you want to limit the motor rotation to only one direction.
- This parameter is valid for all of the reverse rotation and forward rotation keys of the enclosure surface operation panel and parameter unit(FR-PU04/FR-PU07), the start signals (STF, STR signals) via external terminals, and the forward and reverse rotation commands through communication.

4.17.4 Extended parameter display (Pr. 160)

Parameter which can be read from the operation panel and parameter unit can be restricted. In the default setting, only the simple mode parameters are displayed.

Parameter Number	Name	Initial Value	Setting Range	Description
400	Extended function display	0000	9999	Displays only the simple mode parameters
160	selection	9999	0	Displays simple mode + extended parameters

(1) Display of simple mode parameters and extended parameters (Pr. 160)

- •When Pr. 160 = "9999" (initial value), only the simple mode parameters can be displayed on the operation panel and parameter unit (FR-PU04/FR-PU07). (Refer to the parameter list , page 52, for the simple mode parameters.)
- •When Pr. 160 = "0", simple mode parameters and extended parameters can be displayed.

(I) REMARKS

- When RS-485 communication is used to read the parameters with Pr. 551 PU mode operation command source selection ≠ "2", all parameters can be read regardless of the Pr. 160 setting.
- Pr. 15 Jog frequency, Pr. 16 Jog acceleration/deceleration time, and Pr. 991 PU contrast adjustment are displayed as simple mode parameter when the parameter unit (FR-PU04/FR-PU07) is fitted.



Parameters referred to

Pr. 15 Jog frequency Refer to page 86

Pr. 16 Jog acceleration/deceleration time 👺 Refer to page 86

Pr. 551 PU mode operation command source selection Refer to page 171

Pr. 991 PU contrast adjustment Refer to page 238

4.17.5 Password function (Pr. 296, Pr. 297)

Registering 4-digit password can restrict parameter reading/writing.

Parameter Number	Name	Initial Value	Setting Range	Description		
296	Password lock level	9999	1 to 6, 101 to 106	Select restriction level of parameter reading/ writing when a password is registered.		
230	T ussword look level	0000	9999	No password lock		
			1000 to 9998	Register a 4-digit password		
				Displays password unlock error count. (Reading		
297	Password lock/unlock	9999	writing when a password is registered. 9999 No password lock 1000 to 9998 Register a 4-digit password			
				(Valid when Pr. 296 = "101" to "106")		
			(9999)	No password lock (Reading only)		

The above parameters can be set when Pr. 160 Extended function display selection = "0".

When Pr. 296 ≠ "9999" (with password lock), note that Pr. 297 is always available for setting regardless of Pr. 160 setting.

(1) Parameter reading/writing restriction level (Pr. 296)

•Level of reading/writing restriction by PU/NET mode operation command can be selected by Pr. 296.

Pr. 296 Setting	PU Mode Operat	ion Command *3	NET Mode Operation Command *4		
F1. 230 Setting	Read *1	Read *1 Write *2		Write *2	
9999	0	0	0	0	
1, 101	0	×	0	×	
2, 102	0	×	0	0	
3, 103	0	0	0	×	
4, 104	×	×	×	×	
5, 105	×	×	0	0	
6, 106	0	0	×	×	

O: enabled, \times : restricted

- *1 If the parameter reading is restricted by the *Pr. 160* setting, those parameters are unavailable for reading even when "O" is indicated.
- *2 If the parameter writing is restricted by the Pr. 77 setting, those parameters are unavailable for writing even when "O" is indicated.
- *3 Parameter access from unit where parameter is written in PU operation mode (initially set to operation panel, parameter unit) is restricted. (Refer to page 171 for PU mode operation command source selection)
- *4 Parameter access in NET operation mode with RS-485 communication is restricted.



(2) Password lock/unlock (Pr.296, Pr.297)

<Lock>

1) Set parameter reading/writing restriction level.($Pr. 296 \neq 9999$)

Setting "1" to "6": Not display password unlock error count when reading Pr. 297. Setting "101" to "106": Displays password unlock error count when reading Pr. 297.

* When Pr. 296 = "101 to 106", if password unlock error has occurred 5 times, correct password will not unlock the restriction. Parameter all clear can unlock the restriction.

(In this case, parameter setting are cleared.)

2) Write four-digit numbers (1000 to 9998) in Pr. 297 as a password.

(When *Pr. 296* = "9999", *Pr. 297* can't write.)

When password is registered, parameter reading/writing is restricted with the restriction set level in Pr. 296 until unlocking.

• REMARKS

- After registering a password, a read value of Pr. 297 is always "0" to "5".
- When a password restricted parameter is read/written, L [[] [] is displayed.
- Even if a password is registered, parameters which the inverter itself writes, such as inverter parts life, are overwritten occasionally.
- Even if a password is registered, Pr. 991 PU contrast adjustment can be read/written when a parameter unit (FR-PU04/FR-PU07) is connected.

<Unlock>

There are two ways of unlocking the password.

• Enter a password in Pr. 297.

Unlocked when a password is correct. If a password is incorrect, an error occurs and not unlocked.

During Pr. 296 = "101 to 106", if password unlock error has occurred 5 times, correct password will not unlock the restriction. (During password lock)

· Perform parameter all clear.

Password lock is unlocked. Parameter setting are cleared.



NOTE

- If the password has been forgotten, perform parameter all clear to unlock the parameter restriction. In that case, other parameters are also cleared.
- Parameter all clear can not be performed during operation of voltage output.

(3) Parameter operation during password locked/unlocked

		Unio	cked	Password registered	Locked
Parameter operation		Pr. 296 = 9999	Pr. 296 ≠ 9999	<i>Pr. 296</i> ≠ 9999	<i>Pr. 296</i> = 101 to 106
Parametei	roperation	- 11 - 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2		Pr. 297 = 0 to 4	<i>Pr.</i> 297 = 5
		<i>Pr. 297</i> = 9999	<i>Pr. 297</i> = 9999	(Read value)	(Read value)
Pr. 296	Read	0 *1	0	0	0
F1. 290	Write	0 *1	0 *1	X	X
Pr. 297	Read	0 *1	0	0	0
F1. 29/	Write	×	0	0	O *3
Performing pa	arameter clear	0	0	×	X
Performing parameter all clear		0	0	O *2	O *2
Performing pa	arameter copy	0	0	×	X
					O: enabled ×: restricted

- *1 Reading/writing is unavailable when there is restriction to reading by the Pr. 160 setting.
- Unavailable during operation of voltage output.
- Correct password will not unlock the restriction.

> REMARKS

- When Pr. 296 = "4, 5, 104, 105" and using the parameter unit (FR-PU04/FR-PU07), PUJOG operation is unavailable.
- When writing is restricted from PU mode operation command (Pr. 296 = 1, 2, 4, 5, 101, 102, 104, 105), switching of operation mode by easy setting mode is unavailable.



Parameters referred to

Pr. 77 Parameter write selection Refer to page 156 Pr. 160 Extended function display selection Tel Refer to page 157 Pr. 551 PU mode operation command source selection Refer to page 171

4.18 Selection of operation mode and operation location

Purpose	Parameter that should	Refer to Page	
Operation mode selection	Operation mode selection	Pr. 79	160
Started in network operation mode	Operation mode at power-on	Pr. 79, Pr. 340	170
	Operation command source and		
Oalastian of annuation lass than	speed command source during	Pr. 338, Pr. 339	171
Selection of operation location	communication operation, selection	Pr. 551	171
	of operation location		

4.18.1 Operation mode selection (Pr. 79)

Used to select the operation mode of the inverter.

Mode can be changed as desired between operation using external command signals (external operation), operation from the operation panel and PU (FR-PU07/FR-PU04) (PU operation), combined operation of PU operation and external operation (external/PU combined operation), and network operation (when RS-485 communication is used).


Doromatan		lnitial	Cotting			LED Indication
Parameter Number	Name	Initial Value	Setting	Descr	:Off	
Number		value	Range			□:On
			0		Use external/PU switchover mod PU and external operation mode At power on, the inverter is in the	External operation mode EXT PU operation mode PU
			1	Fixed to PU operation mode		PU
			2	Fixed to external operation mode Operation can be performed by and Net operation mode.	External operation mode EXT NET operation mode	
				External/PU combined operation	mode 1	
				Frequency command	Start command	
	Operation		3	Operation panel and PU (FR-PU04/FR-PU07) setting or external signal input (multi-speed setting, across terminals 4-5 (valid when AU signal turns on)).	External signal input (terminal STF, STR)	
79	mode	0	External/PU combined operation	PU EXT		
	selection			Frequency command	Start command	
	Selection		4	External signal input (terminal 2, 4, JOG, multi-speed selection, etc.)	Enter from RUN of the operation panel and FWD and REV of the PU (FR-PU04/FR-PU07)	
			6	Switchover mode Switchover between PU operation, external operation, and NET operation is available while keeping the same operation status.		PU operation mode PU External operation mode EXT NET operation mode
External operation mode (PU operation interlock) X12 signal ON Operation mode can be switched to the PU operation to the PU operation to the PU operation to the PU operation mode can not be switched to				ned to the PU operation mode. operation)	PU operation mode PU External operation mode EXT	

The above parameters can be changed during a stop in any operation mode.



(1) Operation mode basics


- The operation mode specifies the souce of the start command and the frequency command for the inverter.
- Select the "external operation mode" when the start command and the frequency command are applied from a potentiometer, switches, etc. which are provided externally and connecting them to the control terminals. Select "PU operation mode" when the commands are applied using the operation panel or parameter unit (FR-PU04/FR-PU07). Select the "network operation mode (NET operation mode)" when the commands are applied from the RS-485 communication with the PU connector.
- The operation mode can be selected from the operation panel or with the communication instruction code.




(I) REMARKS

- Either "3" or "4" may be set to select the PU/external combined mode. Refer to page 160 for details.
- The stop function (PU stop selection) activated by pressing (STOP) RESET of the operation panel and parameter unit (FR-PU04/FR-PU07) is valid even in other than the PU operation mode in the initial setting. (Refer to Pr. 75 Reset selection/disconnected PU detection/PU stop selection (page 153))

(2) Operation mode switching method





• REMARKS

• Refer to the flow chart on the next page for switching by the external terminal.

PU operation external interlock signal (X12) **Refer to page 166

PU-external operation switch-over signal (X16) 👺 Refer to page 167


External-NET operation switchover signal (X65), NET-PU operation switchover signal (X66) 🐨 Refer to page 168

Pr. 340 Communication startup mode selection TF Refer to page 170




(3) Operation mode selection flow

In the following flowchart, select the basic parameter setting and terminal connection related to the operation mode.



(4) External operation mode (setting "0" (initial value), "2")




- •Select the extenal operation mode when the start command and the frequency command are applied from a frequency setting potentiometer, start switch, etc. which are provided externally and connecting them to the control circuit terminals of the inverter.
- •Basically, parameter changing is disabled in the external operation mode. (Some parameters can be changed. Refer to *page 52* for the parameter list.)
- When "0" or "2" is selected for *Pr. 79*, the inverter enters the external operation mode at power-on. (When using the network operation mode, refer to *page 170*.)
- When parameter changing is seldom necessary, setting
 "2" fixes the operation mode to the external operation mode.

When frequent parameter changing is necessary, setting "0" (initial value) allows the operation mode to be changed easily to the PU operation mode by pressing

(PU EXT) of the operation panel. When you switched to the PU operation mode, always return to the external operation mode.


 The STF and STR signal are used as a start command, and the voltage or current signal to terminal 2, 4, multispeed signal, JOG signal, etc. are used as a frequency command.


(5) PU operation mode (setting "1")



- Select the PU operation mode when applying start and frequency command by only the key operation of the operation panel (FR-PU04/FR-PU07). Also select the PU operation mode when making communication using the PU connector.
- •When "1" is selected for *Pr. 79*, the inverter enters the PU operation mode at power on. You cannot change to the other operation mode.
- •The setting dial of the operation panel can be used for setting like a potentiometer. (Refer to Pr. 161 Frequency setting/key lock operation selection (page 235))


(6) PU/external combined operation mode 1 (setting "3")





- •Select the PU/external combined operation mode 1 when applying frequency command from the operation panel or parameter unit (FR-PU04/FR-PU07) and inputting the start command with the external start switch.
- •Select "3" for *Pr. 79*. You cannot change to the other operation mode.
- •When a frequency is applied from the external signal by multi-speed setting, it has a higher priority than the frequency command from the PU. When AU is on, the command signal to terminal 4 is used.

(7) PU/external combined operation mode 2 (setting "4")



- •Select the PU/external combined operation mode 2 when applying frequency command from the external potentiometer, multi-speed or JOG signal and inputting the start command by key operation of the operation panel or parameter unit (FR-PU04/FR-PU07).
- •Select "4" for *Pr.* 79. You cannot change to the other operation mode.



(8) Switch-over mode (setting "6")

•While continuing operation, you can switch between the PU operation, external operation and network operation (NET operation).

Operation Mode Switching	Switching Operation/Operating Status
External operation → PU operation	Select the PU operation mode with the operation panel or parameter unit. •Rotation direction is the same as that of external operation. •The frequency set with the potentiometer (frequency command) or like is used unchanged. (Note that the setting will disappear when power is switched off or the inverter is reset.)
External operation → NET operation	Send the mode change command to the network operation mode through communication. •Rotation direction is the same as that of external operation. •The value set with the setting potentiometer (frequency command) or like is used unchanged. (Note that the setting will disappear when power is switched off or the inverter is reset.)
PU operation → external operation	Press the external operation key of the operation panel or parameter unit. •The rotation direction is determined by the input signal of the external operation. •The set frequency is determined by the external frequency command signal.
PU operation → NET operation	Send the mode change command to the network operation mode through communication. •Rotation direction and set frequency are the same as those of PU operation.
NET operation → external operation	Command to change to external mode is transmitted by communication. •Rotation direction is determined by the external operation input signal. •The set frequency is determined by the external frequency command signal.
NET operation → PU operation	Select the PU operation mode with the operation panel or parameter unit. •The rotation direction and frequency command in the network operation mode are used unchanged.

(9) PU operation interlock (setting "7")

• The PU operation interlock function is designed to forcibly change the operation mode to the external operation mode when the PU operation interlock signal (X12) input turns off.

This function prevents the inverter from being inoperative by the external command if the mode is accidentally left unswitched from PU operation mode.

- •Set "7" (PU operation interlock) in Pr. 79.
- •For the terminal used for X12 signal (PU operation interlock signal) input, set "12" to any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the function. (Refer to *page 108* for *Pr.178 to Pr.182*.)
- •When the X12 signal is not assigned while MRS signal is assigned, function of the MRS signal switches from output stop to PU operation interlock signal.

X12 (MRS)	Function/Operation					
Signal	Operation Mode	Parameter Write				
	Operation mode (external, PU, NET) switching	Parameter write enabled (depending on Pr. 77 Parameter				
ON	enabled	write selection and each parameter write conditions				
	Output stop during external operation	(Refer to page 52 for the parameter list))				
	Forcibly switched to external operation mode					
OFF	External operation allowed	Parameter write disabled with exception of <i>Pr. 79</i>				
OFF	Switching between the PU and Net operation mode	Parameter write disabled with exception of Pr. 79				
	is enabled					

<Function/operation changed by switching on-off the X12 (MRS) signal>

Operating Condition			Operation		Switching to PU,
Operation	Status X12 (MRS) Signa			Operating Status	NET Operation
Mode	Status		Mode		Mode
	During	ON → OFF *1		If external operation frequency setting and	Disallowed
PU/NET	stop	ON 7 OFF *1	External *2	start signal are entered, operation is	Disallowed
	Running	ON → OFF *1]	performed in that status.	Disallowed
	During	OFF → ON		During stop	Allowed
External	stop	ON → OFF	External *2	During stop	Disallowed
Running		OFF → ON	LAterrial *2	During operation → output stop	Disallowed
	Running	ON → OFF		Output stop → operation	Disallowed

^{*1} The operation mode switches to the external operation mode independently of whether the start signal (STF, STR) is on or off. Therefore, the motor is run in external operation mode when the X12 (MRS) signal is turned off with either of STF and STR on.

^{*2} At fault occurrence, pressing $(\overline{\text{RTSET}})$ of the operation panel resets the inverter.



NOTE

- If the X12 (MRS) signal is on, the operation mode cannot be switched to the PU operation mode when the start signal (STF, STR) is on.
- When the MRS signal is used as the PU interlock signal, the MRS signal serves as the normal MRS function (output stop) by turning on the MRS signal and then changing the *Pr. 79* value to other than "7" in the PU operation mode. As soon as "7" is set to *Pr. 79*, the MRS signal acts as the PU interlock signal.
- When the MRS signal is used as the PU interlock signal, the logic of the signal is as set in Pr. 17. When Pr. 17 = "2", read ON as OFF and OFF as ON in the above explanation.
- Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

(10) Switching of operation mode by external signal (X16 signal)

- •When external operation and operation from the operation panel are used togheter, use of the PU-external operation switching signal (X16) allows switching between the PU operation mode and external operation mode during a stop (during a motor stop, start command off).
- •When Pr: 79 = any of "0, 6, 7", the operation mode can be switched between the PU operation mode and external operation mode. (Pr: 79 = "6" Switch-over mode can be changed during operation)
- •For the terminal used for X16 signal input, set "16" to any of *Pr. 178 to Pr. 182 (input terminal function selection)* to assign the function.

	Pr. 79	X16 Signal State	Operation Mode	Remarks		
	Setting	ON (external) OFF (PU)		Remarks		
0 (initial value)	External operation	PU operation mode	Can be switched to external, PU or NET operation mode		
0 (1	iriitiai vaiue)	mode		can be switched to external, 1 0 or NET operation mode		
	1	PU operation mode		Fixed to PU operation mode		
	2	External operation mode		Fixed to external operation mode (can be switched to NET operation		
	2			mode)		
	3, 4	External/PU combined operation mode		External/PU combined mode fixed		
	6	External operation	PU operation mode	Switching among the external, PU, and NET operation mode is		
	O	mode	FO operation mode	enabled while running.		
	X12 (MRS)	External operation	PU operation mode	Can be switched to external, PU or NET operation mode (output stop		
7	ON	mode	PO operation mode	in external operation mode)		
'	X12 (MRS)	External operation mode		Fixed to external operation mode (forcibly switched to external		
	OFF			operation mode)		



> REMARKS

- The operation mode status changes depending on the setting of *Pr. 340 Communication startup mode selection* and the ON/OFF status of the X65 and X66 signals. (For details, refer to *page 168*)
- The priorities of Pr. 79, Pr. 340 and signals are Pr. 79 > X12 > X66 > X65 > X16 > Pr. 340.



NOTE

• Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

7/

(11) Switching of operation mode by external signals (X65, X66 signals)

- •When Pr. 79 = any of "0, 2, 6", the operation mode switching signals (X65, X66) can be used to change the PU or external operation mode to the network operation mode during a stop (during a motor stop or start command off). (Pr. 79 = "6" Switch-over mode can be changed during operation)
- When switching between the network operation mode and PU operation mode
 - 1)Set Pr. 79 to "0" (initial value) or "6".
 - 2)Set "10" in Pr. 340 Communication startup mode selection.
 - 3)Set "65" in any of Pr. 178 to Pr. 182 to assign the NET-PU operation switching signal (X65) to the terminal.
 - 4)The operation mode changes to the PU operation mode when the X65 signal turns on, or to the network operation mode when the X65 signal turns off.

Pr. 340	Pr. 79 Setting		X65 Sig	nal State	Remarks	
Setting			ON (PU) OFF (NET)		Remarks	
	0 ((initial value)	PU operation mode *1	NET operation mode *2	Cannot be switched to external operation mode	
	1		PU operation mode		Fixed to PU operation mode	
	2		NET operation mode		Fixed to NET operation mode	
	3, 4		External/PU combined operation mode		External/PU combined mode fixed	
10	6		PU operation mode *1	NET operation mode	Operation mode can be switched with operation continued	
			ro operation mode ∗1	*2	Cannot be switched to external operation mode	
	X12 (MRS)		Switching among the external and PU		Output stop in external operation mode	
	7 ON		operation mode is enabled *3		Output stop in external operation mode	
	X12 (MRS) OFF		External on	eration mode	Foreibly switched to external eneration made	
			External ope	cration mode	Forcibly switched to external operation mode	

- *1 NET operation mode when the X66 signal is on.
- *2 PU operation mode when the X16 signal is off.
- *3 External operation mode when the X16 signal is on.
- •When switching between the network operation mode and external operation mode
 - 1) Set *Pr. 79* to "0 (initial value), 2, 6 or 7". (At the *Pr. 79* setting of "7", the operation mode can be switched when the X12 (MRS) signal turns on.)
 - 2) Set "0 (initial value) or 1" in Pr. 340 Communication startup mode selection.
 - 3) Set "66" in any of Pr. 178 to Pr. 182 to assign the NET-PU operation switching signal (X66) to the terminal.
 - 4) The operation mode changes to the network operation mode when the X66 signal turns on, or to the external operation mode when the X66 signal turns off.

			oo signal turis on.	-10(-1-	
Pr. 340	Pr. 79 Setting		X66 Sigr	iai State	Remarks
Setting			ON (NET) OFF (external)		Remains
	0	(initial value)	NET operation mode	External operation mode *1	
	1		PU operation mode		Fixed to PU operation mode
		2	NET operation mode	External operation mode	Cannot be switched to PU operation mode
0 (initial	3, 4		External/PU combined operation mode		External/PU combined mode fixed
value)		6	NET operation mode	External operation mode *1	Operation mode can be switched with operation continued
	7	X12 (MRS) ON	NET operation mode	External operation mode *1	Output stop in external operation mode
		X12 (MRS) OFF	External ope	ration mode	Forcibly switched to external operation mode

^{*}I PU operation mode when the X16 signal is off. When the X65 signal has been assigned, the operation mode changes with the ON/OFF state of the X65 signal.



> REMARKS

• The priorities of Pr. 79, Pr. 340 and signals are Pr. 79 > X12 > X66 > X65 > X16 > Pr. 340.



NOTE

 Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 15 Jog frequency Refer to page 86

Pr. 4 to 6, Pr. 24 to 27, Pr. 232 to Pr. 239 Multi-speed operation Refer to page 84

Pr. 75 Reset selection/disconnected PU detection/PU stop selection Refer to page 153

Pr. 161 Frequency setting/key lock operation selection Refer to page 235

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108

Pr. 190, Pr. 192 (output terminal function selection) Terminal function selection)

Pr. 340 Communication startup mode selection Tel Refer to page 170

4.18.2 Operation mode at power-on (Pr. 79, Pr. 340)

When power is switched on or when power comes back on after instantaneous power failure, the inverter can be started up in the network operation mode.

After the inverter has started up in the network operation mode, parameter write and operation can be performed from a program.

Set this mode for communication operation using PU connector.

Parameter Number	Name	Initial Value	Setting Range	Description
79	Operation mode selection	0	0 to 4, 6, 7	Operation mode selection
73	Operation mode selection	J	0 10 4, 0, 7	(Refer to page 163)
		0	0	As set in Pr. 79.
			1	Network operation mode
340 *	Communication startup		40	Network operation mode
340 *	mode selection			Operation mode can be changed between
			10	the PU operation mode and network
				operation mode from the operation panel.

The above parameters can be changed during a stop in any operation mode.

(1) Specify operation mode at power-on (Pr. 340)

•Depending on the Pr. 79 and Pr. 340 settings, the operation mode at power-on (reset) changes as described below.

Pr. 340 Setting	Pr. 79 Setting	Operation Mode at Power-on, Power Restoration, Reset	Operation Mode Switching		
	0 (initial value)	External operation mode	Switching among the external, PU and Net operation mode is enabled *1		
	1	PU operation mode	Fixed to PU operation mode		
0	2	External operation mode	Switching between the external and NET operation mode is enabled Switching to PU operation mode disabled		
(initial	3, 4	External/PU combined mode	Operation mode switching disabled		
value)	6	External operation mode	Switching among the external, PU, and NET operation mode is enabled while running.		
		X12 (MRS) signal ONExternal operation	Switching among the external, PU and Net operation mode is		
	7	mode	enabled *1		
	ľ	X12 (MRS) signal offExternal operation	Fixed to external operation mode (Forcibly switched to external		
		mode	operation mode.)		
	0	NET operation mode			
	1	PU operation mode			
	2	NET operation mode			
	3, 4	External/PU combined mode			
1	6	NET operation mode	Same as when <i>Pr. 340</i> = "0"		
		X12 (MRS) signal ON NET operation			
	7	mode			
	•	X12(MRS) signal offExternal operation			
		mode			
	0	NET operation mode	Switching between the PU and Net operation mode is enabled *2		
	1	PU operation mode	Same as when <i>Pr. 340</i> = "0"		
	2	NET operation mode	Fixed to NET operation mode		
10	3, 4	External/PU combined mode	Same as when <i>Pr. 340</i> = "0"		
	6	NET operation mode	Switching between the PU and NET operation mode is enabled		
	,	·	while running *2		
	7	External operation mode	Same as when <i>Pr. 340</i> = "0"		

^{*1} Operation mode can not be directly changed between the PU operation mode and network operation mode

^{*2} Operation mode can be changed between the PU operation mode and network operation mode with $\frac{PU}{EXT}$ key of the operation panel and X65 signal.



Parameters referred to

Pr. 79 Operation mode selection 👺 Refer to page 160

^{*} The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



4.18.3 Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 551)

When the RS-485 communication with the PU connector is used, the external start command and frequency command can be made valid. Command source in the PU operation mode can be selected.

From the communication device, parameter unit, etc. which have command source, parameter write or start command can be executed. Parameter read or monitoring can be executed in any operation mode.

Parameter	Name	Initial	Setting	Description	
Number	Name	Value	Range	Description	
338	Communication operation	0	0	Start command source communication	
330	command source	U	1	Start command source external	
			0	Frequency command source communication	
				Frequency command source external (Frequency command from	
	Communication speed command source	0	1	communication is invalid, frequency command from terminal 2 is	
339				valid)	
			2	Frequency command source external (Frequency command from	
				communication is valid, frequency command from terminal 2 is	
				invalid)	
			2	PU connector is the command source when PU operation mode.	
	PU mode operation		4	Operation panel is the command source when PU operation mode.	
551 *	command source selection	0000		Parameter unit automatic recognition	
551 *		9999	9999	Normally, operation panel is the command source. When the	
			3333	parameter unit is connected to the PU connector, PU is the	
				command source.	

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Selects the command source of the PU operation mode (Pr. 551)

- •Any of the operation panel, PU connector can be specified as the command source in the PU operation mode.
- •In the PU operation mode, set *Pr. 551* to "2" when executing parameter write, start command or frequency command during the RS-485 communication with PU communication.
- PU...PU operation mode, NET...network operation mode, —....without command source

Pr. 551		Command Source		
Setting	Operation	Parameter	RS-485	Remarks
Setting	panel	unit	communication	
2	_	PU	PU *1	Switching to NET operation mode
		10	10*1	disabled
4	PU	_	NET	
9999	PU *2	PU *2	NET	
(initial value)	1 0 *2	10*2	INLI	

- *1 The Modbus-RTU protocol cannot be used in the PU operation mode. When using the Modbus-RTU protocol, set Pr. 551 ≠ "2".
- *2 When Pr. 551 = "9999", the priorities of the PU control source is parameter unit (FR-PU04/FR-PU07) > operation panel.



NOTE

- When performing the RS-485 communication with the PU connector when *Pr. 551* = "9999", PU mode command source does not automatically change to the PU connector.
- When Pr. 551 = "2" (PU mode PU connector), the operation mode cannot be switched to the network operation mode.
- Changed setting value is made valid when powering on or resetting the inverter.
- The Modbus-RTU protocol cannot be used in the PU operation mode. Select network operation mode (NET mode command source).

^{*} Pr. 551 is always write-enabled.

7/

(2) Controllability through communication

- •Controllability through communcation in each operation mode is shown below.
- •Monitoring and parameter read can be performed from any operation regardless of operation mode.

Operation Location	Condition (Pr. 551 Setting)	Operation Mode	PU Operation	External Operation	External/PU Combined Operation Mode 1 (Pr. 79 = 3)	External/PU Combined Operation Mode 2 (<i>Pr.</i> 79 = 4)	NET Operation
		Run command (start)	0	×	×	0	×
		Run command (stop)	0	Δ *3	Δ *3	0	×
Control by	2 (PU connector)	Running frequency setting	0	×	0	×	×
RS-485		Parameter write	O*4	× *5	O*4	O *4	× *5
communica		Inverter reset	0	0	0	0	×
tion from		Run command (start)	×	×	×	×	O *1
PU		Run command (stop)	×	×	×	×	O *1
connector	Other than the above	Running frequency setting	×	×	×	×	O *1
		Parameter write	×*5	× *5	× *5	× *5	O *4
		Inverter reset	×	×	×	×	O *2
Control		Inverter reset	0	0	0	0	0
circuit external	_	Run command (start, stop)	×	0	0	×	×*1
terminals		Frequency setting	×	0	Δ*6	0	×*1

O: Enabled, x: Disabled, Δ: Some are enabled

- *1 As set in Pr.338 Communication operation command source and Pr. 339 Communication speed command source (Refer to page 171)
- *2 At occurrence of RS-485 communication error, the inverter cannot be reset from the computer.
- *3 Enabled only when stopped by the PU. At a PU stop, PS is displayed on the operation panel. As set in Pr. 75 PU stop selection. (Refer to page 153)
- 4 Some parameters may be write-disabled according to the Pr. 77 Parameter write selection setting and operating status. (Refer to page 156)
- *5 Some parameters are write-enabled independently of the operation mode and command source presence/absence. When Pr. 77 = "2", write is enabled. (Refer to the parameter list on page 52) Parameter clear is disabled.
- *6 Available with multi-speed setting and terminal 4-5 (valid when AU signal is ON).

(3) Operation at error occurrence

Error Definition	Operation Mode Condition (Pr. 551 setting)		External Operation	External/PU Combined Operation Mode 1 (Pr. 79 = 3)	External/PU Combined Operation Mode 2 (Pr. 79 = 4)	NET Operation
Inverter fault	_	Stop				
PU disconnection of	2 (PU connector) 9999 (automatic recognition)	Stop/continued *1, *3				
the PU	Other than the above	Stop/continued*1				
RS-485 communication	2 (PU connector)	Stop/ continued*2	Continued		Stop/ continued*2	_
error of the PU connector	Continued				Stop/ continued*2	

- *1 Can be selected using Pr. 75 Reset selection/disconnected PU detection/PU stop selection.
- *2 Can be selected using Pr. 122 PU communication check time interval.
- *3 In the PU JOG operation mode, operation is always stopped when the PU is disconnected. Whether fault (E.PUE) occurrence is allowed or not is as set in Pr. 75 Reset selection/disconnected PU detection/PU stop selection.



(4) Selection of control source in network operation mode (Pr. 338, Pr. 339)

•As control sources, there are the operation command source that controls the signals related to the inverter start command and function selection and the speed command source that controls the signals related to frequency setting.

•In network operation mode, the commands from the external terminals and communication are as listed below.

O	nerat	Operation Pr. 338 Co		338 Communication operation		0: NET			1: Externa	al	
_	ocati			command source	0.1121			1. External			Remarks
			Pi	r. 339 Communication speed	O. NET	4. [-4	0. [O. NIET	4. Futamal	0. [Remarks
S	Selection command source		command source	0: NET	1: External	2: External	U: NE I	1: External	2: External		
Fix	Fixed Running frequency from										
fun	ctio	n		nunication	NET	_	NET	NET	_	NET	
(te	min	al-	Termi		_	External	_	_	External	_	
,	uival						l			1	
	ctio		Termi	nal 4	_	Exte	ernal	_	Exte	ernal	
-				Low speed operation							
		0	RL	command/remote setting	NET	Exte	ernal	NET	Exte	ernal	
				clear						D 50 HOH	
				Middle speed operation							Pr. 59 = "0"
		1	RM	command/remote setting	NET	Exte	ernal	NET	Exte	ernal	(multi-speed) $Pr: 59 \neq$ "0"
				function							(remote)
		_		High speed operation							,
		2	RH	command/remote setting	NET	Exte	ernal	NET	Exte	ernal	
		3	RT	function Second function selection	NET.				Evtornol		
		4	AU	Current input selection	NET — Combined		External — Combined				
		5	JOG	Jog operation selection	Combined			External			
		7	OH	External thermal relay input	— Evte		ernal				
				, ,		I					Pr: 59 = "0"
		8	REX	Fifteen speed selection	NET External		NET	External		(multi-speed)	
Ē	ting	10	X10	Inverter operation enable signal	Exte		ernal				
Selective function	Pr. 178 to Pr. 182 setting	12	X12	PU operation external interlock			Exte	ernal			
e fr	r. 1	14	X14	PID control valid terminal	NET	Exte	ernal	NET	Exte	ernal	
ectiv	8 to P	16	X16	PU-external operation switchover			Exte	ernal			
Sel	178	18	X18	V/F switching		NET		External			
	Pr.			Output stop		Combined		External		Pr. 79 ≠ "7"	
		24	MRS	PU operation interlock	External				Pr: 79 = "7" When the X12 signal is not assigned		
		25		Start self-holding selection	_		External				
		37		Traverse function selection	NET		External				
		60		Forward rotation command	NET		External				
		61	_	Reverse rotation command	NET		External				
		62	RES	Reset	Exte		ternal				
		65	X65	PU/NET operation switchover	Exte		ternal				
		66	X66	NET-external operation switching	Ext			xternal			
		67	X67	Command source switchover	Exte			ernal			
TEV	xplanation of table1										

[Explanation of table]

External : Command is valid only from control terminal. NET : Command only from communication is valid

Combined: Command from both control terminal and communication is valid.

—: Command from either of control terminal and communication is invalid.

• REMARKS

• The command source of communication is as set in Pr. 551.

• The *Pr.* 338 and *Pr.* 339 settings can be changed while the inverter is running when *Pr.* 77 = "2". Note that the setting change is reflected after the inverter has stopped. Until the inverter has stopped, communication operation command source and communication speed command source before the setting change are valid.



Switching of command source by external terminal (X67)

- •In the network operation mode, the command source switching signal (X67) can be used to switch the start command source and speed command source.
- Set "67" to any of Pr. 178 to Pr. 182 (input terminal function selection) to assign the X67 signal to the control terminal.
- •When the X67 signal is off, the start command source and speed command source are control terminal.

X67 Signal State	Start Command Source	Speed Command Source	
No signal assignment	According to Pr. 338	According to Pr. 339	
ON			
OFF	Command is valid only	from control terminal.	



• REMARKS

- The ON/OFF state of the X67 signal is reflected only during a stop. It is reflected after a stop when the terminal is switched while the inverter is running.
- When the X67 signal is off, a reset via communication is disabled.



• Changing the terminal assignment using Pr. 178 to Pr. 182 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 59 Remote function selection 🕦 Refer to page 88 Pr. 79 Operation mode selection 🖫 Refer to page 160



4.19 Communication operation and setting


Purpose	Parameter that s	should be Set	Refer to Page
Communication operation from PU	Initial setting of computer link communication (PU connector)	Pr. 117 to Pr. 124	178
connector	Modbus-RTU communication	Pr. 117, Pr. 118, Pr. 120, Pr.	195
	specifications 122, Pr. 343, Pr. 502, Pr. 549		193
Restrictions on parameter write	Communication EEPROM write	Pr. 342	182
through communication	selection		

4.19.1 Wiring and configuration of PU connector

Using the PU connector, you can perform communication operation from a personal computer etc.

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

(1) PU connector pin-outs



Pin Number	Name	Description
1)	SG	Earth (ground)
1)	30	(connected to terminal 5)
2)	_	Parameter unit power supply
3)	RDA	Inverter receive+
4)	SDB	Inverter send-
5)	SDA	Inverter send+
6)	RDB	Inverter receive-
7)	SG	Earth (ground)
")	30	(connected to terminal 5)
8)	_	Parameter unit power supply




NOTE

• Pins No. 2 and 8 provide power to the parameter unit. Do not use these pins for RS-485 communication.

When making RS-485 communication between the FR-D700 series, FR-E500 series and FR-S500 series, Incorrect connection of pins No.2 and No.8 (parameter unit power supply) of the above PU connector may result in the inverter malfunction or failure.


When multiple inverters are connected using pins No.2 and No.8, power is provided from the inverter which is powered on to the inverters which are powered off in case inverters which are powered on and off are mixed. In such a case, a protective circuit of the inverter, which is on, functions to stop communication.

When connecting multiple inverters for RS-485



communication, make sure to disconnect cables from No.2 and No.8 so that pins No.2 and No.8 are not connected between inverters.


When using the RS-485 converter which receives power from the inverter, make sure that power is provided from one inverter only. (*Refer to the figure below.*)




• Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector. The product could be damaged due to differences in electrical specifications.

(2) PU connector communication system configuration

●Connection of a computer to the inverter (1:1 connection)



● Combination of computer and multiple inverters (1:n connection)



REMARKS

Refer to the following when fabricating the cable on the user side.
 Examples of product available on the market (as of February, 2008)


	Product Type		Maker	
1	10BASE-T cable	SGLPEV-T 0.5mm × 4P *1	Mitsubishi Cable Industries, Ltd.	

^{*1} Do not use pins No. 2, 8 of the 10BASE-T cable. (Refer to page 175)




(3) Connection with RS-485 computer

●Wiring of one RS-485 computer and one inverter



●Wiring of one RS-485 computer and "n" (multiple) inverters



- *1 Make connection in accordance with the instruction manual of the computer to be used with. Fully check the terminal numbers of the computer since they vary with the model.
- *2 The inverters may be affected by reflection depending on the transmission speed or transmission distance. If this reflection hinders communication, provide a terminating resistor. If the PU connector is used to make a connection, use a distributor since a terminating resistor cannot be fitted. Connect the terminating resistor to only the inverter remotest from the computer. (Terminating resistor: 100Ω)




NOTE

- Do not use pins No. 2, 8 of the 10BASE-T cable. (Refer to page 175)
- When making RS-485 communication between the FR-D700 series, FR-E500 series and FR-S500 series, incorrect
 connection of pins No.2 and 8 (parameter unit power supply) of the above PU connector may result in the inverter
 malfunction or failure. (Refer to page 175)

(4) Two-wire type connection

If the computer is 2-wire type, a connection from the inverter can be changed to 2-wire type by passing wires across reception terminals and transmission terminals of the PU connector pin.





> REMARKS

- A program should be created so that transmission is disabled (receiving state) when the computer is not sending and reception is disabled (sending state) during sending to prevent the computer from receiving its own data.
- The passed wiring length should be as short as possible.

4.19.2 Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)

Used to perform required settings for RS-485 communication between the inverter and personal computer.

- Use PU connector of the inverter for communication.
- You can perform parameter setting, monitoring, etc. using Mitsubishi inverter protocol or Modbus-RTU protocol.
- To make communication between the personal computer and inverter, initialization of the communication specifications must be made to the inverter.

Data communication cannot be made if the initial settings are not made or there is any setting error.

Parameter Number	Name	Initial Value	Setting Range	Desc	cription			
117	PU communication	0	0 to 31 (0 to 247)	Inverter station number specification Set the inverter station numbers when two or more				
117	station number	O	*1	inverters are connected to one personal computer.				
				Communication speed				
118	PU communication speed	192	48, 96, 192, 384		equals the communication			
				speed. Example)19200bps if 192				
				Stop bit length	Data length			
	PU communication stop		0	1bit	- 8bit			
119	bit length	1	1	2bit	ODIL			
			10	1bit	- 7bit			
			11	2bit	7 010			
	PU communication parity		0	Without parity check				
120	check	2	1	With odd parity check				
	onour .		2	With even parity check				
	PU communication		0 to 150ms		tween data transmission to			
123	waiting time setting	9999		the inverter and respons				
	maning and county		9999	Set with communication	data.			
	PU communication CR/LF selection		0	Without CR/LF				
124		1	1	With CR				
			2	With CR/LF				
549	Protocol selection	0	0	Mitsubishi inverter (computer link operation) protoc				
		,	1	Modbus-RTU protocol				

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

^{*1} When "1" (Modbus-RTU protocol) is set in *Pr. 549*, the setting range within parenthesis is applied.



NOTE

 Always reset the inverter after making the initial settings of the parameters. After you have changed the communication-related parameters, communication cannot be made until the inverter is reset.



4.19.3 Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)

You can select the inverter operation when a communication line error occurs during RS-485 communication from the PU connector.


Parameter	Name	Initial	Setting		Desc	ription				
Number		Value	Range			•				
121	Number of PU communication retries	1	0 to 10	consecutive errors come to trip (de Valid only Mitsu	pends on <i>Pr. 502</i>) bishi inverter (cor	error occurrence permissible value, mputer link operat the inverter will no	the inverter will			
			the inverter will re	or come to trip.						
			0	RS-485 communication can be made. Note that a communication fault (E.PUE) occurs as soon as the inverter is switched to the operation mode with command source. (NET mode at initial value)						
122	PU communication check time interval	0	0.1 to 999.8s	Communication check (signal loss detection) time interval If a no-communication state persists for longer than the permissible time, the inverter will come to trip (depends on <i>Pr. 502</i>).						
			9999	No communicat	No communication check (signal loss detection)					
				At fault occurrence	Indication	Fault output	At fault removal			
	Stop mode selection		0	Coasts to stop	E.PUE	Output	Stop (E.PUE)			
502	at communication error	0	1	Decelerates to stop	After stop E.PUE	Output after stop	Stop (E.PUE)			
			2	Decelerates to stop	After stop E.PUE	Without output	Automatic restart functions			

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)


(1) Retry count setting (Pr.121)

- •Set the permissible number of retries at data receive error occurrence. (Refer to page 187 for data receive error for retry)
- •When data receive errors occur consecutively and exceed the permissible number of retries set, an inverter trips (E.PUE) and a motor stops (as set in *Pr. 502*).
- •When "9999" is set, an inverter fault is not provided even if data receive error occurs but an alarm signal (LF) is output. For the terminal used for the LF signal output, assign the function by setting "98 (positive logic) or 198 (negative logic)" in *Pr. 190 or Pr. 192 (output terminal function selection)*.

Example: PU connector communication, Pr. 121 = "1" (initial value)



Example: PU connector communication, Pr. 121 = "9999"




REMARKS

• Pr. 121 is valid only when Mitsubishi inverter (computer link operation) protocol is selected. Pr. 121 is not valid when Modbus-RTU communication protocol is selected.

(2) Signal loss detection (Pr.122)

- •If a signal loss (communication stop) is detected between the inverter and master as a result of a signal loss detection, a communication fault (E.PUE) occurs and the inverter trips. (as set in *Pr. 502*).
- •When the setting is "9999", communication check (signal loss detection) is not made.
- •When the setting value is "0" (initial value), RS-485 communication can be made. However, a communication fault (E.PUE) occurrs as soon as the inverter is switched to the operation mode (network operation mode in the initial setting) with the control.
- •A signal loss detection is made when the setting is any of "0.1s to 999.8s". To make a signal loss detection, it is necessary to send data (refer to Mitsubishi inverter protool control code (page 186), Modbus-RTU comunciation protocol (page 196)) from the computer within the communication check time interval. (The inverter makes communication check (clearing of communication check counter) regardless of the station number setting of the data sent from the master).
- •Communication check is made from the first communication in the operation mode with control source valid (network operation mode in the initial setting).

Example: PU connector communication, Pr. 122 = "0.1 to 999.8s"



CAUTION

Always set the communication check time interval before starting operation to prevent hazardous conditions. Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal cable breakage etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter trips (E.PUE).

The inverter can be coasted to a stop by turning on its RES signal or by switching power off.

If communication is broken due to signal cable breakage, computer fault, etc. the inverter does not detect such a fault. This should be fully noted.



(3) Stop operation selection at occurrence of communication fault (Pr. 502)

•Stop operation when retry count excess (Mitsubishi inverter protocol only) or signal loss detection error occurs can be selected.


Operation at fault occurrence


Pr. 502 Setting	Operation	Indication	Fault Output	
0 (initial value)	Coasts to stop.	E. PUE lit	Provided	
1	Decelerates to stop	E. PUE lit after stop	Provided after stop	
2	Decelerates to stop	L. I OL III alter stop	Not provided	


Operation at fault removal

Pr.502 Setting	Operation	Indication	Fault Output
0 (initial value)	Kept stopped	E. PUE	Kept provided
1	перт эторрей	2.1 62	rept provided
2	Automatic restart functions	Normal display	Not provided


● Pr. 502 setting "0" (initial value)







● Pr. 502 setting "2"



(I) REMARKS

- The fault output indicates fault output signal (ALM signal) or alarm bit output.
- When the setting was made to provide a fault output, the fault description is stored into the faults history. (The fault description is written to the faults history when a fault output is provided.)

When no fault output is provided, the fault definition overwrites the fault indication of the faults history temporarily, but is not stored.

After the fault is removed, the fault indication returns to the ordinary monitor, and the faults history returns to the preceding fault indication.

- When the *Pr.* 502 setting is "1 or 2", the deceleration time is the ordinary deceleration time setting (e.g. *Pr.* 8, *Pr.* 44, *Pr.* 45). In addition, acceleration time for restart is the normal acceleration time (e.g. *Pr.* 7, *Pr.* 44).
- When "2" is set in Pr. 502, run command/speed command at restarting follows the command before an fault occurrence.
- When "2" is set in *Pr.* 502 at occurrence of a communication error and the error is removed during deceleration, the inverter accelerates again at that point.



Parameters referred to

Pr. 7 Acceleration time, Pr. 8 Deceleration time ** Refer to page 91 Pr. 190, Pr. 192 (output terminal function selection) ** Refer to page 114

4.19.4 Communication EEPROM write selection (Pr. 342)

When parameter write is performed from RS-485 comuunication with the inverter PU connector, parameters storage device can be changed from EEPROM + RAM to RAM only. Set when a frequent parameter change is necessary.

Parameter Number	Name	Initial Value	Setting Range	Description
342	Communication EEPROM	0	0	Parameter values written by communication are written to the EEPROM and RAM.
342	write selection	U	1	Parameter values written by communication are written to RAM.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

• When changing the parameter values frequently, set "1" in Pr. 342 to write them to the RAM only. The life of the EEPROM will be shorter if parameter write is performed frequently with the setting unchanged from "0 (initial value)" (EEPROM write).



(I) REMARKS

• When "1" (write to RAM only) is set in Pr. 342, powering off the inverter will erase the changed parameter values. Therefore, the parameter values available when power is switched on again are the values stored in EEPROM previously.



4.19.5 Mitsubishi inverter protocol (computer link communication)


You can perform parameter setting, monitor, etc. from the PU connector of the inverter using the Mitsubishi inverter protocol (computer link communication).

(1) Communication

•The communication specifications are given below.

14	em	Description	Related
"	em	Description	Parameter
Communication	orotocol	Mitsubishi protocol (computer link)	Pr. 549
Conforming stan	dard	EIA-485 (RS-485)	_
Number of conne	ctable devices	1:N (maximum 32 units), setting is 0 to 31 stations	Pr. 117
Communication PU connector		Selected from among 4800/9600/19200 and 38400bps	Pr. 118
speed PU connector		Selected from among 4000/9000/19200 and 30400bps	F1. 110
Control procedur	е	Asynchronous	_
Communication r	nethod	Half-duplex	_
	Character system	ASCII (7 bits or 8 bits can be selected)	Pr. 119
	Start bit	1bit	_
Communication	Stop bit length	1 bit or 2 bits can be selected	Pr. 119
Communication	Parity check	Check (even, odd) or no check can be selected	Pr. 120
	Error check	Sum code check	_
	Terminator	CR/LF (presence/absence selectable)	Pr. 124
Waiting time sett	ing	Selectable between presence and absence	Pr. 123

(2) Communication procedure



- Data communication between the computer and inverter is made in the following procedure.
 - Request data is sent from the computer to the inverter. (The inverter will not send data unless requested.)
 - 2) After waiting for the waiting time
 - The inverter sends return data to the computer in response to the computer request.
 - 4) After waiting for the inverter data processing time
 - Answer from the computer in response to reply data 3) of the inverter is transmitted. (Even if 5) is not sent, subsequent communication is made properly.)
- If a data error is detected and a retry must be made, execute retry operation with the user program. The inverter comes to trip if the number of consecutive retries exceeds the parameter setting.
- On receipt of a data error occurrence, the inverter returns retry data 3) to the computer again. The inverter comes to trip if the number of consecutive data errors reaches or exceeds the parameter setting.

(3) Communication operation presence/absence and data format types

- •Data communication between the computer and inverter is made in ASCII code (hexadecimal code).
- •Communication operation presence/absence and data format types are as follows:

No.	Oneret	ion	Run	Operation	Multi	Parameter	Inverter	Monitor	Parameter
NO.	Operat	1011	Command	Frequency	command	Write	Reset	Wioriitor	Read
1)	Communication requeinverter in accordance program in the computer	ce with the user		A, A2 *3	A3	A, A2 *3	А	В	В
2)	Inverter data processir	ng time	Present	Present	Present	Present	Present	Present	Present
3)	Reply data from the inverter (Data 1) is	No error *1 (Request accepted)	С	С	C1*4	С	C *2	E, E1, E2, E3 *3	E, E2 *3
,	checked for error)	With error. (Request rejected)	D	D	D	D	D *2	D	D
4)	Computer processing	delay time				10ms or mo	re		
5)	Answer from computer in response to reply data 3).	No error *1 (No inverter processing)	Absent	Absent	Absent (C)	Absent	Absent	Absent (C)	Absent (C)
3)	(Data 3) is checked for error)	With error. (Inverter outputs 3) again.)	Absent	Absent	F	Absent	Absent	F	F

- *1 In the communication request data from the computer to the inverter, 10ms or more is also required after "no data error (ACK)". (Refer to page 186)
- *2 Reply from the inverter to the inverter reset request can be selected. (Refer to page 190)
- *3 When any of "0.01 to 9998" is set in *Pr.* 37 and "01" in instruction code HFF sets data format to A2 or E2. In addition, data format is always A2 and E2 for read or write of *Pr.* 37.
- *4 At mode error, and data range error, C1 data contains an error code. (Refer to page 194) Except for those errors, the error is returned with data format D.

Data writing format

Communication request data from the computer to the inverter 1)

Format								Νι	ımber	of Ch	aracte	rs							
loillat	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
Α	ENQ *1	Inve stat numb	tion		uction ide	*3	Dai		ta		Sum check		*4						
A1	ENQ *1	Inve stat numb	tion		uction de	*3	Data Sum check		*4										
A2	ENQ *1	Inve stat numb	tion		uction ide	*3		Data						ım eck	*4				
А3	ENQ *1	Inve stat numb	tion		uction ide	*3	Send Receive data data Da type type			ta1 Da		Da	ta2		Sui che		*4		

Reply data from the inverter to the computer 3) (No data error detected)

Format		Number of Characters																	
i Ommat	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
С	ACK *1	Inverte station number	n *2	*4															
C1	STX *1	Inverte station number		Send data type	Receive data type	Error code 1	Error code 2		Data1		Data2			ETX *1	Su che		*4		

Reply data from the inverter to the computer 3) (With data error)

Format	Nι	Number of Characters										
Tormat	1	1 2 3		4	5							
D	NAK *1	Inve stat numb		Error code	*4							

- *1 Indicate a control code
- *2 Specify the inverter station numbers between H00 and H1F (stations 0 to 31) in hexadecimal.
- *3 Set waiting time. When the *Pr. 123 (waiting time setting)* is other than 9999, create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- *4 CR, LF code

When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must also be made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using *Pr. 124 (CR, LF selection)*.



Data reading format

Communication request data from the computer to the inverter 1)

Format		Number of Characters											
Torritat	1	2	3	4	5	6	7	8	9				
В	ENQ	Q Inverter		Inetructi	on code	*3	Sı	ım	*4				
ь	*1	station no	umber *2	Instruction code		5	che	**-					

Reply data from the inverter to the computer 3) (No data error detected)

Format		Number of Characters												
Tomat	1	2	3	4	5	6	7	8	9	10	11	12	13	
Е	STX	_	erter		Read	d data		ETX		ım	*4			
_	*1	station nu	umber *2					*1	che	eck	·			
E1	STX	Inve	erter	Page	d data	ETX	Sı	ım	*4			•		
	*1	station no	umber *2	incac	uala	*1	che	eck						
E2	STX	Inve	erter			Pond	ldata			ETX Su		ım	*4	
LZ	*1	station nu	umber *2		Read data					*1		eck	*4	

Format		Number of Characters							
Tomat	1	2	3	4 to 23	24	25	26	27	
E3	STX *1	Inve station nu	erter umber *2	Read data (Inverter type information)	ETX *1	Su che	im eck	*4	

Reply data from the inverter to the computer 3) (With data error)

Format	Number of Characters					
Tomat	1	2	3	4	5	
D	NAK	K Inverter		Error	*4	
	*1	station number *2		code	*4	

Send data from computer to inverter during data read 5)

Format	Number of Characters					
Tormat	1	2	3	4		
C (Without data error)	ACK *1	Inverter station number *2		*4		
F (With data error)	NAK *1	Inve		*4		

- Indicate a control code
- Specify the inverter station numbers between H00 and H1F (stations 0 to 31) in hexadecimal. *2
- Set waiting time. When the Pr. 123 (waiting time setting) is other than 9999, create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- CR, LF code

When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must also be made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using Pr. 124 (CR, LF selection).

(4) Data definitions

1) Control code

Signal	ASCII Code	Description
STX	H02	Start of Text (Start of data)
ETX	H03	End of Text (End of data)
ENQ	H05	Enquiry (Communication request)
ACK	H06	Acknowledge (No data error detected)
LF	H0A	Line Feed
CR	H0D	Carriage Return
NAK	H15	Negative Acknowledge (Data error detected)

2) Inverter station number

Specify the station number of the inverter which communicates with the computer.

3) Instruction code


Specify the processing request, e.g. operation or monitoring, given by the computer to the inverter. Hence, the inverter can be run and monitored in various ways by specifying the instruction code as appropriate. (*Refer to page 52*)

4) Data

Indicates the data such as frequency and parameters transferred to and from the inverter. The definitions and ranges of set data are determined in accordance with the instruction codes. (Refer to page 52)

5) Waiting time

Specify the waiting time between the receipt of data at the inverter from the computer and the transmission of reply data. Set the waiting time in accordance with the response time of the computer between 0 and 150ms in 10ms increments. (e.g. 1 = 10ms, 2 = 20ms).




REMARKS


- When the *Pr. 123 PU communication waiting time setting* setting is other than 9999, create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- The data check time changes depending on the instruction code. (Refer to page 187)

6) Sum check code

The sum check code is 2-digit ASCII (hexadecimal) representing the lower 1 byte (8 bits) of the sum (binary) derived from the checked ASCII data.



* When the *Pr. 123 Waiting time setting* ≠ "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)






7) Error code


If any error is found in the data received by the inverter, its definition is sent back to the computer together with the NAK code.

Error	Error Item	Error Description	Inverter Operation
Code		·	'
H0	Computer NAK error	The number of errors consecutively detected in communication request	
	,	data from the computer is greater than allowed number of retries.	
H1	Parity error	The parity check result does not match the specified parity	
H2	Sum check error	The sum check code in the computer does not match that of the data	Brought to trip (E. PUE)
112	Sum check end	received by the inverter.	if error occurs
		The data received by the inverter has a grammatical mistake.	continuously more than
H3	Protocol error	Alternatively, data receive is not completed within the predetermined	the allowable number of
		time. CR or LF is not as set in the parameter.	retry times.
H4	Framing error	The stop bit length differs from the initial setting.	
	•	New data has been sent by the computer before the inverter completes	
H5	Overrun error	receiving the preceding data.	
H6	_	_	_
			Does not accept
H7	Character error	racter error The character received is invalid (other than 0 to 9, A to F, control code	received data but is not
			brought to trip.
H8	_	_	_
H9	_	_	_
		Parameter write was attempted in other than the computer link operation	
HA	Mode error	mode, when operation command source is not selected or during inverter	
		operation.	Does not accept
LID	Instruction code	The constitution of the co	received data but is not
HB	error	The specified command does not exist.	brought to trip.
110	Data sanas assas	Invalid data has been specified for parameter write, frequency setting,	
HC	Data range error	etc.	
HD	_	_	_
HE	_	_	_
HF	_	_	_

(5) Response time



[Formula for data sending time]



Communication specifications

Name	Number of Bits		
Stop bit longth	1 bits		
Stop bit length	Stop bit length		
Data langth		7 bits	
Data length		8 bits	
Parity check	Present	1 bits	
Failty Check	Absent	0	

●Data check time

Item	Check Time
Various monitors, operation command,	< 12ms
frequency setting (RAM)	< 12III5
Parameter read/write, frequency setting	< 30ms
(EEPROM)	< 30IIIS
Parameter clear/all clear	< 5s
Reset command	No answer


(6) Instructions for the program

- 1) When data from the computer has any error, the inverter does not accept that data. Hence, in the user program, always insert a retry program for data error.
- 2) All data communication, e.g. run command or monitoring, are started when the computer gives a communication request. The inverter does not return any data without the computer's request. Hence, design the program so that the computer gives a data read request for monitoring, etc. as required.
- 3) Program example
 - To change the operation mode to computer link operation

Programming example of Microsoft® Visual C++® (Ver.6.0)

```
#include <stdio.h>
#include <windows.h>
void main(void){
     HANDLÉ
                       hCom:
                                         //Communication handle
     DCB
                       hDcb:
                                         //Structure for communication setting
     COMMTIMEOUTS
                                hTim:
                                        // Structure for time out setting
                                                 // Send buffer
     char
                       szTx[0x10];
                                                 // Receive buffer
     char
                       szRx[0x10]:
     char
                       szCommand[0x10];// Command
                                                 // For buffer size storing
     int
                       nTx,nRx;
     int
                       nSum;
                                                 // For sum code calculation
     BOOL
                       bRet;
     int
                       nRet;
     int
                       i;
     //**** Opens COM1 port****
     hCom = CreateFile ("COM1", (GENERIC_READ | GENERIC_WRITE), 0, NULL, OPEN_EXISTING, FILE_ATTRIBUTE_NORMAL, NULL);
     if (hCom != NULL) {
              //**** Makes a communication setting of COM1 port****
              GetCommState(hCom,&hDcb);
                                                                                     // Retrieves current communication information
              hDcb.DCBlength = sizeof(DCB);
                                                                                     // Structure size setting
                                                                                     // Communication speed=19200bps
              hDcb.BaudRate = 19200;
              hDcb.ByteSize = 8;
                                                                                     // Data length=8bit
              hDcb.Parity = 2;
                                                                                     // Even parity
              hDcb.StopBits = 2;
                                                                                     // Stop bit=2bit
              bRet = SetCommState(hCom,&hDcb);
                                                                                     // Sets the changed communication data
              if (bRet == TRUE) {
                       //*** Makes a time out setting of COM1 port***
                       Get CommTimeouts(hCom,&hTim);
                                                                                     // Obtains the current time out value
                       hTim.WriteTotalTimeoutConstant = 1000;
                                                                                     // Write time out 1s
                       hTim.ReadTotalTimeoutConstant = 1000;
                                                                                     // Read time out 1s
                       SetCommTimeouts(hCom,&hTim);
                                                                                     // Changed time out value setting
                       //**** Sets the command to switch the operation mode of the station 1 inverter to the network operation mode ****
                       sprintf(szCommand,"01FB10000");
                                                                                     // Send data (NET operation write)
                       nTx = strlen(szCommand):
                                                                                     //Send data size
                       //**** Generates sum code****
                                                                                     // Initialization of sum data
                       nSum = 0:
                       for (i = 0; i < nTx; i++) {
                                nSum += szCommand[i];
                                                                                     // Calculates sum code
                                nSum \&= (0xff);
                                                                                     // Masks data
                       }
                       //**** Generates send data****
                                                                                     // Initialization of send buffer
                       memset(szTx,0,sizeof(szTx));
                       memset(szRx,0,sizeof(szRx)):
                                                                                     // Initialization of receive buffer
                       sprintf(szTx,"\5%s%02X",szCommand,nSum);// ENQ code+send data+sum code
                       nTx = 1 + nTx + 2;
                                                                                     // Number of ENQ code+number of send data+number of sum code
                       nRet = WriteFile(hCom,szTx,nTx,&nTx,NULL);
                       //**** Sending *
                       if(nRet != 0) {
                               nRet = ReadFile(hCom,szRx,sizeof(szRx),&nRx,NULL);
                       //**** Receiving ****
                                if(nRet != 0) {
                                         //**** Displays the receive data ****
                                         for(i = 0;i < nRx;i++) {
                                                 printf("%02X ",(BYTE)szRx[i]);// Consol output of receive data
                                                  // Displays ASCII coder in hexadecimal. Displays 30 when "0"
                                         printf("\n\r");
                               }
              CloseHandle(hCom);
                                                                                     // Close communication port
     }
```





<u>A</u> CAUTION

Always set the communication check time interval before starting operation to prevent hazardous conditions. Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal loss etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter will come to trip (E.PUE, E.SER).

The inverter can be coasted to a stop by switching on its RES signal or by switching power off.

If communication is broken due to signal cable breakage, computer fault etc., the inverter does not detect such a fault. This should be fully noted.

(7) Setting items and set data

After completion of parameter settings, set the instruction codes and data then start communication from the computer to allow various types of operation control and monitoring.

No.		Item	Read/ Write	Instruction Code	Data Definition	Number of Data Digits (Format)
1	Operation mode		Read H7B H0000: Network operation Operation mode H0001: External operation		H0000: Network operation H0001: External operation	4 digits (B, E/D)
			Write	HFB	H0002: PU operation	4 digits (A, C/D)
		Output frequency /speed	Read	H6F	H0000 to HFFFF: Output frequency in 0.01Hz increments Speed increments 0.001 (when $Pr. 37 = 0.01$ to 9998) When "0.01 to 9998" is set in $Pr. 37$ and "01" in instruction code HFF, the data format is E2. When "100" is set in $Pr. 52$, the monitor value is different depending on whether the inverter is at a stop or running. (Refer to page 123) H0000 to HFFFF: Output current (hexadecimal) in 0.01A	4 digits (B, E/D), 6 digits (B, E2/D)
		current	Read	H70	increments	(B, E/D)
		Output voltage	Read	H71	H0000 to HFFFF: Output voltage (hexadecimal) in 0.1V increments	4 digits (B, E/D)
2	Monitor	Special monitor	Read	H72	H0000 to HFFFF: Monitor data selected in instruction code HF3	4 digits (B, E/D), 6 digits (B, E2/D)
	Mc	Special monitor Selection No.	Read	H73	H01 to H3C: Monitor selection data	2 digits (B, E1/D)
			Write	HF3	Refer to the special monitor No. table (page 192)	2 digits (A1, C/D)
	Dist	Fault description	Read	H74 to H77	h74 First fault in past Latest fault H75 Third fault in past Second fault in past H76 Fifth fault in past Fourth fault in past H77 Seventh fault in past Sixth fault in past Refer to the alarm data table (page 193)	4 digits (B, E/D)
3		command ansion)	Write	HF9	Control input commands such as the forward rotation signal (STF)	4 digits (A, C/D)
	Run	command	Write	HFA	and reverse rotation signal (STR). (For details, refer to page 193)	2 digits (A1, C/D)
4	moni (expa	ter status tor ansion) ter status	Read	H79	Monitor the states of the output signals such as forward rotation, reverse rotation and inverter running (RUN). (For details, <i>refer to page 193</i>)	4 digits (B, E/D) 2 digits
	moni		Read	H7A		(B, E1/D)
	Set frequency (RAM) Set frequency (EEPROM)		Read	H6D H6E	Read set frequency/speed from RAM or EEPROM. H0000 to HFFFF: Set frequency in 0.01Hz increments Speed increments 0.001 (when <i>Pr. 37</i> = 0.01 to 9998) When "0.01 to 9998" is set in <i>Pr. 37</i> and "01" in instruction code HFF, the data format is E2.	4 digits (B, E/D), 6 digits (B, E2/D)
5	Set f	requency И)		HED	Write set frequency/speed to RAM or EEPROM. H0000 to H9C40 (0 to 400.00Hz): Frequency increments 0.01Hz Speed increments 0.001 (when <i>Pr. 37</i> = 0.01 to 9998)	4 digits
	Set frequency (RAM, EEPROM)		Write	HEE	 When "0.01 to 9998" is set in <i>Pr. 37</i> and "01" in instruction code HFF, the data format is A2. To change the set frequency consecutively, write data to the inverter RAM. (instruction code: HED) 	(A, C/D), 6 digits (A2, C/D)
Dofor	to	- 101 for data f	ormat (A	A1 A2 A2 F	3, C, C1, D, E, E1, E2, E3)	

Refer to page 184 for data format (A, A1, A2, A3, B, C, C1, D, E, E1, E2, E3)



No.		Item	Read/ Write	Instruction Code	Data Definition	Number of Data Digits (Format)
6	Inver	ter reset	Write	HFD	H9696: Inverter reset As the inverter is reset at start of communication by the computer, the inverter cannot send reply data back to the computer. H9666: Inverter reset	4 digits (A, C/D)
					When data is sent normally, ACK is returned to the computer and then the inverter is reset.	4 digits (A, D)
7	Fault clear	definition all	Write	HF4	H9696: Faults history batch clear	4 digits (A, C/D)
					All parameters return to the initial values. Whether to clear communication parameters or not can be selected according to data. (O: Clear, x: Not clear) Refer to page 52 for parameter clear, all clear, and communication parameters.	
					Clear Type Data Communication Pr.	
					Parameter clear H9696 O	
8	Para	meter clear	Write	HFC	H5A5A ×	4 digits
Ŭ	All cl	ear	· · · · · ·	1 0	All parameter clear	(A, C/D)
					H55AA ×	
					When clear is executed for H9696 or H9966, communication-related parameter settings also return to the initial values. When resuming operation, set the parameters again. Executing clear will clear the instruction code HEC, HF3, and HFF settings. During password lock, only all parameter clear is available with H9966 and H55AA.	
9	Parameter		H00 to H63	Refer to the instruction code (<i>Refer to page 52</i>) and write and/or read parameter values as required. When setting $Pr.~100$ and later, link parameter extended setting	4 digits (B, E/D), 6 digits (B, E2/D)	
10					must be set. Data format of $Pr. 37$ read and write is E2 and A2	4 digits (A, C/D), 6 digits (A2, C/D)
	Link	parameter	Read	H7F	Parameter description is changed according to the H00 to H09 setting.	2 digits (B, E1/D)
11		nsion setting	Write	HFF	For details of the settings, refer to the parameter instruction code (<i>Refer to page 52</i>).	2 digits (A1, C/D)
		and parameter	Read	H6C	Setting calibration parameter *1 H00: Frequency *2 H01: Parameter-set analog value	2 digits (B, E1/D)
12	changing (instruction code HFF = 1, 9) Write		HEC	 H02: Analog value input from termin *1 Refer to the list of calibration parameters on the next page for calibration parameters. *2 The gain frequency can also be written using <i>Pr. 125</i> (instruction code: H99) or <i>Pr. 126</i> (instruction code: H9A). 	2 digits (A1, C/D)	
13	Multi	command	Write/	HF0	Available for writing 2 commands, and monitoring 2 items for	10 digits
	watt	Jammana	Read	0	reading data (<i>Refer to page 194</i> for detail)	(A3, C1/D)
	onitor	Inverter type	Read	H7C	Reading inverter type in ASCII code. "H20" (blank code) is set for blank area Example of FR-D740 H46, H52, H2D, H44, H37, H34, H30, H20H20	20 digits (B, E3/D)
14	Inverter type monitor	Capacity	Read	H7D	Reading inverter capacity in ASCII code. Data is read in increments of 0.1kW, and rounds down 0.01kW increments "H20" (blank code) is set for blank area Example 0.4K" 4" (H20, H20, H20, H20, H20, H34) 0.75K" 7" (H20, H20, H20, H20, H20, H37)	6 digits (B, E2/D)

Refer to page 184 for data format (A, A1, A2, A3, B, C, C1, D, E, E1, E2, E3)



• REMARKS

- Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999".
- For the instruction codes HFF, HEC and HF3, their values are held once written but cleared to zero when an inverter reset or all clear is performed.

Example) When reading the C3 (Pr. 902) and C6 (Pr. 904) settings from the inverter of station 0

	Computer Send Data	Inverter Send Data	Description
1)	ENQ 00 FF 0 01 82	ACK 00	Set "H01" to the expansion link parameter.
2)	ENQ 00 EC 0 01 7E	ACK 00	Set "H01" to second parameter changing.
3)	ENQ 00 5E 0 0F	STX 00 0000 ETX 25	C3 (Pr. 902) is read. 0% is read.
4)	ENQ 00 60 0 FB	STX 00 0000 ETX 25	C6 (Pr. 904) is read. 0% is read.

To read/write C3 (Pr. 902) and C6 (Pr. 904) after inverter reset or parameter clear, execute from 1) again.

List of calibration parameters

	Name		Instruction			
Parameter			Code			
raiailletei			Write	Extended		
C2 (902)	Terminal 2 frequency setting bias frequency	5E	DE	1		
C3 (902)	Terminal 2 frequency setting bias	5E	DE	1		
125 (903)	Terminal 2 frequency setting gain frequency	5F	DF	1		
C4 (903)	Terminal 2 frequency setting gain	5F	DF	1		
C5 (904)	Terminal 4 frequency setting bias frequency	60	E0	1		
C6 (904)	Terminal 4 frequency setting bias	60	E0	1		
126 (905)	Terminal 4 frequency setting gain frequency	61	E1	1		
C7 (905)	Terminal 4 frequency setting gain	61	E1	1		

[Special monitor selection No.]

Refer to page 123 for details of the monitor description.

Data	Description	Unit
H01	Output frequency/speed *1	0.01Hz/
1101	Output frequency/speed *1	0.001
H02	Output current	0.01A
H03	Output voltage	0.1V
H05	Frequency setting/speed setting *1	0.01Hz/
поэ	Frequency setting/speed setting *1	0.001
H08	Converter output voltage	0.1V
H09	Regenerative brake duty	0.1%
H0A	Electronic thermal relay function	0.1%
	load factor	
H0B	Output current peak value	0.01A
H0C	Converter output voltage peak value	0.1V
H0E	Output power	0.01kW
H0F	Input terminal status *2	_

Description	Unit
Output terminal status *3	_
Cumulative energization time	1h
Actual operation time	1h
Motor load factor	0.1%
Cumulative power	1kWh
PID set point	0.1%
PID measured value	0.1%
PID deviation	0.1%
Motor thermal load factor	0.1%
Inverter thermal load factor	0.1%
Cumulative power 2	0.01kWh
PTC thermistor resistance	0.01kΩ
	Output terminal status *3 Cumulative energization time Actual operation time Motor load factor Cumulative power PID set point PID measured value PID deviation Motor thermal load factor Inverter thermal load factor Cumulative power 2

*1 When "0.01 to 9998" is set in Pr. 37 and "01" in instruction code HFF, the data format is 6 digits (E2).




[Fault data]

Refer to page 245 for details of fault description

Data	Definition
H00	No fault
1100	present
H10	E.OC1
H11	E.OC2
H12	E.OC3
H20	E.OV1
H21	E.OV2
H22	E.OV3
H30	E.THT

Data	Definition
H31	E.THM
H40	E.FIN
H52	E.ILF
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT
H91	E.PTC

Data	Definition
HB0	E.PE
HB1	E.PUE
HB2	E.RET
HC0	E.CPU
HC4	E.CDO
HC5	E.IOH
HC7	E.AIE



[Run command]

14	Instruction	Bit	Decembris	Francis
Item	Code	Length	Description	Example
Run command	HFA	8bit	b0: AU (current input selection) *2 b1: forward rotation command b2: reverse rotation command b3: RL (low speed operation command) *1*2 b4: RM (middle speed operation command) *1*2 b5: RH (high speed operation command) *1*2 b6: RT (second function selection)*2 b7: MRS (output stop) *2	[Example 1] H02 Forward rotation b7
Run command (expansion)	HF9	16bit	b0: AU (current input selection) *2 b1: forward rotation command b2: reverse rotation command b3: RL (low speed operation command) *1*2 b4: RM (middle speed operation command) *1*2 b5: RH (high speed operation command) *1*2 b6: RT (second function selection)*2 b7: MRS (output stop) *1*2 b8 to b15: —	[Example 1] H0002 Forward rotation b15

^{*1} The signal within parentheses is the default setting. The description changes depending on the setting of Pr. 180 to Pr. 182 (input terminal function selection) (page 108).

[Inverter status monitor]

	Instruction	Bit		
Item	Code	Length	Description	Example
Inverter status monitor	Н7А	8bit	b0: RUN (inverter running) * b1: Forward rotation b2: Reverse rotation b3: SU (up-to-frequency) b4: OL (overload) b5: — b6: FU (frequency detection) b7: ABC (fault) *	[Example 1] H02 During forward rotation b7 b0 0 0 0 0 0 0 1 0 [Example 2] H80 Stop at fault occurrence b7 1 0 0 0 0 0 0 0 0
Inverter status monitor (expansion)	H79	16bit	b0: RUN (inverter running) * b1: Forward rotation b2: Reverse rotation b3: SU (up-to-frequency) b4: OL (overload) b5: — b6: FU (frequency detection) b7: ABC (fault) * b8 to b14: — b15: Fault occurrence	[Example 1] H0002 During forward rotation b15

^{*} The signal within parentheses is the default setting. Definitions change according to the Pr.190, Pr. 192 (output terminal function selection).

^{*2} When Pr. 551 = "2" (PU Mode control source is PU connector), only forward rotation and reverse rotation can be used.

7

[Multi command (HF0)]

Sending data format from computer to inverter

Format		Number of Characters																	
Torritat	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
А3	ENQ	Inve stat num	ion	Co	uction de F0)	Waiting time	data	Receive data type*2		Data	a1*3				ta2 ·3		Su che		CR/LF

Reply data format from inverter to computer (No data error detected)

Form		Number of Characters																	
1 01111	1 2 3 4 5 6 7 8 9 10 11								11	12	13	14	15	16	17	18	19		
C1	STX	Inve stat num	tion	data		code 1	Error code2 *5		Data	a1*4				ita2 •4		ETX	Su che		CR/LF

- *1 Specify the data type of sending data (from computer to inverter).
- *2 Specify the data type of reply data (from inverter to computer).
- *3 Combination of data 1 and data 2 for sending

Data Type	Data Type Data 1		Remarks						
0	Run command	Set frequency	Run command (expansion) is same as instruction code HF9						
0	(expansion)	(RAM)	(Refer to page 193)						
4	Run command	Set frequency	The unit of set frequency is always by four digits, even when "0.01						
'	(expansion)	(RAM, EEPROM)	to 9998" is set in Pr. 37 and "01" is set in instruction code HFF.						

*4 Combination of data 1 and data 2 for reply

Data Type	Data 1	Data 2	Remarks
0	Inverter status	Output frequency	Inverter status monitor (expansion) is same as instruction code
0	monitor (expansion)	(speed)	H79 (Refer to page 193)
1	Inverter status monitor (expansion)	Special monitor	The unit of speed monitor is always by four digits (rounds down after the decimal point), even when "0.01 to 9998" is set in <i>Pr. 37</i> and "01" is set in instruction code HFF. Replys the monitor item specified in instruction code HF3 for special monitor.(<i>Refer to page 192</i>)

^{*5} Error code for sending data 1 is set in error code 1, and error code for sending data 2 is set in error code 2. Mode error (HA), instruction code error (HB), data range error (HC) or no error (HF) is replied.



4.19.6 Modbus RTU communication specifications (Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)

Using the Modbus RTU communication protocol, communication operation or parameter setting can be performed from the PU connector of the inverter.

Parameter	Name	Initial Value	Setting		Dosci	rintion				
Number	Name	illitiai value	Range	Description						
	PU communication		0	No reply to the n	naster *					
117	station number	0		Inverter station r	number specificat	ion				
	Station number		1 to 247	Set the inverter	station numbers v	vhen two or more	inverters are			
				connected to on	e personal compu	uter.				
	PU communication		48, 96, 192,	Communication	•					
118	speed	96	384	_	e × 100 equals the	e communication	speed.			
	Specu			Example) 9600b						
			0	Without parity ch						
			_	Stop bit length 2						
120	PU communication	2	1	With odd parity of						
	parity check			Stop bit length 1bit						
			2	With even parity						
				Stop bit length 1						
					nication can be r					
			0	` ,	ccurs as soon a		switched to the			
400	PU communication	0		operation mode with command source.						
122	check time interval	0	999 85	Communication check (signal loss detection) time interval If a no-communication state persists for longer than the permissible						
				time, the inverter will come to trip (depends on $Pr. 502$).						
			9999		on check (signal	• •	102).			
	Communication error		3333		, ,		ing Madhua DTII			
343		0	_	communication (mber of communi	ication errors dur	ing woodbus-RTO			
	count			At Fault	reading only)		At Fault			
				Occurrence	Indication	Fault Output	Removal			
				Occurrence			Stop			
	Stop mode selection		0	Coasts to stop.	E.PUE	Output	(E.PUE)			
502	at communication	0		Decelerates to	After stop	Output after	Stop			
	error		1	stop	E.PUE	stop	(E.PUE)			
			2	Decelerates to stop	After stop E.PUE	Without output	Automatic restart functions			
549	Protocol selection	0	0		er (computer link	operation) protoc	ol			
J-7J	i rotocoi selectioni		1	Modbus-RTU pro	otocol					
T		I I .		IIOII /D C	•					

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

Some functions are invalid for broadcast communication. (Refer to page 198)



• When "1" (Modbus-RTU protocol) is set in *Pr. 549* and "384" (38400bps) in *Pr. 118*, parameter unit (FR-PU04/FR-PU07) is disabled. When using the parameter unit (FR-PU04/FR-PU07), change parameter using the operation panel.



(I) REMARKS

- Set Pr. 549 Protocol selection to "1" to use the Modbus RTU protocol.
- When PU connector is selected as NET mode operation source (when Pr. 551 PU mode operation command source selection ≠"2"), Modbus RTU communication operation can be performed. (Refer to page 171)

^{*} When Modbus-RTU communication is performed from the master with address 0 (station number 0) set, broadcast communication is selected and the inverter does not send a response message. When response from the inverter is necessary, set a value other than "0" (initial value is 0) in Pr. 117 PU communication station number.

\mathbb{Z}

(1) Communication

•The communication specifications are given below.

	Item	Description	Related Parameter
Communica	ation protocol	Modbus-RTU protocol	Pr. 549
Conforming	standard	EIA-485(RS-485)	_
Number of o	connectable	1:N (maximum 32 units), setting is 0 to 247 stations	Pr. 117
Communica	ation speed	Selected from among 4800/9600/19200 and 38400bps	Pr. 118
Control procedure		Asynchronous	_
Communication method		Half-duplex	_
	Character system	Binary (always 8 bits)	_
	Start bit	1bit	_
	Otan hit lamath	Select from the following three types	
Communi	Stop bit length	 No parity, stop bit length 2 bits 	Pr. 120
cation	Parity check	 No odd parity, stop bit length 1 bits 	P1. 120
	railly check	Even parity, stop bit length 1 bit	
	Error check	CRC code check	_
Terminator		Not used	_
Waiting time	e setting	Not used	_

(2) Outline

The Modbus protocol is the communication protocol developed by Modicon for PLC.


The Modbus protocol performs serial communication between the master and slave using the dedicated message frame. The dedicated message frame has the functions that can perform data read and write. Using the functions, you can read and write the parameter values from the inverter, write the input command of the inverter, and check the operating status. In this product, the inverter data are classified in the holding register area (register addresses 40001 to 49999). By accessing the assigned holding register address, the master can communicate with the inverter which is a slave.

> REMARKS

There are two different serial transmission modes: ASCII (American Standard Code for Information Interchange) mode and RTU (Remote Terminal Unit) mode. This product supports only the RTU mode in which 1-byte (8-bit) data is transmitted as-is. Only the communication protocol is defined by the Modbus protocol, and the physical layer is not stipulated.



(3) Message format



Data check time

Item	Check Time		
Various monitors, operation command,	<20ms		
frequency setting (RAM)	~201115		
Parameter read/write, frequency setting	<50ms		
(EEPROM)	\301118		
Parameter clear/all clear	<5s		
Reset command	No answer		

1) Query

The master sends a message to the slave (= inverter) at the specified address.

2) Normal Response

After receiving the query from the master, the slave executes the requested function and returns the corresponding normal response to the master.

3) Error Response

If an invalid function code, address or data is received, the slave returns it to the master.

When a response description is returned, the error code indicating that the request from the master cannot be executed is

No response is returned for the hardware-detected error, frame error and CRC check error.

4) Broadcast

By specifying address 0, the master can send a message to all slaves. All slaves that received the message from the master execute the requested function. In this communication, the slaves do not return a response to the master.




The slave executes the function independently of the inverter station number setting (Pr. 117) during broadcast communication.

(4) Message frame (protocol)

Communication method

Basically, the master sends a query message (question) and the slave returns a response message (response). When communication is normal, Device Address and Function Code are copied as they are, and when communication is abnormal (function code or data code is illegal), bit 7 (= 80h) of Function Code is turned on and the error code is set to Data Bytes.

Query message from Master



The message frame consists of the four message fields as shown above.

By adding the no-data time (T1: Start, End) of 3.5 characters to the beginning and end of the message data, the slave recognizes it as one message.

Protocol details

The four message fields will be explained below.

Start	1) ADDRESS	2) FUNCTION	3) DATA	4) CRC	CHECK	End
T1	8bit	8bit	n×8bit	L 8bit	H 8bit	T1

The address code is 1 byte long (8 bits) and any of 0 to 247 can be set. Set 0 to send a broadcast message (all-address instruction) or any of 1 to 247 to send a message to each slave. When the slave responds, it returns the address set from the master. The value set to Pr. II? PU communication station number is the slave address. The function code is 1 byte long (8 bits) and any of 1 to 255 can be set. The master sets the function that it wants to request from the slave, and the slave performs the requested operation. The following table gives the supported function codes. An error response is returned if the set function code is other than those in the following table. When the slave returns a normal response, it returns the function code set by the master. When the slave returns an error response, it returns the function code set by the master. When the slave returns an error response, it returns the function code. Code Function Name Outline Broadcast Communication H03 Read Holding Register Reads the holding register data. Disallowed Writes data to the holding Allowed Preset Single Registers Writes data to the holding register. H08 Diagnostics Writes data to multiple consecutive holding registers. Read Holding Register Reads the number of registers that succeeded in communication Disallowed consecutive holding registers. Reads the number of positers that succeeded in communication last time. Table 1:Function code list The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side recalculates CRC during message receiving, and compares the result of that calculat	Message Field	Description											
When the slave responds, it returns the address set from the master. The value set to Pr. I17 PU communication station number is the slave address. The function code is 1 byte long (8 bits) and any of 1 to 255 can be set. The master sets the function that it wants to request from the slave, and the slave performs the requested operation. The following table gives the supported function codes. An error response is returned if the set function code is other than those in the following table. When the slave returns a normal response, it returns the function code set by the master. When the slave returns an error response, it returns the function code set by the master. When the slave returns an error response, it returns the function code. Code		The address	·										
When the slave responds, it returns the address set from the master. The value set to Pr. 117 PU communication station number is the slave address. The function code is 1 byte long (8 bits) and any of 1 to 255 can be set. The master sets the function that it wants to request from the slave, and the slave performs the requested operation. The following table gives the supported function codes. An error response is returned if the set function code is other than those in the following table. When the slave returns a normal response, it returns the function code set by the master. When the slave returns an error response, it returns the function code. Code	1) ADDDESS field	message (all-address instruction) or any of 1 to 247 to send a message to each slave.											
The function code is 1 byte long (8 bits) and any of 1 to 255 can be set. The master sets the function that it wants to request from the slave, and the slave performs the requested operation. The following table gives the supported function codes. An error response is returned if the set function code is other than those in the following table. When the slave returns a normal response, it returns the function code set by the master. When the slave returns an error response, it returns the function code set by the master. When the slave returns an error response, it returns the function code set by the master. When the slave returns an error response, it returns the function code set by the master. When the slave returns an error response, it returns the function code set by the master. When the slave returns an error response, it returns the function code set by the master. When the slave returns an error response, it returns the function code.	1) ADDRESS lielu	When the s	lave responds, it returns the a	ddress set from the master.									
that it wants to request from the slave, and the slave performs the requested operation. The following table gives the supported function codes. An error response is returned if the set function code is other than those in the following table. When the slave returns a normal response, it returns the function code set by the master. When the slave returns an error response, it returns the function code set by the master. When the slave returns an error response, it returns the function code. Code		The value s											
table gives the supported function codes. An error response is returned if the set function code is other than those in the following table. When the slave returns a normal response, it returns the function code set by the master. When the slave returns an error response, it returns H80 + function code. Code													
other than those in the following table. When the slave returns a normal response, it returns the function code set by the master. When the slave returns an error response, it returns H80 + function code. Code		that it wants	to request from the slave, and	d the slave performs the requested or	peration. The following								
When the slave returns a normal response, it returns the function code set by the master. When the slave returns an error response, it returns H80 + function code. Code		table gives	the supported function codes.	An error response is returned if the	set function code is								
slave returns an error response, it returns H80 + function code. Code		other than t	hose in the following table.										
2) FUNCTION field H03 Read Holding Register Reads the holding register data. Disallowed		When the s	lave returns a normal respons	e, it returns the function code set by	the master. When the								
2) FUNCTION field H03 Read Holding Register Reads the holding register data. Disallowed H06 Preset Single Register register. H08 Diagnostics Function diagnosis (communication check only) H10 Preset Multiple Registers Reads the nolding register. H46 Read Holding Register Reads to the holding registers. Read Holding Register Writes data to multiple consecutive holding registers. Reads the number of registers that succeeded in communication last time. Table 1:Function code list The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side		slave return	s an error response, it returns	H80 + function code.									
2) FUNCTION field H03 Read Holding Register Reads the holding register data. H06 Preset Single Register Preset Single Register Preset Single Register. H08 Diagnostics Prunction diagnosis (communication check only) H10 Preset Multiple Registers Preset Reads the holding registers Preset Reads the holding Register Preset Reads the holding Registers Preset Reads the holding Register Preset Reads the holding Registers Preset Reads the holding Registers Preset Reads the holding Registers Preset Re		Codo	Function Name	Outline.	Broadcast								
2) FUNCTION field H06 Preset Single Register H08 Diagnostics Function diagnosis (communication check only) Writes data to multiple consecutive holding registers. Read Holding Register Access Log Reads the number of registers that succeeded in communication last time. Table 1:Function code list The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side		Code	Function Name	Outline	Communication								
Field H06 Preset Single Register register. Function diagnosis Communication check only		H03	Read Holding Register	Reads the holding register data.	Disallowed								
H08 Diagnostics Function diagnosis (communication check only) H10 Preset Multiple Registers Consecutive holding registers. Read Holding Register Access Log Reads the number of registers that succeeded in communication last time. Table 1:Function code list The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side	I '	H06 Proset Single Pegist	Preset Single Register	Writes data to the holding	Allowed								
H08 Diagnostics (communication check only) H10 Preset Multiple Registers Writes data to multiple consecutive holding registers. Allowed	field	1100	Troot onigie regioter	· ·	Allowed								
H10 Preset Multiple Registers Writes data to multiple consecutive holding registers.		Н08 Г	Diagnostics	1	Disallowed								
Read Holding Register Reads the number of registers that succeeded in communication last time. Table 1:Function code list The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side				`									
Read Holding Register Access Log Reads the number of registers that succeeded in communication last time. Table 1:Function code list The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side		H10	Preset Multiple Registers	-	Allowed								
that succeeded in communication last time. Table 1:Function code list The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side				5 5									
Table 1:Function code list Table 1:Function code list The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side		l ⊔⊿6	Read Holding Register	_	Disallowed								
Table 1:Function code list The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side		1140	Access Log		Disallowed								
The format changes depending on the function code (Refer to page 199). Data includes the byte count, number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side			Toble										
number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side			Table	1:Function code list									
number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side		The format	changes depending on the fur	nction code (Refer to page 199). Data in	cludes the byte count.								
The received message frame is checked for error. CRC check is performed, and 2 byte long data is added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side	3) DATA field			, , , , , , , , , , , , , , , , , , , ,	, , , , , , , , , , , , , , , , , , ,								
added to the end of the message. When CRC is added to the message, the low-order byte is added 4) CRC CHECK field added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte. The CRC value is calculated by the sending side that adds CRC to the message. The receiving side					nd 2 byte long data is								
4) CRC CHECK field The CRC value is calculated by the sending side that adds CRC to the message. The receiving side													
field The CRC value is calculated by the sending side that adds CRC to the message. The receiving side	1) ODO OUEOU												
TIEIO		The CRC va	alue is calculated by the send	ng side that adds CRC to the messa	ge. The receiving side								
	TIEID												
actual value received in the CRC CHECK field. If these two values do not match, the result is defined			•	•									
as error.													



(5) Message format types

The message formats corresponding to the function codes in Table 1 on page 198 will be explained.

•Read holding register data (H03 or 03)

Can read the description of **1)** system environment variables, **2)** real-time monitor, **3)** faults history, and **4)** inverter parameters assigned to the holding register area (refer to the register list (page 204))

Query message

1) Slave Address	2) Function	Starting Address		No. of Points		CRC Check	
(8bit)	H03	Н	L	Н	L	L	Н
(obit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

1) Slave Address	2) Function	Byte Count	Data CRC Ch				Check
(8bit)	H03 (8bit)	(8bit)	H (8bit)	L (8bit)	 (n × 16bit)	L (8bit)	H (8bit)

Query message setting

Message	Setting Description				
1) Slave Address	Address to which the message will be sent				
1) Slave Address	Broadcast communication cannot be made (0 is invalid).				
2) Function	Set H03.				
	Set the address at which holding register data read will be started.				
2) Charting Address	Starting address = Starting register address (decimal)-40001				
3) Starting Address	For example, setting of the starting address 0001 reads the data of the holding				
	register 40002.				
A) No. of Doints	Number of holding registers from which data will be read				
4) No. of Points	The number of registers from which data can be read is a maximum of 125.				

Description of normal response

Message	Setting Description
5) Byte Count	The setting range is H02 to H14 (2 to 20).
5) Byte Count	Twice greater than the No. of Point specified at 4) is set.
	The number of data specified at 4) is set. Data are read in order of Hi byte and Lo
6) Data: Read data	byte, and set in order of starting address data, starting address + 1 data, starting
	address + 2 data,

Example: To read the register values of 41004 (Pr. 4) to 41006 (Pr. 6) from the slave address 17 (H11)

Query message

Slave Address	Function	Starting Address		No. of F	Points	CRC (Check
H11	H03	H03	HEB	H00	H03	H77	H2B
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

Slave Address	Function	Byte Count		Data				CRC C	Check	
H11	H03	H06	H17	H70	H0B	HB8	H03	HE8	H2C	HE6
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Read value

Register 41004(*Pr. 4*): H1770 (60.00Hz) Register 41005(*Pr. 5*): H0BB8 (30.00Hz) Register 41006(*Pr. 6*): H03E8 (10.00Hz)



• Write holding register data (H06 or 06)

Can write the description of 1) system environment variables and 4) inverter parameters assigned to the holding register area (refer to the register list (page 204)).

Query message

1) Slave Address	2) Function	3) Register Address		4) Pres	et Data	CRC (Check
(8bit)	H06	Н	L	Н	L	L	Н
(ODIL)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

1) Slave Address	2) Function	3) Register Address		4) Pres	et Data	CRC	Check
(8bit)	H06	Н	L	Н	L	L	Н
(obit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Query message setting

Message	Setting Description
1) Slave Address	Address to which the message will be sent
1) Slave Address	Setting of address 0 enables broadcast communication
2) Function	Set H06.
	Address of the holding register to which data will be written
2) Decister Address	Register address = Holding register address (decimal)-40001
3) Register Address	For example, setting of register address 0001 writes data to the holding register
	address 40002.
4) Propet Date	Data that will be written to the holding register
4) Preset Data	The written data is always 2 bytes.

Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message. No response is made for broadcast communication.

Example: To write 60Hz (H1770) to 40014 (running frequency RAM) at slave address 5 (H05).

Query message

Slave Address	Function	Register Address		Preset	Data	CRC Check		
H05	H06	H00	H0D	H17	H70	H17	H99	
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

Same data as the query message



NOTE

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.



•Function diagnosis (H08 or 08)

A communication check can be made since the query message sent is returned unchanged as a response message (function of sub function code H00).

Sub function code H00 (Return Query Data)

Query message

1) Slave Address	2) Function	3) Subfunction		4) [ate	CRC Check		
(8bit)	H08	H00	H00	Н	L	L	Н	
(ODIL)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

1) Slave Address	2) Function	3) Subfunction		4) [ate	CRC Check		
(8bit)	H08	H00	H00	Н	L	L	Н	
(obit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Query message setting

Message	Setting Description			
1) Slave Address	Address to which the message will be sent			
1) Slave Address	Broadcast communication cannot be made (0 is invalid).			
2) Function	Set H08.			
3) Subfunction	Set H0000.			
4) Data	Any data can be set if it is 2 bytes long. The setting range is H0000 to HFFFF			

• Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message.



NOTE

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.

• Write multiple holding register data (H10 or 16)

You can write data to multiple holding registers.

Query message

1)Slave Address	2) Function	3 Star Add	,	4) No. of Registers		5) ByteCount		6) Data			CRC Check	
(8bit)	H10 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	(8bit)	H (8bit)	L (8bit)	 (n×2×8bit)	L (8bit)	H (8bit)	

Normal response (Response message)

ĺ	1)Slave Address	2)Function	3)Starting Address		4)No. of I	Registers	CRC Check	
	(8bit)	H10 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	L (8bit)	H (8bit)

· Query message setting

Message	Setting Description				
1) Clave Address	Address to which the message will be sent				
1) Slave Address	Setting of address 0 enables broadcast communication				
2) Function	Set H10.				
	Address where holding register data write will be started				
2) Starting Address	Starting address = Starting register address (decimal)-40001				
3) Starting Address	For example, setting of the starting address 0001 reads the data of the ho				
	register 40002.				
4) No. of Dointo	Number of holding registers where data will be written				
4) No. of Points	The number of registers where data can be written is a maximum of 125.				
5) Puta Caunt	The setting range is H02 to HFA (0 to 250).				
5) Byte Count	Set a value twice greater than the value specified at 4).				
	Set the data specified by the number specified at 4). The written data are set in				
6) Data	order of Hi byte and Lo byte, and arranged in order of the starting address data,				
	starting address + 1 data, starting address + 2 data				



• Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message.

Example: To write 0.5s (H05) to 41007 (Pr. 7) at the slave address 25 (H19) and 1s (H0A) to 41008 (Pr.8).

Query message

Slave Address	Function		ting ress	No. of	Points	Byte Count		Da	nta		CRC	Check
H19	H10	H03	HEE	H00	H02	H04	H00	H05	H00	H0A	H86	H3D
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

Slave Address	Function	Starting Address		No. of	Points	CRC Check		
H19	H10	H03	HEE	H00	H02	H22	H61	
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

• Read holding register access log (H46 or 70)

A response can be made to a query made by the function code H03 or H10.

The starting address of the holding registers that succeeded in access during previous communication and the number of successful registers are returned.

In response to the query for other than the above function code, 0 is returned for the address and number of registers.

Query message

1) Slave Address	2) Function	CRC (Check
(8bit)	H46	L	Н
(ODIL)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

1) Slave Address	2) Function	3) Starting	g Address	4) No. of Points		CRC Check	
(8bit)	H46	H	L	H	L	L	H
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Query message setting

Message	Setting Description
1) Slave Address	Address to which the message will be sent
1) Slave Address	Broadcast communication cannot be made (0 is invalid).
2) Function	Set H46.

• Description of normal response

Message	Setting Description	
	The starting address of the holding registers that succeeded in access is returned.	
2) Starting Address	Starting address = Starting register address (decimal)-40001	
3) Starting Address	For example, when the starting address 0001 is returned, the address of the	
	holding register that succeeded in access is 40002.	
4) No. of Points	The number of holding registers that succeeded in access is returned.	

Example: To read the successful register starting address and successful count from the slave address 25 (H19).

Query message

Slave Address	lave Address Function CRC C		Check
H19	H46	H8B	HD2
(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

Slave Address	Function	Starting	Address	No. of	Points	CRC (Check
H19	H10	H03	HEE	H00	H02	H22	H61
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Success of two registers at starting address 41007 (Pr. 7) is returned.



• Error response

An error response is returned if the query message received from the master has an illegal function, address or data. No response is returned for a parity, CRC, overrun, framing or busy error.



No response message is sent in the case of broadcast communication also.

Error response (Response message)

1) Slave Address	2) Function	3) Exception Code	CRC (Check
(0h;t)	H80 + Function	(Obit)	L	Н
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Message	Setting Description
1) Slave Address	Address received from the master
2) Function	Master-requested function code + H80
3) Exception Code	Code in the following table

Error code list

Code	Error Item	Error Description
01	ILLEGAL FUNCTION	The set function code in the query message from the master cannot be
01	(Function code illegal)	handled by the slave.
	ILLEGAL DATA ADDRESS *1	The set register address in the query message from the master cannot be
02 (Address illegal)		handled by the inverter.
		(No parameter, parameter read disabled, parameter write disabled)
	ILLEGAL DATA VALUE	The set data in the query message from the master cannot be handled by the
03		inverter.
	(Data illegal)	(Out of parameter write range, mode specified, other error)

- *1 An error will not occur in the following cases.
 - 1) Function code H03 (Read holding register data)
 - When the No. of Points is 1 or more and there is one or more holding registers from which data can be read
 - 2) Function code H10 (Write multiple holding register data)
 - When the No. of Points is 1 or more and there is 1 or more holding registers to which data can be written

Namely, when the function code H03 or H10 is used to access multiple holding registers, an error will not occur if a non-existing holding register or read disabled or write disabled holding register is accessed.



(I) REMARKS

An error will occur if all accessed holding registers do not exist.

Data read from a non-existing holding register is 0, and data written there is invalid.

· Message data mistake detection

To detect the mistakes of message data from the master, they are checked for the following errors. If an error is detected, a trip will not occur.

Error check item

Error Item	Error Description	Inverter Operation
Darity orror	The data received by the inverter differs from the	
Parity error	specified parity (Pr. 334 setting).	
Framing arrar	The data received by the inverter differs from the	
Framing error	specified stop bit length (Pr. 333).	
Overrun error	The following data was sent from the master before	1) Pr.343 is increased by 1 at error
Overruit error	the inverter completes data receiving.	occurrence.
	The message frame data length is checked, and the	2)The terminal LF is output at error
Message frame error	received data length of less than 4 bytes is regarded	occurrence.
	as an error.	
	A mismatch found by CRC check between the	
CRC check error	message frame data and calculation result is	
	regarded as an error.	

(6) Modbus registers

System environment variable

Register	Definition	Read/write	Remarks
40002	Inverter reset	Write	Any value can be written
40003	Parameter clear	Write	Set H965A as a written value.
40004	All Parameter clear	Write	Set H99AA as a written value.
40006	Parameter clear *1	Write	Set H5A96 as a written value.
40007	All parameter clear *1	Write	Set HAA99 as a written value.
40009	Inverter status/control input instruction*2	Read/write	See below.
40010	Operation mode/inverter setting *3	Read/write	See below.
40014	Running frequency (RAM value)	Read/write	According to the <i>Pr. 37</i> settings, the frequency
40015	Running frequency (EEPROM value)	Write	and selectable speed are in 1r/min increments.

- *1 The communication parameter values are not cleared.
- *2 For write, set the data as a control input instruction. For read, data is read as an inverter operating status.
- *3 For write, set data as the operation mode setting. For read, data is read as the operation mode status.

<Inverter status/control input instruction>

	Definition			
Bit				
Dit	Control input instruction	Inverter status		
0	Stop command	RUN (inverter running) *2		
1	Forward rotation command	Forward rotation		
2	Reverse rotation command	During reverse rotation		
3	RH (high-speed operation	SU (up-to-frequency)		
3	command)*1	30 (up-to-frequency)		
4	RM (middle-speed operation	OL (overload)		
4	command)*1	OL (overload)		
5	RL (low-speed operation	0		
5	command)*1			
6	0	FU (frequency detection)		
7	RT (second function selection)	ABC (fault) *2		
8	AU (current input selection)	0		
9	0	0		
10	MRS (output stop)	0		
11	0	0		
12	0	0		
13	0	0		
14	0	Ō		
15	0	Fault occurrence		

<Operation mode/inverter setting>

Mode	Mode Read Value	
Wode	Read Value	Value
EXT	H0000	H0010
PU	H0001	_
EXT	H0002	
JOG	H0002	_
NET	H0004	H0014
PU+EXT	H0005	_

The restrictions depending on the operation mode changes according to the computer link specifications.

Each assigned signal is valid or invalid depending on NET. (Refer to page 171)

●Real time monitor

Refer to page 123 for details of the monitor description.

Register	Description	Unit
40201	Output frequency/speed *1	0.01Hz/1
40202	Output current	0.01A
40203	Output voltage	0.1V
40205	Output frequency setting/speed	0.01Hz/
40203	setting *1	0.001
40208	Converter output voltage	0.1V
40209	Regenerative brake duty	0.1%
40210	Electronic thermal relay function	0.1%
40210	load factor	0.170
40211	Output current peak value	0.01A
40212	Converter output voltage peak value	0.1V
40214	Output power	0.01kW
40215	Input terminal status *2	_

Register	Description	Unit
40216	Output terminal status *3	_
40220	Cumulative energization time	1h
40223	Actual operation time	1h
40224	Motor load factor	0.1%
40225	Cumulative power	1kWh
40252	PID set point	0.1%
40253	PID measured value	0.1%
40254	PID deviation	0.1%
40261	Motor thermal load factor	0.1%
40262	Inverter thermal load factor	0.1%
40263	Cumulative power 2	0.01kWh
40264	PTC thermistor resistance	0.01kΩ

b0

*1 When "0.01 to 9998" is set in Pr. 37 and "01" in instruction code HFF, the data format is 6 digits (E").

*2 Input terminal monitor details b15

	_	_	_	_	_	_	_	_	_	RH	RM	RL		_	STR	STF
*3	Output terminal monitor details															
	b15															b0
	_	_	_	_	_	_	_	_	_	_	ABC	-	_	_	_	RUN

^{*1} The signal within parentheses is the default setting. The description changes depending on the setting of *Pr. 180 to Pr. 182 (input terminal function selection) (refer to page 108)*.

^{*2} The signal within parentheses is the default setting. Definitions change according to the Pr. 190, Pr. 192 (output terminal function selection) (refer to page 114).



Parameter

Parameter	Register	Parameter Name	Read/ Write	Remarks
0 to 999	41000 to 41999	Refer to the parameter list (page 52) for the parameter names.	Read/write	The parameter number + 41000 is the register number.
C2(902)	41902	Terminal 2 frequency setting bias frequency	Read/write	
C3(902)	42092	Terminal 2 frequency setting bias (Analog value)	Read/write	The analog value (%) set to C3 (902) is read.
03(302)	43902	Terminal 2 frequency setting bias (Terminal analog value)	Read	The analog value (%) of the voltage (current) applied to the terminal 2 is read.
125(903)	41903	Terminal 2 frequency setting gain frequency	Read/write	
C4(903)	42093	Terminal 2 frequency setting gain (Analog value)	Read/write	The analog value (%) set to C4 (903) is read.
C4(903)	43903	Terminal 2 frequency setting gain (Terminal analog value)	Read	The analog value (%) of the voltage (current) applied to the terminal 2 is read.
C5(904)	41904	Terminal 4 frequency setting bias frequency	Read/write	
C6(904)	42094	Terminal 4 frequency setting bias (Analog value)	Read/write	The analog value (%) set to C6 (904) is read.
C0(904)	43904	Terminal 4 frequency setting bias (Terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.
126(905)	41905	Terminal 4 frequency setting gain frequency	Read/write	
C7(905)	42095	Terminal 4 frequency setting gain (Analog value)	Read/write	The analog value (%) set to C7 (905) is read.
C7(905)	43905	Terminal 4 frequency setting gain (Terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.

Faults history

Register	Definition	Read/write	Remarks
40501	Fault history 1	Read/write	Being 2 bytes in length, the data is stored as
40502	Fault history 2	Read	"H00OO".
40503	Fault history 3	Read	The error code can be referred to in the low-order 1
40504	Fault history 4	Read	byte.
40505	Fault history 5	Read	*
40506	Fault history 6	Read	Performing write using the register 40501 batch-
40507	Fault history 7	Read	clears the faults history.
40508	Fault history 8	Read	Set any value as data.

Fault code list

Data	Definition
H00	No fault
HUU	present
H10	E.OC1
H11	E.OC2
H12	E.OC3
H20	E.OV1
H21	E.OV2
H22	E.OV3
H30	E.THT

Data	Definition
H31	E.THM
H40	E.FIN
H52	E.ILF
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT
H91	E.PTC
	10

Data	Definition
HB0	E.PE
HB1	E.PUE
HB2	E.RET
HC0	E.CPU
HC4	E.CDO
HC5	E.IOH
HC7	E.AIE

(7) Pr. 343 Communication error count

You can check the cumulative number of communication errors.

Parameter	Setting Range	Minimum Setting Range	Initial Value
343	(Reading only)	1	0

^{*} Refer to page 245 for details of fault definition.




NOTE

The number of communication errors is temporarily stored into the RAM. As it is not stored into the EEPROM performing a power supply reset or inverter reset clears the value to 0.

(8) Output terminal LF "alarm output (communication error warnings)"

During a communication error, the alarm signal (LF signal) is output by open collector output. Assign the used terminal using *Pr. 190 or Pr. 192 (output terminal function selection)*.





NOTE

The LF signal can be assigned to the output terminal using Pr.~190~or~Pr.~192. Changing the terminal assignment may affect the other functions. Make setting after confirming the function of each terminal.



4.20 Special operation and frequency control

Purpose	Parameter t	Refer to Page	
Perform process control such as pump and air volume.	PID control	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577	207
Dancer control	PID control (dancer control setting)	Pr. 44, Pr. 45, Pr. 128 to Pr. 134	215
Traverse function	Traverse function	Pr. 592 to Pr. 597	221
Avoid overvoltage alarm due to regeneration by automatic adjustment of output frequency	Regeneration avoidance function	Pr. 882, Pr. 883, Pr. 885, Pr. 886	223

4.20.1 PID control (Pr. 127 to Pr. 134, Pr. 575 to Pr. 577)

The inverter can be used to exercise process control, e.g. flow rate, air volume or pressure.

The terminal 2 input signal or parameter setting is used as a set point and the terminal 4 input signal.

The terminal 2 input signal or parameter setting is used as a set point and the terminal 4 input signal used as a feedback value to constitute a feedback system for PID control.


Parameter		Initial	Setting					
Number	Name	Value	Range		Descrip	otion		
	PID control automatic		_	Frequency at which	the control is auto	omatically changed to PID control.		
127	switchover frequency	9999	9999	Without PID automa	tic switchover fun	ction		
			0	PID action is not performed				
			20	PID reverse action Measured value (terminal 4)				
			21	PID forward action	Set value (termin	nal 2 or <i>Pr. 133</i>)		
128	PID action selection	0	40	PID reverse action	Addition	For dancer control		
120	rib action selection	O	41	PID forward action	method: fixed	set point (Pr. 133),		
			42	PID reverse action	Addition	measured value (terminal 4) main speed (frequency command		
			43	PID forward action	method: ratio	of the operation mode)		
129 *1	PID proportional band	100%	0.1 to 1000%	manipulated variable measured value. He response sensitivity	nal band is narrow (parameter setting is small), the riable varies greatly with a slight change of the e. Hence, as the proportional band narrows, the tivity (gain) improves but the stability deteriorates, e.g. Gain Kp= 1/proportional band			
			9999		No proportional control			
130 *1	PID integral time	1s	0.1 to 3600s	For deviation step input, time (Ti) required for only the integral (I) action to provide the same manipulated variable as that for the proportional (P) action. As the integral time decreases, the set point is reached earlier but hunting occurs more easily. No integral control.				
		9999		Maximum value If the feedback value exceeds the setting, the FUP signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4) is equivalent to 100%. No function				
131	PID upper limit		0 to 100%					
			9999					
132	PID lower limit	9999	0 to 100% 9999	Minimum frequency If the process value falls below the setting range, the FDN signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4) is equivalent to 100%. No function				
133 *1	PID action set point	9999		Used to set the set p		rol.		
134 *1	PID differential time	9999	9999 0.01 to 10.00s 9999	Terminal 2 input is the set point. For deviation ramp input, time (Td) required for providing only the manipulated variable for the proportional (P) action. As the differential time increases, greater response is made to a deviation change. No differential control.				
575	Output interruption detection time	1s	0 to 3600s	575.				
576	Output interruption detection level	0Hz	0 to 400Hz	Without output interruption function Set the frequency at which the output interruption processing is performed.				

Parameter	Nome	Initial	Setting	December 41 and		
Number	Name	Value	Range	Description		
577	Output interruption	1000%	900 to	Set the level (Pr. 577 minus 1000%) at which the PID output interruption		
5//	cancel level	1000%	1100%	function is canceled		

The above parameters can be set when Pr. 160 Extended function display selection ="0". (Refer to page 157)

(1) PID control basic configuration

•Pr. 128 = "20, 21" (measured value input)



Kp: Proportionality constant Ti: Integral time S: Operator Td: Differential time


(2) PID action overview

1)PI action

A combination of proportional control action (P) and integral control action (I) for providing a manipulated variable in response to deviation and changes with time.

[Operation example for stepped changes of process value]

(Note) PI action is the sum of P and I actions.




2)PD action

A combination of proportional control action (P) and differential control action (D) for providing a manipulated variable in response to deviation speed to improve the transient characteristic.

[Operation example for proportional changes of process value]

(Note) PD action is the sum of P and D actions.




^{*1} Pr. 129, Pr. 130, Pr. 133 and Pr. 134 can be set during operation. They can also be set independently of the operation mode.



3)PID action

The PI action and PD action are combined to utilize the advantages of both actions for control.

(Note) PID action is the sum of P, I and D actions.




4)Reverse operation

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is positive, and decreases the manipulated variable if deviation is negative.



5)Forward action

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is negative, and decreases the manipulated variable if deviation is positive.




Relationships between deviation and manipulated variable (output frequency)

	Deviation			
	Positive	Negative		
Reverse action	71	7		
Forward action	7	71		

(3) Connection diagram

- •Source logic
- •*Pr.* 128 = **20**
- Pr. 182 = 14
- •*Pr.* 190 = 15
- •*Pr.* 192 = 16



- *1 The power supply must be selected in accordance with the power specifications of the detector used.
- *2 The used output signal terminal changes depending on the Pr. 190 , Pr. 192 (output terminal selection) setting.
- *3 The used input signal terminal changes depending on the Pr. 178 to Pr. 182 (input terminal selection) setting.



(4) I/O signals and parameter setting

- •Set "20, 21" in Pr. 128 to perform PID operation.
- Set "14" in any of Pr. 178 to Pr. 182 (input terminal function selection) to assign PID control selection signal (X14) to turn the X14 signal on.

When the X14 signal is not assigned, only the Pr. 128 setting makes PID control valid.

• Enter the set point using the inverter terminal 2 or Pr. 133 and enter the measured value to terminal 4.



(I) REMARKS

- When Pr. 128 = "0" or X14 signal is off, normal inverter operation is performed without PID action.
- Turning ON/OFF of bit of the terminal, to which X14 signal is assigned through network as RS-485 communication, enables

	Signal	Terminal Used	Function	Description	Parameter Setting
	X14	Depending on	PID control	Turn on X14 signal to perform PID	Set 14 in any of <i>Pr. 178</i> to <i>Pr.</i>
	A14	Pr. 178 to Pr. 182	selection	control. *1	182.
				You can input the set point for PID	<i>Pr. 128</i> = 20, 21,
	2	2	Set point input	control.*4	Pr. 133 = 9999
	2	2	Set point input	0 to 5V 0 to 100%	<i>Pr.</i> 73 = 1 *2, 11
٠,				0 to 10V 0 to 100%	<i>Pr.</i> 73 = 0, 10
Input	PU		Set point input	Set the set point (Pr. 133) from the	<i>Pr. 128</i> = 20, 21
=	FU	_	Set point input	operation panel.	<i>Pr. 133</i> = 0 to 100%
				Input the signal from the detector	<i>Pr. 128</i> = 20, 21
			Measured value	(measured value signal).	17. 120 – 20, 21
	4	4		4 to 20mA . 0 to 100%	<i>Pr. 267</i> = 0 *2
			input	0 to 5V 0 to 100%	<i>Pr. 267</i> = 1
				0 to 10V 0 to 100%	Pr. 267 = 2
				Output to indicate that the process value	<i>Pr. 128</i> = 20, 21
	FUP		Upper limit output	signal exceeded the maximum value (Pr.	<i>Pr. 131</i> ≠ 9999
	FUP				Set 15 or 115 in Pr. 190
				131).	or Pr. 192 *3
					<i>Pr. 128</i> = 20, 21
	FDN		Lower limit output	Output when the process value signal falls below the minimum value (<i>Pr. 132</i>).	<i>Pr. 132</i> ≠ 9999
	FUN				Set 14 or 114 in Pr. 190
					or Pr. 192. *3
		Depending on		"Hi" is output to indicate that the output	
Output		Pr. 190, Pr. 192	Forward (reverse)	indication of the parameter unit is	Set 16 or 116 in Pr. 190
Ont	RL		rotation direction	forward rotation (FWD) or "Low" to	or Pr. 192. *3
			output	indicate that it is reverse rotation (REV)	
				or stop (STOP).	
	PID		During PID control	Turns on during DID control	Set 47 or 147 in Pr. 190
	FID		activated	Turns on during PID control.	or Pr. 192. *3
			PID output	Turns on when the PID output	Pr. 575 ≠9999
	SLEEP		interruption	interruption function is performed.	Set 70 or 170 in Pr. 190 or
			ппенирион	interruption function is performed.	Pr.192. *3
	SE	SE	Output terminal	Common terminal for open collector	
	JL	JL	common	output terminal.	
a. 1	Mhan the V11 signal	is not assigned, only	he Pr. 128 setting makes	DID control volid	

- When the X14 signal is not assigned, only the Pr. 128 setting makes PID control valid.
- The shaded area indicates the parameter initial value.
- When 100 or larger value is set in any of Pr.190, Pr.192 (output terminal function selection), the terminal output has negative logic. (Refer to page 114 for details)
- When Pr. 561 PTC thermistor protection level \neq "9999", terminal 2 is not available for set point input. Use Pr. 133 for set point input.




- Changing the terminal function using any of Pr. 178 to Pr. 182 and Pr. 190, Pr. 192 may affect the other functions. Make
- setting after confirming the function of each terminal.

 When the *Pr. 267* setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (Refer to page 145 for setting)


(5) PID automatic switchover control (Pr. 127)

- •The system can be started up without PID control only at a start.
- •When the frequency is set to *Pr. 127 PID control automatic switchover frequency* within the range 0 to 400Hz, the inverter starts up without PID control from a start until output frequency is reached to the set frequency of *Pr. 127*, and then it shifts to PID control. Once the system has entered PID control operation, it continues PID control if the output ferquency falls to or below *Pr.127*.



(6) PID output suspension function (SLEEP function) (SLEEP signal, Pr. 575 to Pr. 577)

- •The inverter stops operation if the output frequency after PID operation remains at less than the *Pr. 576 Output interruption detection level* setting for longer than the time set in *Pr. 575 Output interruption detection time*. This function can reduce energy consumption in the low-efficiency, low-speed range.
- •When the deviation (= set value measured value) reaches the PID output shutoff cancel level (*Pr. 577* setting -1000%) while the PID output interruption function is on, the PID output interruption function is canceled and PID control operation is resumed automatically.
- •While the PID output interruption function is on, the PID output interruption signal (SLEEP) is output. At this time, the inverter running signal (RUN) is off and the PID control operating signal (PID) is on.
- •For the terminal used for the SLEEP signal output, assign the function by setting "70" (positive logic) or "170" (negative logic) in *Pr. 190 or Pr. 192 (output terminal function selection)*.




(7) PID monitor function

- •The PID control set point, measured value and deviation value can be displayed on the operation panel and output from terminal AM.
- •The deviation monitor displays a negative value on the assumption that 1000 is 0%. (The deviation monitor cannot be output from the terminal AM.)
- •For each monitor, set the following value in Pr. 52 DU/PU main display data selection and Pr. 158 AM terminal function selection.

Setting	Monitor Description	Minimum Increments	Terminal AM Full Scale	Remarks
52	PID set point	0.1%	100%	
53	PID measured value	0.1%	100%	_
54	PID deviation	0.1%	_	Value cannot be set to Pr. 158.
				Displays 1000 when the PID deviation is 0%.




(8) Adjustment procedure



(9) Calibration example

(A detector of 4mA at 0°C and 20mA at 50°C is used to adjust the room temperature to 25°C under PID control. The set point is given to across inverter terminals 2-5 (0 to 5V).)



*When calibration → Using calibration Pr. 902 and Pr. 903 (terminal 2) or Pr. 904 and Pr. 905 (terminal is required 4), calibrate the detector output and target setting input. Make calibration in the PU mode during an inverter stop.

<Set point input calibration>

- 1. Apply the input voltage of 0% set point setting (e.g. 0V) across terminals 2-5.
- 2. Enter in C2 (Pr. 902) the frequency which should be output by the inverter at the deviation of 0% (e.g. 0Hz).
- 3. In C3 (Pr.902), set the voltage value at 0%.
- 4. Apply the voltage of 100% set point (e.g. 5V) to across terminals 2-5.
- 5. Enter in Pr.125 the frequency which should be output by the inverter at the deviation of 100% (e.g. 50Hz).
- 6. In C4 (Pr.903), set the voltage value at 100%.

<Measured value calibration>


- 1. Apply the input current of 0% measured value (e.g. 4mA) across terminals 4-5.
- 2. Make calibration using C6 (Pr. 904).
- 3. Apply the input current of 100% measured value (e.g. 20mA) across terminals 4-5.
- 4. Make calibration using C7 (Pr. 905).





> REMARKS

• The frequency set in C5 (Pr. 904) and Pr. 126 should be the same as set in C2 (Pr. 902) and Pr. 125.

The results of the above calibration are as shown below:









NOTE

- If the multi-speed (RH, RM, RL, REX signal) or jog operation (JOG signal) is entered with the X14 signal on, PID
 control is stopped and multi-speed or jog operation started.
- If the setting is as follows, PID control becomes invalid.


Pr. 79 Operation mode selection ="6" (switchover mode)

When the inverter is at a stop with Pr. 261 Power failure stop selection selected.

- Changing the terminal function using any of Pr. 178 to Pr. 182, Pr. 190, Pr. 192 may affect the other functions. Make setting after confirming the function of each terminal.
- When PID control is selected, the minimum frequency is the frequency set in *Pr. 902* and the maximum frequency is the frequency set in *Pr. 903*.

Pr. 1 Maximum frequency and Pr. 2 Minimum frequency settings are also valid.

- The remote operation function is invalid during PID operation.
- When the control is switched to PID control during normal operation, the frequency command value calculated by PID operation using 0Hz as standard is used without the frequency during the operation.



Operation when control is switched to PID control during normal operation



Parameters referred to

Pr. 59 Remote function selection Refer to page 88

Pr. 73 Analog input selection Refer to page 145

Pr. 79 Operation mode selection Refer to page 160

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108

Pr. 190, Pr. 192 (output terminal function selection) Refer to page 114

Pr. 261 Power failure stop selection Refer to page 137

Pr. 561 PTC thermistor protection level Refer to page 95

C2 (Pr. 902) to C7 (Pr. 905) Frequency setting voltage (current) bias/gain 👺 Refer to page 148



4.20.2 Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)


Performs PID control by feedbacking the position detection of the dancer roller, controlling the dancer roller is in the specified position.

Parameter Number	Name	Initial Value		Setting Range		Description	on	
44	Second acceleration/ deceleration time	FR-D740-080 or less FR-D720S-008 to 100 5s FR-D740-120 and 160 10s		0 to 3600s	speed during	This parameter is the acceleration time of the maspeed during dancer control. It will not function a second acceleration/deceleration time.		
45	Second	9999		0 to 3600s	This parameter is the deceleration time of the maspeed during dancer control. It will not function a			
	deceleration time			9999	second deceleration time.			
				0	PID action is not performed			
				20	PID reverse action PID forward	Measured value (terminal 4)		
				21	PID forward Set value (terminal 2 or <i>Pr. 133</i>) action		III ai 2 01 <i>Pr. 133)</i>	
128	PID action	0		40	PID reverse action	Addition method: fixed	For dancer control	
	selection			41	PID forward action	Addition method: fixed	set point (Pr. 133), measured value	
				42	PID reverse action	Addition method: ratio	(terminal 4) main speed (speed	
				43	PID forward action	Addition method: ratio	operation mode)	
129 *1	PID proportional band	100%		0.1 to 1000%	If the proportional band is narrow (parameter setting is small), the manipulated variable varies greatly with a slight change of the measured value Hence, as the proportional band narrows, the response sensitivity (gain) improves but the stability deteriorates, e.g. hunting occurs. Gain Kp = 1/proportional band			
				9999	No proportional control			
130 *1	PID integral time	1s		0.1 to 3600s	the integral (I) manipulated v action. As the	action to providerariable as that for integral time dec	(Ti) required for only e the same or the proportional (P) creases, the set point occurs more easily.	
				9999	No integral control.			
131	PID upper limit	9999		0 to 100%	signal is outpu	k value exceeds ut. The maximum easured value (to	the setting, the FUP n input (20mA/5V/ erminal 4) is	
				9999	No function			
132	PID lower limit	9999		0 to 100%	Minimum value If the process value falls below the setting range, the FDN signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4 is equivalent to 100%.		maximum input	
	PID action set			0 to 100%	No function Used to set th	e set point for P	ID control.	
133 *1	point	9999		9999	Used to set the set point for PID control. Always 50%			
134 *1	PID differential time	9999		0.01 to 10.00s	For deviation ramp input, time (Td) required for providing only the manipulated variable for the proportional (P) action. As the differential time increases, greater response is made to a deviation change.			
	1				No differential	control.		

The above parameters can be set when Pr.160 Extended function display selection ="0". (Refer to page 157)

^{*1} Pr. 129, Pr. 130, Pr. 133 and Pr.134 can be set during operation. They can also be set independently of the operation mode.

(1) Dancer control block diagram



*1 The main speed can be selected from all operation mode such as external (analog voltage input, multi-speed), PU (digital frequency setting), communication (RS-485).

Set point and measured value of PID control

	Input	Input Signal	Pr.267 Setting	Voltage/Current Input Switch
Set point	Pr. 133	0 to 100%	_	_
Measured	When measured value is input as current (4 to 20mA)	4mA 0%, 20mA100%	0	V
value	When measured value is input as voltage	0V 0%, 5V100%	1	
		0V 0%, 10V100%	2	VI



NOTE


- Changing the terminal function using any of *Pr.178 to Pr.182* may affect the other functions. Make setting after confirming the function of each terminal.
- When the *Pr. 267* setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (*Refer to page 145* for setting)



(2) Dancer control overview


Performs dancer control by setting 40 to 43 in *Pr. 128 PID action selection*. The main speed command is the speed command of each operation mode (external, PU, communication). Performs PID control by the position detection signal of the dancer roller, then the result is added to the main speed command. For acceleration/deceleration of the main speed, set the acceleration time in *Pr. 44 Second acceleration/deceleration time* in *Pr. 45 Second deceleration time*.

* Set 0s normally to Pr. 7 Acceleration time and Pr.8 Deceleration time. When the Pr. 7 and Pr. 8 setting is large, response of dancer control during acceleration/ deceleration is slow.



(3) Connection diagram

- Source logic
- •Pr. 128 = 41
- •Pr. 182 = 14
- •Pr. 190 = 15
- •*Pr.* 192 = 16



- *1 The main speed command differs according to each operation mode (external, PU, communication)
- *2 The used output signal terminal changes depending on the Pr. 190, Pr. 192 (output terminal selection) setting.
- *3 The used input signal terminal changes depending on the Pr. 178 to Pr. 182(input terminal selection) setting.

7/

(4) I/O signals and parameter setting

- •Set "40 to 43" in Pr. 128 to perform dancer control.
- •Set "14" in any of *Pr. 178 to Pr. 182* (*input terminal function selection*) to assign PID control selection signal (X14) to turn the X14 signal on.

When the X14 signal is not assigned, only the Pr. 128 setting makes dancer control valid.

- •Input the main speed command (external, PU, communication). The main speed command in any operation mode can be input. (Note that terminal 4 can not be used as the main speed command.)
- •Input the set point using *Pr. 133*, then input the measured value signal (dancer roller position detection signal) across terminal 4 and 5 of the inverter.



REMARKS

- When Pr. 128 = "0" or X14 signal is off, normal inverter operation is performed without dancer control.
- Turning ON/OFF of bit of the terminal, to which X14 signal is assigned through network as RS-485 communication, enables dancer control

S	ignal	Terminal Used	Function	Description	Parameter Setting
	X14	Depending on <i>Pr. 178</i> to <i>Pr. 182</i>	PID control selection	Turn on X14 signal to perform dancer control. *1	Set 14 in any of <i>Pr. 178 to Pr. 182</i> .
Input	put		Measured value	Input the signal from the dancer roller detector (measured value signal).	<i>Pr.128</i> = 40, 41, 42, 43
	4	4	input	4 to 20mA0 to 100%	Pr.267 = 0 *2
			input	0 to 5V0 to 100%	Pr.267 = 1
				0 to 10V0 to 100%	<i>Pr.267</i> = 2
	FUP		Upper limit output	Output to indicate that the measured value signal exceeded the maximum value (<i>Pr. 131</i>).	Pr.128 = 40, 41, 42, 43 $Pr.131 \neq 9999$ Set 15 or 115 in $Pr.190$ or $Pr.192.*3$
nt	FDN	Depending on	Lower limit output	Output when the measured value signal falls below the minimum value (Pr. 132).	Pr.128 = 40, 41, 42, 43 $Pr.132 \neq 9999$ Set 14 or 114 in $Pr.190$ or $Pr.192.*3$
Output	RL	Pr. 190, Pr. 192 Forward (reverse) rotation direction output		Output is "ON" when the output indication of the parameter unit is forward rotation (FWD) and "OFF" when reverse rotation (REV) or stop (STOP).	Set 16 or 116 in <i>Pr. 190</i> or <i>Pr. 192.</i> *3
	PID		During PID control activated	Turns on during PID control.	Set 47 or 147 in <i>Pr. 190</i> or <i>Pr. 192.</i> *3
	SE	SE	Output terminal common	Common terminal for open collector output terminal	

- *1 When the X14 signal is not assigned, only the Pr. 128 setting makes dancer control valid.
- *2 The shaded area indicates the parameter initial value.
- *3 When 100 or larger value is set in any of Pr. 190, Pr. 192 (output terminal function selection), the terminal output has negative logic. (Refer to page 114 for details)




NOTE

- Changing the terminal function using any of *Pr. 178 to Pr. 182, Pr.190, Pr.192* may affect the other functions. Make setting after confirming the function of each terminal.
- When the *Pr. 267* setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (*Refer to page 145* for setting)
- Turn off PID output suspension function (Pr. 575 = "9999") while using Dancer control.
- When Pr. 561 PTC thermistor protection level ≠ "9999", terminal 2 is not available for main speed command. Terminal 2 is used as PTC thermistor input terminal.



(5) Parameter details



•When ratio ($Pr.\ 128$ = "42, 43") is selected for addition method, PID control × (ratio of main speed) is added to the main speed. The ratio is determined by the $Pr.\ 125$ Terminal 2 frequency setting gain frequency and C2 ($Pr.\ 902$) Terminal 2 frequency setting bias frequency. The frequency setting signal is set to 0 to 50Hz in the range between 0 to 100% in the initial setting. The ratio is (×100%) when the main speed is 50Hz and (×50%) when 25Hz.



NOTE

- Even when C4 (Pr. 903) is set to other than 100%, the frequency setting signal is considered as 100%.
- Even when C3 (Pr. 903) is set to other than 0%, the frequency setting signal is considered as 0%.
- When C2 (Pr. 902) is set to other than 0Hz, the frequency setting signal is 0% when C2 (Pr. 902) is less than the set frequency.
- •Turning X14 signal on/off during operation by assigning X14 signal results in the following operation.

When X14 signal is on: Uses output frequency unchanged as the main speed command and continues operation by dancer control.

When X14 signal is off: Ends dancer control and continues operation at the set frequency made valid.

Pr. 128 Setting	PID Action	Addition Method	Set Point	Measured Value	Main Speed Command
40	Reverse action	Fixed			
41	Forward action	i ixeu	Pr. 133	Terminal 4	Speed command for each
42	Reverse action	Ratio	F1. 155	Terriniai 4	operation mode
43	Forward action	Natio			

- •Action of *Pr. 129 PID proportional band, Pr. 130 PID integral time, Pr. 131 PID upper limit, Pr. 132 PID lower limit, Pr. 134 PID differential time* is the same as PID control. For the relationship of controlled variable (%) of PID control and frequency, 0% is equivalent to the set frequency of *Pr. 902* and 100% to *Pr. 903*.
- •For the *Pr. 133 PID action set point* setting, set frequency of *Pr. 902* is equivalent to 0% and *Pr. 903* to 100%. When *9999* is set in *Pr. 133*, 50% is the set point.



> REMARKS

Pr. 127 PID control automatic switchover frequency is invalid.

(6) Output signal

•Output terminal assignment during dancer control (PID control) operation

PID signal turns on during dancer control (PID control) or at a stop by PID control (in the status PID operation being performed inside) (The signal is off during normal operation.)

For the terminal used for PID signal output, assign the function by setting "47 (positive logic) or 147 (negative logic)" in *Pr.* 190 or *Pr.* 192 (output terminal function selection).



NOTE

Changing the terminal function using any of *Pr. 178* to *Pr. 182, Pr. 190, Pr. 192* may affect the other functions. Make setting after confirming the function of each terminal.

(7) PID monitor function

- •The PID control set point and measured value can be output to the operation panel monitor display and terminal AM.
- •For each monitor, set the following value in Pr. 52 DU/PU main display data selection and Pr. 158 AM terminal function selection.

Setting Monitor Description		Minimum	Terminal AM	Remarks
		Increments Full Scale		Remarks
52	PID set point	0.1%	100%	
53	PID measured value	0.1%	100%	_
54	54 PID deviation 0.1%			Value cannot be set in Pr. 158.
54 FID deviation	FID deviation	0.176	_	Displays 1000 when the PID deviation is 0%.


(8) Priorities of main speed command

- •The priorities of the main speed speed command source when the speed command source is external are as follows. JOG signal > multi-speed setting signal (RL/RM/RH/REX) > temrinal 2
- ullet The priorities of the main speed speed command source when "3" is set in Pr.~79.
- Multi-speed setting signal (RL/RM/RH/REX) > set frequency (digital setting by PU, operation panel)
- •Terminal 4 can not be selected as the main speed speed command even when AU terminal is turned on.
- •Even when a remote operation function is selected by setting a value other than "0" in *Pr. 59*, compensation of the remote setting frequency to the main speed is ignored (changes to 0).

(9) Adjustment procedure

Dancer roller position detection signal adjustment

When terminal 4 input is voltage input, 0V is minimum position and 5V(10V) is maximum position. When current is input, 4mA is minimum position and 20mA is maximum position. (initial value) When 0 to 7V is output from the potentiometer, it is necessary to calibrate C7 (Pr.905) at 7V.



(Example) Control at a dancer center position using a 0 to 7V potentiometer

- 1) After changing the current/voltage input switch to "V", set "2" in Pr. 267 to change terminal 4 input to voltage input.
- 2) Input 0V to across terminal 4 and 5 to calibrate *C6* (*Pr. 904*). (% display displayed at analog calibration is irrelevant to % of the feed back value.)
- 3) By inputting 7V to across terminal 4 to 5, calibrate C7(Pr. 905) (% display displayed at analog calibration is irrelevant to % of the feed back value.)
- 4) Set 50% in Pr.133.



NOTE

When the Pr. 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (Refer to page 145 for setting)



REMARKS

- In normal PID control, PID control is stopped when multi-speed operation signal (RH, RM, RL, REX signal) or JOG signal is
 input. In dancer control, however, PID control continues handling the signals as the main speed.
- During dancer control, Second acceleration/deceleration time of Pr.44 and Pr.45 are the parameters for acceleration/deceleration time setting to the main speed command source. They do not function as the second function.
- When switchover mode is set with "6" in Pr. 79, dancer control (PID control) is invalid.
- · Speed command of terminal 4 input from terminal AU is invalid when dancer control is selected.
- Acceleration/deceleration of the main speed command is the same operation as when frequency command is increased/ decreased by analog input.
- Therefore, SU signal remains on even if the starting signal is turned on/off.(always in the constant speed state)
- The DC brake operation starting frequency when turning off the starting signal is not Pr. 10 but a smaller value of either Pr. 13 or 0.5Hz.
- The set frequency monitor is always variable as "main speed command+PID control".
- The main speed setting frequency accelerates for the acceleration/deceleration time set in Pr.~44 and Pr.~45 and the output frequency accelerates/decelerates for the acceleration/deceleration time set in Pr.~7 and Pr.~8. Therefore, when the set time of Pr.~7 and Pr.~8 is longer than Pr.~44 and Pr.~45, the output frequency accelerates/decelerates for the acceleration/deceleration time set in Pr.~7 and Pr.~8.
- For the integral term limit, a smaller value of either the PID manipulated variable (%) value converted from the linear, interpolated *Pr. 1 Maximum frequency* with *Pr. 902* and *Pr. 903* , or 100% is used for limit.
- Although the output frequency is limited by the minimum frequency, operation limit of the integral term is not performed.



Parameters referred to

Pr. 59 Remote function selection Refer to page 88

Pr. 73 Analog input selection Refer to page 145

Pr. 79 Operation mode selection Refer to page 160

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 108

Pr. 190, Pr. 192 (output terminal function selection) Refer to page 114

Pr. 561 PTC thermistor protection level Refer to page 95

C2 (Pr. 902) to C7 (Pr. 905) Frequency setting voltage (current) bias/gain Refer to page 148




4.20.3 Traverse function (Pr. 592 to Pr. 597)

Traverse operation which varies the amplitude of the frequency in a constant cycle can be performed.

Parameter	Nome	Initial	Setting	Description
Number	Name	Value	Range	Description
	Traverse function		0	Traverse function invalid
592	selection	0	1	Traverse function is valid only in the external operation mode
	Selection		2	Traverse function is valid independently of operation mode
502	Maximum amplitude	400/	0.4- 0.50/	A morality rate are a control at the control and a control
593	amount	10%	0 to 25%	Amplitude amount during traverse operation
	Amplitude		0 to 50%	
594	compensation amount	10%		Compensation amount at the time of amplitude inversion
	during deceleration			(acceleration → deceleration)
	Amplitude		0 to 50%	
595	compensation amount	10%		Compensation amount during amplitude inversion operation
	during acceleration			(deceleration → acceleration)
F0C	Amplitude acceleration	-	0.4.45.20005	
596	time	5s	0.1 to 3600s	Acceleration time during traverse operation
507	Amplitude deceleration	F	0.4.45.20005	Desclaration time during transports and another
597	time	5s	0.1 to 3600s	Deceleration time during traverse operation

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

- · When "1" or "2" is set in *Pr. 592 Traverse function selection*, turning on the traverse operation signal (X37) makes the traverse function valid.
- · Set "37" in any of *Pr. 178 to Pr. 182 Input terminal function selection* and assign the X37 signal to the external terminal. When the X37 signal is not assigned to the input terminal, the traverse function is always valid (X37-ON).




- f0: set frequency
- f1: amplitude amount from the set frequency (f0 × Pr. 593/100)
- f2: compensation amount at transition from acceleration to deceleration (f1 × Pr. 594/100)
- f3: compensation amount at transition from deceleration to acceleration (f1 × Pr. 595/100)
- t1: time from acceleration during traverse operation (Time from (f0 f1) to (f0 + f1)
- t2: time from deceleration during traverse operation (Time from (f0 + f1) to (f0 f1) (*Pr. 597*)
- 1) When the starting command (STF or STR) is switched on, the output frequency accelerates to the set frequency f0 according to the normal *Pr. 7 Acceleration time*.
- 2) When the output frequency reaches f0, traverse operation can be started by switching the X37 signal on, then the frequency accelerates to f0 + f1. (The acceleration time at this time depends on the Pr. 596 setting.)
- 3) After having accelerated to f0 + f1, compensation of f2 (f1 × *Pr.* 594) is made and the frequency decreases to f0-f1. (The deceleration time at this time depends on the *Pr.* 597 setting.)
- 4) After having decelerated to f0 f1, compensation of f3 ($f1 \times Pr. 595$) is made and the frequency again accelerates to f0 + f1.
- 5) If the X37 signal is turned off during traverse operation, the frequency accelerates/decelerates to f0 according to the normal acceleration/deceleration time (*Pr. 7, Pr. 8*). If the start command (STF or STR) is turned off during traverse operation, the frequency decelerates to a stop according to the normal deceleration time (*Pr. 8*).




REMARKS


When the second function signal (RT) is on, normal acceleration/deceleration time (*Pr. 7, Pr. 8*) is the same as second acceleration/deceleration time (*Pr. 44, Pr. 45*).




If the set frequency (f0) and traverse operation parameters (Pr. 593 to Pr. 597) are changed, pattern operation is performed at changed f0 after the output frequency reached f0 before change.



When the output frequency exceeds Pr. 1 Maximum frequency or Pr. 2
 Minimum frequency, the output frequency is clamped at maximum/
 minimum frequency while the set pattern exceeds the maximum/
 minimum frequency.



When the traverse function and S-pattern acceleration/deceleration (Pr. 29 ≠ 0) are selected, S-pattern acceleration/deceleration is performed only in the areas where operation is performed in normal Acceleration and deceleration time (Pr. 7, Pr. 8). For acceleration/deceleration during traverse operation, linear acceleration/deceleration is made.



When stall prevention is activated during traverse operation, traverse operation is stopped and normal operation is performed. When stall prevention operation ends, the motor accelerates/decelerates to f0 in normal acceleration/deceleration time (Pr. 7, Pr. 8). After the output frequency reaches f0, traverse operation is again performed.



NOTE

- When the value of amplitude inversion compensation amount (Pr. 594, Pr. 595) is too large, pattern operation as set is not performed due to overvoltage shut-off and stall prevention.
- Changing the terminal assignment using *Pr. 178 to Pr. 182 (input terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.



Parameters referred to

Pr. 1 Maximum frequency Refer to page 90

Pr. 7 Acceleration time Table Refer to page 91

Pr. 29 Acceleration/deceleration pattern selection Refer to page 107

Pr. 178 to Pr. 182 (input terminal function selection) Refer to page 132



4.20.4 Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)

This function detects a regeneration status and increases the frequency to avoid the regenerative status.


Possible to avoid regeneration by automatically increasing the frequency and continue operation if the fan happens
to rotate faster than the set speed due to the effect of another fan in the same duct.


Parameter Number	Name	Initia	l Value	Setting Range	Description	
	Regeneration	0		0	Regeneration avoidance function invalid	
882	avoidance operation			1	Regeneration avoidance function is always valid	
002	selection			2	Regeneration avoidance function is valid only during a constant speed operation	
883	Regeneration		400 VDC	300 to 800V	Bus voltage level at which regeneration avoidance operates. When the bus voltage level is set to low, overvoltage error will be less apt	
003	avoidance operation level	400V class	780 VDC	300 10 000 0	to occur. However, the actual deceleration time increases. The set value must be higher than the "power supply voltage \times	
885	Regeneration avoidance	6	Hz	0 to 10Hz	Limit value of frequency which rises at activation of regeneration avoidance function.	
005	compensation frequency limit value	0	ПΖ	9999	Frequency limit invalid	
886	Regeneration avoidance voltage gain	100%		0 to 200%	Responsiveness at activation of regeneration avoidance. A larger setting will improve responsiveness to the bus voltage	
665	Regeneration avoidance frequency gain		00%	0 to 200%	change. However, the output frequency could become unstable. When vibration is not suppressed by decreasing the <i>Pr. 886</i> setting, set a smaller value in <i>Pr. 665</i> .	


The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)


(1) What is regeneration avoidance function? (Pr. 882, Pr. 883)

- •When the regeneration load is large, the DC bus voltage rises and an overvoltage fault (E. OV□) may occur. When this bus voltage rise is detected and the bus voltage level reaches or exceeds *Pr. 883*, increasing the frequency avoids the regeneration status.
- •The regeneration avoidance function is always on when "1" is set in *Pr.* 882 and activated only during a constant speed when "2" is set in *Pr.* 882.














REMARKS

- The accel/decel ramp while the regeneration avoidance function is operating changes depending on the regeneration load.
- The DC bus voltage of the inverter is about $\sqrt{2}$ times as input voltage. When the input voltage is 220VAC, bus voltage is approximately 311VDC. When the input voltage is 440VAC, bus voltage is approximately 622VDC. However, it varies with the input power supply waveform.
- The *Pr.* 883 setting should be kept higher than the DC bus voltage level. Otherwise, the regeneration avoidance function is always on even in the non-regeneration status and the frequency increases.
- While overvoltage stall (() is activated only during deceleration and stops the output frequency, the regeneration avoidance function is always on (Pr. 882 = 1) or activated only during a constant speed (Pr. 882 = 2) and increases the frequency according to the regeneration amount.



(2) Limit regeneration avoidance operation frequency (Pr. 885)

You can limit the output frequency compensated for (increased) by the regeneration avoidance function.

- •The frequency is limited to the output frequency (frequency prior to regeneration avoidance operation) + *Pr. 885 Regeneration avoidance compensation frequency limit value* during acceleration or constant speed. If the regeneration avoidance frequency exceeds the limit value during deceleration, the limit value is held until the output frequency falls to 1/2 of *Pr. 885*.
- •When the frequency increased by regeneration avoidance function has reached *Pr. 1 Maximum frequency*, it is limited to the maximum frequency.
- •When *Pr.* 885 is set to "9999", regeneration avoidance function operation frequency setting is invalid.

(3) Regeneration avoidance function adjustment (Pr. 665, Pr. 886)

•If the frequency becomes instable during regeneration avoidance operation, decrease the setting of *Pr. 886 Regeneration avoidance voltage gain*. Reversely, if sudden regeneration causes an overvoltage alarm, increase the setting.

When vibration is not suppressed by decreasing the *Pr. 886* setting, set a smaller value in *Pr. 665 Regeneration avoidance frequency gain.*



NOTE

- When regeneration avoidance operation is performed, 🗗 (overvoltage stall) is displayed and the OL signal is output.
- · When regeneration avoidance operation is performed, stall prevention is also activated at the same time.
- The regeneration avoidance function cannot shorten the actual deceleration time taken to stop the motor. The actual
 deceleration time depends on the regeneration energy consumption capability. When shortening the deceleration
 time, consider using the regeneration unit (FR-BU2, FR-CV, FR-HC) and brake resistor (MRS type and FR-ABR etc.,) to
 consume regeneration energy at constant speed.
- When using the regeneration unit (FR-BU2, FR-CV, FR-HC) and brake resistor (MRS type and FR-ABR etc.,), set *Pr. 882* to "0 (initial value)" (regeneration avoidance function invalid). When using the regeneration unit, etc. to consume regeneration energy at deceleration, set *Pr. 882* to "2" (regeneration avoidance function valid only at a constant speed).
- When regeneration avoidance operation is performed, the OL signal output item of *Pr. 156* also becomes the target of \Box (overvoltage stall). *Pr. 157 OL signal output timer* also becomes the target of \Box (overvoltage stall).



Parameters referred to

Pr. 1 Maximum frequency Refer to page 78

Pr. 8 Deceleration time Refer to page 91

Pr. 22 Stall prevention operation level Refer to page 74



Purpose	Parameter th	Refer to Page	
Increase cooling fan life	Cooling fan operation selection	Pr. 244	225
To determine the maintenance time	Inverter part life display	Pr. 255 to Pr. 259	226
	Maintenance output function	Pr. 503, Pr. 504	230
of parts.	Current average value monitor signal	Pr. 555 to Pr. 557	231
Freely available parameter	Free parameter	Pr. 888, Pr. 889	233

4.21.1 Cooling fan operation selection (Pr. 244)

You can control the operation of the cooling fan (FR-D740-036 or more, FR-D720S-070 or more) built in the inverter.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Operates in power-on status. Cooling fan on/off control invalid (the cooling fan is always on at power on)
244	Cooling fan operation selection	1	1	Cooling fan on/off control valid The fan is always on while the inverter is running. During a stop, the inverter status is monitored and the fan switches on-off according to the temperature.

The above parameters can be set when Pr.160 Extended function display selection = "0". (Refer to page 157)

- In either of the following cases, fan operation is regarded as faulty, [FN] is shown on the operation panel, and the fan fault (FAN) and alarm (LF) signals are output.
 - Pr. 244 = "0"

When the fan comes to a stop with power on.

•Pr. 244 = "1"

When the inverter is running and the fan stops during fan ON command.

• For the terminal used for FAN signal output, set "25 (positive logic) or 125 (negative logic)" to *Pr. 190* or *Pr. 192 (output terminal function selection)*, and for the LF signal, set "98 (positive logic) or 198 (negative logic)".



NOTE

• Changing the terminal assignment using *Pr. 190, Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 190, Pr. 192 (output terminal function selection) 🕼 Refer to page 114

4.21.2 Display of the life of the inverter parts (Pr. 255 to Pr. 259)

Degrees of deterioration of main circuit capacitor, control circuit capacitor, cooling fan and inrush current limit circuit can be diagnosed by monitor.

When any part has approached the end of its life, an alarm can be output by self diagnosis to prevent a fault.

(Use the life check of this function as a guideline since the life except the main circuit capacitor is calculated theoretically.)

For the life check of the main circuit capacitor, the alarm signal (Y90) will not be output if a measuring method of (4) is not performed.


Parameter	Name	Initial Value	Setting	Description
Number	Name	iiiitiai vaiue	Range	Description
				Displays whether the control circuit capacitor,
255	Life alarm status display	0	(0 to 15)	main circuit capacitor, cooling fan, and each parts
255	Life didiffi status display	· ·	(0 to 13)	of the inrush current limit circuit has reached the
				life alarm output level or not. (Reading only)
	Inrush current limit circuit			Displays the deterioration degree of the inrush
256	life display	100%	(0 to 100%)	current limit circuit.
				(Reading only)
	Control circuit capacitor life			Displays the deterioration degree of the control
257		100%	(0 to 100%)	circuit capacitor.
	display			(Reading only)
				Displays the deterioration degree of the control
258	Main circuit capacitor life display	100%	(0 to 100%)	circuit capacitor.
230		100 /6		(Reading only)
				The value measured by <i>Pr. 259</i> is displayed.
				Setting "1" and turning the power supply off starts
	Main circuit capacitor life		0, 1	the measurement of the main circuit capacitor life.
259	•	0		When the Pr. 259 value is "3" after powering on
	measuring		(2, 3, 8, 9)	again, the measuring is completed.
				Writes deterioration degree in Pr. 258.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



(1) Life alarm display and signal output (Y90 signal, Pr. 255)

•Whether any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit has reached the life alarm output level or not can be checked by *Pr. 255 Life alarm status display* and life alarm signal (Y90).



Pr. 255 (decimal)	Bit (binary)	Inrush Current Suppression Circuit Life	Cooling Fan Life	Main Circuit Capacitor Life	Control Circuit Capacitor Life
15	1111	0	0	0	0
14	1110	0	0	0	×
13	1101	0	0	×	0
12	1100	0	0	×	×
11	1011	0	×	0	0
10	1010	0	×	0	×
9	1001	0	×	×	0
8	1000	0	×	×	×
7	0111	×	0	0	0
6	0110	×	0	0	×
5	0101	×	0	×	0
4	0100	×	0	×	×
3	0011	×	×	0	0
2	0010	×	×	0	×
1	0001	×	×	×	0
0	0000	×	×	×	×

O: With warnings, \times : Without warnings

- •The life alarm signal (Y90) turns on when any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit reaches the life alarm output level.
- •For the terminal used for the Y90 signal, set "90" (positive logic) or "190" (negative logic) to *Pr. 190 or Pr. 192 (output terminal function selection)*.



NOTE

• Changing the terminal assignment using *Pr. 190, Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

(2) Inrush current limit circuit life display (Pr. 256)

- •The life of the inrush current limit circuit (relay, contactor and inrush resistor) is displayed in Pr. 256.
- •The number of contact (relay, contactor, thyristor) ON times is counted, and it is counted down from 100% (1 million times) every 1%/10,000 times.

As soon as 10% (900,000 times) is reached, Pr. 255 bit 3 is turned on and also an alarm is output to the Y90 signal.

(3) Control circuit capacitor life display (Pr. 257)

- •The deterioration degree of the control circuit capacitor is displayed in Pr. 257 as a life.
- In the operating status, the control circuit capacitor life is calculated from the energization time and temperature, and is counted down from 100%.

As soon as the control circuit capacitor life falls below 10%, *Pr. 255* bit 0 is turned on and also an alarm is output to the Y90 signal.

(4) Main circuit capacitor life display (Pr. 258, Pr. 259)

- •The deterioration degree of the control circuit capacitor is displayed in Pr. 258 as a life.
- On the assumption that the main circuit capacitor capacitance at factory shipment is 100%, the capacitor life is displayed in *Pr. 258* every time measurement is made.

When the measured value falls to or below 85%, Pr. 255 bit 1 is turned on and also an alarm is output to the Y90 signal.

- Measure the capacitor capacity according to the following procedure and check the deterioration level of the capacitor capacity.
 - 1) Check that the motor is connected and at a stop.
 - 2) Set "1" (measuring start) in Pr. 259.
 - 3) Switch power off. The inverter applies DC voltage to the motor to measure the capacitor capacity while the inverter is off.
 - 4) After confirming that the LED of the operation panel is off, power on again.
 - 5) Check that "3" (measuring completion) is set in *Pr. 259*, read *Pr. 258*, and check the deterioration degree of the main circuit capacitor.

Pr. 259	Description	Remarks
0	No measurement	Initial value
1	Measurement start	Measurement starts when the
'	Weasurement start	power supply is switched off.
2	During measurement	
3	Measurement complete	Only displayed and cannot be
8	Forced end	set
9	Measurement error	

> REMARKS

- When the main circuit capacitor life is measured under the following conditions, "forced end" (Pr. 259 = "8") or "measuring error" (Pr. 259 = "9") occurs or it remains in "measuring start" (Pr. 259 = "1"). Therefore, do not measure in such case.
 - In addition, even when "measurement completion" (Pr. 259 = "3") is confirmed under the following conditions, normal measurement can not be done.
 - (a) FR-HC or FR-CV is connected.
 - (b) DC power supply is connected to the terminal + and -.
 - (c) The power supply switched on during measurement.
 - (d) The motor is not connected to the inverter.
 - (e) The motor is running (coasting)
 - (f) The motor capacity is two rank smaller as compared to the inverter capacity.
 - (g) The inverter is tripped or a fault occurred when power is off.
 - (h) The inverter output is shut off with the MRS signal.
 - (i) The start command is given while measuring.
 - (j) The parameter unit (FR-PU04/FR-PU07) is connected.
 - (k) Use terminal PC as power supply.
 - (I) I/O terminal of the control terminal block is on (continuity).
- Turning the power on during measuring before LED of the operation panel turns off, it may remain in "measuring" (*Pr. 259* = "2") status. In such case, carry out operation from step 2.



POINT

For the accurate life measuring of the main circuit capacitor, perform after more than 3 hrs passed since the turn off of the power as it is affected by the capacitor temperature.



Mhen measuring the main circuit capacitor capacity (*Pr. 259 Main circuit capacitor life measuring* = "1"), the DC voltage is applied to the motor for 1s at powering off. Never touch the motor terminal, etc. right after powering off to prevent an electric shock.



(5) Cooling fan life display

•The cooling fan speed of 50% or less is detected and "FN" is displayed on the operation panel and parameter unit (FR-PU04/FR-PU07). As an alarm display, Pr. 255 bit2 is turned on and also an alarm is output to the Y90 signal.



(I) REMARKS

• When the inverter is mounted with two or more cooling fans, the life of even one cooling fan is diagnosed.



• For replacement of each part, contact the nearest Mitsubishi FA center.

7

4.21.3 Maintenance timer alarm (Pr. 503, Pr. 504)


When the cumulative energization time of the inverter reaches the parameter set time, the maintenance timer output signal (Y95) is output.

(MT) is displayed on the operation panel.

This can be used as a guideline for the maintenance time of peripheral devices.

Parameter Number	Name	Initial Value	Setting Range	Description
503	Maintenance timer	0	0 (1 to 9998)	Displays the cumulative energization time of the inverter in 100h increments. (Reading only) Writing the setting of "0" clears the cumulative energization time.
504	Maintenance timer alarm output set time	9999	0 to 9998	Time taken until when the maintenance timer alarm output signal (Y95) is output. No function

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)



- The cumulative energization time of the inverter is stored into the EEPROM every hour and is displayed in *Pr. 503 Maintenance timer* in 100h increments. *Pr. 503* is clamped at 9998 (999800h).
- When the *Pr. 503* value reaches the time set to *Pr. 504 Maintenance timer alarm output set time* (100h increments), the maintenance timer alarm output signal (Y95) is output.
- For the termial used for the Y95 signal output, assign the function by setting "95" (positive logic) or "195" (negative logic) to *Pr. 190 or Pr. 192 (output terminal function selection)*.



NOTE

- The cumulative energization time is counted every hour. The energization time of less than 1h is not counted.
- Changing the terminal assignment using *Pr. 190, Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 190, Pr. 192 (output terminal function selection) 📭 Refer to page 114




4.21.4 Current average value monitor signal (Pr. 555 to Pr. 557)

The average value of the output current during constant speed operation and the maintenance timer value are output as a pulse to the current average value monitor signal (Y93).

The pulse width output to the I/O module of the programmable controller or the like can be used as a guideline due to abrasion of machines and elongation of belt and for aged deterioration of devices to know the maintenance time.


The current average value monitor signal (Y93) is output as pulse for 20s as 1 cycle and repeatedly output during constant speed operation.



Parameter Number	Name	Initial Value	Setting Range	Description
555	Current average time	1s	0.1 to 1.0s	Time taken to average the current during start pulse output (1s).
556	Data output mask time	0s	0.0 to 20.0s	Time for not obtaining (mask) transient state data.
557	Current average value monitor signal output reference current	Rated inverter current	0 to 500A	Reference (100%) for outputting the signal of the current average value.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.



- The pulse output of the current average value monitor signal (Y93) is shown above.
- For the terminal used for the Y93 signal output, assign the function by setting "93" (positive logic) or "193" (negative logic) to *Pr. 190 RUN terminal function selection*. The function can not be assigned to *Pr. 192 A,B,C terminal function selection*.
- 1) Setting of Pr. 556 Data output mask time

The output current is unstable (transient state) right after the operation is changed from the acceleration/deceleration state to the constant speed operation. Set the time for not obtaining (mask) transient state data in *Pr.* 556.

2) Setting of Pr. 555 Current average time

The average output current is calculated during Hi output of start pulse (1s). Set the time taken to average the current during start bit output in Pr. 555.

3) Setting of Pr.557 Current average value monitor signal output reference current


Set the reference (100%) for outputting the signal of the current average value. Obtain the time to output the signal from the following calculation.

$\frac{\text{Output current average value}}{\textit{Pr. 557} \, \text{setting}} \times \text{5s (Output current average value 100\%/5s)}$

Note that the output time range is 0.5 to 9s and the output time is either of the following values when the output current average value is the corresponding percentage of the Pr. 557 setting.

Less than 10% ... 0.5s, more than 180% ... 9s

Example) when Pr. 557 = 10A and the average value of output current is 15A As 15A/10A x 5s=7.5, the current average value monitor signal is output as low pulse shape for 7.5s.




4) Setting of Pr. 503 Maintenance timer

After the output current average value is output as low pulse shape, the maintenance timer value is output as high pulse shape. The output time of the maintenance timer value is obtained from the following calculation.


$$\frac{Pr. 503 \times 100}{40000h} \times 5s \quad \text{(Maintenance timer value 100\%/5s)}$$

Note that the output time range is 2 to 9s, and it is 2s when the Pr. 503 setting is less than 16000h and 9s when exceeds 72000h.



REMARKS

- Mask of data output and sampling of output current are not performed during acceleration/deceleration.
- When the speed is changed to acceleration/deceleration from constant speed during start pulse output, the data is judged as
 invalid, the start pulse is output as high pulse shape for 3.5s, and the end signal is output as low pulse shape for 16.5s.
 The signal is output for at least 1 cycle even when acceleration/deceleration state continues after the start pulse output is
 completed.



- When the output current value (inverter output current monitor) is 0A on completion of the 1 cycle signal output, the signal is not
 output until the speed becomes constant next time
- The current average value monitor signal (Y93) is output as low pulse shape for 20s (without data output) under the following condition.
 - (a) When the motor is in the acceleration/deceleration state on completion of the 1 cycle signal output
 - (b) When 1-cycle signal output was ended during restart operation with the setting of automatic restart after instantaneous power failure (*Pr.* 57 ≠ "9999")
 - (c) When restart operation was being performed at the point of data output mask end with the setting of automatic restart after instantaneous power failure (*Pr.* 57 ≠ "9999")



NOTE

• Changing the terminal assignment using *Pr. 190, Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



Parameters referred to

Pr. 57 Restart coasting time Refer to page 131

Pr. 190, Pr. 192 (output terminal function selection) Refer to page 114

Pr. 503 Maintenance timer Refer to page 230



4.21.5 Free parameter (Pr. 888, Pr. 889)

You can input any number within the setting range 0 to 9999.

For example, the number can be used:

- As a unit number when multiple units are used.
- As a pattern number for each operation application when multiple units are used.
- As the year and month of introduction or inspection.

Parameter Number	Name	Initial Value	Setting Range	Description
888	Free parameter 1	9999	0 to 9999	Any values can be set. Data is held even
889	Free parameter 2	9999	0 to 9999	if the inverter power is turned off.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr.77 Parameter write selection.



Pr. 888 and Pr. 889 do not influence the inverter operation.

4.22 Setting from the parameter unit and operation panel

Purpose	Parameter	that should be Set	Refer to Page
Selection of rotation direction by (RUN) of the operation panel	RUN key rotation direction selection	Pr. 40	234
Switch the display language of the parameter unit	PU display language selection	Pr. 145	234
Use the setting dial of the operation panel like a potentiometer for frequency setting. Key lock of operation panel	Operation panel operation selection	Pr. 161	235
Change the magnitude of change of frequency setting by the setting dial of the operation panel	Magnitude of frequency change setting	Pr. 295	237
Control of the parameter unit buzzer	PU buzzer control	Pr. 990	238
Adjust LCD contrast of the parameter unit	PU contrast adjustment	Pr. 991	238

4.22.1 RUN key rotation direction selection (Pr. 40)

Used to choose the direction of rotation by operating (RUN) of the operation panel.

Parameter Number	Name	Initial Value	Setting Range	Description
40	RUN key rotation direction	0	0	Forward rotation
	selection		1	Reverse rotation

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

4.22.2 PU display language selection(Pr.145)

You can switch the display language of the parameter unit (FR-PU04/FR-PU07) to another.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Japanese
	PU display language selection	1	1	English
			2	German
145			3	French
			4	Spanish
			5	Italian
			6	Swedish
			7	Finnish

The above parameters can be set when *Pr. 160 Extended function display selection* = "0". (*Refer to page 157*)



4.22.3 Operation panel frequency setting/key lock operation selection (Pr. 161)

The setting dial of the operation panel can be used for setting like a potentiometer. The key operation of the operation panel can be disabled.

Parameter Number	Name	Initial Value	Setting Range	Description	
		0	0	Setting dial frequency setting mode	Key lock mode invalid
161	Frequency setting/key lock operation selection		1	Setting dial potentiometer mode	Rey lock mode invalid
			10	Setting dial frequency setting mode	Key lock mode valid
			11	Setting dial potentiometer mode	Rey lock mode valid

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Using the setting dial like a potentiometer to set the frequency. Operation example Changing the frequency from 0Hz to 50Hz during operation Operation -Display -1. Screen at powering on The monitor display appears. PU indication is lit. 2. Press $\frac{PU}{FXT}$ to choose the PU operation mode. PRM indication is lit. 3. Press (MODE) to choose the parameter setting MODE mode. (The parameter number read previously 4. Turn until P. 150 (Pr. 160) appears. **5**. Press(SET) to read the currently set value. " 9999 "(initial value) appears. 6. Turn (💢) to change it to the set value "[]". 7. Press(SET) to set. (SET) Flicker Parameter setting complete!! 8. Change *Pr. 161* to the setting value of " \ " (SET) in the similar manner. (Refer to step 4 to 7.) Flicker Parameter setting complete!! 9. Mode/monitor check (MODE Press (MODE) twice to choose the monitor/ frequency monitor. 10.Press (RUN) to start the inverter.

11. Turn (until " 5 [] [] " appears.

You need not press (SET)

The flickering frequency is the set frequency.

The frequency flickers for about 5s.



> REMARKS

- If the display changes from flickering "50.00" to "0.00", the setting of Pr. 161 Frequency setting/key lock operation selection may not
- Independently of whether the inverter is running or at a stop, the frequency can be set by merely turning the dial.
 When the frequency is changed, it will be stored in EEPROM as the set frequency after 10s.

(2) Disable the setting dial and key operation of the operation panel (Press [MODE] long (2s))

- Operation using the setting dial and key of the operation panel can be made invalid to prevent parameter change, and unexpected start or frequency setting.
- •Set "10 or 11" in Pr. 161, then press (MODE) for 2s to make the setting dial and key operation invalid.
- •When the setting dial and key operation is made invalid, **HIII** appears on the operation panel. When the setting dial and key operation is invalid, **\(\)** appears if the setting dial or key operation is performed. (When the setting dial or key operation is not performed for 2s, the monitor display appears.)
- •To make the setting dial and key operation valid again, press (MODE) for 2s.

• REMARKS

Even if the setting dial and key operation are disabled, the monitor display and (STOP) are valid.





• Release the operation lock to release the PU stop by key operation.



4.22.4 Magnitude of frequency change setting (Pr. 295)

When setting the set frequency with the setting dial, frequency changes in 0.01Hz increments in the initial status. Setting this parameter increases the magnitude of frequency which changes according to the rotated amount of the setting dial, improving operability.


Parameter Number	Name	Initial Value	Setting Range	Description
			0	Function invalid
295	Magnitude of frequency change setting	0	0.01	The minimum varying width when the set frequency is changed by the setting dial can
			0.10	
			1.00	be set.
			10.00	be set.

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

(1) Basic operation

When a value other than "0" is set in *Pr. 295*, the minimum varying width when the set frequency is changed by the setting dial can be set

For example, when "1.00Hz" is set in Pr. 295, one click (one dial gauge) of the setting dial changes the frequency in increments of 1.00Hz \rightarrow 2.00Hz \rightarrow 3.00Hz.





^{*}One rotation of the setting dial equals to 24 clicks (24 dial gauses).



REMARKS

- When machine speed display is selected with *Pr. 37*, the minimum increments of the magnitude of change is determined by *Pr.295* as well. Note that the setting value may differ as speed setting changes the set machine speed and converts it to the speed dislay again.
- When the set frequency (speed) is 100 or more, frequency is displayed in 0.1 increments. Therefore, the minimum varying width is 0.1 even when *Pr.* 295 < 0.1.
- When the machine speed setting is 1000 or more, frequency is displayed in 1 increments. Therefore, the minimum varying width is 1 even when *Pr.* 295 < 1.



NOTE

- For Pr. 295, unit is not displayed.
- This parameter is valid only in the set frequency mode. When other frequency-related parameters are set, it is not activated.
 - When 10 is set, frequency setting changes in 10Hz increments. Note the excess speed. (in potentiometer mode)

4.22.5 Buzzer control (Pr. 990)

You can make the buzzer "beep" when you press the key of the parameter unit (FR-PU04/FR-PU07).

Parameter Number	Name	Initial Value	Setting Range	Description
990	PU buzzer control	1	0	Without buzzer
990	FU Duzzei Control	!	1	With buzzer

The above parameters can be set when Pr. 160 Extended function display selection = "0". (Refer to page 157)

4.22.6 PU contrast adjustment (Pr. 991)

Contrast adjustment of the LCD of the parameter unit (FR-PU04/FR-PU07) can be performed. Decreasing the setting value makes contrast light.

Parameter Number	Name	Initial Value	Setting Range	Description
991	PU contrast adjustment	58	0 to 63	0: Light ↓ 63: Dark

The above parameter is displayed as simple mode parameter only when the parameter unit FR-PU04/FR-PU07 is connected.

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.




4.23 Parameter clear/ All parameter clear



POINT

- Set "1" in *Pr.CL Parameter clear, ALLC all parameter clear* to initialize all parameters. (Parameters are not cleared when "1" is set in *Pr. 77Parameter write selection*.)
- Refer to the extended parameter list on page 52 for parameters cleared with this operation.




Flicker ··· Parameter setting complete!!

- Turn to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.

Setting	Description
0	Not executed.
	Return parameters to the initial values. (Parameter clear returns all parameters except calibration
1	parameters, terminal function selection parameters to the initial values. Refer to the parameter list on
	page 52 for availability of parameter clear and all parameter clear.





The inverter is not in the PU operation mode.

Is PU connector used?

- 1. Press $\frac{PU}{EXT}$. [PU] is lit and the monitor (4 digit LED) displays "1". (When Pr. 79 = "0" (initial value))
- 2. Carry out operation from step 6 again.

4.24 Initial value change list

Displays and sets the parameters changed from the initial value.

Operation Display -1. Screen at powering on The monitor display appears. PU indication is lit. 2. Press $\frac{PU}{FXT}$ to choose the PU operation mode. PRM indication is lit 3. Press (MODE) to choose the parameter setting mode. (The parameter number read previously appears.) 4. Turn until Pr.[H appears. It may take several seconds 5. Pressing (SET) changes to the initial value for creating the initial value change list screen. change list. "P---" flickers while creating the list. 6. Turning displays the parameter number changed • Press (SET) to read the currently set value. and press (SET) to change the (SET setting (refer to step 6 and 7 on page 51) Flicker Parameter setting complete!! •Turn (to read another parameter. •The display returns to ₽ - - - after all parameters are displayed. 7. Pressing (SET) in P - - status returns to

NOTE



- Calibration parameters (C1 (Pr. 901) to C7 (Pr. 905)) are not displayed even they are changed from the initial settings.
- Only simple mode parameter is displayed when simple mode is set ($Pr. 16\theta$ = "9999" (initial value))
- Pr. 160 is displayed independently of whether the setting value is changed or not.

(SET) displays the change list again.

• When parameter setting is changed after creating the initial value change list, the setting will be reflected to the initial value change list next time.

Parameters referred to

the parameter setting mode.


• Pressing

Pr. 160 Extended function display selection Refer to page 157
C1 (Pr. 901) AM terminal calibration Refer to page 129
C2(Pr. 902) to C7(Pr. 905) (Frequency setting bias/gain parameter) Refer to page 148

Turning sets other parameters.

4.25 Check and clear of the faults history

(1) Check for the faults history



(2) Clearing procedure



POINT

• Set "1" in *Er.CL Fault history clear* to clear the faults history. Parameters are not cleared when "1" is set in *Pr. 77 Parameter write selection*.

Operation 1. Screen at powering on The monitor display appears. 2. Press MODE to choose the parameter setting mode. 3. Turn until Er.CL (faults history clear) appears. 4. Press (SET) to read the currently set value. "0" (initial value) appears. 5. Turn to change it to the set value " 1".

Flicker...Faults history clear complete!!

- Turn to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.



6. Press (SET) to set.

Parameters referred to

Pr. 77 Parameter write selection Refer to page 156

5 TROUBLESHOOTING

This chapter provides the "TROUBLESHOOTING" of this product.

Always read the instructions before using the equipment

5.1	Reset method of protective function	244
	List of fault or alarm indications	
5.3	Causes and corrective actions	246
5.4	Correspondences between digital and actual characters	254
5.5	Check first when you have some troubles	255

2

3

Ļ

5

6

7

Reset method of protective function

When a fault occurs in the inverter, the inverter trips and the PU display automatically changes to any of the following fault or alarm indications.

If the fault does not correspond to any of the following faults or if you have any other problem, please contact your sales representative.

- Retention of fault output signal...When the magnetic contactor (MC) provided on the input side of the inverter is opened when a fault occurs, the inverter's control power will be lost and the fault output will not be
- Fault or alarm indicationWhen a fault or alarm occurs, the operation panel display automatically switches to the fault or alarm indication.
- Resetting methodWhen a fault occurs, the inverter output is kept stopped. Unless reset, therefore, the inverter cannot restart. (Refer to page 244)
- When any fault occurs, take the appropriate corrective action, then reset the inverter, and resume operation. Not doing so may lead to the inverter fault and damage.

Inverter fault or alarm indications are roughly divided as below.

- (1) Error message
 - A message regarding operational fault and setting fault by the operation panel and parameter unit (FR-PU04 /FR-PU07) is displayed. The inverter does not trip.
- (2) Warnings
 - The inverter does not trip even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.
- (3) Alarm
 - The inverter does not trip. You can also output an alarm signal by making parameter setting.
- - When a fault occurs, the inverter trips and a fault signal is output.

5.1 Reset method of protective function

(1) Resetting the inverter

The inverter can be reset by performing any of the following operations. Note that the internal thermal integrated value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the inverter. Recover about 1s after reset is cancelled.


Operation 1: Using the operation panel, press (STOP)



to reset the inverter.


(This may only be performed when a fault occurs (Refer to page 249 for fault.))

Operation 2: Switch power off once, then switch it on again.



Operation 3: Turn on the reset signal (RES) for more than 0.1s. (If the RES signal is kept on, "Err." appears (flickers) to indicate that the inverter is in a reset status.)







5.2 List of fault or alarm indications

Operation Panel Indication			Name	Refer to Page
	E	E	Faults history	241
ge	HOLd	HOLD	Operation panel lock	246
ıessa	LOCA	LOCd	Password locked	246
Error message	Er I to Er 4	Er1 to 4	Parameter write error	246
	Err.	Err.	Inverter reset	247
	0L	OL	Stall prevention (overcurrent)	247
	οL	oL	Stall prevention (overvoltage)	247
sbu	rb	RB	Regenerative brake prealarm	248
Warnings	ſΗ	TH PS	Electronic thermal relay function prealarm	248
	25		PU stop	248
	ПГ МТ	MT	Maintenance signal output	248
	Uo	UV	Undervoltage	248
Alarm	۶n	FN	Fan fault	249
	E.DC 1	E.OC1	Overcurrent trip during acceleration	249
	€.00.2	E.OC2	Overcurrent trip during constant speed	249
	E.003	E.OC3	Overcurrent trip during deceleration or stop	249
	8.0 ₀ 1	E.OV1	Regenerative overvoltage trip during acceleration	250
ıļţ	S.002	E.OV2	Regenerative overvoltage trip during constant speed	250
Fau	E.O u 3	E.OV3	Regenerative overvoltage trip during deceleration or stop	250
	ЕЛНГ	E.THT	Inverter overload trip (electronic thermal relay function)	250
	E.CHN	E.THM	Motor overload trip(electronic thermal relay function)	251
	8.81 n	E.FIN	Fin overheat	251

Operation Panel Indication			Name	Refer to Page
	ELLF	E.ILF *	Input phase loss	251
	E.OL F	E.OLT	Stall prevention	251
	Е. БЕ	E. BE	Brake transistor alarm detection	251
	E. GF	E.GF	Output side earth (ground) fault overcurrent at start	252
	E. LF	E.LF	Output phase loss	252
	<i>E.OHI</i> E.	E.OHT	External thermal relay operation	252
ult	E.P.C.C	E.PTC*	PTC thermistor operation	252
Fault	E. PE	E.PE	Parameter storage device fault	252
	E.PUE	E.PUE	PU disconnection	253
	E E.F	E.RET	Retry count excess	253
	E.C P U	E.CPU	CPU fault	253
	8.0 d 0	E.CDO*	Output current detection value exceeded	253
	8.1 OH	E.IOH *	Inrush current limit circuit fault	253
	E.R.1 E	E.AIE *	Analog input fault	253

 $[\]ast~$ If a fault occurs when using with the FR-PU04, "Fault 14" is displayed on the FR-PU04.

5.3 Causes and corrective actions

(1) Error message

A message regarding operational troubles is displayed. Output is not shutoff.

Operation panel indication	HOLD HOLD			
Name	Operation par	el lock		
Description	Operation lock mode is set. Operation other than (RESET) is made invalid. (Refer to page 236)			
Check point				
Corrective action	Press MODE for	2s to release lock.		

Operation panel indication	LOCd	LOCA			
Name	Password locked				
Description	Password function is active. Display and setting of parameter is restricted.				
Check point					
Corrective action	Enter the password in <i>Pr. 297 Password lock/unlock</i> to unlock the password function before operating. (<i>Refer to page 158</i>)				

Operation panel	Er1	C_ /					
indication	E11	ברי					
Name	Write disable error						
Description	write. 2. Frequency	ted to make parameter setting when <i>Pr. 77 Parameter write selection</i> has been set to disable parameter jump setting range overlapped. I inverter cannot make normal communication.					
Check point	 Check the setting of <i>Pr. 77 Parameter write selection. (Refer to page 156).</i> Check the settings of <i>Pr. 31 to Pr. 36 (frequency jump). (Refer to page 79)</i> Check the connection of the PU and inverter. 						

Operation panel indication	Er2	ξ - c'					
Name	Write error du	ring operation					
Description	When parame	ter write was performed during operation with a value other than "2" (writing is enabled independently					
Description	of operation status in any operation mode) is set in Pr. 77 and the STF (STR) is on.						
Check point	1. Check the Pr. 77 setting. (Refer to page 156).						
Check point	2. Check that the inverter is not operating.						
Corrective action	1. Set "2" in <i>Pr</i> : 77.						
Corrective action	2. After stoppi	ng operation, make parameter setting.					

Operation panel indication	Er3	Er3		
Name	Calibration error			
Description Analog input bias and gain calibration values are too close.				
Check point	Check the set	Check the settings of C3, C4, C6 and C7 (calibration functions). (Refer to page 148).		

Operation panel Er4		E-4				
Name	Mode designa	tion error				
Description	You attempted to make parameter setting in the NET operation mode when Pr. 77 is not 2.					
Chack point	Check that operation mode is PU operation mode.					
Check point	2. Check the Pr. 77 setting. (Refer to page 156).					
Corrective action	1. After setting the operation mode to the "PU operation mode", make parameter setting. (Refer to page 160)					
Corrective action	2. After setting "2" in <i>Pr. 77</i> , make parameter setting.					



Operation panel indication	Err.	Err.			
Name	Inverter reset				
Description	Executing reset using RES signal, or reset command from communication or PU				
Description	Displays at	powering off.			
Corrective action	action • Turn off the reset command				

(2) Warnings

When a warning occurs, the output is not shut off.

Operation panel	01	ū	FR-PU04					
indication	OL	0L	FR-PU07	OL				
Name	Stall prevention	n (overcurrent)						
	During acceleration	prevention operation decreases to prevention	When the output current of the inverter exceeds the stall prevention operation level (<i>Pr. 22 Stall prevention operation level</i> , etc.), this function stops the increase in frequency until the overload current decreases to prevent the inverter from resulting in overcurrent trip. When the overload current has reduced below stall prevention operation level, this function increases the frequency again.					
Description	During constant-speed operation	prevention operation prevent the inverte	When the output current of the inverter exceeds the stall prevention operation level (<i>Pr. 22 Stall prevention operation level</i> , etc.), this function reduces frequency until the overload current decreases to prevent the inverter from resulting in overcurrent trip. When the overload current has reduced below stall prevention operation level, this function increases the frequency up to the set value.					
	During deceleration	prevention operation decreases to prevention	When the output current of the inverter exceeds the stall prevention operation level (<i>Pr. 22 Stall prevention operation level</i> , etc.), this function stops the decrease in frequency until the overload current decreases to prevent the inverter from resulting in overcurrent trip. When the overload current has decreased below stall prevention operation level, this function decreases the frequency again.					
Check point	 Check that the <i>Pr. 0 Torque boost</i> setting is not too large. Check that the <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i> settings are not too small. Check that the load is not too heavy. Are there any failure in peripheral devices? Check that the <i>Pr. 13 Starting frequency</i> is not too large. Check that the <i>Pr. 22 Stall prevention operation level</i> is appropriate 			B Deceleration time settings are not too small. too large.				
Corrective action	 Increase or decrease the <i>Pr. 0 Torque boost</i> setting 1% by 1% and check the motor status. (<i>Refer to page 69</i>) Set a larger value in <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i>. (<i>Refer to page 91</i>) Reduce the load weight. Try general-purpose magnetic flux vector control. 							

Operation panel	oL		FR-PU04	
indication		O L	FR-PU07	oL
Name	Stall prevention	on (overvoltage)		
Description	During deceleration	 If the regenerative energy of the motor becomes excessive to exceed the regenerative energy consumption capability, this function stops the decrease in frequency to prevent overvoltage trip. As soon as the regenerative energy has reduced, deceleration resumes. If the regenerative energy of the motor becomes excessive when regeneration avoidance function is selected (<i>Pr.</i> 882 = 1), this function increases the speed to prevent overvoltage trip. (<i>Refer to page 223</i>). 		
Check point		sudden speed reduction. t regeneration avoidance function (<i>Pr. 882, Pr. 883, Pr. 885, Pr. 886</i>) is used. (<i>Refer to page 223</i>).		
Corrective action	The deceleration time may change. Increase the deceleration time using <i>Pr. 8 Deceleration time</i> .			

Operation panel indication	PS	<i>P</i> S	FR-PU04 FR-PU07	PS	
Name	PU stop				
Description	Stop with STOP of the PU is set in <i>Pr. 75 Reset selection/disconnected PU detection/PU stop selection</i> . (For <i>Pr. 75 refer to page 153</i> .)				
Check point	Check for a stop made by pressing (STOP) of the operation panel.				
Corrective action	Turn the start signal off and release with $\frac{PU}{EXT}$.				

Operation panel	DD.		FR-PU04	DD.			
indication	RB	70	FR-PU07	RB			
Name	Regenerative brake prealarm						
	Appears if the regenerative brake duty reaches or exceeds 85% of the Pr. 70 Special regenerative brake duty value.						
	When the setting of Pr. 70 Special regenerative brake duty is the initial value (Pr. 70 = "0"), this warning does not occur. If						
Decembelon	the regenerative brake duty reaches 100%, a regenerative overvoltage (E. OV_) occurs.						
Description	The RBP signal can be simultaneously output with the [RB] display. For the terminal used for the RBP signal output,						
	assign the function by setting "7 (positive logic) or 107 (negative logic)" in Pr. 190 or Pr. 192 (output terminal function						
	selection). (Refer to page 114).						
Check point 1. Check that the brake resistor duty is not high.							
Check point	2. Check that the <i>Pr. 30 Regenerative function selection</i> and <i>Pr. 70 Special regenerative brake duty</i> settings are correct.						
Corrective action 1. Increase the deceleration time.							
Concente action	2. Check that the <i>Pr. 30 Regenerative function selection</i> and <i>Pr. 70 Special regenerative brake duty</i> settings.						

Operation panel	TU	ſH	FR-PU04	TH		
indication	TH	1 17	FR-PU07	ТН		
Name	Electronic thermal relay function prealarm					
	Appears if the cumulative value of the Pr. 9 Electronic thermal O/L relay reaches or exceeds 85% of the preset level. If					
	it reaches 100% of the Pr. 9 Electronic thermal O/L relay setting, a motor overload trip (E. THM) occurs.					
Description	The THP signal can be simultaneously output with the [TH] display. For the terminal used for THP signal output,					
	assign the function by setting "8 (positive logic) or 108 (negative logic)" in Pr. 190 or Pr. 192 (output terminal function					
	selection). (Refer to page 114).					
Check point	1. Check for large load or sudden acceleration.					
Check point	2. Is the Pr. 9 Electronic thermal O/L relay setting is appropriate? (Refer to page 95)					
Corrective action	Reduce the load and frequency of operation.					
Corrective action	2. Set an appropriate value in Pr. 9 Electronic thermal O/L relay. (Refer to page 95)					

Operation panel	panel	ΠΓ	FR-PU04			
indication	IVI I	111	FR-PU07	MT		
Name	Maintenance signal output					
	Indicates that the cumulative energization time of the inverter has reached a given time.					
Description	When the setting of Pr. 504 Maintenance timer alarm output set time is the initial value (Pr. 504 = "9999"), this warning					
	does not occur.					
Chack point	The Pr. 503 Maintenance timer setting is larger than the Pr. 504 Maintenance timer alarm output set time setting. (Refer to					
Check point	page 230).					
Corrective action	Setting "0" in Pr. 503 Maintenance timer erases the signal.					

Operation panel	UV	11.	FR-PU04		
indication	UV		FR-PU07		
Name	Undervoltage				
Description	If the power supply voltage of the inverter decreases, the control circuit will not perform normal functions. In addition, the motor torque will be insufficient and/or heat generation will increase. To prevent this, if the power supply voltage decreases below about 115VAC (230VAC for 400V class), this function stops the inverter output and displays !!u . An alarm is reset when the voltage returns to normal.				
Check point	Check that the power supply voltage is normal.				
Corrective action	Check the power supply system equipment such as power supply.				



(3) Alarm

When an alarm occurs, the output is not shut off. You can also output an alarm signal by making parameter setting. (Set "98" in *Pr. 190 or Pr. 192 (output terminal function selection)*. *Refer to page 114*).

Operation panel	FN		FR-PU04	FN				
indication	FIN	7 7	FR-PU07	FN				
Name	Fan fault	Fan fault						
Description	For the inverter that contains a cooling fan, F_{\Box} appears on the operation panel when the cooling fan stops due to an alarm or different operation from the setting of <i>Pr. 244 Cooling fan operation selection</i> .							
Check point	Check the cooling fan for an alarm.							
Corrective action	Check for fan	alarm. Please conta	act your sales	representative.				

(4) Fault

When a fault occurs, the inverter trips and a fault signal is output.

Operation panel	E.OC1	8.00	,	FR-PU04	OC During Acc		
indication	E.OC1	[.U.L	1	FR-PU07	OC Burning Acc		
Name	Overcurrent tr	ip during acce	eleratio	on			
Description		When the inverter output current reaches or exceeds approximately 200% of the rated current during acceleration, the protective circuit is activated and the inverter trips.					
Check point	 Check for sudden acceleration. Check that the downward acceleration time is not long in vertical lift application. Check for output short-circuit/ground fault. Check that stall prevention operation is appropriate. Check that regeneration is not performed frequently. (Check that the output voltage becomes larger than the V/F reference value at regeneration and overcurrent occurs due to the high voltage.) 						
Corrective action	Increase the acceleration time. (Shorten the downward acceleration time in vertical lift application. When "E.OC1" is always lit at starting, disconnect the motor once and start the inverter. If "E.OC1" is still lit, contact your sales representative.						

Operation panel indication	E.OC2	5.00.3	FR-PU04 FR-PU07	Stedy Spd OC					
	O								
Name	Overcurrent tr	p during constant sp	peed						
Description	When the inve	rter output current re	eaches or exc	eeds approximately 200% of the rated current during constant speed					
Description	operation, the protective circuit is activated and the inverter trips.								
	1. Check for sudden load change.								
Check point	2. Check for output short-circuit/ground fault.								
	3. Check that stall prevention operation is appropriate.								
	1. Keep load stable.								
Corrective action	2. Check the v	2. Check the wiring to make sure that output short circuit/ground fault does not occur.							
	3. Perform sta	3. Perform stall prevention operation appropriately. (<i>Refer to page 74</i>).							

Operation panel indication	E.OC3	E.003	FR-PU04 FR-PU07	OC During Dec				
Name	Overcurrent tr	Overcurrent trip during deceleration or stop						
Description		When the inverter output current reaches or exceeds approximately 200% of the rated inverter current during deceleration (other than acceleration or constant speed), the protective circuit is activated and the inverter trips.						
Check point	1. Check for sudden speed reduction. 2. Check for output short-circuit/ground fault. 3. Check for too fast operation of the motor's mechanical brake. 4. Check that stall prevention operation is appropriate.							
Corrective action	1. Increase the deceleration time. 2. Check the wiring to make sure that output short circuit/ground fault does not occur. 3. Check the mechanical brake operation. 4. Perform stall prevention operation appropriately. (<i>Refer to page 74</i>).							

Operation panel	E.OV1	600	1	FR-PU04	OV During Acc			
indication	E.0V1	נו	1	FR-PU07	OV During Acc			
Name	Regenerative	Regenerative overvoltage trip during acceleration						
		If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value,						
Description	the protective circuit is activated and the inverter trips. The circuit may also be activated by a surge voltage produce							
	in the power supply system.							
Check point	1. Check for too slow acceleration. (e.g. during downward acceleration in vertical lift load)							
Check point	2. Check that the <i>Pr. 22 Stall prevention operation level</i> is not lower than the no load current.							
	1. • Decrease the acceleration time.							
Corrective action	 Check the 	• Check that regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (Refer to page 223).						
	2. Set a value	larger than th	e no lo	oad current in	Pr. 22 Stall prevention operation level.			

Operation panel	E.OV2	8.002	FR-PU04	Stedy Spd OV				
indication	E.OV2	C.UUC	FR-PU07	Stedy Spd OV				
Name	Regenerative	overvoltage trip	during constant	speed				
	If regenerative	e energy causes	the inverter's inte	ernal main circuit DC voltage to reach or exceed the specified value,				
Description	the protective	circuit is activate	ed to stop the inv	erter output. The circuit may also be activated by a surge voltage				
	produced in the power supply system.							
Check point	1. Check for s	Check for sudden load change.						
Check point	2. Check that the Pr. 22 Stall prevention operation level is not lower than the no load current.							
	1. • Keep load stable.							
• Check that regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (Refer to page								
Corrective action	 Use the b 	Use the brake resistor, brake unit or power regeneration common converter (FR-CV) as required.						
	2. Set a value	larger than the r	no load current in	Pr. 22 Stall prevention operation level.				

Operation panel	E.OV3	8.003	FR-PU04	OV During Dec				
indication	E.0V3	C.UUJ	FR-PU07					
Name	Regenerative	Regenerative overvoltage trip during deceleration or stop						
Description	If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.							
Check point	Check for sudden speed reduction.							
Corrective action	Longer theUse regene	brake cycle. ration avoidance fui	`nction <i>(Pr. 882,</i>	leration time which matches the moment of inertia of the load) Pr. 883, Pr. 885, Pr. 886). (Refer to page 223). egeneration common converter (FR-CV) as required.				

Operation panel	E.THT	E.F.H.F	FR-PU04	Inc. Oceanand				
indication	E.1H1	<u> </u>	FR-PU07	Inv. Overload				
Name	Inverter overlo	oad trip (electronic t	thermal relay fu	unction)				
	If the tempera	ture of the output tr	ansistor eleme	nt exceeds the protection level under the condition that a current not				
Description	less than the r	ated inverter curre	nt flows and ov	ercurrent trip does not occur (200% or less), the electronic thermal				
	relay activates	to stop the inverte	er output. (Over	load capacity 150% 60s, 200% 0.5s)				
	1. Check that	acceleration/decele	eration time is r	not too short.				
	2. Check that torque boost setting is not too large (small).							
Check point	3. Check that load pattern selection setting is appropriate for the load pattern of the using machine.							
	4. Check the motor for use under overload.							
	5. Check for too high surrounding air temperature.							
	1. Increase ac	celeration/decelera	ition time.					
	2. Adjust the to	2. Adjust the torque boost setting.						
Corrective action	3. Set the load	3. Set the load pattern selection setting according to the load pattern of the using machine.						
	4. Reduce the	load weight.						
	5. Set the surr	ounding air temper	ature to within	the specifications.				



Operation panel indication	E.THM	E.CHO	FR-PU04	Motor Ovrload				
Name	Motor overloa	Motor overload trip (electronic thermal relay function) *1						
Description	The electronic thermal relay function in the inverter detects motor overheat due to overload or reduced cooling capability during constant-speed operation and pre-alarm (TH display) is output when the integrated value reaches 85% of the <i>Pr. 9 Electronic thermal O/L relay</i> setting and the protection circuit is activated to stop the inverter output when the integrated value reaches the specified value. When running a special motor such as a multi-pole motor or multiple motors, provide a thermal relay on the inverter output side since such motor(s) cannot be protected by the electronic thermal relay function.							
Check point	 Check the motor for use under overload. Check that the setting of <i>Pr. 71 Applied motor</i> for motor selection is correct. (<i>Refer to page 98</i>). Check that stall prevention operation setting is correct. 							
Corrective action		ant-torque motor, se		-torque motor in <i>Pr. 71 Applied motor</i> . s correct. (<i>Refer to page 74</i>).				

Resetting the inverter initializes the internal thermal integrated data of the electronic thermal relay function.

Operation panel indication	E.FIN	E.F!	n	FR-PU04 FR-PU07	H/Sink O/Temp	
Name	Fin overheat	<u> </u>		Н		
Description	If the heatsink overheats, the temperature sensor is actuated and the inverter trips. The FIN signal can be output when the temperature becomes approximately 85% of the heatsink overheat protection operation temperature. For the terminal used for the FIN signal output, assign the function by setting "26 (positive logic) or 126 (negative logic)" in <i>Pr. 190 or Pr. 192 (output terminal function selection)</i> . (<i>Refer to page 114</i>).					
Check point	 Check for too high surrounding air temperature. Check for heatsink clogging. Check that the cooling fan is not stopped (Check that Fn is not displayed on the operation panel). 					
Corrective action	 Set the surr Clean the h Replace the 	eatsink.	empera	ature to within	the specifications.	

Operation panel		ELLE	FR-PU04	Fault 14		
indication	E.ILF		FR-PU07	Input phase loss		
Name	Input phase lo	SS *				
Description	This fault is output when function valid setting (=1) is set in <i>Pr. 872 Input phase loss protection selection</i> and one phase of the three phase power input is lost. (<i>Refer to page 141</i>). It may function if phase-to-phase voltage of the three-phase power input becomes largely unbalanced.					
Check point	 Check for a break in the cable for the three-phase power supply input. Check that phase-to-phase voltage of the three-phase power input is not largely unbalanced. 					
Corrective action	 Wire the cables properly. Repair a break portion in the cable. Check the <i>Pr. 872 Input phase loss protection selection</i> setting. Set <i>Pr. 872</i> = "0" (without input phase loss protection) when three-phase input voltage is largely unbalanced. 					

Available only for three-phase power input specification model.

Operation panel indication	E.OLT	E.DL [FR-PU04 FR-PU07	Stll Prev STP (OL shown during stall prevention operation)				
Name	Stall preventio	Stall prevention						
Description	•	If the output frequency has fallen to 1Hz by stall prevention operation and remains for 3s, a fault (E.OLT) appears and trips the inverter. OL appears while stall prevention is being activated.						
Check point	Check the motor for use under overload. (Refer to page 75).							
Corrective action	Reduce the load weight. Check the Pr. 22 Stall prevention operation level setting.							

Operation panel indication	E.BE	E.	<i>68</i>	FR-PU04 FR-PU07	Br. Cct. Fault			
Name	Brake transist	Brake transistor alarm detection						
Description	transistor alar	When a brake transistor alarm has occurred due to the large regenerative energy from the motor etc., the brake transistor alarm is detected and the inverter trips. In this case, the inverter must be powered off immediately.						
Check point	 Reduce the load inertia. Check that the frequency of using the brake is proper. Check that the brake resistor selected is correct. 							
Corrective action	Replace the in	Replace the inverter.						

Operation panel	E.GF		GF	FR-PU04	Ground Fault		
indication	E.GF	<u></u>		FR-PU07 Ground Fault	Ground Faunt		
Name	Output side ea	Output side earth (ground) fault overcurrent at start					
Description	the inverter's	The inverter trips if an earth (ground) fault overcurrent flows at start due to an earth (ground) fault that occurred on the inverter's output side (load side). Whether this protective function is used or not is set with <i>Pr. 249 Earth (ground) fault detection at start</i> .					
Check point	Check for a ground fault in the motor and connection cable.						
Corrective action	Remedy the ground fault portion.						

Operation panel	E.LF	Œ	LF	FR-PU04	E.LF			
indication	E.LF	L .	<u>_</u> '	FR-PU07	ELLF			
Name	Output phase	Output phase loss						
Description	This function s	This function stops the inverter output if one of the three phases (U, V, W) on the inverter's output side (load side) is						
Description	lost. Whether the protective function is used or not is set with Pr. 251 Output phase loss protection selection.							
Check point	 Check the v 	Check the wiring. (Check that the motor is normal.)						
Check point	Check that the capacity of the motor used is not smaller than that of the inverter.							
Corrective action	Wire the cables properly.							
Corrective action	Check the I	Pr. 251 O	utput phase l	se loss protection selection settting.				

Operation panel indication	E.OHT	E.0HF	FR-PU04 FR-PU07	OH Fault					
Name	External them	External thermal relay operation							
Description	If the external thermal relay provided for motor overheat protection or the internally mounted temperature relay in the motor, etc. switches on (contacts open), the inverter output is stopped. Functions when "7" (OH signal) is set to any of <i>Pr. 178 to Pr. 182 (input terminal function selection)</i> . This protective function does not function in the initial status (OH signal is not assigned).								
Check point	 Check for motor overheating. Check that the value of 7 (OH signal) is set correctly in any of <i>Pr. 178 to Pr. 182 (input terminal function selection)</i>. 								
Corrective action		load and frequency relay contacts are re	•	cally, the inverter will not restart unless it is reset.					

Operation panel	E.PTC	FPSS	FR-PU04	Fault 14			
indication	E.PIC		FR-PU07	PTC activated			
Name	PTC thermisto	or operation					
Description	value set in Pr	Inverter trips when resistance of PTC thermistor connected between terminal 2 and terminal 10 is more than the value set in <i>Pr. 561 PTC thermistor protection level</i> . This protective function does not function when <i>Pr. 561</i> setting is initial value (<i>Pr. 561</i> = "9999").					
Check point	 Check the connection of the PTC thermistor. Check the <i>Pr. 561 PTC thermistor protection level</i> setting. Check the motor for operation under overload. 						
Corrective action	Reduce the lo	ad weight.					

Operation panel	E.PE	<u>_</u>	Ü	FR-PU04	Corrupt Memry			
indication	L.FL	<u>.</u>		FR-PU07	Corrupt Merriry			
Name	Parameter storage device fault (control circuit board)							
Description	Appears when	Appears when a fault occurred in the stored parameters. (EEPROM fault)						
Check point	Check for too	Check for too many number of parameter write times.						
	Please contac	Please contact your sales representative.						
Corrective action	When performing parameter write frequently for communication purposes, set "1" in <i>Pr. 342</i> to enable RAM write. Note							
	that powering	off returr	ns the inverte	er to the status	s before RAM write.			



Operation panel	E.PUE	EPHE	FR-PU04	PU Leave Out					
indication	E.PUE	C.	FR-PU07	FO Leave Out					
Name	PU disconnec	PU disconnection							
Description	 This function stops the inverter output if communication between the inverter and PU is suspended, e.g. the parameter unit (FR-PU04/FR-PU07) is disconnected, when "2", "3", "16" or "17" was set in <i>Pr. 75 Reset selection/disconnected PU detection/PU stop selection.</i> This function stops the inverter output when communication errors occurred consecutively for more than permissible number of retries when a value other than "9999" is set in <i>Pr. 121 Number of PU communication retries</i> during the RS-485 communication with the PU connector (use <i>Pr. 502 Stop mode selection at communication error</i> to change). This function also stops the inverter output if communication is broken within the period of time set in <i>Pr. 122 PU communication check time interval</i> during the RS-485 communication with the PU connector. 								
Check point	 Check that the parameter unit cable is fitted tightly. Check the <i>Pr.</i> 75 setting. Check that RS-485 communication data is correct. And check that the settings of communication parameter at inverter match settings of the computer. Check that data is transmitted from the computer within a time set in <i>Pr.</i> 122 PU communication check time interval. 								
Corrective action	Check the cor	arameter unit cable nmunication data ar Pr. 122 PU communication	nd communica	tion settings. e interval setting. Or set "9999" (no communication check).					

Operation panel indication	E.RET	E E.F	FR-PU04 FR-PU07	Retry No Over				
Name	Retry count ex	Retry count excess						
Description	If operation cannot be resumed properly within the number of retries set, this function trips the inverter. Functions only when $Pr. 67$ Number of retries at fault occurrence is set. When the initial value ($Pr. 67 = 0$) is set, this protective function does not function.							
Check point	Find the cause of fault occurrence.							
Corrective action	Eliminate the	cause of the error p	receding this e	error indication.				

Operation panel indication	E.CPU	E.C P U	FR-PU04 FR-PU07	CPU Fault			
Name	CPU fault	CPU fault					
Description	Stops the inve	Stops the inverter output if the communication fault of the built-in CPU occurs.					
Check point	Check for dev	Check for devices producing excess electrical noises around the inverter.					
Corrective action		res against noises act your sales repre		vices producing excess electrical noises around the inverter.			

Operation panel	E.CDO	8.C d O	FR-PU04					
indication	L.CDO		FR-PU07	OC detect level				
Name		Output current detection value exceeded						
Description	This function i	This function is activated when the output current exceeds the Pr. 150 Output current detection level setting.						
Check point	Check the sett	Check the settings of Pr. 150 Output current detection level, Pr. 151 Output current detection signal delay time, Pr. 166 Output						
Officer point	current detection signal retention time, Pr. 167 Output current detection operation selection. (Refer to page 119)							

Operation panel	E IOU	EJ 0H	FR-PU04				
indication	E.IOH	כיי עיי	FR-PU07	Inrush overheat			
Name	Inrush current	Inrush current limit circuit fault					
Description	This function is	This function is activated when the resistor of the inrush current limit circuit overheats. The inrush current limit circuit fault					
Check point	Check that fre	Check that frequent power ON/OFF is not repeated.					
Corrective action	Configure a circuit where frequent power ON/OFF is not repeated.						
Confective action	If the problem still persists after taking the above measure, please contact your sales representative.						

Operation panel	E.AIE	E.R.1 E	FR-PU04	Fault 14			
indication	E.AIE	C	FR-PU07	Analog in error			
Name	Analog input fa	Analog input fault					
Description	Appears when	Appears when 30mA or more is input or a voltage (7.5V or more) is input with the terminal 4 set to current input.					
Check point	Check the setting of Pr. 267 Terminal 4 input selection and voltage/current input switch. (Refer to page 145).						
Corrective action	Either give a frequency command by current input or set <i>Pr. 267 Terminal 4 input selection</i> , and voltage/current input switch to voltage input.						

- If protective functions of E.ILF, E.AIE, E.IOH, E.PTC, E.CDO are activated when using the FR-PU04, "Fault 14" is displayed.

 Also when the faults history is checked on the FR-PU04, the display is "E.14".
- If faults other than the above appear, contact your sales representative.

5.4 Correspondences between digital and actual characters

There are the following correspondences between the actual alphanumeric characters and the digital characters displayed on the operation panel:

Actual	Digital
0	[]
2	
3	<u> </u>
4	'- /
5	5
6	<u>5</u>
7	
8	
9	9

Actual	Digital
A	
В	
C	
D	<u></u>
E	\mathcal{E}
F	F
G	
Н	
J	
L	

Actual	Digital
M	[7]
N	,-,
0	\mathcal{D}
0	ø
Р	
S	5
T	/ -
U	[_/
V	<u></u>
r	
-	_



5.5 Check first when you have some troubles



POINT

If the cause is still unknown after every check, it is recommended to initialize the parameters (initial value) then reset the required parameter values and check again.

5.5.1 Motor will not start

1) Check the Pr. 0 Torque boost setting if V/F control is exercised. (Refer to page 69)

2) Check the main circuit.

- Check that a proper power supply voltage is applied. (Operation panel display is provided.)
- Check that the motor is connected properly.
- Check that the jumper across + and P1 is connected.

3) Check the input signals

- Check that the start signal is input.
- Check that both the forward and reverse rotation start signals are not input simultaneously.
- Check that the frequency setting signal is not zero. (When the frequency command is 0Hz and the start command is entered, RUN LED of the operation panel flickers.)
- Check that the AU signal is on when terminal 4 is used for frequency setting.
- Check that the output stop signal (MRS) or reset signal (RES) is not on.
- Check that the sink or source jumper connector is fitted securely. (Refer to page 21)
- Check that the jumper across S1-SC, S2-SC is connected.

4) Check the parameter settings

- Check that Pr. 78 Reverse rotation prevention selection is not set.
- Check that the Pr. 79 Operation mode selection setting is correct.
- Check that the bias and gain (calibration parameter C2 to C7) settings are correct.
- Check that the starting frequency Pr. 13 Starting frequency setting is not greater than the running frequency.
- Check that frequency settings of each running frequency (such as multi-speed operation) are not zero. Check that especially the maximum frequency Pr. 1 Maximum frequency is not zero.
- Check that the Pr. 15 Jog frequency setting is not lower than the Pr. 13 Starting frequency value.
 - Check that the operation location by Pr. 551 is appropriate. (Example: write from the operation panel is disabled when parameter unit is connected)

(Refer to page 234).

5) Inspection of load

- Check that the load is not too heavy.
- Check that the shaft is not locked.

6) Others

Check that the operation panel display does not show a fault (e.g. E.OC1).

5.5.2 Motor generates abnormal noise

No carrier frequency noises (metallic noises) are generated.

Soft-PWM control to change the motor tone into an unoffending complex tone is factory-set to valid by *Pr. 72 PWM frequency selection*.

Adjust Pr. 72 PWM frequency selection to change the motor tone.

Check for any mechanical looseness.

Contact the motor manufacturer.

5.5. 3	3 Motor generates heat abnormally
	Is the fan for the motor is running? (Check for dust accumulated.) Check that the load is not too heavy. Lighten the load. Are the inverter output voltages (U, V, W) balanced? Check that the <i>Pr. 0 Torque boost</i> setting is correct. Was the motor type set? Check the setting of <i>Pr. 71 Applied motor</i> . When using any other manufacturer's motor, perform offline auto tuning. (<i>Refer to page 100.</i>)
5.5.4	4 Motor rotates in opposite direction
	Check that the phase sequence of output terminals U, V and W is correct. Check that the start signals (forward rotation, reverse rotation) are connected properly. (<i>Refer to page 19</i>). Check that the <i>Pr. 40 RUN key rotation direction selection</i> setting is correct. (<i>Refer to page 234</i>).
5.5.5	5 Speed greatly differs from the setting
	 Check that the frequency setting signal is correct. (Measure the input signal level.) Check that the <i>Pr. 1, Pr. 2, Pr. 19, Pr. 245, calibration parameter Pr. 125, Pr. 126, C2 to C7</i> settings are correct. Check that the input signal lines are not affected by external noise. (use shielded cables) Check that the load is not too heavy. Check that the <i>Pr. 31</i> to <i>Pr. 36 (frequency jump)</i> settings are correct.
5.5.6	6 Acceleration/deceleration is not smooth
	Check that the acceleration and deceleration time settings are not too short. Check that the load is not too heavy. Check that the torque boost (<i>Pr. 0, Pr. 46</i>) setting is not too large to activate the stall function under V/F control.
5.5.7	7 Motor current is large
	 Check that the load is not too heavy. Check that the <i>Pr. 0 Torque boost</i> setting is correct. Check that the <i>Pr. 3 Base frequency</i> setting is correct. Check that the <i>Pr. 19 Base frequency voltage</i> setting is correct. Check that the <i>Pr. 14 Load pattern selection</i> setting is correct.
5.5.8	B Speed does not increase
	- Check that the <i>Pr. 1 Maximum frequency</i> setting is correct. (If you want to run the motor at 120Hz or more, set <i>Pr. 18 High speed maximum frequency</i> . (<i>Refer to page 78</i>). - Check that the load is not too heavy. (In agitators, etc., load may become heavier in winter.)

— Check that the torque boost (Pr. 0, Pr. 46) setting is not too large to activate the stall function under V/F control.

— Check that the brake resistor is not connected to terminals + and P1 or P1-PR accidentally.

TROUBLESHOOTING

5.5.9 Speed varies during operation

When slip compensation is set, the output frequency varies with load fluctuation between 0 and 2Hz. This is a normal operation and is not a fault.

1) Inspection of load

Check that the load is not varying.

2) Check the input signals

- Check that the frequency setting signal is not varying.
- Check that the frequency setting signal is not affected by noise. Set filter to the analog input terminal using Pr. 74
 Input filter time constant.
 - Check for a malfunction due to undesirable currents when the transistor output unit is connected. (Refer to page 22)

3) Others

- Check that the value of Pr. 80 Motor capacity is correct to the inverter capacity and motor capacity under generalpurpose magnetic flux vector control.
- Check that the wiring length is not exceeding 30m when general-purpose magnetic flux vector control is exercised. Perform offline auto tuning. (Refer to page 100).
- Check that the wiring length is not too long for V/F control.
- Change the Pr. 19 Base frequency voltage setting (about 3%) under V/F control.

5.5.10 Operation mode is not changed properly

If the operation mode does not change correctly, check the following:

1) External input signal

Check that the STF or STR signal is off. When it is on, the operation mode cannot be changed.

2) Parameter setting

Check the Pr. 79 setting.

When the Pr.~79~Operation~mode~selection setting is "0" (initial value), the inverter is placed in the external operation mode at input power-on. At this time, press $\frac{PU}{EXT}$ on the operation panel (press $\frac{PU}{EXT}$) when the parameter unit (FR-PU04/FR-PU07) is used) to switch to the PU operation mode. For other values (1 to 4, 6, 7), the operation mode is limited accordingly.

- Check that the operation location by *Pr. 551* is correct. (Example: write from the operation panel is disabled when parameter unit is connected)

(Refer to page 234).

5.5.11 Operation panel display is not operating

- Check that wiring is securely performed and installation is correct.
- Make sure that the connector is fitted securely across terminals + and P1.

5.5.12 Parameter write cannot be performed

- Make sure that operation is not being performed (signal STF or STR is not ON).
- Make sure that you are not attempting to set the parameter in the external operation mode.
 - Check Pr. 77 Parameter write selection.
- Check Pr. 161 Frequency setting/key lock operation selection.
- Check that the operation location by *Pr. 551* is correct. (Example: write from the operation panel is disabled when parameter unit is connected)

(Refer to page 234).

MEMO

PRECAUTIONS FOR MAINTENANCE AND INSPECTION

This chapter provides the "PRECAUTIONS FOR MAINTENANCE AND INSPECTION" of this product.

Always read the instructions before using the equipment

3.1	Inspection items	260
3.2	Measurement of main circuit voltages currents and nowers	267

2

3

ŀ

5

3

7

The inverter is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

Precautions for maintenance and inspection

For some short time after the power is switched off, a high voltage remains in the smoothing capacitor. When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched off, and then make sure that the voltage across the main circuit terminals + and - of the inverter is not more than 30VDC using a tester, etc.

6.1 Inspection items

6.1.1 Daily inspection

Basically, check for the following faults during operation.

- (1) Motor operation fault
- (2) Improper installation environment
- (3) Cooling system fault
- (4) Abnormal vibration, abnormal noise
- (5) Abnormal overheat, discoloration

During operation, check the inverter input voltages using a tester.

6.1.2 Periodic inspection

Check the areas inaccessible during operation and requiring periodic inspection.

Consult us for periodic inspection.

- (1) Check for cooling system fault......Clean the air filter, etc.
- (2) Tightening check and retightening.....The screws and bolts may become loose due to vibration, temperature changes, etc. Check and tighten them.

Tighten them according to the specified tightening torque (Refer to page 16).

- (3) Check the conductors and insulating materials for corrosion and damage.
- (4) Measure insulation resistance.
- (5) Check and change the cooling fan and relay.



6.1.3 Daily and periodic inspection

Area of	Inspection Item			Interval		Corrective Action at	Customer's								
Inspection			Description	Daily	Periodic *2	Alarm Occurrence	Check								
	Surrounding environment		Check the surrounding air temperature, humidity, dirt, corrosive gas, oil mist, etc.	0		Improve environment									
General	Overall unit		Check for unusual vibration and noise.	0		Check alarm location and retighten									
	Power supply voltage		Check that the main circuit voltages are normal.*1	0		Inspect the power supply									
			(1) Check with megger (across main circuit terminals and earth (ground) terminal).		0	Contact the manufacturer									
	Gen	eral	(2) Check for loose screws and bolts.		0	Retighten									
			(3) Check for overheat traces on the parts.		0	Contact the manufacturer									
			(4) Check for stain		0	Clean									
			(1) Check conductors for distortion.		0	Contact the manufacturer									
	Con	ductors, cables	(2) Check cable sheaths for breakage and deterioration (crack, discoloration, etc.)		0	Contact the manufacturer									
Main circuit	Tern	ninal block	Check for damage.		0	Stop the device and contact the manufacturer.									
			(1) Check for liquid leakage.		0	Contact the manufacturer									
	Smc	oothing aluminum	(2) Check for safety valve projection and bulge.		0	Contact the manufacturer									
	electrolytic capacitor		(3) Visual check and judge by the life check of the main circuit capacitor (<i>Refer to page 262</i>)		0										
	Rela	ny	Check that the operation is normal and no chatter is heard.		0	Contact the manufacturer									
	Operation check		(1) Check that the output voltages across phases with the inverter operated alone is balanced		0	Contact the manufacturer									
Control			Check that no fault is found in protective and display circuits in a sequence protective operation test.		0	Contact the manufacturer									
circuit, Protective		Overall	(1) Check for unusual odor and discoloration.		0	Stop the device and contact the manufacturer.									
circuit	Ą		(2) Check for serious rust development		0	Contact the manufacturer									
	ırts che	irts che	irts che	arts che	arts check	arts che	arts che	arts che	arts che	Aluminum electrolytic	(1) Check for liquid leakage in a capacitor and deformation trance		0	Contact the manufacturer	
	P	capacitor	(2) Visual check and judge by the life check of the main circuit capacitor (<i>Refer to page 262</i>)		0										
			(1) Check for unusual vibration and noise.	0		Replace the fan									
0 "	Coo	ling fan	(2) Check for loose screws and bolts		0	Retighten									
Cooling system			(3) Check for stain		0	Clean									
Зузісііі	Unn	toink	(1) Check for clogging		0	Clean									
	nea	tsink	(2) Check for stain		0	Clean									
	India	cation	(1) Check that display is normal.	0		Contact the manufacturer									
Display	mul	JauOH	(2) Check for stain		0	Clean									
Display	Mete	er	Check that reading is normal	0		Stop the device and contact the manufacturer.									
Load motor	Ope	ration check	Check for vibration and abnormal increase in operation noise	0		Stop the device and contact the manufacturer.									
			1			1									

It is recommended to install a device to monitor voltage for checking the power supply voltage to the inverter.

One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. Consult us for periodic inspection.

6.1.4 Display of the life of the inverter parts

The self-diagnostic alarm is output when the life span of the control circuit capacitor, cooling fan and each parts of the inrush current limit circuit is near to give an indication of replacement time.

The life alarm output can be used as a guideline for life judgement.

Parts	Judgement Level
Main circuit capacitor	85% of the initial capacity
Control circuit capacitor	Estimated remaining life 10%
Inrush current limit circuit	Estimated remaining life 10%
iniush current limit circuit	(Power on: 100,000 times left)
Cooling fan	Less than 50% of the predetermined speed



POINT

Refer to page 226 to perform the life check of the inverter parts.

6.1.5 Checking the inverter and converter modules

<Preparation>

- (1) Disconnect the external power supply cables (R/L1, S/L2, T/L3) and motor cables (U, V, W).
- (2) Prepare a tester. (Use 100Ω range.)

<Checking method>

Change the polarity of the tester alternately at the inverter terminals R/L1, S/L2, T/L3, U, V, W, + and -, and check for continuity.




NOTE

- 1. Before measurement, check that the smoothing capacitor is discharged.
- 2. At the time of discontinuity, the measured value is almost ∞ . When there is an instantaneous continuity, due to the smoothing capacitor, the tester may not indicate ∞ . At the time of continuity, the measured value is several to several ten's-of ohms depending on the module type, circuit tester type, etc. If all measured values are almost the same, the modules are without fault.

<Module device numbers and terminals to be checked>

		Tester I	Polarity	Measured		Tester Polarity		Measured
		\oplus	0	Value		(+)	0	Value
	D1	R/L1	+	Discontinuity	D4	R/L1	=	Continuity
<u>_</u>	וטו	+	R/L1	Continuity	D4	_	R/L1	Discontinuity
Converter module	D2	S/L2	+	Discontinuity	D5	S/L2	=	Continuity
on on	D2	+	S/L2	Continuity	DS	_	S/L2	Discontinuity
0 -	D3*	T/L3*	+	Discontinuity	D6*	T/L3*	=	Continuity
		+	T/L3*	Continuity		_	T/L3*	Discontinuity
	TR1	U	+	Discontinuity	TR4	U	=	Continuity
	IIXI	+	U	Continuity		_	U	Discontinuity
Inverter module	TR3	V	+	Discontinuity	TR6	V	=	Continuity
Jve	113	+	V	Continuity	INO	_	V	Discontinuity
	TD.	W	+	Discontinuity		W	=	Continuity
	TR5	+	W	Continuity	TR2	_	W	Discontinuity



(Assumes the use of an analog meter.)

6.1.6 Cleaning

Always run the inverter in a clean status.

When cleaning the inverter, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.



NOTE

Do not use solvent, such as acetone, benzene, toluene and alcohol, as they will cause the inverter surface paint to peel off. The display, etc. of the operation panel and parameter unit (FR-PU04/FR-PU07) are vulnerable to detergent and alcohol. Therefore, avoid using them for cleaning.

^{*} T/L3, D3 and D6 are only for the three-phase power input specification models.



6.1.7 Replacement of parts

The inverter consists of many electronic parts such as semiconductor devices.

The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the inverter. For preventive maintenance, the parts must be replaced periodically.

Use the life check function as a guidance of parts replacement.

Part Name	Standard Replacement Interval *1	Description
Cooling fan	10 years	Replace (as required)
Main circuit smoothing capacitor	10 years *2	Replace (as required)
On-board smoothing capacitor	10 years	Replace the board (as required)
Relays	_	as required

Replacement years for when the yearly average surrounding air temperature is 40°C (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)

Output current: 80% of the inverter rated current



NOTE

For parts replacement, consult the nearest Mitsubishi FA Center.

(1) Cooling fan

The replacement interval of the cooling fan used for cooling the parts generating heat such as the main circuit semiconductor is greatly affected by the surrounding air temperature. When unusual noise and/or vibration is noticed during inspection, the cooling fan must be replaced immediately.



For parts replacement, consult the nearest Mitsubishi FA Center.

Inverter Type	Fan Type	Units
FR-D740-036 to 080	MMF-06F24ES-RP1 BKO-CA1638H01	1
FR-D720S-070 and 100	WIVIF-00F24E3-RF1 BRO-CA1030H01	'
FR-D740-120, 160	MMF-06F24ES-RP1 BKO-CA1638H01	2

The FR-D740-022 or less, FR-D720S-008 to 042 are not provided with a cooling fan.


●Removal

1) Push the hooks from above and remove the fan cover

FR-D740-080 or less FR-D720S-070 and 100




FR-D740-120 or more




- 2) Disconnect the fan connectors.
- 3) Remove the fan.

FR-D740-080 or less FR-D720S-070 and 100



FR-D740-120 or more




Example for FR-D740-160



Reinstallation


 After confirming the orientation of the fan, reinstall the fan so that the arrow on the left of "AIR FLOW" faces up.




<Fan side face>

- 2) Reconnect the fan connectors.
- 3) When wiring, use care to avoid the cables being caught by the fan.

FR-D740-080 or less FR-D720S-070 and 100




FR-D740-120 or more




4) Reinstall the fan cover.

FR-D740-080 or less FR-D720S-070 and 100



FR-D740-120 or more



Example for FR-D740-160

Example for FR-D740-036



NOTE

- Installing the fan in the opposite air flow direction can cause the inverter life to be shorter.
- Prevent the cable from being caught when installing a fan.
- Switch the power off before replacing fans. Since the inverter circuits are charged with voltage even after power off, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.

(2) Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing in the main circuit DC section, and an aluminum electrolytic capacitor is used for stabilizing the control power in the control circuit. Their characteristics are deteriorated by the adverse effects of ripple currents, etc. The replacement intervals greatly vary with the surrounding air temperature and operating conditions. When the inverter is operated in air-conditioned, normal environment conditions, replace the capacitors about every 10 years.

When a certain period of time has elapsed, the capacitors will deteriorate more rapidly. Check the capacitors at least every year (less than six months if the life will be expired soon).

The appearance criteria for inspection are as follows:

- 1) Case: Check the side and bottom faces for expansion
- 2) Sealing plate: Check for remarkable warp and extreme crack.
- 3) Check for external crack, discoloration, liquid leakage, etc. Judge that the capacitor has reached its life when the measured capacitance of the capacitor reduced below 80% of the rating.



POINT

Refer to page 226 to perform the life check of the main circuit capacitor.

(3) Relays

To prevent a contact fault, etc., relays must be replaced according to the cumulative number of switching times (switching life).



6.2 Measurement of main circuit voltages, currents and powers


Since the voltages and currents on the inverter power supply and output sides include harmonics, measurement data depends on the instruments used and circuits measured.

When instruments for commercial frequency are used for measurement, measure the following circuits with the instruments given on the next page.

• When installing meters etc. on the inverter output side

When the inverter-to-motor wiring length is large, especially in the 400V class, small-capacity models, the meters and CTs may generate heat due to line-to-line leakage current. Therefore, choose the equipment which has enough allowance for the current rating.

To measure and display the output voltage and output current of the inverter, it is recommended to use the AM-5 terminal output function of the inverter.



* At, As, Vt, Vs, W12, W13 are only for the three-phase power input specification models.

Examples of Measuring Points and Instruments

Measuring Points and Instruments

Item	Measuring Point	Measuring Instrument	Remarks (Reference Measure	d Value)	
Power supply voltage	R/L1-S/L2	Moving-iron type AC	Commercial power supply		
V1	S/L2-T/L3	voltmeter	Within permissible AC voltage fluctuati	on (Refer to	
Dawer aventy side	T/L3-R/L1		page 274)		
Power supply side	R/L1, S/L2, T/L3 line	Moving-iron type AC			
current I1	current	ammeter			
	R/L1, S/L2, T/L3 and				
Power supply side	R/L1-S/L2,	Electrodynamic type single-			
power	S/L2-T/L3,	phase wattmeter	P1=W11+W12+W13 (3-wattmeter meth	nod)	
P1	T/L3-R/L1,				
	Calculate after measuring po	ower supply voltage, power			
Power supply side	supply side current and pow	er supply side power.			
power factor	[Three-phase power supply]		[Single-phase power supply]		
Pf1	$Pf_1 = \frac{P_1}{\sqrt{3}V_1 \times I_1} \times 100$	%	$Pf_1 = \frac{P_1}{V_1 \times I_1} \times 100 \%$		
		Rectifier type AC voltage			
Output side voltage		meter *1	Difference between the phases is with	n 1% of the	
V2	Across U-V, V-W and W-U	(moving-iron type cannot	maximum output voltage.		
		measure)			
Output side current	U, V and W line currents	Moving-iron type AC	Difference between the phases is 10%	or lower of	
12	O, v and vv line currents	ammeter *2	the rated inverter current.		
Output side power	U, V, W and	Electrodynamic type single-	P2 = W21 + W22		
P2	U-V, V-W	phase wattmeter	2-wattmeter method (or 3-wattmeter m	ethod)	
Output side meure	Calculate in similar manner	to power supply side power factor	or.		
Output side power	D _o				
factor Pf2	$Pf_2 = \frac{P_2}{\sqrt{3}V_2 \times I_2} \times 100$	%			
1 12	√3 V 2 × 12				
Converter output	Across + and -	Moving-coil type (such as tester)	Inverter LED display is lit. 1.35 × V1		
Frequency setting	Across 2(positive)-5		0 to 10VDC4 to 20mADC		
signal	Across 4(positive)-5		0 to 10VDC4 to 20MADC		
Frequency setting power supply	Across 10(positive)-5	Moving-coil type (tester and such may be	5.2VDC	"5" is common.	
Frequency meter	Across AM(positive) F	used)	Approx. 10VDC at maximum		
signal	Across AM(positive)-5	(internal resistance $50k\Omega$ or	frequency (without frequency meter)		
Start signal	STF, STR	more)	When open	"PC" is	
Select signal	Across RH, RM, RL -		20 to 30VDC	common.	
	PC (positive)		ON voltage: 1V or less	30	
			Continuity check *3		
Fault signal	Across A-C	Moving-coil type	<normal> <fault< td=""><td></td></fault<></normal>		
	Across B-C	(such as tester)	Across A-C Discontinuity Continu	•	
			Across B-C Continuity Disconti	nuity	

^{*1} Use an FFT to measure the output voltage accurately. An FA tester or general measuring instrument cannot measure accurately.

^{*2} When the carrier frequency exceeds 5kHz, do not use this instrument since using it may increase eddy-current losses produced in metal parts inside the instrument, leading to burnout. In this case, use an approximate-effective value type.

^{*3} When the setting of Pr. 192 A,B,C terminal function selection is positive logic

6.2.1 Measurement of powers


Using an electro-dynamometer type meter, measure the power in both the input and output sides of the inverter using the twoor three-wattmeter method. As the current is liable to be imbalanced especially in the input side, it is recommended to use the three-wattmeter method.

Examples of process value differences produced by different measuring meters are shown below.

An error will be produced by difference between measuring instruments, e.g. power calculation type and two- or three-wattmeter type three-phase wattmeter. When a CT is used in the current measuring side or when the meter contains a PT on the voltage measurement side, an error will also be produced due to the frequency characteristics of the CT and PT.

[Measurement conditions]


Constant-torque (100%) load, note that 60Hz or more should be constantly output 3.7kW, 4-pole motor, value indicated in 3-wattmeter method is 100%.



Example of Measuring Inverter Input Power

[Measurement conditions]

Constant-torque (100%) load, note that 60Hz or more should be constantly output 3.7kW, 4-pole motor, value indicated in 3-wattmeter method is 100%.



Example of Measuring Inverter Output Power

6.2.2 Measurement of voltages and use of PT

(1) Inverter input side

As the input side voltage has a sine wave and it is extremely small in distortion, accurate measurement can be made with an ordinary AC meter.

(2) Inverter output side

Since the output side voltage has a PWM-controlled rectangular wave, always use a rectifier type voltmeter. A needle type tester can not be used to measure the output side voltage as it indicates a value much greater than the actual value. A moving-iron type meter indicates an effective value which includes harmonics and therefore the value is larger than that of the fundamental wave. The value monitored on the operation panel is the inverter-controlled voltage itself. Hence, that value is accurate and it is recommended to monitor values using the operation panel.

(3) PT

No PT can be used in the output side of the inverter. Use a direct-reading meter. (A PT can be used in the input side of the inverter.)

6.2.3 Measurement of currents

Use a moving-iron type meter on both the input and output sides of the inverter. However, if the carrier frequency exceeds 5kHz, do not use that meter since an overcurrent losses produced in the internal metal parts of the meter will increase and the meter may burn out. In this case, use an approximate-effective value type.


Since current on the inverter input side tends to be unbalanced, measurement of three phases is recommended. Correct value can not be obtained by measuring only one or two phases. On the other hand, the unbalanced ratio of each phase of the output side current should be within 10%.


When a clamp ammeter is used, always use an effective value detection type. A mean value detection type produces a large error and may indicate an extremely smaller value than the actual value. The value monitored on the operation panel is accurate if the output frequency varies, and it is recommended to monitor values (provide analog output) using the operation panel. Examples of process value differences produced by different measuring meters are shown below.

[Measurement conditions]

[Measurement conditions]

Value indicated by moving-iron type ammeter is 100%. Value indicated by moving-iron type ammeter is 100%.





Example of measuring inverter input current

Example of measuring inverter output current


6.2.4 Use of CT and transducer

A CT may be used in both the input and output sides of the inverter, but the one used should have the largest possible VA ability because an error will increase if the frequency gets lower.

When using a transducer, use the effective value calculation type which is immune to harmonics.

6.2.5 Measurement of inverter input power factor

Calculate using effective power and apparent power. A power-factor meter can not indicate an exact value.



6.2.6 Measurement of converter output voltage (across terminals + and -)


The output voltage of the converter is developed across terminals + and - and can be measured with a moving-coil type meter (tester). Although the voltage varies according to the power supply voltage, approximately 270V to 300V (540V to 600V for the 400V class) is output when no load is connected and voltage decreases when a load is connected.

When regenerative energy is returned from the motor during deceleration, for example, the converter output voltage rises to nearly 400 to 450V (800V to 900V for the 400V class) maximum.



6.2.7 Insulation resistance test using megger

• For the inverter, conduct the insulation resistance test on the main circuit only as shown below and do not perform the test on the control circuit. (Use a 500VDC megger.)



NOTE

- Before performing the insulation resistance test on the external circuit, disconnect the cables from all terminals of the inverter so that the test voltage is not applied to the inverter.
- For the continuity test of the control circuit, use a tester (high resistance range) and do not use the megger or buzzer.

6.2.8 Pressure test

Do not conduct a pressure test. Deterioration may occur.

MEMO

7 SPECIFICATIONS

This chapter provides the "SPECIFICATIONS" of this product. Always read the instructions before using the equipment

7.1	Rating	274
7.2	Common specifications	275
7.3	Outline dimension drawings	276

ı

2

3

Ļ

5

6

7.1 Rating

7.1.1 Inverter rating

• Three-phase 400V power supply

	Model FR-D740-□-EC	012	022	036	050	080	120	160	
App	olicable motor capacity (kW)*1	0.4	0.75	1.5	2.2	3.7	5.5	7.5	
	Rated capacity (kVA)*2	1.2	2.0	3.0	4.6	7.2	9.1	13.0	
put	Rated current (A)	1.2	2.2	3.6	5.0	8.0	12.0	16.0	
Rated current (A) 1.2 2.2 3.6 5.0 Overload current rating*3 150% 60s, 200% 0.5s (inverse-t					time characteristics)				
	Voltage*4	Three-phase 380 to 480V							
oly	Rated input voltage/frequency	Three-phase 380 to 480V 50Hz/60Hz							
supply	Permissible AC voltage fluctuation	325 to 528V 50Hz/60Hz							
er s	Permissible frequency fluctuation	±5%							
Power	Power supply capacity (kVA)*5	1.5	2.5	4.5	5.5	9.5	12	17	
Pro	tective structure (JEM1030)	Enclosed type (IP20)							
Cooling system		Self-cooling Forced air cooling							
App	proximate mass (kg)	1.2	1.2	.2 1.3 1.4 1.5 3.1 3.				3.1	

- *1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- *2 The rated output capacity indicated assumes that the output voltage is 440V.
- *3 The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
- *4 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about $\sqrt{2}$ that of the power supply.
- *5 The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).

Single-phase 200V power supply

	Model FR-D720S-□-EC	800	014	025	042	070	100		
App	licable motor capacity (kW)*1	0.1	0.2	0.4	0.75	1.5	2.2		
	Rated capacity (kVA)*2	0.3	0.5	1.0	1.6	2.8	3.8		
put	Rated current (A)	0.8	1.4	2.5	4.2	7.0	10.0		
Output	Overload current rating*3	150% 60s, 200% 0.5s (inverse-time characteristics)							
	Voltage*4	Three-phase 200 to 240V							
<u>></u>	Rated input voltage/frequency	Single-phase 200 to 240V 50Hz/60Hz							
supply	Permissible AC voltage fluctuation	170 to 264V 50Hz/60Hz							
er s	Permissible frequency fluctuation	±5%							
Power	Power supply capacity (kVA)*5	0.5	0.9	1.5	2.3	4.0	5.2		
Pro	tective structure (JEM1030)	Enclosed type (IP20)							
Cod	oling system	Self-cooling Force				Forced a	ir cooling		
App	roximate mass (kg)	0.5	0.6	0.9	1.1	1.5	1.9		

- *1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- *2 The rated output capacity indicated assumes that the output voltage is 230V.
- *3 The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
- *4 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about $\sqrt{2}$ that of the power supply.
- *5 The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).



Common specifications 7.2

L								
l	Control method			Soft-PWM control/high carrier frequency PWM control (V/F control, general-purpose magnetic flux vector control, optimum excitation control can be selected)				
_				0.2 to 400Hz				
SL	Fre	,	Analog input Digital input	0.06Hz/60Hz (terminal2, 4: 0 to 10V/10bit) 0.12Hz/60Hz (terminal2, 4: 0 to 5V/9bit) 0.06Hz/60Hz (terminal4: 0 to 20mA/10bit) 0.01Hz				
is	Ero	quency	Analog input	Within ±1% of the max. output frequency (25°C ±10°C)				
Σį		curacy	Digital input	Within 0.01% of the set output frequency				
sbe		-		Base frequency can be set from 0 to 400Hz				
0	VOI	tage/frequency o	naracteristics	Constant torque/variable torque pattern can be selected				
Ę	Sta	rting torque		150% or more (at 1Hz)when general-purpose magnetic flux vector control and slip compensation is set				
ပိ	Tor	que boost		Manual torque boost				
			ration time setting	0.1 to 3600s (acceleration and deceleration can be set individually), linear or S-pattern acceleration/deceleration mode can be selected.				
	DC injection brake			Operation frequency (0 to 120Hz), operation time (0 to 10s), operation voltage (0 to 30%) variable				
	Stall prevention operation level		eration level	Operation current level can be set (0 to 200% adjustable), whether to use the function or not can be selected				
	Frequency setting Analog input signal		Analog input	Two points Terminal 2: 0 to 10V, 0 to 5V can be selected Terminal 4: 0 to 10V, 0 to 5V, 4 to 20mA can be selected				
	o.9		Digital input	Entered from operation panel and parameter unit. Frequency setting increments is selectable				
	Sta	rt signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.				
	Input signal Operational functions			Five points You can select from among multi-speed selection, remote setting, second function selection, terminal 4 input selection, JOG operation selection, PID control valid terminal, external thermal input, PU-external operation switchover, V/F switchover, output stop, start self-holding selection, traverse function selectiom, forward rotation, reverse rotation command, inverter reset, PU-NET operation switchover, external-NET operation switchover, command source switchover, inverter operation enable signal, and PU operation external interlock Maximum/minimum frequency setting, frequency jump operation, external thermal relay input selection, automatic restart after instantaneous power failure operation, forward/reverse rotation prevention, remote setting, second function, multi-speed operation, regeneration avoidance, slip compensation, operation mode selection, offline				
Operation specifications	Open collector			auto tuning function, PID control, computer link operation (RS-485), optimum excitation control, power failure stop, speed smoothing control, Modbus-RTU One point				
o		Output signal points	output	One point				
ati		points	Relay output	One point				
Ope	Operating status		S	You can select from among inverter operation, up-to-frequency, overload alarm, output frequency detection, regenerative brake prealarm, electronic thermal relay function prealarm, inverter operation ready, output current detection, zero current detection, PID lower limit, PID upper limit, PID forward/reverse rotation output, fan alarm*2, heatsink overheat pre-alarm, deceleration at an instantaneous power failure, PID control activated, PID output interruption, during retry, life alarm, current average value monitor, remote output, alarm output, fault output, fault output 3, and maintenance timer alarm				
	Output	For meter Output points	Analog output	0 to 10VDC: one point				
	For meter			You can select from among output frequency, motor current (steady), output voltage, frequency setting, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, reference voltage output, motor load factor, PID set point, PID measured				
		For meter		value, output voltage peak value, reletence voltage dutput, motor load factor, FID set point, FID measured value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC				
	Par	eration panel	Operating status	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor				
dication	Par (FR	eration panel rameter unit R-PU07)	Fault definition	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, PTC thermistor resistance. Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored				
Indication	Par (FR	eration panel rameter unit R-PU07)	Fault definition Operating status	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, PTC thermistor resistance. Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/ frequency/cumulative energization time right before the fault occurs) are stored Not used				
Indication	Par (FR	eration panel rameter unit t-PU07) ditional display the parameter	Fault definition Operating status Fault definition	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, PTC thermistor resistance. Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored				
Indication	Par (FR Add	eration panel rameter unit t-PU07) ditional display the parameter	Fault definition Operating status	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, PTC thermistor resistance. Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/ frequency/cumulative energization time right before the fault occurs) are stored Not used				
Indication	Add by uni	eration panel rameter unit t-PU07) ditional display the parameter t (FR-PU04/FR-	Fault definition Operating status Fault definition Interactive guidance	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, PTC thermistor resistance. Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/ frequency/cumulative energization time right before the fault occurs) are stored Not used Output voltage/current/frequency/cumulative energization time immediately before the fault occurs				
Indication o	Par (FR Add by uni PU	eration panel rameter unit t-PU07) ditional display the parameter t (FR-PU04/FR- 07) only	Fault definition Operating status Fault definition Interactive guidance	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, PTC thermistor resistance. Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored Not used Output voltage/current/frequency/cumulative energization time immediately before the fault occurs Function (help) for operation guide <protective functions=""> Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure *5, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, PTC thermistor operation*4, parameter error, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, analog input error, stall prevention operation, output current detection value exceeded Varning functions> Fan alarm*2, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error, regenerative brake prealarm *4, electronic thermal relay function prealarm, maintenance output *4, undervoltage,</protective>				
Indication	Add by uni PU	eration panel rameter unit R-PU07) ditional display the parameter t (FR-PU04/FR- 07) only	Fault definition Operating status Fault definition Interactive guidance	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, PTC thermistor resistance. Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/ frequency/cumulative energization time right before the fault occurs) are stored Not used Output voltage/current/frequency/cumulative energization time immediately before the fault occurs Function (help) for operation guide <protective functions=""> Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure *5, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, PTC thermistor operation*4, parameter error, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, analog input error, stall prevention operation, output current detection value exceeded <warning functions=""> Fan alarm*2, overcurrent stall prevention, overvoltage stall prevention, put stop, parameter write error, regenerative brake prealarm *4, electronic thermal relay function prealarm, maintenance output *4, undervoltage, operation panel lock, password locked, inverter reset</warning></protective>				
Indication o	Par (FR Add by uni PU	eration panel rameter unit t-PU07) ditional display the parameter t (FR-PU04/FR- 07) only tive/warning function	Fault definition Operating status Fault definition Interactive guidance ction	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, PTC thermistor resistance. Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/ frequency/cumulative energization time right before the fault occurs) are stored Not used Output voltage/current/frequency/cumulative energization time immediately before the fault occurs Function (help) for operation guide <protective functions=""> Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure *5, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, PTC thermistor operation*4, parameter error, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, analog input error, stall prevention operation, output current detection value exceeded <warning functions=""> Fan alarm*2, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error, regenerative brake prealarm *4, electronic thermal relay function prealarm, maintenance output *4, undervoltage, operation panel lock, password locked, inverter reset -10°C to +50°C (non-freezing) *3</warning></protective>				
ronment d	Add by united by techniques and tech	eration panel rameter unit t-PU07) ditional display the parameter t (FR-PU04/FR- 07) only tive/warning function	Fault definition Operating status Fault definition Interactive guidance ction	value, output power, PID deviation, Motor thermal load factor, Inverter thermal load factor 0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, output power, cumulative power, motor thermal load factor, inverter thermal load factor, PTC thermistor resistance. Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/ frequency/cumulative energization time right before the fault occurs) are stored Not used Output voltage/current/frequency/cumulative energization time immediately before the fault occurs Function (help) for operation guide <protective functions=""> Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure *5, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, PTC thermistor operation*4, parameter error, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, analog input error, stall prevention operation, output current detection value exceeded <warning functions=""> Fan alarm*2, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error, regenerative brake prealarm *4, electronic thermal relay function prealarm, maintenance output *4, undervoltage, operation panel lock, password locked, inverter reset -10°C to +50°C (non-freezing) *3 90%RH maximum (non-condensing)</warning></protective>				

- Temperatures applicable for a short time, e.g. in transit.


 As the FR-D740-022 or less, FR-D720S-042 or less is not provided with the cooling fan, this alarm does not function.

 When using the inverters at the surrounding air temperature of 40°C or less, the inverters can be installed closely attached (0cm clearance). This protective function does not function in the initial status.


 This protective function is available with the three-phase power input specification model only.

7.3 Outline dimension drawings


●FR-D720S-008 to 042




- ●FR-D740-012 to 080
- ●FR-D720S-070




●FR-D720S-100




●FR-D740-120, 160




●Parameter unit (option) (FR-PU07)



●Parameter unit (option) (FR-PU04)



•Enclosure surface operation panel (option) (FR-PA07)



APPENDIX

This chapter provides the "APPENDIX" of this product. Always read the instructions before using the equipment.

Appendix1 Index

Numerics	E
15-speed selection (combination with three speeds RL, RM,	Earth (ground) fault detection at start (Pr. 249)141
RH)(REX signal)84, 108	Easy operation mode setting (easy setting mode)50
	Electronic thermal O/L relay pre-alarm (TH)95, 248
A	Electronic thermal O/L relay pre-alarm (THP signal) 95, 114
Acceleration time, deceleration time setting (Pr. 7, Pr. 8, Pr.	Electronic Thermal Relay Function Load Factor
20, Pr. 21, Pr. 44, Pr. 45)	Extended parameter display (Pr. 160)
Acceleration/deceleration pattern (Pr. 29)94	External thermal relay input (OH signal)95, 108
Actual operation time	External thermal relay operation (E.OHT)95, 252
Alarm output (LF signal)	External/NET operation switchover (turning on X66 selects
Analog input fault (E.AIE)253	NET operation) (X66 signal)108, 168
Analog input selection(Pr. 73, Pr. 267)	_
Applied motor (Pr. 71, Pr. 450)98	F
Automatic restart after instantaneous power failure/flying start	Fan alarm (FN)
(Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr.	Fan fault output (FAN signal)114, 225
299, Pr. 611) <i>131</i>	Fault or alarm indication
Avoid mechanical resonance points (frequency jumps) (Pr. 31	Fault output (ALM signal)114, 117
to Pr. 36)79	Fault output 3 (power-off signal) (Y91 signal)114, 117
_	Faults history (E)
В	Fin overheat (E.FIN)
Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)80	Forward rotation command (assigned to STF terminal (Pr.
Basic operation (factory setting)49	178) only) (STF signal)
Bias and gain of frequency setting voltage (current) (Pr. 125,	Free parameter (Pr. 888, Pr. 889)
Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	Frequency setting value
Brake transistor alarm detection (E.BE)251	Front cover5
Buzzer control (Pr. 990)	
,	G
C	General-purpose magnetic flux vector control
Cables and wiring length16	(Pr. 71, Pr. 80) <i>70</i>
Change the parameter setting value51	
Changing the control logic21	H
Checking the inverter and converter modules	Heatsink overheat pre-alarm (FIN signal)114, 251
Cleaning	High speed operation command (RH signal)84, 108
Command source switchover (turning on X67 makes Pr. 338	3 · p · · · · p · · · · · · · · · · · ·
and Pr. 339 commands valid) (X67 signal)108, 171	1
Communication EEPROM write selection (Pr. 342) 182	Initial settings and specifications of RS-485 communication
Condition selection of function validity by second function	(Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)
selection signal (RT signal)111	Input phase loss (E.ILF)
Connection of a DC reactor (FR-HEL)32	Input terminal function selection(Pr. 178 to Pr. 182)108
Connection of a dedicated external brake resistor	Input Terminal Status
(FR-ABR)28	Input/output phase loss protection selection
Connection of the brake unit (FR-BU2)30	(Pr. 251, Pr. 872)
Connection of the high power factor converter (FR-HC)31	Inrush current limit circuit fault (E.IOH)
Connection of the power regeneration common converter	Insulation resistance test using megger
(FR-CV)	Inverter I/O Terminal Monitor
Connection to the PU connector	Inverter installation environment
Control circuit terminal	Inverter operation ready (RY signal)
Converter Output Voltage	Inverter output shutoff signal (MRS signal, Pr. 17)
Converter output voltage peak value	Inverter overload trip (electronic thermal relay function)
Cooling fan operation selection (Pr. 244)225	(E.THT)
Cooling system types for inverter panel9	Inverter placement
CPU fault (E.CPU)	Inverter reset (Err.)
Cumulative energization time	Inverter reset (RES signal)
Cumulative power	Inverter run enable signal(FR-HC/FR-CV connection) (X10
Current average value monitor signal (Pr. 555 to Pr. 557) 231	signal)
Current average value monitor signal (Y93 signal)114, 231	Inverter running (RUN signal)
ourront aronago valuo momor oignar (100 oignar) 1, 201	Inverter thermal load factor
D	Inverter-generated noises and their reduction techniques 36
Daily and periodic inspection261	inverter-generated holdes and their reduction techniques30
Daily inspection	J
Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)	
DC injection brake (Pr. 10 to Pr. 12)	Jog operation (Pr. 15, Pr. 16)
Detection of output frequency	JOG operation selection (JOG signal)86, 108
(SU, FU signal, Pr. 41 to Pr. 43)	L
Display of the life of the inverter parts	-
(Pr. 255 to Pr. 259)	Leakage currents and countermeasures
During PID control activated (PID signal)114, 207, 215	Life alarm (Y90 signal)
	Load pattern selection (Pr. 14)82
During retry (Y64 signal)	Low-speed operation command (RL signal)84, 108

M	Periodic inspection
Magnitude of frequency change setting (Pr. 295)	Peripheral devices4
Maintenance signal output (MT)230, 248	PID control (Pr. 127 to Pr. 134, Pr. 575, Pr. 577)207
Maintenance timer alarm (Pr. 503, Pr. 504)	PID control valid terminal (X14 signal)108, 207, 215
Maintenance timer signal (Y95 signal)114, 230	PID Deviation
Manual torque boost (Pr. 0, Pr. 46)69	PID Forward/Reverse Rotation Output
Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	(RL signal)
Measurement of converter output voltage (across terminals	PID lower limit (FDN signal)
P-N)	PID Measured Value
Measurement of currents	PID Set Point
Measurement of inverter input power factor	Power failure deceleration signal (Y46 signal)114, 137
Measurement of powers	Power supply harmonics
Measurement of voltages and use of PT	Power-failure deceleration stop function (Pr. 261)
Middle-speed operation command (RM signal)	Pressure test
Mitsubishi inverter protocol (computer link communication)	PTC thermistor operation
Modbus RTU communication specifications (Pr. 117, Pr. 118,	PTC thermistor resistance95
Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	PU contrast adjustment (Pr. 991)238
Monitor display selection of DU/PU and terminal AM (Pr. 52,	PU disconnection (E.PUE)
Pr. 158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564) 123	PU display language selection(Pr. 145)234
Motor Load Factor	PU operation external interlock (X12 signal)108, 160
Motor overheat protection (Electronic thermal O/L relay) (Pr.	PU stop (PS)
9, Pr. 51)	PU/NET operation switchover (turning on X65 selects PU
Motor overheat protection (Electronic thermal O/L relay, PTC	operation) (X65 signal)108, 168
thermistor protection) (Pr. 9, Pr. 51, Pr. 561)	PU-external operation switchover (turning on X16 selects
Motor overload trip (electronic thermal relay function)	external operation) (X16)
(E.THM)	PWM carrier frequency and soft-PWM control (Pr. 72, Pr.
Motor thermal load factor	240)
Motor Torque	
'	R
N	Reference of the terminal AM (analog voltage output) (Pr. 55,
Names and functions of the operation panel48	Pr. 56)
, , , , , , , , , , , , , , , , , , ,	Reference voltage output
0	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883,
Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to	Pr. 885, Pr. 886)
Pr. 27, Pr. 232 to Pr. 239)	Regenerative brake duty105, 123
Operation mode at power-on (Pr. 79, Pr. 340)	Regenerative brake prealarm (RB)105, 248
Operation mode selection (Pr. 79)	Regenerative brake prealarm (RBP signal)105, 114
Operation panel frequency setting/key lock operation	Regenerative overvoltage trip during acceleration
selection (Pr. 161)	(E.OV1)
Operation panel lock (HOLD)	Regenerative overvoltage trip during constant speed
Operation selection at communication error occurrence (Pr.	(E.OV2)
121, Pr. 122, Pr. 502)	Regenerative overvoltage trip during deceleration or stop
Optimum excitation control (Pr. 60)	(E.OV3)
Output current	Remote output (REM signal)
Output current detection (Y12 signal)114, 114, 119	Remote output selection (REM signal, Pr. 495 to Pr. 497)
Output current detection function (Y12 signal, Y13 signal, Pr.	
150 to Pr. 153)	Remote setting (RH, RM, RL signal)88, 108 Remote setting function (Pr. 59)88
Output current detection value exceeded	Replacement of parts
Output Current Peak Value	Reset selection/disconnected PU detection/PU stop selection
Output frequency	(Pr. 75)
Output frequency detection (FU signal)	Response level of analog input and noise elimination
Output phase loss (E.LF)	(Pr. 74)
Output power	Retry count excess (E.RET)
(E.GF)	Retry function (Pr. 65, Pr. 67 to Pr. 69)
Output stop (MRS signal)	Reverse rotation command (assigned to STR terminal (Pr.
Output stop (MNO signar)	179) only) (STR singnal)
Output Terminal Status	Reverse rotation prevention selection (Pr. 78)157
Output voltage	RUN key rotation direction selection (Pr. 40)234
Overcurrent trip during acceleration (E.OC1)	,
Overcurrent trip during constant speed (E.OC2)	S
Overcurrent trip during deceleration or stop (E.OC3)	Second function selection (RT signal)108, 111
Overload alarm (OL signal)	Selection of a regenerative brake (Pr. 30, Pr. 70)105
oronoud diami (or oighdi)	Setting dial push51
P	Slip compensation (Pr. 245 to Pr. 247)
Parameter list	Specification of main circuit terminal
Parameter storage device fault	Speed display and speed setting (Pr. 37)
(control circuit board) (E.PE)	Speed smoothing control (Pr. 653)144
Parameter write disable selection (Pr. 77)	Stall prevention (E.OLT)74, 251
Parameter write error (Er1 to Er4)	Stall prevention (overcurrent) (OL)74, 247
Password function	Stall prevention (overvoltage) (oL)223, 247
Password locked	Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr.

156, Pr. 157, Pr. 277)	4
Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 551	1)
Start self-holding selection (STOP signal)	
250)	
Starting frequency and start-time hold function (Pr. 13, Pr. 571)9) 3
Stop selection (Pr. 250))7
т	
Terminal 4 input selection (AU signal)108, 14	!5
Terminal AM calibration (calibration parameter Pr. 645, C1	
(Pr.901))	9
supply and the motor wiring	.5
Terminal connection diagram	
To exhibit the best performance of the motor performance (offline auto tuning) (Pr. 71, Pr. 80, Pr. 82 to Pr. 84, Pr. 90 Pr. 96)),
Traverse function (Pr. 592 to Pr. 597)	21
U	
Undervoltage (UV)24	18
Up-to-frequency signal (SU signal)	8
v	
V/F switchover (V/F cntrol is exercised when X18 is on) (X18 signal)	
W	
Wiring and configuation of PUconnector17	
Wiring cover	
Wiring instructions	
Z	
Zero current detection (Y13 signal) 114 11	g

MEMO

*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Dec., 2007	IB(NA)-0600353ENG-A	First edition
Mar., 2008	IB(NA)-0600353ENG-B	Partial modification
		Introduced products on bar terminals
		Instruction Code (Multi command, Inverter type monitor)
Apr., 2008	IB(NA)-0600353ENG-C	Additions
		• FR-D720S-008 to 100
L		

1 For Maximum Safety

- Mitsubishi inverters are not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi sales representative.
- Although this product was manufactured under conditions of strict quality control, you are strongly advised to
 install safety devices to prevent serious accidents when it is used in facilities where breakdowns of the product
 are likely to cause a serious accident.
- Please do not use this product for loads other than three-phase induction motors.