


RS485 OPTION CARD Install Manual



NOTE:

1. The black wire connect to "com" or "24G" terminal of TM2
2. The red wire connect to "24V" terminal of TM2.