Dokumentation Nr.: WS-ATEX-IN01	Atex Instruction manual	W+S Meßsysteme
	Seite 1 / 6	Ausgabe Nr.001007
Erst: 290907 Weber		vom: 29.09.2007



## ATEX Directive (94/9/EC) Essential Health and Safety Requirements Instruction for Installation of X700

W+S Meßsysteme GmbH Humboldtstrasse 11 D-78 549 Spaichingen

The X700 Incremental or Absolut Shaft Encoder is a flameproof construction containing the electronics. Based on the very low current consumption the temperature class will not be affected by the electronics. The shaft is designed with two precision ball bearings and a separate flamepath.

### X 700 Flameproof Shaft Encoder

- X700 -

#### PRODUCT SUMMARY

Shaft Encoder
Supply: 50 VDC, 3A

Ambient temperature range at T6:  $(-20^{\circ}C < Tamb < +60^{\circ}C)$ Ambient temperature range at T4:  $(-20^{\circ}C < Tamb < +100^{\circ}C)$ 

Marked: W+S Meßsysteme GmbH

Type: X700

Protected for use in potentially explosive atmospheres (flameproof enclosure)

EEx d IIC or EEx I

The product type has been tested in accordance with the European Standard EN50014:1992E and EN 50018:1994 E.

#### Description of the Apparatus

The X700 Shaft Encoder is a measurement instrument manufactured by W+S Meßsysteme GmbH. The unit is a rotating electrical device rated at 50Vdc 3A for determining rotor angular movement of an industrial electric motor as part of a feedback control system. The unit comprises a 316 stainless steel shaft which rotates in 316 stainless steel stator body with a 316 stainless steel lid which is screwed onto the stator. On the end of the shaft is an encoder disc which has an opto-electronic pick up and conditioning circuit fixed to the body above the rotating disc. The cover has cable entry points in the back, which can be machined to accept M12 to M24 suitably certified cable glands.

Page 1 of 5

#### PRODUCT CERTIFICATION & CODING

Demko 02 ATEX 133213 X

**CE 1254** 

T135°C IP 67

I / II 2GD EEXd IIC T4 Tamb =  $100 \, ^{\circ}$ C

 $X \rightarrow$  heat resistance cable for T4 class

I / II 2GD EEXd IIC T6 Tamb =  $60^{\circ}$ C

#### COMPLIANCE JUSTIFICATION DETAILS FOR X700

- The *X700* is considered as normally not ignition capable after the application of operating faults.
- There are no foreseeable adverse surrounding area conditions.
- The *X700* is manufactured from materials which are considered as not able to trigger off an explosion in normal operating modes and various fault modes in accordance with the requirements for Cat (X) equipment.
- The materials used in the construction of the *X700* are not known to react with any explosive atmospheres to which it may be subjected. It is the responsibility of the end user to ensure that the *X700* is selected correctly for the potentially explosive atmosphere in which the equipment is to be put into service.
- The *X700* contains no replacement parts or components.
- The X700 does not produce flammable gases or dusts in normal operating modes.
- The *X700* does not cause injury or harm when used in conjunction with the installation guide.
- The *X700* does not produce ignition capable electrical sparks or arcs and has been designed not to produce potential ignition sources from electromagnetic, acoustic, optical or other such extraneous energy sources.
- The X700 is not considered as a safety device and is not suitable for connection into a safety system and performs no critical measuring or alarm functions.

Page 2 of 5

### **Hazardous Area Installation Standards & Requirements:**

The installer should refer to the latest edition of the following standards before installing or operating in a Hazardous Area:

**EN 1127-1** Explosive Atmospheres - Explosion prevention and protection, basic concepts and methodology.

**EN 60079-14** Electrical apparatus for explosive gas atmospheres - Part 14:Electrical installations in hazardous areas (other than mines)

## <u>Instructions for the Installation of X700 in a Hazardous Area:</u>

*Installation must be handled by skilled personnel (only)* 

Observe precaution for handling of electrostatic sensitive devices

*Installation with power off (only)* 

Connect to earth first

Connect to GND

*Insulate Channels not in use separately* 

Do not slam with Hammer or use any unnecessary violence

Do not untighten the cable gland. It is part of ATEX certification

Do not open the Encoder. The Certification will be repealed

No modifications allowed

Do not connect outputs to supply voltage.

If the device is mounted to electric machinery with high current or voltage on the shaft, precausions have to be taken for galvanic separation

*Maintenance not necessary (Lifetime lubricated ball bearings)* 

## <u>Instructions for the Maintenance of *X700* in a Hazardous Area:</u>

Maintenance not necessary

## **Specifications & Operational parameters**


#### Flameproof Encoder X700

Mechanical Secifications:	Electrical Specifications:	
Cover 316 Stainless steel	<b>Supply voltage 4.75 - 30VDC</b>	
Body 316 Stainless steel	Current Consumption40 mA	
Shaft 316 Stainless steel	Output circuit Push-Pull / RS 422	
Speed max. 6000 rpm	Impulse frequency 300 kHz	
Torque < 0.4 Nm	Logic level high Vcc-0.7VDC	
Shaft load 50 N axial and radial	Logic level low 0.25 VDC max.	
Protection IP 67	Short circuit protection 100%	
<b>Temperature</b> −20° 75°C		
Weight 1250 g		

 $X=Cable:\ldots$  Mechanically and chemically resistant, flame retardant and screened Important: the encoder must be mounted/installed with special resistance cables in T4 version for ambient temperature of  $100^\circ$ 

Page 3 of 5

#### **Label Details and Information**



Serial number connection and wire colour

# Part numbering system flameproof encoder

## A BB-C DEFGH-XXXXX

A = Group Function I (incremental) A (absolut)

B = Main Feature X (Solid shaft flameproof)
B = Basic Number 700 (70mm diameter body)
C = Shaft size 12 ( 12 mm diameter shaft)

D= Mechanical option O (none)

E= Connections O (2 meter cable)
F= Exit Location A (axial cable gland)

G= Output Signals 6 ( A, B, O, complements) H= Output Type 3 ( Push Pull, 4.75..30VDC)

XXXXX = Pulses/Revolution (1 up to 10000 ppr)

## Refer to Drawing X700-LB01 T4 and T6


### Sample:



## Printed label placed in the label window

Part number (sample print)

Page 4 of 5



Serial No.: with Production code, purchase order number behind

means: Year/ Month

198200 means: customer and order number

means: for sample the encoder number three in that order

Specials:  $X \rightarrow$  heat resistance cable for T4 class!

Karl-Heinz Weber Senior Engineer W+S Meßsysteme GmbH Humboldtstrasse 11 D-78 549 Spaichingen

Page 5 of 5